


Signature Roller Shades



Reference Guide

Effective 8/1/2015

SignatureWindowCoverings.com



Signature Roller Shade Warranty

Signature Window Coverings LLC products sold to original purchaser, only for residential use, covers defects in materials and workmanship. Commercial warranty may be changed due to negotiated terms.

This warranty does not cover wear and tear as a result of abuse or misuse by the original purchaser(or tenants) or improper installation. This categorization is made by Signature Window Coverings LLC. Materials, including pvc and other plastics, may discolor when in direct sunlight for an extended period of time. This is considered normal wear on the product and is not covered under warranty. All cords will eventually wear but are covered for 1 year. Signature Window Coverings LLC will not cover any product requested and built that are not in the normal specifications outlined in this guide. Fabric colors may not match previous orders or swatches due to variances from lots. Signature Window Coverings LLC is not responsible for variations in fabric colors. Roller shades that are ordered may experience Telescoping (over a 3 to 1, lengthXwidth ratio), which is a tracking issue, and are not covered by Signature Window Coverings warranty. Any product discontinued is not warrantied. Some fabrics may have cupping issues. This is not under warranty as it is considered normal by Signature Window Coverings LLC.

Signature Window Coverings offers a limited lifetime warranty on roller shade products/ components. This only is offered to the original purchaser and user of the product(s). This warranty time period may be changed in contract negotiations for commercial(s) applications.

If a warranty request is issued, Signature Window Coverings will repair or replace the defective product at it's own discretion. Repairs made by Signature Window Coverings Llc. will take place in the factory.

Signature Window Coverings LLC is not responsible for incidental damages due to transportation or re-installation of replacement product nor are we responsible for costs induced in transporting the product from dealer to the product's owner.

It is the responsibility of the dealer to inspect any and all products it receives from Signature Window Coverings LLC prior to transporting the product(s) to the owner's property.

Motors used in roller shades are covered with a 5 year warranty. Signature Window Coverings LLC is not liable to make house calls for re-pair or replacement of any product.

Any shipment that requires a company not owned by Signature Window Coverings LLC that is damaged during transit is not the responsibility of Signature Window Coverings LLC to incur the costs associated with the product(s) replacement.



Roller Shade Specifications

Size Standards

Clutch Roller Shades

Width – Minimum 8" and Maximum – 126" (Contact SWC for commercial lengths. Size restrictions based on Fabric)

Height - Maximum - 180"

Cordless Roller Shades

Width - Minimum 24" and Maximum - 84"

Height - Maximum 72"

Motorized Roller Shade

Size maximum and minimum is determined by square footage and type of fabric being considered.

Signature Express Fabric

1% and 3% Twill Fabric

Battery Motor Max width 100" with square footage max at 39.

Sonesse 30 Max Width 120" with square footage max at 141.

Sonesse 50 Max width 200" with square footage max at 267.

BW 1%, 3%, 5% Fabric

Battery Motor Max width 100" with square footage max at 39.

Sonesse 30 Max Width 120" with square footage max at 141.

Sonesse 50 Max width 200" with square footage max at 267.

Blackout Fabric

Battery Motor Max width 100" with square footage max at 53.

Sonesse 30 Max Width 120" with square footage max at 160.

Sonesse 50 Max width 200" with square footage max at 267.

Sheerweave Fabric

SW2360

Battery Motor Max width 100" with square footage max at 58.

Sonesse 30 Max Width 120" with square footage max at 160.

Sonesse 50 Max width 200" with square footage max at 267.

SW2390

Battery Motor Max width 100" with square footage max at 50.

Sonesse 30 Max Width 120" with square footage max at 160.

Sonesse 50 Max width 200" with square footage max at 267.

SW3000

Battery Motor Max width 100" with square footage max at 44.

Sonesse 30 Max Width 120" with square footage max at 157.

Sonesse 50 Max width 200" with square footage max at 267.

SW2410

Battery Motor Max width 100" with square footage max at 42.

Sonesse 30 Max Width 120" with square footage max at 152.

Sonesse 50 Max width 200" with square footage max at 267.

SW2500

Battery Motor Max width 100" with square footage max at 35.

Sonesse 30 Max Width 120" with square footage max at 130.

Sonesse 50 Max width 200" with square footage max at 267.

SW5000

Battery Motor Max width 100" with square footage max at 41.

Sonesse 30 Max Width 120" with square footage max at 151.

Sonesse 50 Max width 200" with square footage max at 267.

SW7000

Battery Motor Max width 100" with square footage max at 50.

Sonesse 30 Max Width 120" with square footage max at 160.

Sonesse 50 Max width 200" with square footage max at 267.


SW7100

Battery Motor Max width 100" with square footage max at 27.

Sonesse 30 Max Width 120" with square footage max at 104.

Sonesse 50 Max width 200" with square footage max at 267.

Assembly Instructions for Open Roll Clutch Roller Shade Blind




Fitting the Brackets

Bracket positions illustrated are for a blind with the control chain on the right. For blind with the control chain on the left, the brackets should be at the opposite end. Brackets can be fixed to any flat surface above, behind or to the side of the blind. They must be level to ensure the smooth operation of the blind. Check that the rolled up fabric will not touch any surface. To calculate the spacing between the bracket, add $35 \text{mm} \ (1\ \frac{3}{8}\text{"})$ to the width of blind fabric. Fix the brackets so that the outside of the bracket are this distance apart.

Fitting the blind

Hold the blind to the bracket with fabric hanging from the back of the blind. Fit the spring plunger into its bracket. Push the blind into this bracket, depressing the plunger. With the locating hook pointing downwards place the hook into the vertical part of "+"-shape hole in the bracket. Allow the hook to drop downward so that it locks into place in the bracket.






Fascia Colors



The images above are examples of fascia colors offered by Signature Window Coverings. The images are for example purposes only. The window coverings in the image may not represent the window coverings that Signature Window Covering may produce.


3" Square

Fascia






CASSETTE COMPONENTS



Roller Shade System Recommended drop of Fabric



Fascia	Clutch & Tube	Max. drop of Fabric
4" Fascia	1 3/4" Clutch & Tube (45mm)	200" drop
	1 1/2" Clutch & Tube (40mm)	208" drop
3" Fascia	1 1/2" Clutch & Tube (40mm)	102" drop
	1 1/4" Clutch & Tube (32mm)	128" drop

Note: The above is for guidance only, each blind must be checked after assembly to confirm that it functions correctly. Signature Window Coverings(SWC) does not warranty ordering out of spec items. SWC can void warranty at anytime before delivery of product.



Cassette	Clutch & Tube	Max. drop of Fabric
4" Cassette	1 3/4" Clutch & Tube (45mm)	102" drop
	1 1/2" Clutch & Tube (40mm)	128" drop
3" Cassette	1 1/2" Clutch & Tube (40mm)	60" drop
	1 1/4" Clutch & Tube (32mm)	72" drop