

Jumparoo Rentals of Rhode Island Corp.

Safety Rules & Directions

SPECIFIC RULES TO FOLLOW:

1. **NEVER** enter an inflatable unless an attendant is present.
2. Compatible age groups must play in the unit at the same time. Age group must not be mixed. Different sized children should not be mixed. This can cause injury or harm to others.
3. The bounce house is designed for children and **IS NOT RECOMMENDED FOR USE BY ADULTS.**
4. The maximum number of children allowed in a “**Standard 15x15**” is:

<i>Ages 2 to 8</i>	<i>8 Children</i>
<i>Ages 9 to 13</i>	<i>6 Children</i>
<i>Ages 14 to 17</i>	<i>4 Children</i>

5. All persons **MUST** remove shoes, glasses, jewelry and anything else that may cause harm to the inflatable or themselves. **NO** flips or somersaults.
6. **NO** open flames within 10-15 feet of any inflatable rental. (Fire pit, etc.)
7. **NO** food or drink inside or near (within 10 feet) of an inflatable rental.
8. **DO NOT** cut the plastic ties on front of any inflatable.
9. **DO NOT** tape or fasten anything to the inflatable rental.
10. **DO NOT** climb on side walls, supports or netting. **DO NOT** pull on netting. This can cause harm to the inflatable rental and charges may apply (minimum \$250).
11. **DO NOT BY ANY REASON USE WATER ON ANY INFLATABLE UNIT UNLESS OTHERWISE NOTED.** Inflatable rentals **ARE NOT** designed to hold extra weight of water or adults. This will cause the unit to stretch and will cause additional charges to lessee for costs of needed additional repair or equipment replacement.
12. **DO NOT FOR ANY REASON USE SILLY STRING IN OR AROUND ANY UNITS.** This will ruin a unit causing damages and fees will apply.
13. The maximum number of children allowed on any “**Water Slide**” at any time is:

<i>Ages 2 to 8</i>	<i>4 Children</i>
<i>Ages 9 to 13</i>	<i>3 Children</i>
<i>Ages 14 to 17</i>	<i>2 Children</i>

SHOULD THE INFLATABLE START TO DEFLATE:

1. If inflatable starts to deflate; **STOP BOUNCING** and move to the front of the entrance and exit carefully, remain calm.
2. If the motor has stopped. Check the cord connection at the outlet and at the motor. Remember using more than one extension cord can trip the breaker and cause a lower electrical voltage.
3. If the motor continues to run – Check the air intake on the side of the motor for any blockage. Check the inflatable tubes and make sure they are straight and snug up to the ties on the motor(s).
4. If you are experiencing any other problems with the rental equipment, please call us **IMMEDIATELY** for service(s).

EXTRA FEES:

1. A \$30 re-delivery fee will be added if you are unavailable at time of agreed delivery. Our drivers work hard and should not be returning multiple times past agreed delivery time frame.
2. A \$50 Fee will be added to the reservation credit card used if unit becomes unavailable for pickup at the agreed upon pick-up time. (Drivers show up on agreed upon time and event is still going on or drivers are unable to remove unit off property due to any type of obstacle)
3. **ALL CANCELLATIONS** done in less than 48 hours will result in full payment being charged. Any inflatable canceled with 48 hours notice or more will have a reservation fee good for **ONE** year from original booking date.