



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
124.013		DUAL TEMP PRESSURE INDICATOR
124.04		AC/DC VOLTMETER
124.115		DUAL TEMP PRESSURE INDICATOR
124.933		TEMP IND
1000		OVEN HEATER
4100		RELAY ASSEMBLY
5003		SWITCH
6204	4810-00-800-0079	VALVE, PRESS
6301		VALVE
7046	1650-00-071-6388	CYLINDER ASSEMBLY ACTUATING LINE
7556		CYLINDER ASSY
8118	1680-01-107-2666	ACTUATOR ASSY TRIM TAB
8347	1680-00-373-8044	GEAR BOX ASSEMBLY AL
8353		BALL SCREW
8430		BALL SCREW
8446	1680-00-615-1335	ACTUATOR, MECHANICAL
8446	1680-00-615-1335	ACTUATOR
8521	1680-01-257-2445	GEAR BOX ASSEMBLY
8526		ACTUATOR,ELECTRO-MECHANICAL,LINE
8544		GEAR BOX
8545	1680-01-217-5837	BALLSCREW ASSY
8546	1680-01-222-2551	BALLSCREW ASSEMBLY
8546	1680-01-222-2551	JACKSCREW
8656		ACTUATOR
10280		VALVE
10640		VALVE
10850		VALVE
10870		VALVE
11170		VALVE
11460		VALVE
11660		VALVE
11670		VALVE
13210	4810-00-564-7793	VALVE, LINEAR
13210	4810-00-564-7793	VALVE
13930	4810-00-717-5076	VALVE, FLAP SELECTOR
14080		VALVE
15811	5930-00-139-9003	SWITCH, PRESSURE
16000	5996-00-501-2379	N1 AMPLIFIER
20348		SHUTTLE VALVE
20349		SHUTTLE VALVE
20350		SHUTTLE VALVE
20355		SHUTTLE VALVE
21021	4810-00-738-6358	VALVE SOLENOID
22281		Dual Tachometer
22705	6610-00-006-5783	INDICATOR, MACH AND TRUE AIRSPEED
22887		SHUTTLE VALVE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
22888		SHUTTLE VALVE
22889		SHUTTLE VALVE
27100		SUCTION PUMP
27100	4320-01-096-3873	PUMP
27531		SHUTTLE VALVE
34538		ACTUATOR
39606	2935-01-244-1475	COOLER LUBRICATING
40088	5930-00-621-4524	SWITCH, PRESSURE
40122	5930-00-629-6660	SWITCH, PRESSURE
44910	6230-00-887-2308	LANTERN ELECTRIC
47560	4810-00-208-9693	VALVE LINEAR DIRECT
47560	4810-00-208-9693	VALVE
47610	4810-00-208-9709	VALVE, LINEAR
47610	4810-00-208-9709	VALVE
47680	4810-00-761-6225	VALVE SOLENOID
49740	4810-00-612-2696	VALVE RAMP CONTROL
50320		DAMPENER , FLUID PRESSURE
50659		SHUTTLE VALVE
50900	4810-00-522-4592	VALVE
51060	4320-00-738-6225	PUMP
52760		VALVE, SELECTOR EMERG
52760	4820-01-033-2869	VALVE
53230	1680-01-102-4577	SHUT-OFF VALVE
53404		VALVE
54055	4320-00-717-1138	PUMP UNIT,CENTRIFUGAL
55742	6615-00-459-9599	REPEATER, SERVO
57273	1650-00-794-7638	VALVE
66039	4320-00-616-3812	PUMP, AXIAL PISTONS
66039	4320-00-616-3812	PUMP
70262	1650-00-803-2221	VALVE BYPASS
89000	6620-00-901-7848	TRANSMITTER, PRESSURE
95023	5930-00-961-8507	SWITCH, PRESSURE
95024	5930-00-961-8506	SWITCH, PRESSURE
96620		VALVE
96760		VALVE
96940		VALVE
100266	6610-00-557-3030	INDICATOR, ATTITUDE
102150		OUTFLOW VALVE
102402	5895-00-593-0509	EXCITER ASSEMBLY
102981	1650-00-873-6241	TURBINE DRIVES
102981	1650-00-873-6241	AIR TURBINE DRIVE
103432		SHUT OFF VALVE
104156		VALVE
104156	4810-00-529-3584	BUTTERFLY VALVE
104901	1650-00-872-7516	DRIVE UNIT,AIR TURBINE
104901	1650-00-872-7516	AIR TURBINE DRIVE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
106040		VALVE
106388	4810-00-513-4471	VALVE, BUTTERFLY
106388	4810-00-513-4471	BUTTERFLY VALVE
106616		VALVE
108420		STARTER CONTROL VALVE
108420		REGULATOR
108605	4810-00-541-6805	VALVE BUTTERFLY
108605	4810-00-541-6805	VALVE
109185		VALVE
109365		VALVE
110535		VALVE
111065		VALVE
113538		ACTUATOR
113538	1680-00-554-2624	ACTUATOR
115715	4320-00-6314859	PUMP, CENTRIFUGAL -1/12/2011 - 30/11/2012
115715	4320-00-631-4859	ROTARY PUMP
119125		ANTI ICE VALVE
121000		VALVE
121010	4810-01-232-2676	VALVE SOLENOID
121355	4810-00-555-1418	VALVE BUTTERFLY
121535		VALVE
132845		VALVE
135801	6625-00-649-2864	AMMETER
144625	4810-00-522-4592	VALVE
144865	1650-00-794-7636	VALVE
150201		ACTUATOR
152292		VALVE
152297	2995-00-775-9213	ACTUATOR, MOTOR ASSY
154485		CURRENT TRANSFORMER
166726	6625-00-555-4522	INDICATOR, LOADMETER
177913		ACTUATOR
179307	2915-00-616-5726	ACTUATOR ELECTRO ME
190772	2915-00-626-3123	VALVE ASSY PARALLEL
201090		COOLING TURBINE
202921	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
203430	1660-00-793-1564	TURBINE, AIRCRAFT CO
203430	1660-00-793-1564	COOLING TURBINE
254030	6625-00-235-4782	VOLTMETER
301701	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
326544	4320-00-404-1977	PUMP
338992		ROD ASSY
341448		MLG TORQUE STRUT ASSY
341982		UPLOCK
343978		VALVE
343978	4820-00-092-4246	VALVE
344052		ROD ASSY, AILERON



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
344403	1660-00-307-1996	DUCT ASSY
345384		DOOR ACCESS AIRCRAFT
345745		RESERVOIR
348205		VALVE
350690		STARTER
354690		STARTER
396374	4320-01-100-9434	PUMP
398648		VALVE
400201	6645-00-950-8599	CLOCK AIRCRAFT
400202		CLOCK, AIRCRAFT MECHANICAL
400240	6645-00-076-3050	CLOCK
409202		ACCUMULATOR
411600		VALVE RELIEF TANK
428066		PUMP ASSEMBLY VARIABLE DISPLACEMENT
502600		VALVE
519661	1610-00-651-3887	INDICATOR ASSY OIL
520104	6625-00-649-2864	AMMETER
520430		VALVE DISCHARGE
537874	6105-00-628-7433	MOTOR 200VAC
538278		AUTOMATIC F. SWITCH
546488	1610-00-179-6130	Valve Housing Cover
548025		ACCUMULATOR
549460		ACCUMULATOR
551025		ACCUMULATOR
551050		ACCUMULATOR
551580		ACCUMULATOR
552430		ACCUMULATOR
554654	1610-00-876-1812	SPINNER FRONT PROPELLOR
554665	1610-00-873-6251	SPINNER, PROP, A/I, REAR
560501	1610-00-873-6424	AFTERBODY HALF BODY
572865	1610-00-862-5524	BRUSH BLOCK, PROPELLER
575427	6130-00-056-6718	STATIC INVERTER
582855	1610-00-009-6832	VALVE HOUSING
600748	6615-00-390-8510	GYROSCOPE, DISPLACEMENT
603281	6105-00-836-5259	MOTOR
603887	6105-00-565-9003	MOTOR-TACHOMETER GENERATOR
603888	6615-00-565-9004	INTEGRATOR ASSY, AMPLIFIER
604390	5996-00-348-3844	AMPLIFIER ASSY, AUTOPILOT
611692	4320-00-072-2291	MOTORPUMP
613146	5985-00-867-2600	CONTROL, PEDESTAL
615058	6625-00-794-8188	PRE-AMPLIFIER ASSEMBLY
617149	5930-00-463-7442	SWITCH, PRESSURE
618320	6615-00-676-2609	CONTROL, TURN, AUTOMATIC PILOT
618751	6615-00-676-3828	CONTROL, ALTITUDE ENCODING
667857	6615-00-663-8372	GYROSCOPE
669780		RELAY BOX



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
692525	5930-00-732-2509	SWITCH PRESS OIL
692993		VALVE SHUT-OFF
695004		CYLINDER ASSY
695035		CYLINDER
695036		CYLINDER
695037	1650-00-092-4252	CYLINDER,RAMP UPLOCK
695037	1650-00-092-4252	CLYINDER
695038		CYLINDER
695040		NLG STEERING CYLINDER
695043		NLG UPLOCK CYLINDER
695187	6610-00-580-9363	INDICATOR, POSITION
695189	6610-00-580-9690	INDICATOR, POSITION
695190	6610-00-808-7037	ALTIMETER
695197	4810-00-529-3253	VALVE LINEAR DIRECTIONAL CONTROL
695197	4810-00-728-3396	VALVE
695225	6610-00-514-5612	INDICATOR, AIRSPEED
695260	6625-00-649-2864	AMMETER
695261	6685-00-692-8341	INDICATOR, TEMPERATURE
695271	4810-00-691-6713	VALVE
695292	6610-00-530-0961	TRANSMITTER, FLAP POSITION
695324	4140-00-564-5980	FAN, COOLING
695345	5930-00-296-6186	SWITCH, PRESSURE
695420	6620-00-526-7917	TRANSMITTER, PRESSURE
695908	4320-00-616-3812	PUMP
697752	4810-00-575-7781	VALVE
697753	4810-01-039-0459	VALVE
759057		PUMP
761442		CYLINDER
765000	1680-00-073-0841	SUPPRESSOR, SURGE
800530		EXTINGUISHER BOTTLE
1009350		ACTUATOR
1105123	1680-01-208-0174	ACTUATOR,ELECTRO-MECHANICAL,LINEAR
1505380	5841-00-845-4243	GENERATOR,STABILIZATION DATA
1775277	6605-00-532-0310	TRANSMITTER, INDUCTION
1776956	6615-00-605-8497	ADAPTER, ELEVATOR TRIM
1887850	5841-01-051-6339	RADAR AND BEACON CI
1889519		SYNCHRONIZER
1889520		ANTENNA
1889523	5841-01-053-7872	Indicator, Az Range APN-59
4012375	6615-01-442-1421	GYROSCOPE, DISPLACEMENT
4079653	5930-01-481-3559	SWITCH ASSEMBLY
5231975	2915-00-897-3164	NOZZLE FUEL SPRAYING
5232105	2915-00-655-1933	FUEL NOZZLE
6404486	2915-00-464-6946	SPEED SENSING CONTROL
6404524		CONTROL
6404525		CONTROL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
6719826		VALVE
6730338		SWITCH
6739352		FILTER
6739595		FILTER
6780223		VALVE
6781563		VALVE
6781566		VALVE
6781640		SWITCH
6781978	4810-00-540-2106	VALVE SOLENOID
6782647		RELAYBOX
6788029		FILTER
6789595		FILTER
6792265	4320-00-674-0932	PUMP,ROTARY
6792265	4320-00-674-0932	PUMP
6793049		PUMP
6794207		COORINATOR
6794213		COORDINATOR
6794215	2915-00-777-9017	CONTROL ASSEMBLY, CO
6794320		NOZZLE,FUEL SPRAY
6805150	6620-00-690-8903	INDICATOR, TORQUEMETER
6805387		FILTER
6809105		FILTER
6809387		PUMP
6809573		VALVE
6809618	2915-00-655-1933	NOZZLE ASSY FUEL
6809636		RELAY BOX
6809639	5945-00-854-4392	RELAY ASSY
6811702		VALVE
6812632		VALVE
6813972	6620-00-581-2278	INDICATOR, TORQUEMETER
6814707	6620-00-632-3631	INDICATOR, TORQUEMETER
6814740		CONTROL
6815100		SPEED CONTROL
6815120	6620-00-621-4269	INDICATOR, TORQUEMETER
6815131	6620-00-673-6867	INDICATOR, TORQUEMETER
6815622	2995-00-877-3666	VALVE ASSY ANTI-ICEING
6815922		FILTER
6815930		FILTER
6821460		FILTER
6821480		CONTROL
6821490		FILTER
6821491	2915-01-107-2763	FILTER, FLUID
6821493		SPEED VALVE
6821701	6150-00-859-6815	WIRING HARNESS BRANCHED
6824286	4810-00-749-8896	VALVE SOLENOID
6826922		SWITCH



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
6827239	2915-00-706-2719	VALVE ASSY TEMP
6827959		FILTER
6829274	6620-00-856-8263	FUEL FLOW INDICATOR
6829276	6620-00-053-2850	INDICATOR, TORQUEMETER
6829319		FILTER
6842961		FILTER
6842962		FILTER
6843151		COORINATOR
6843165		SWITCH
6844223		COORINATOR
6846396		PUMP
6846567	4320-00-012-7080	PUMP ASSY OIL SCAVENGE EXTERNAL
6847347		VANE SEGMENT,COMPRESSOR,AIRCRAFT
6850818		PUMP & FILTER ASSY
6852536	6620-00-914-2742	INDICATOR, TORQUEMETER
6852620		SEAL METALLIC AIRCRAFT
6858628		VALVE
6859424	2840-00-127-5730	HOUSING MECHANICAL P&A
6870095	2915-00-458-2767	AMPLIFIER TEMPERATURE
6870215		PUMP & FILTER ASSY
6871121		SPEED CONTROL
6871208		FILTER
6871248		SEAL METALLIC AIRCRAFT
6871749		FILTER
6873465	2915-00-464-6946	CONTROL ASSY SPEED SEN'R
6873466		CONTROL SPEED
6877256		FILTER
6877853		FILTER
6886127		SWITCH
6888911		SPEED CONTROL
6889811		CONTROL
6889842		SPEED CONTROL
6891597		FILTER
6894068	2840-01-049-1153	LINER COMBUSTION
6895037		COORINATOR
7854687		SPEED CONTROL
8427707	2935-01-202-5339	COOLER ASSY OIL AIRCRAFT
8575504		SPEED SENSING CONTROL
8575600	2915-00-622-4036	CONTROL ASSEMBLY,SP
8576000		CONTROL
9550616	1630-00-809-0394	MAIN WHEEL
9560685		BRAKE ASSY
23002366		RELAYBOX
23004669		SEAL ASSY
23006660		PUMP
23031741		VANE SEGMENT 2ND STAGE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
23031745	2840-01-255-7498	VANE
23031746	2840-01-247-0263	VANE
23031747	2840-01-247-0266	VANE
23031748	2840-01-247-0264	VANE
23037203		RETAINER ASSY
23052609	5996-01-274-7553	AMPLIFIER TEMPERATUR
23059687	5996-01-406-4035	AMPLIFIER. ELECTRONIC CONTROL
23064874	2915-01-444-7667	FUEL CONTROL ASSY
26020066	5930-00-860-4159	THERMOSTAT ANTI ICING
26130010	4810-00-987-3948	VALVE,SOLENOID (SHUTOFF VALVE)
26130010	4810-00-987-3948	VALVE
26930988	1660-00-166-2362	CONTROL BOX, ELECTRICAL
27231318	1660-01-021-4981	CONTROL BOX, ELECTRICAL
27241301	4820-00-006-5087	CHECK VALVE
27431471	1660-01-015-5017	REGULATOR, EJECTOR
76123002		SYNCHROPHASER
185500000		BRAKE
1384740101	6615-00-061-3131	GYROSCOPE, RATE SWITCHING MC-1
1855000000		BRAKE
1.65E+29		ADAPTER
3.8E+74		VALVE
3.6E+85		STARTER
1.855E+98		BRAKE
1.855E+99	1650-00-626-5729	DISC,BRAKE
1.65E+142		BRAKE
1.65E+304		BRAKE ASSY
HEAT		
00000C522	5835-01-128-7757	CKPIT VOICE RECDR (A 100A) W/UNDERWATR LOC BEACON
0019000-01	6625-01-006-1584	TEST SET TACAN
015-870145-3-8	1680-01-437-0394	REEL HARNESS
022489-054-03	4320-00-654-3617	PUMP FUEL ROTARY
066-01127-1601		Mode S Transponder
066-01149-0048		RECEIVER
066-01171-3706	6610-01-433-2219	INDICATOR VERTICAL
066-03084-0032		INDICATOR, RADAR TARGET
066-04031-1122		GPS RECEIVER
066-04031-2121		GPS RECEIVER
066-1071-00		TRANSPONDER
066-1077-00		DIG ADF REC
066-3031-01		RADIO ALT IND
066-3046-07		HSI IND
066-3084-32		IND RADAR
066-50000-2220	5841-01-514-7274	(TCAS) PROCESSOR,RADAR DATA
066-50000-2930		TCAS PROCESSOR
0666-5000-2220		T.C.A.S PROCESSOR
071-01480-0001		TCAS CONTROL PANEL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
071-01480-001		TCAS CONTROLLER OF TCAS PROCESSOR TPA-81A
071-01515-1301		TCAS CONTROL PANEL
071-01519-0101		RT/ VERTICAL12" ANT
08-60170-001		ACCUMULATOR
08-8422-001		ACCUMULATOR
08-8422-0011		ACCUMULATOR
08-8422-001-1		ACCUMULATOR
088422-010	1650-00-640-8491	ACCUMULATOR HYDRAULIC
08-8422-010		ACCUMULATOR
08-8423-001		ACCUMULATOR
08-8423-001-1		ACCUMULATOR
08-8423-010		ACCUMULATOR
08-8423-030		ACCUMULATOR
08-8423-030-1		ACCUMULATOR
08-8424-001		ACCUMULATOR
08-8424-0011		ACCUMULATOR
08-8424-001-1		ACCUMULATOR
08-8424-010		ACCUMULATOR
08-8424-100		CYLINDER
08-8425-010		ACCUMULATOR
08-8425-030		ACCUMULATOR
08-8425-100		CYLINDER
092-000-001	6340-00-304-5556	DETECTOR ICE
10-0108-1	6220-01-537-0689	LIGHT, PANEL
10018-01		INDICATOR TORQUEMETER
10-0240-20	6220-01-533-4952	INDICATOR, LIGHT
10-0240-21	6220-01-533-4994	INDICATOR, LIGHT
10-0240-23	6220-01-533-5015	INDICATOR, LIGHT
10-0240-25	6220-01-533-5229	INDICATOR, LIGHT
10-0240-27	6220-01-533-5254	INDICATOR, LIGHT
10-0240-76	6220-01-533-5271	INDICATOR, LIGHT
10-0240-78	6220-01-533-5300	INDICATOR, LIGHT
10-0240-83	6220-01-533-5236	INDICATOR, LIGHT
10-0250-3	6220-01-537-0683	INDICATOR, LIGHT
10040-1000-0101	6680-01-220-4090	FUEL QTY DIGITAL INDICATOR
10040-3000-0101		FUEL QTY IND.
10040-5000-0101	6680-01-224-7271	INDICATOR, LIQUID
1005910-4		HYD. PRESSURE REDUCER VALVE
1005910-5	4829-99-983-3598	VALVE REGULATING
100-601702-051		MCDU CMA-2014
100-601900-402		FMU CMA-900
10073-0101	6680-01-350-8049	INDICATOR, LIQUID
10074-0101		FUEL QUANTITY INDICATOR
1008700-1		ACCUMULATOR
1008700-2		ACCUMULATOR
1008700-3		ACCUMULATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1008700-4		ACCUMULATOR
1008700-5		ACCUMULATOR
1008700-6		ACCUMULATOR
1008700-7		ACCUMULATOR
1009350-1		ACTUATOR
1009350-2	2915-00-616-5726	ACTUATOR ELECTRO ME
1009350-2		ACTUATOR, ROTARY
10095-0101	6620-01-394-4018	INDICATOR
10-1026		VALVE
10-1026-1		VALVE
1010530-6		ACCUMULATOR
10-111160-3	2925-00-706-2720	EXCITER IGNITION
10-111160-6		VIBRATOR, IGNITION COIL
1012200-4	4810-00-014-1772	VALVE, LINEAR, DIRECT
10-1296-1	6220-01-534-0550	PANEL, INDICATING, LIGHT
10-1301-1	6220-01-537-0674	PANEL, INDICATING, LIGHT
10-1326-1	6220-01-309-8385	LIGHT UNIT, EMERGENCY
101450-31243	6610-01-176-9314	ALTIMETER ENDCODER
1018-1-200		CONTROL DISPLAY UNIT
102076-1-5		OUTFLOW VALVE CONTROLLER
102076-1-6		OUTFLOW VALVE CONTROLLER
102076-3	1660-00-784-7463	AIR PRESS CONTROLLER
102076-3		OUTFLOW VALVE CONTROLLER
102076-3-11		OUTFLOW VALVE CONTROLLER
102076-3-12		OUTFLOW VALVE CONTROLLER
102076-350-1		OUTFLOW VALVE CONTROLLER
102076-5	1660-00-857-0742	CONTROLLER
102076-5		OUTFLOW VALVE CONTROLLER
102076-500-3		OUTFLOW VALVE CONTROLLER
102076-745-3	1660-00-784-7463	CABIN PRESS CONTROL
102076-745-3		OUTFLOW VALVE CONTROLLER
102116-2-1		CABIN AIR PRESS VALVE
102116-3-1		CABIN AIR PRESS VALVE
102150-0	1660-00-343-4692	REGULATOR,AIR PRESSURE,AIRCRAFT
102150-0		CABIN AIR PRESS VALVE
102150-0		VALVE
102150-0-12		VALVE
102150-0-12		CABIN AIR PRESS VALVE
102150-0-13		CABIN AIR PRESS VALVE
102150-0-13		CABIN AIR PRESS VALVE
102150-0-14		CABIN AIR PRESS VALVE
102150-0-14		CABIN AIR PRESS VALVE
102150-0-15		CABIN AIR PRESS VALVE
102376-4-1		VALVE
102538-2-1	1660-00-062-0301	CONTROLLER,AIR PRESSURE,AIRCRAFT
102538-2-1		CABIN AIR PRESS CONTROL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
102538-2-1		AIR PRESSURE CONT.
102538-3-1		CONTROLLER
102538-5-1		CABIN AIR PRESS CONTROL
102650FA		DC MOTOR
102842ED	1680-00-675-8017	ACTUATOR, ELECTRO-MECH
102842ED		ACTUATOR
102842ED	1680-00-675-8017	ACTUATOR
102842FM		ACTUATOR
102842FN	2915-00-775-6674	ACTUATOR,ELECTRO-MECHANICAL,ROTA
103006-1-6		VALVE
103006-1-9		VALVE
103006-2-6		VALVE
103006-714		VALVE
103006-810-1		VALVE
1030119-2		CCA
103036-3	1660-00-783-6159	REG AIR FLOW
103036-3		CABIN AIR PRESS VALVE
103036-3	1660-00-783-6159	SAFETY VALVE
103036-3-6		SAFETY VALVE
103036-5	1660-01-483-3094	REGULATOR, AIR FLOW
103036-724	1660-00-735-3655	REGULATOR,AIR PRESSURE,AIRCRAFT
103036-724		SAFETY VALVE
103036-780-1		SAFETY VALVE
103036-780-1	1660-00-777-0721	AIR PRESSURE REG
103104-2-4		VALVE
103104-2-5		VALVE
103104-3		VALVE
103104-6-1		VALVE
103104-942		VALVE
103104-942-2		VALVE
103430-2		VALVE
103430-3		VALVE
103432-1		VALVE SHUT OFF
10401N01P00	6620-01-394-4019	INDICATOR, PRESSURE
10405N01P00	6620-01-394-4042	INDICATOR, PRESSURE
104156-1	4810-00-529-3584	BUTTERFLY VALVE
104156-1-6		VALVE
104156-1-6	4810-00-529-3584	BUTTERFLY VALVE
104156-1-7	4810-00-529-3584	VALVE BUTTERFLY
104156-1-7	4810-00-529-3584	BUTTERFLY VALVE
10450-31105	6610-00-160-3226	PRESSURE ALTIMETER
10450-31105	6610-00-160-3226	ALTIMETER, PRESSURE
1051R274		GEAR BOX, LANDING GEAR
1051R274	1620-00-014-3131	GEARBOX
1051R300	1620-00-406-5828	GEAR BOX LANDING GEAR
1051R300	1620-00-406-5828	GEARBOX



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
106040-0-7		VALVE
106040-1		VALVE
106040-1-1		FLOW CONTROL AND SHUT OFF
106040-2		VALVE
106040-2	1660-00-610-0601	AIR PRESS REG
106040-2-2		VALVE
106040-3	1660-00-625-6195	REGULATOR AIR PRESSURE
106040-3		VALVE
106040-3	1660-00-625-6195	AIR PRESS REG
106040-3-1		VALVE
106040-4		VALVE
106040-4-1	1660-00-084-6707	REGULATOR AIR PRESSURE
106040-4-1		VALVE
106040-4-1	1660-00-084-6707	AIR PRESS REG
10-61068-1	4410-00-689-1609	HEATER WATER ELECT
106388-1-2	4810-00-513-4471	VALVE BUTTERFLY
106388-1-2		VALVE
106388-3-1		VALVE
106475-1		VALVE
106475-1	4810-00-529-3929	VALVE
106475-2		VALVE
106475-3		VALVE
106475-4		VALVE
106616-0-3		VALVE
106616-0-3	1660-00-610-9686	VALVE
106616-1		VALVE
106616-1-1	1660-00-084-6708	FLOW CONTROL AND SHUT OFF VALVE (FLT DECK)
106616-1-1		VALVE
106616-1-1	1660-00-084-6708	VALVE
106616-2	1660-00-084-6708	VALVE
106A154-1	6220-01-309-8385	LIGHT UNIT, EMERGENCY
107996-1-1		PNEUMATIC THERMOSTAT
107996-66	6685-00-934-8208	THERMOSTAT, FLOW CONTROL
108032-0-39		REGULATOR DIFERENCIAL PRESSURE
108032-3		REGULATOR
108136-1	1660-01-293-4916	REGULATOR
108136-1-1		REGULATOR
108136-11-1		REGULATOR
108136-21-3		REGULATOR
108136-22-1		REGULATOR
108136-25-1	1660-01-213-0439	REGULATOR
108136-26-1	4820-01-548-3932	REGULATOR
108354-4		REGULATOR
10870-2		VALVE
109016-11	2835-00-682-5352	VALVE
109016-11-1	2835-00-682-5352	VALVE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
109016-7	4810-00-797-3261	VALVE LOAD CONTROL
109016-7		VALVE
109206-2		VALVE
109206-3		VALVE
109206-7		VALVE
109350-6	4820-00-639-9685	REGULATOR
109382-13	4810-00-494-5727	VALVE BUTTERFLY
109486-6-1		VALVE, BLEEDER
109710-1-1		VALVE
109710-1-1	4810-00-299-7847	BUTTERFLY VALVE
109710-2	4810-01-014-2632	BUTTERFLY VALVE
109710-2-1		APU BUTTERFLY VALVE
109710-2-1		VALVE
109710-3-1		VALVE
109710-4-1		VALVE
109710-5-1		VALVE
109710-6	4810-01-229-3584	BUTTERFLY VALVE
109710-6-1		BLEED VALVE
109710-6-1		VALVE
109710-7-1		VALVE
109710-8-1		VALVE
109710-9	4810-01-229-3584	BUTTERFLY VALVE
109710-9-1	4810-01-393-3991	CONVERT LVC
109710-9-1	4810-01-393-3991	VALVE, BUTTERFLY
109710-9-1	4810-01-229-3584	BUTTERFLY VALVE
10C-0001-0026	1660-00-122-8101	CONVERTER LIQUID OXY
10C-0001-26	1660-00-122-8101	CONVERTER, LIQUID OXYGEN
10C-0001-26	1660-00-122-8101	CONVERTER, LIQUID OXYGEN
10-C0001-26	1660-00-768-5256	CONVERTER, LIQUID OXYGEN
1105123-1	1680-01-254-6893	ACTUATOR, ELECTRO-MECHANICAL, LINE
1105123-1		ACTUATOR
11060-2		VALVE
11060-3		POWER BRAKE VALVE
11060-7	1630-00-859-3997	VALVE, POWER BRAKE
110745-1		VALVE
1111-5	1650-00-650-7610	CYLINDER ASSY, ACTUATING
1111-548030		VALVE
1111-568748		VALVE
1111-568749		VALVE
111302-5	6605-01-245-7660	INDICATOR, HORIZONTAL SITUATION
1121F8-2.0		VALVE
1121F-8-2.0		VALVE
1121F8-9.0		VALVE
1121F-8-9.0		VALVE
114672-0		PUMP AND CONTROL ASSEMBLY, FUEL
114PS205-2	3010-00-420-5226	ACTUATOR, ELECTRO-MECHANICAL, ROTARY



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
115-230	6685-01-329-0849	INDICATOR TEMPERATURE
1164-1		VALVE
116595-01	6610-00-557-3030	INDICATOR, ATTITUDE
11670-1		VALVE
118115-01	6615-00-530-3061	GYROSCOPE, DISPLACEMENT
1184R125	1680-00-733-3491	WINCH AIRCRAFT MOUNTED
1184R125	1680-00-733-3491	WINCH, AIRCRAFT
1184R125	1680-00-733-3491	WINCH
118769-01	6610-00-590-8270	INDICATOR, REMOTE ATTITUDE
118930-01	6610-00-607-8292	INDICATOR, REMOTE ATTITUDE
118930-02-01	6610-00-965-9840	INDICATOR
1192-30-111101		NAVIGATION COMPUTER UNIT
1192-30-111101		NAVIGATION COMPUTER UNIT
119538-01	6615-00-613-5476	GYROSCOPE
119538-02	6615-00-555-3962	GYROSCOPE
120435-1		VALVE
12085-1		MOTOR ASSY PYLON
121000-1		VALVE
121000-1	4810-01-220-6060	VALVE
12-10001-01	6680-01-419-1995	TRANSMITTER, LIQUID QUANTITY
121000-2		VALVE
121000-2	4810-01-220-6060	VALVE
1214BX-8-05	6610-00-526-7947	INDICATOR AIR SPEED
1214DX8-05	6610-00-530-0026	INDICATOR AIR SPEED
121535-1	4810-00-706-0266	SHUTOFF VALVE ASSY
121535-1	4810-00-706-0266	VALVE AIR BLEED
121535-1	4810-00-706-0266	VALVE
121672-01	6615-00-550-6628	GYROSCOPE, DISPLACEMENT
121672-01-15	6615-00-973-2218	GYROSCOPE, DISPLACEMENT
121672-01-16	6615-00-074-4036	GYROSCOPE, DISPLACEMENT
121672-01-17	6615-00-900-5959	VERTICAL DISPLACEMENT GYRO
1221LP	6220-00-808-3655	PANEL, INDICATING, LIGHT
123488-010-01	4320-00-631-4859	FUEL PUMP
123488-010-01	4320-00-631-4859	CENTRIFUGAL FUEL PUMP
123510-010-01		PUMP
123510-011-01		PUMP
123510-014-01	2915-01-185-1847	PUMP
124.115-3		DUAL TEMP PRESSURE INDICATOR
124-1006-1	6620-01-328-0926	INDICATOR ENG OIL TE
124-1007-1	6620-01-308-2520	INDICATOR PRESSURE
124-1207	6685-01-328-7139	INDICATOR TEMPERATURE
124623-01	6615-00-581-2265	GYROSCOPE, DISPLACEMENT
124623-01-09	6615-00-852-1611	GYROSCOPE, DISPLACEMENT
124623-01-10	6615-00-951-9140	GYROSCOPE, DISPLACEMENT
124623-01-12	6615-00-994-8940	GYROSCOPE, DISPLACEMENT
124623-01-13	6615-00-999-2630	GYROSCOPE, DISPLACEMENT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
124623-01-14		MD1 Gyro
124-934		DUAL AC/DC VOLT
124-934A		DUAL AC/DC VOLT
126-179	6620-01-308-2604	INDICATOR, ITT
127123-01	6615-00-585-0990	INDICATOR
130211-3		HYD SERVO VALVE
130234-5		HYD SERV VALVE
130234-7		HYD SERVO VALVE
131400-01	6610-00-580-9562	INDICATOR
13210-1		VALVE
132555-1		VALVE OIL SHUT OFF
1333-613233		ENGINE BLEED SHUT OFF
1333-613233M1	4810-00-065-9471	VALVE BUTTERFLY
1334-3		HYD SERVO VALVE
1334-5		HYD SERVO VALVE
1334-7		HYD SERVO VALVE
1356-512107		ACCUMULATOR
1356-512457		ACCUMULATOR
1356-512463		ACCUMULATOR
1356-512465		ACCUMULATOR
1356-512471		ACCUMULATOR
1356-512473		ACCUMULATOR
1356-512475		ACCUMULATOR
1356-542107		ACCUMULATOR
1356-542838		ACCUMULATOR
1356-542839		ACCUMULATOR
1356-542897	1650-00-987-8389	Accumulator Assembly, Double Shell
1356-542899	1650-00-721-6416	ACCUMULATOR, HYDRAULIC
1356-542901		ACCUMULATOR
1356-542903		ACCUMULATOR
1356-542905		ACCUMULATOR
1356-552235		ACCUMULATOR
1356-552237		ACCUMULATOR
1356-583315		ACCUMULATOR
1356-583317		ACCUMULATOR
136600-01-03	6610-00-855-9349	INDICATOR
1371-598820	4810-00-737-3349	VALVE SOLENOID
1371-598850		VALVE
1372-3		SERVO VALVE HYDRAULIC
138094-01-02	6610-00-990-9825	INDICATOR
138474-01-01	6615-00-061-3131	GYROSCOPE
139100-01-01	6615-00-994-2152	DISPLACEMENT GYRO
13V600-6		VALVE
140180-01-01	6615-00-738-6204	RATE GYRO
140260-01-03	6615-00-928-0072	GYROSCOPE
14080-1	4810-00-610-9390	VALVE LINEAR DIRECT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
14080-1	4810-00-610-9390	VALVE LINEAR DIRECT
14125-1-A	6615-00-618-9804	GYROSCOPE
142765-1		VALVE
142853-01-02	6615-00-135-7967	DEMODULATOR
142853-41-02	6615-00-135-7967	DEMODULATOR
14602-1J-D1	6610-00-663-8798	INDICATOR, ATTITUDE
14602-1J-F1	6610-00-663-8800	INDICATOR, ATTITUDE
147601-2	2915-00-072-6226	HEATER AND STRAINER
147B31	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31A2	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31A3	6685-00-005-9025	INDICATOR TEMPERATURE
147B31A4	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31B	6685-00-692-8341	INDICATOR, TEMPERATURE
147B31F	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31G	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B8	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
14950-17	1660-00-856-0550	REGULATOR OXYGEN
14950-34		OXYGEN REGULATOR
14950-34M	1660-01-010-4949	OXYGEN REGULATOR
14950-40	1660-00-169-1888	OXYGEN REGULATOR
14950-45	1660-00-169-1888	REGULATOR,OXYGEN,DILUTER DEMAND
149D6050-1	1680-01-021-8032	DROGUE STOWAGE ASSEMBLY
15-0009-3	6220-01-534-1102	LIGHT, DOME
15-0015-37	6220-01-509-4789	LIGHT, COCKPIT, AIRCRAFT
15-0015-39	6220-01-509-4790	LIGHT, COCKPIT, AIRCRAFT
15-0069-1	6220-01-534-0539	SPOTLIGHT
15019-1A1	6615-00-207-4771	TRANSMITTER, FLUXGATE
15-0601-23	6220-01-509-4792	LIGHT, COCKPIT, AIRCRAFT
15-0836-3	6220-01-509-4402	LIGHT, DOME
15101-1EA1	6610-00-514-5272	INDICATOR, THREE AXIS TRIM
15150-1	6615-00-570-4960	CONTROL, SLAVING
152050-4		OIL COOLER
15236-1A1	6615-00-325-6981	ADAPTER, AUTOPILOT
15482-1A1	5996-00-855-9045	AMPLIFIER, ELECT
1580997-2	6115-00-327-4068	ROTOR GENERATOR
15811-1	5930-00-139-9003	SWITCH, PRESSURE
15826-1-A	6615-00-618-9800	GYROSCOPE, DISPLACEMENT
158410-3		OIL COOLER
159245-3		ALTIMETER, INDICATOR
162B2	6685-00-553-4726	INDICATOR, TEMPERATURE
162B202A	6685-00-553-4726	INDICATOR LAMP
162B203	6685-00-514-5327	INDICATOR, TEMPERATURE
162B2A	6685-00-838-7429	INDICATOR, TEMPERATURE
162B2D	6685-00-097-6263	INDICATOR,TEMPERATURE,ELECTRICAL RESISTANCE
162B2G	6685-00-005-9024	INDICATOR TEMP
162B3	6685-01-484-9826	INDICATOR, TEMPERATURE RATIO



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
162B3F	6685-00-514-5327	INDICATOR, TEMPERATURE
162B4	6685-00-514-5328	INDICATOR, TEMPERATURE
164-1	6680-00-753-8932	LIQUID OXY QTY IND
16430-1		PUMP
1650E412	1620-00-677-6681	BALLSCREW MAIN GEAR
1650E420		BRAKE
1650E490		BRAKE
1650E615		BALL SCREW
1650R319	1680-00-627-9857	GEAR BOX ASSY, MAIN
1652-6AJ-B6-1	6610-00-639-3615	INDICATOR, RATE OF CLIMB
168396-01-01	6605-01-250-9782	CONTROL, INDICATOR
168396-02-01	6605-01-311-9074	CONTROL, INDICATOR
168396-03-01	6605-01-436-5128	CONTROL, INDICATOR
16VZ001-55	6615-00-137-6038	GYROSCOPE, RATE
1701BX-03	6610-00-844-1195	INDICATOR, AIRSPEED
1701BX8-04	6610-00-844-1195	INDICATOR, AIRSPEED
1701CX8-04	6610-00-531-4160	INDICATOR, AIRSPEED
1701DX10-04	6610-01-067-0228	INDICATOR AIRSPEED
1701DX4-04	6610-00-585-4931	INDICATOR AIRSPEED
1701DX8-04	6610-00-179-9033	INDICATOR AIR SPEED
1701DX-8-04	6610-00-179-9033	INDICATOR AIR SPEED
172-1704	6685-00-450-4489	TRANSMITTER, PRESSURE
1790043-1	6615-00-887-6765	POWER SUPPLY, MONITOR
179250-0003	5865-01-451-2868	COUNTERMEASURES DISPENSER SWITCH
17960-0102-002		GNS-XLS FMS
179684-1	5996-00-605-8496	AMPLIFIER ASSY
179822-1		TD amplifier
17M700-274		FLIGHT RECORDER
18000-2	5826-01-459-5969	INDICATOR BEARING
18-0044-1	6695-01-381-1905	LIGHT, INSTRUMENT
18-0045-1	6695-01-381-2277	LIGHT, INSTRUMENT
18-0046-1	6695-01-381-2047	LIGHT, INSTRUMENT
18-0049-1	6695-01-381-2126	LIGHT, INSTRUMENT
18-0062-1	6695-01-381-1526	LIGHT, INSTRUMENT
18-0063-1	6695-01-425-5333	LIGHT, INSTRUMENT
180-147		CONTAINER
18-1105	6685-00-557-0215	FUEL PRESSURE IND.
18-1278		OIL PRESS IND
18-1704	6685-00-450-4489	TRANSMITTER, HYDRAULIC PRESSURE
18-54903-3	1660-01-049-3423	PRESSURE REG. VALVE SHUT OFF
188440-2-1		HEAT EXCH
18900-160	4820-00-880-4744	VALVE REGULATING TE
190585-1	4810-00-540-2106	VALVE
190772-1		VALVE
190772-2	2915-00-626-3123	VALVE ASSY PARALLEL
191006-1-1	1660-00-588-3478	WATER SEPERATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
191006-1-2	1660-01-044-0091	WATER SEPARATOR, AIR CON
191390-2-2	1660-01-150-9084	HEAT EXCHANGER
19-20-5	6610-00-580-9363	INDICATOR, POSITION
1-A	6610-00-526-4798	INDICATOR, AIRSPEED
1A20454H01	4440-01-324-1783	COMPRESSOR DEHYDRATOR
1A23446H01	5895-01-316-1232	INTERROGATOR SET
1D17431G01	6130-01-182-3032	POWER SUPPLY
1D17431G02	6130-01-318-3166	POWER SUPPLY
1D17627G01	5840-01-182-6432	EXCITER RADIO
1D17627G01	5840-01-182-6432	EXCITER RADIO
1D18517G01		CIRCUIT CARD ASSEMBLY
1D18517G01		CIRCUIT CARD ASSEMBLY
1D18517G02	5998-01-316-0046	CIRCUIT CARD ASSEMBLY
1D20464G01	6130-01-221-6862	INVERT POWER MODULE
1D20801G01	6130-01-215-8501	POWER SUPPLY
1D22877G01		ANTENNA PEDESTAL
1D23052G01	6130-01-262-8351	POWER SUPPLY
1D23551G01	5840-01-350-9085	DISPLAY UNIT RADAR
1D27054G01		CIRCUIT CARD ASSY
1D27545G02	5998-01-300-2228	CIRCUIT BOARD
1D27545G02	5998-01-300-2228	CIRCUIT BOARD
1D27749G02	5998-01-299-9945	CIRCUIT BOARD
1D27749G02	5998-01-299-9945	CIRCUIT BOARD
1D5745G2	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
1D5745G3	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
1EN61-6B	5930-00-709-1054	SWITCH, PUSH
1G107	5930-00-615-7340	SWITCH, PRESSURE
20000532091-001	6615-01-415-0067	CONTROL, MODE SELECT
200027176-10		NLG STEERING CYLINDER
200-037-002	6680-01-073-7582	INDICATOR, LIQUID QUANTITY
200-037-005	6680-01-120-7609	INDICATOR, LIQUID QUANTITY
200-1000-01	6130-01-360-4061	POWER SUPPLY
200-1001-01	6220-01-360-5434	CONTROL ELEC. LIGHT
20-0106-1	6220-01-533-5349	LIGHT, INDICATOR
2006629-105		ARM
201-004-001	6620-01-038-5801	TORQUE INDICATOR
201090-1		COOLING TURBINE
201090-10		COOLING TURBINE
201090-11		COOLING TURBINE
20140-0351	6610-00-006-5783	AIRSPEED INDICATOR
20201-3	1650-00-611-0431	CONSTANT SPEED DRIVE
20-224-01	6680-01-290-5920	INDICATOR, LIQUID QUANTITY
202919-306	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
202921-303	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
203-003-002	6680-00-333-6757	QUANTITY INDICATOR
203430-1		COOLING TURBINE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
203430-2		COOLING TURBINE
203430-4		COOLING TURBINE
203430-4-1		COOLING TURBINE
203720-1	1660-00-897-4306	TURBINE, AIRCRAFT
203720-2		TURBINE
203720-3		TURBINE COOLER
203720-3-1		TURBINE
2038091-0502		RX-AFC MOD
2039669-0503	6220-01-343-1578	PANEL, INDICATING, LIGHT
2041232-1104	6210-00-140-8738	RADAR PILOTO INDICATOR
2041232-3110		RADAR INDICATOR
204A1A5A	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
2052002-521	5826-00-543-0759	RECEIVER
206-075-190-1		TEMP. INDICATOR
2067157-0162		RADAR TRANSCEIVER
2068599-0705	5985-01-495-3531	WAVE GUIDE SWITCH
2070409-0101		RADAR ANTENNA
2070410-0101	5821-01-408-7392	TRANSCEIVER
2070552-0103		RADAR CONTROL UNIT
2070963-0103		WEATHER RADAR RT
2070963-0104		RECEIVER TRANSMITTER RADAR
2070963-0105	5841-01-314-9947	TRANSCEIVER RADAR
2070964-0107	5841-01-314-9991	SCOPE RADAR
2070965-0105		CONTROL SET RADAR
207410-0101		RNTX UNIT RADAR IF
209-070-262-101	5895-01-252-5691	TEMP INDICATOR
209-070-262-3		INDICATOR TEMP
209-070-262-9		INDICATOR,TEMP PRESS
209-070-263-1	6625-00-248-6971	DUAL AC/DC VOLT
209-070-263-3		DUAL INDICATOR
209-070-264-1	6625-00-248-6976	AMP METER
209-070-264-3		DUAL AMP METER
209-070-275-1	6620-15-160-0834	INDICATOR FUEL 0-50 PSI
20B95-4	6110-01-109-5099	REGULATOR VOLTAGE
20B95-4A	6110-01-109-5099	REGULATOR,VOLTAGE
210-2360	4730-00-626-9199	SWIVEL JOINT
21086-1	1660-00-730-0150	CONVERTER,LIQUID OXYGEN
211-009-002	6680-01-121-7070	INDICATOR, LIQUID QUANTITY
211-009-003	6680-01-123-2647	INDICATOR, LIQUID QUANTITY
211-009-004	6680-01-121-7071	INDICATOR, LIQUID QUANTITY
211-009-005	6680-01-342-7698	INDICATOR, LIQUID QUANTITY
2118-363		ACCELEROMETER
2118-364	6610-01-391-9062	ACCELEROMETER, MECHANICAL
2119-001	6610-00-585-5929	ACCELEROMETER
2119-001-2	6610-00-585-1355	ACCELEROMETER
2119-001-3	6610-00-684-1666	ACCELEROMETER, MECHANICAL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
2119-500	6610-00-007-1030	ACCELEROMETER, MECHANICAL
2120-1		VALVE
212-070-108-7	6680-01-492-3356	TRIPLE TACH IND.
212-070-116-9	6620-01-492-3358	PRESSURE INDICATOR
212-070-160-005		DUAL TORQUE IND.
212-070-160-101		DUAL TORQUE IND.
212-070-160-15		DUAL TORQUE IND.
212-070-160-17		DUAL TORQUE IND.
212-070-160-5	6680-01-478-4288	DUAL TORQUE IND.
212-070-160-7	6680-01-492-3357	DUAL TORQUE IND
212-070-238-3		ALTIMETER
212-070-238-7		ALTIMETER
212-070-239-001	6610-00-617-6056	VERTICAL SPEED INDICATOR
212-075-036-101	6625-01-252-7616	INDICATOR,TEMPERATURE
212-075-037-101		GAS PRODUCER TACH
212-075-067-105		ITT INDICATOR
212-075-420-3		ITT INDICATOR
212-075-562-1		ITT INDICATOR
212-075-562-3	6685-01-492-2612	INDICATOR I.T.T.
2187C		GEAR BOX
2196D		GEAR BOX
2196E		GEAR BOXFLAP
219A967	1630-00-914-1329	WHEEL LANDING GEAR
219A967-1		NOSE WHEEL
21B17-10-B	6110-01-044-4331	REGULATOR VOLTAGE
21SN27-3	5930-01-502-4004	SWITCH, PRESSURE
2200440-6-1		REFRIGERATOR UNIT
22A524	6680-00-585-1503	GENERATOR, TACHOMETER
22A554	6680-00-585-1503	GENERATOR, TACHOMETER
22A703		TACH GENERATOR
2301420-1	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
23052609A	5996-01-274-7553	AMPLIFIER TEMPERATURE
23079-1020		ARMATURE
23410-3	1630-00-998-7897	VALVE, BRAKE CONTROL
235550-4	5821-01-245-9095	RECEIVER, TRANSMITTER
239-004		FREQUENCY METER
2488136G001	5865-01-178-0408	DOWN CONVERTER MIXER
25100-004		ALERTER
25122A37B-1-A1		HYD PRESSURE IND.
25122-A37B-1-A1	6685-00-557-0215	INDICATOR, SYNCHRO
2527T100-1	1680-00-070-9980	WINCH
25430135-02		TEMP CONTROL BOX
25430135-03		TEMP CONTROL BOX
25430135-04	1660-00-735-3655	CONTROL BOX, ELECTRICAL
25430135-06		CONTROL BOX TEM
25430135-07	1660-00-387-4319	BOX CONTROL TEMP



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
25430135-08		TEMP CONTROL BOX
25430135-09		TEMP CONTROL BOX
25530562-01		THERMOSTAT
25730032-02		SOLENOID SHUT-OFF VALVE
25730032-03		SOLENOID SHUT-OFF VALVE
25730032-04		AIR CONTROL VALVE
25730043-02		SOLENOID SHUT-OFF VALVE
25730043-03		VALVE,SOLENOID
25730043-04		VALVE
2586257-1	6605-00-447-9654	COMPENSATOR, REMOTE
2586261-1	6605-00-447-9665	DIGITAL CONTROLLER
2586333-1		DIRECTIONAL GYRO
2586333-2	6615-00-180-0895	DIRECTIONAL GYRO
2586333-3	6615-01-065-7226	GYROSCOPE DISPLACEMENT
2587193-43	6615-01-020-7531	GYRO DIRECTIONAL
2588302-3		GYROSCOPE DISPLACEMENT
2589226-1		AMP POWER SUPPLY
2591200-901	6605-01-034-8737	MAGNETIC COMPENSATOR
2591201-902	6605-01-034-5256	COUPLER, COMPASS
2591202-912	6605-01-036-5089	CONTROLLER, COMPASS
26130010-01	4810-00-987-3948	VALVE SOLENOID
2690346-1	6615-01-260-8214	RATE INTEGRATING GYRO, LC22
270-2196-020	6615-01-068-8713	AIRSPEED SENSOR
27231317-01	1660-01-014-4509	CONTROLLER TEMPERATURE
27231318-01	1660-01-021-4981	CONTROL, TEMPERATURE
275540-003	5826P275540-003	RMI
27620-1	1650-01-217-7899	BRAKE HYDRO-MECANICAL
27620-2		BRAKE
27A10614-101-11		ACCUMULATOR
28300-8		VALVE
28300-81		VALVE
28B135-145A		AC GENERATOR
28B58-93	6115-01-224-5848	GEN ALTERNATING
28B58-9B	6115-01-224-5848	GENERATOR ALTERNATOR BEN
28B58-9-B	6115-01-224-5848	GENERATOR, BENDIX
28VS200C1	6130-00-081-7844	POWER SUPPLY
28VS200C-1	6130-00-081-7844	POWER SUPPLY
2905-001	6105-01-216-4182	MOTOR,DIRECT CURRENT
29270-10A-A1	1660-00-243-0393	OXYGEN REGULATOR
29270-10A-B1	1660-00-243-0393	OXYGEN REGULATOR
2CM11BAA5	6620-00-785-2251	ALTERNATOR
2CM353C1	6115-00-946-8441	Generator Alt
2CM353C1P	6115-00-946-8441	GENERATOR
2CM5ADR	6680-00-487-4289	Tach Generator
2CM63E1A	2925-00-178-0940	GENERATOR
2CM9ADE8	6680-00-008-4544	TACHOMETER GENERATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
300-0746-002	6685-01-366-3065	TRANSMITTER, PRESSURE
3006T88G05	2915-00-143-6107	VALVE, FUEL PRESS
30-1131-1	6220-01-055-3992	LIGHT, NAVIGATIONAL
30-2217-1	6220-01-426-4360	LIGHT, NAVIGATIONAL
30-231	6340-01-087-2792	SMOKE DETECTOR TYPE II
30678-17	1680-00-797-4478	ACTUATOR ELECTRO MECH
30A8-690		VALVE
31008-1066		ROTOR,GENERATOR
31-032599-04	5985-01-154-9125	AMPLIFIER DETECTOR
31220-003		GENERATOR
31220-004	6115-00-678-6319	GENERATOR AC
31416000-1	6130-01-387-7271	POWER SUPPLY
318357-000	5998-01-236-3735	BACKPLANE ASSEMBLY
318427-001	5998-01-407-6121	CIRCUIT CARD ASSEMBLY
318476-901	5998-01-269-6978	VIDEO PROCESSOR NO. 1 CIRCUIT CARD ASSEMBLY
318557-000	5998-01-236-3735	BACKPLANE ASSEMBLY
32005-007	6680-00-585-1503	TACHOMETER GENERATOR
320362-3-1		VALVE , SOLENOIDE
32-054528-02	5865-01-165-9375	RF ASSEMBLY (A5)
32-054542-01	5865-01-059-4560	IF FILTER
32-054576-01	6130-01-059-1470	POWER SUPPLY
3213722-1-1		VALVE
3213722-2-1	4810-01-004-5634	VALVE REGULATING
3213722-3-1	4820-01-093-9141	BLEED VALVE ASSY
3213722-5-1	4810-01-157-2583	VALVE REGULATING FLUID
3213722-6-1		VALVE
321502-3-1		VALVE
321502-4-1	4810-00-796-1672	VALVE BUTERFLY
32220-1	1680-01-387-6739	WINCH, AIRCRAFT
3252010-1101	6610-01-039-5020	ALTIMETER, ENCODING
325996-003	5998-01-459-5226	CIRCUIT CARD ASSEMBLY
3260011-0101	1660-01-005-6318	REG OXYG DILUTER
3290290-1-1	4810-01-482-4911	VALVE, BUTTERFLY
3290290-2-1		VALVE
3290290-2-3	4810-01-417-7022	VALVE, BUTTERFLY
3302196-13		MLG SHOCK STRUT ASSY
3302196-15		CYLINDER
3302196-17	1620-01-449-2064	PISTON
3302196-19		MLG SHOCK STRUT ASSY
3302196-21	1620-01-450-4647	CYLINDER
330332-4	2915-00-706-2719	TD VALVE
330332-5	2915-01-318-8927	VALVE, TEMPERATURE D
3303583-5	1620-00-572-2605	COLLAR, ACTUATOR ATT
3303591-1	1620-00-085-2624	NLG STRUT ASSY
3303591-3	1620-00-505-1184	LANDING GEAR,RETRACTABLE (NLG STRUT ASSY)
3303595-1	1630-01-391-7191	NOSE LANDING GEAR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
330625-101	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
330625-211	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
3308-950	6605-00-020-3886	SERVO MECHASISM
3316498-1		MLG SHOCK STRUT ASSY
3316498-3	1620-01-521-5645	CYLINDER AND PISTON
3316498-5		CYLINDER AND PISTON
3316498-7		MLG SHOCK STRUT ASSY
3316498-9		CYLINDER AND PISTON
3316500-13	1620-01-304-4562	RET LANDING GEAR
3316500-15		MLG SHOCK STRUT ASSY
3318488-1	1660-01-130-4645	CONTROL BOX WINDSHIELD
332D-11A	6615-00-348-3874	VERTICAL REFERENCE
332D-6	6615-00-556-8024	VERTICAL GYRO
3-34D15	6130-01-170-7850	MC-1, POWER SUPPLY
338329-26		LEADING EDGE, OUTER
339814-601		ELEV CTL BOOSTER MECH ASY
339814-604		ELEV CTL BOOSTER MECH ASY
340070-1		CYLINDER
3400770-1		CYLINDER
3400770-3		CYLINDER
3400770-5		CYLINDER
3400770-7	1620-00-410-0874	NLG CYLINDER
3400770-9		CYLINDER
3401835-3		PARTS KIT PROPELLER
3402292-1	6110-01-109-5100	PANEL CONTROL
3403172-1	4920-01-236-7670	TEST SET, INDICATOR
34102C1C4-1C1	6620-00-959-6614	INDICATOR, TACHOMETER
34102-C1C-4-1C1	6620-00-959-6614	INDICATOR, TACHOMETER
341417-3		MANIFOLD ELEVATOR
343D902G01		INDICATOR HEIGHT
34538-2		ACTUATOR
34538-4	1680-00-845-0699	ACTUATOR SPOILER DOOR
345726-7		NLG DRAG BRACE ASSY
345726-8		NLG DRAG BRACE ASSY
345A-7	6615-00-134-5980	RATE OF TURN SENSOR
345A-7A	6615-00-134-5980	RATE OF TURN SENSOR
345C-2A	6615-01-043-2763	ACCELERATION SENSOR
3505228-1-1	2995-00-337-5145	STARTER,ENGINE,AIR TURBINE
3505230-1		STARTER
3505230-1-1	2995-00-337-5116	STARTER ENGINE
35-055	4810-00-528-3666	VALVE, SOLENOID
3505672-1	2995-01-227-6650	STARTER
3505672-1-1		STARTER
3505674-1	2995-01-227-6649	STARTER
3505674-1-1		STARTER
3505786-1	2995-01-493-4166	STARTER,ENGINE,AIR TURBINE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
3505786-1-1		STARTER
351484-3	1650-00-652-5021	HYDRAULIC BOOSTER
351484-600	1650-00-652-5021	HYDRAULIC BOOSTER
351485-3		AILERON BOOSTER ASSEMBLY
351485-4		AILERON BOOSTER QUAD ASSY
351486-9		BOOSTER
35160-0124	6610-01-346-2795	INDICATOR, RATE OF CLIMB
352-1	7025-01-211-6011	PRINTER AUTOMATIC
352773-5		RESERVOIR
352773-6		RESERVOIR
352863-9		SCOOP ASSEMBLY ENGINE
352866-13	4820-01-395-5254	VALVE
352866-3	4820-01-395-5254	VALVE
353D226G01	5840-01-066-9001	INTERFERENCE BLANKER SET
353D582G01	5985-01-027-0225	COUPLER ROTARY RADIO
354148-3		AILERON BOOSTER ASSY
354148-4		AILERON BOOSTER QUAD ASSY
354148-600		AILERON BOOSTER ASSEMBLY
354153-1		RUDDER CTL BOOSTER ASSY
354153-601		RUDDER CTL BOOSTER ASSY
354731-1		FAN
355390-2	1560-00-576-3920	GEARBOX
355390-3	1560-00-576-3920	GEARBOX
355390-501	1560-00-576-3920	GEARBOX
355883-3		FRAME
35-589	4810-00-870-8922	VALVE
3567609-3703	6685-01-146-8649	AUTOSYN PRESSURE TRANSMITTER
356883-1		EXHAUST
3571281-8102	6620-01-159-4330	TACHOMETER
358800-1		UPLOCK ASSY
358800-5		UPLOCK ASSY
358800-7		UPLOCK ASSY
358800-9		UPLOCK ASSY
359900-27		CONTROL COLUMN
360-058-001	6680-01-099-0790	TOTALIZER, FUEL QUANTITY
3603100-1		FUEL CONTROL
3603100-1-1	2910-01-013-2741	FUEL CONTROL
360414-1L	1560-00-613-6501	DOOR ACCESS AIRCRAFT
3604174-1	5930-01-019-5594	SWITCH SLIDE
3604174-1-1	5930-01-019-5594	SWITCH SLIDE
3605812-12		APU STARTER
3605812-14		APU STARTER
3605812-17		APU STARTER
3605812-18		APU STARTER
3605812-18-1		APU STARTER
360614-1	1560-00-624-9338	DOOR, AIRCRAFT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
3609150-3-1		FUEL CONTROL UNIT
3609150-8	2910-01-329-3239	FUEL CONTROL
36104-1H8A1	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
36104-1L11A2	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
36105-1N1C1	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
3614657-0102	5841-01-314-9993	MODE SELECTOR
362511-1		OIL TANK ASSY
362511-95	1560-00-886-9037	Tank Oil
363001-1		DOOR PASSENGER AIRCRAFT
363498-1	1650-00-652-9673	ELEVATOR HYD BOOSTER
363576-11		UPLOCK ASSY
363576-12		UPLOCK ASSY
363576-13		UPLOCK ASSY
363576-14		UPLOCK ASSY
363576-15		UPLOCK ASSY
363576-17		UPLOCK ASSY
363576-2		UPLOCK ASSY
363576-5		UPLOCK ASSY
363576-6		UPLOCK ASSY
363576-7		UPLOCK ASSY
363576-9		UPLOCK
363590-1		STRUT ASSY NLG
363590-3		STRUT ASSY NLG
363590-5		STRUT ASSY NLG
363590-7		STRUT ASSY NLG
364697-1		RUDDER CTL BOOSTER ASSY
364D540G01		FREQUENCY MULTIPLIER
365D019G01	5840-01-158-0146	PULSE FREQUENCY MODULE
36726-1		MOTOR
36745-1		DIRECT CURRENT MOTOR
36A225543G01	6115-00-412-0340	STATOR,GENERATOR
36A84		STARTER
36E165-2C		AIR STARTER
36E165-2QC	2995-01-329-6341	STARTER,ENGINE,AIR TURBINE
36E79-10QA	2995-01-604-7728	STARTER
36E79-12QA	2995-01-124-1891	STARTER
36E79-12QB	2995-01-604-7727	STARTER
36E79-18QA		STARTER
36E79-18QB	2995-01-452-1844	STARTER
36E80-10QA		STARTER
36E80-12QA		STARTER
36E80-12QB	2995-01-164-9483	STARTER
36E80-8QA		STARTER
36E84-16QA		STARTER
36E84-16QB	2995-00-574-3573	STARTER
36E84-16QC	2995-01-050-2462	STARTER



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
36E84-18		STARTER
36E84-18F	2995-01-060-4443	STARTER, AIR TURBINE
36E84-18QA		STARTER
36E84-18QC	2995-01-060-4443	STARTER, ENGINE, AIR TUR
36E84-18QD	2995-01-130-9394	STARTER ENGINE AIR TURBINE
36E84-18QF	2995-01-194-8153	STARTER,ENGINE,AIR TURBINE
370012-1		LEADING EDGE, VERTICAL
370018-5	1560-00-928-3106	ELEVATOR AIRCRAFT
370018-6	1560-00-928-3105	ELEVATOR AIRCRAFT
370019-602	1560-00-659-0362	VALVE
370438-1		MLG SHOCK STRUT ASSY
370438-13	1620-00-784-5509	STRUT
370438-7	1620-00-784-5507	STRUT
370442-1		MLG TORQUE STRUT ASSY
370510-29	1560-00-716-2869	LEADING EDGE AIRCRAFT
370639-3L		DRIVE
370639-3R		DRIVE
370749-1	1650-00-620-7514	CYLINDER ASSEMBLY
370750-1	1650-00-788-8799	CYL ASS RAMP
370768-1		RESERVOIR
370772-1		RESERVOIR ASSY
370772-3		RESERVOIR ASSY
370772-5		RESERVOIR ASSY
370888-1		RESERVOIR ASSY
370888-3		RESERVOIR ASSY
370888-7		RESERVOIR ASSY
371671-1		STRUT ASSY NLG
371688-101	2910-00-907-7481	FUEL PUMP & CONTROL ASSY
371688-39	2915-01-171-3486	PUMP & CONTROL UNIT FUEL
371689-11		NLG DRAG BRACE ASSY
371689-12		NLG DRAG BRACE ASSY
371689-7		NLG DRAG BRACE ASSY
371689-8		NLG DRAG BRACE ASSY
372021-11	1650-01-132-3641	SERVO MECHANISM, HYDRAULIC/PNEUMATIC, AIRCR
372021-11X119	1650-01-132-3641	BOOSTER ASSY RUDDER
372021-3		RUDDER CTL BOOSTER ASSY
372021-5	1650-00-651-4180	RUDDER CONTROL BOOSTER
372021-7		SERVOMECHANISM, HYDRAULIC/PNEUMAT
372522-80	1560-00-084-3747	DOOR LANDING GEAR
372682-1		CYLINDER ASSY
372697-18	2920-01-013-9867	STARTER,ENGINE,ELECTRICAL
372697-18-1	2920-01-359-9819	STARTER
372697-21-1		APU STARTER
372697-24-1	2925-01-217-5889	STARTER, ENGINE, ELECTRICAL
373531-1		VALVE
373531-3		VALVE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
373531-5	1620-00-953-5572	NLG STEERING VALVE
373531-5A		VALVE
373531-7	1620-00-953-5572	VALVE, STEERING
374453-3		HYDRAULIC ASSY
374454-1		HYDRAULIC ASSY
374455-1		AILERON BOOSTER QUAD ASSY
374455-2	1650-00-784-9692	AILERON BOOSTER ASSY
374455-3	1650-00-784-9692	SERVOMECHANISM HYDRAULIC
374455-5		AILERON BOOSTER QUAD ASSY
374455-7	1650-01-134-4415	SERVOMECHANISM HYDRAULIC
374461-5	1650-00-784-9693	ELEVATOR CONTROL BOOSTER ASSY
374461-601		ELEV CTL BOOSTER MECH ASY
374461-605		ELEV CTL BOOSTER MECH ASY
374461-7		BOOSTER
374761-1		RESERVOIR ASSY
374761-17		RESERVOIR
375322-10		STARTER, ENGINE, ELE
375322-7	2920-00-573-0329	STARTER
375322-8	2990-00-483-1432	STARTER
375322-9	2920-00-060-0057	STARTER ASSY
375456-7	1560-00-912-1806	FLAP INBOARD LH
37604-1E5A1	5826-00-882-1203	INDICATOR, BEARING DISTANCE
376269-1		VALVE
376269-7		VALVE
376730-0-024	2835-00-007-7955	GTC
376730-0-24	2835-00-007-7955	GAS TURBINE COMPRESSOR
37D401750P104		SPRAYBAR ASSY, MAIN
380409-15		RESERVOIR ASSY
380410-13		RESERVOIR ASSY
380410-29		RESERVOIR ASSY
380606-1		RESERVOIR ASSY
38106-001	6130-01-217-5880	POWER SUPPLY, REMOTE
381116-1	2835-01-056-6467	AUXILIARY TURBINE (APU)
381116-1-7		APU
381116-1-8	2835-01-437-1578	ENGINE,GAS TURBINE,NONAIRCRAFT
381252-1-1	2835P381252-1-1	APU ASSY GTC P85-185L
38140-7	1680-00-677-6238	ROTARY ACTUATOR
38140-9-1		ROTARY ACTUATOR
381410-19		RESERVOIR ASSY
382052-1	1560-00-716-2869	LEADING EDGE ASSY
383056-1		STARTER
383056-1-3		STARTER
383056-1-4		STARTER
383074-1-1		STARTER
383074-1-2		STARTER
383074-1-5		STARTER



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
383076-1-1		STARTER
383076-1-2		STARTER
383076-1-5		STARTER
383198-1-1	2995-00-985-1355	STARTER ENGINE AIR TURBINE
383198-1-2		STARTER
383198-1-3		STARTER
383198-1-4		STARTER
383198-1-4-1		STARTER
383298-1-4		STARTER
383350-11-1		STARTER
383350-12-1		STARTER
383350-13-1		STARTER
383350-14-1		STARTER
383350-2-1		STARTER
383350-3-1		STARTER
383350-4-1		STARTER
383350-5-1		STARTER
383350-6		STARTER
383350-6-1		STARTER
383350-7		STARTER
383350-7-1		STARTER
383350-8-1		STARTER
383350-9-1		STARTER
383534-1-2		STARTER
383534-2-1	2995-00-007-7957	STARTER ASSY
383534-2-2		STARTER
383534-7-1		STARTER
383650-1-1		STARTER
383650-1-2		STARTER
383652-1-1		STARTER
383968-1-1		STARTER
383968-1-2		STARTER
388028-19	1620-01-423-3708	PISTON, LANDING GEAR
388046-3	1620-00-862-8285	CYLINDER & PISTON
388046-9	1620-01-270-3196	CYLINDER & PISTON
388058-1		MLG SHOCK STRUT ASSY
388058-19		MLG SHOCK STRUT ASSY
388058-3		PISTON ASSY
388058-5		CYLINDER ASSY
388058-9		MLG SHOCK STRUT ASSY
388059-11	1620-00-862-4057	PISTON AY SHOCK STRUT
388064-1		MLG TORQUE STRUT ASSY
388064-3	1620-00-805-8495	DRAG BRACE, LANDING GEAR, MLG
388071-3	1620-00-085-2624	LANDING GEAR, RETRAC
389154-1	1560-00-888-2231	RADOME ASSY
38E73-4A	2925-01-038-5770	VALVE CONTROL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
38E73-5A		VALVE
38E73-6A		VALVE
38E73-7A	4810-01-060-5087	VALVE ASSY, STARTER CONTR
39-075	1630-00-908-9999	VALVE, DUAL CONTROL
39-075A	1630-00-998-7896	VALVE, SKID CONTROL
392122-1		VALVE
392122-1-1	4810-00-897-7308	VALVE, STARTER CONTROL
393004-23681	6680-00-618-5806	INDICATOR, LIQUID QTY
393004-34750	6680-00-809-4354	INDICATOR, LIQUID QTY
393004-65333	6685-00-872-3976	INDICATOR, LIQUID QTY
393084-11358	6680-00-981-7828	INDICATOR, LIQUID QTY
393084-11881	6680-00-877-7009	INDICATOR, LIQUID QTY
396308-1-1	4810-01-040-2372	VALVE CONTROL FLOW
396308-2-1	4810-01-040-2372	VALVE CONTROL FLOW
396308-2-2	4810-01-040-2372	VALVE CONTROL FLOW
396308-3-1		VALVE
398648-1-1		VALVE, BUTTERFLY
398648-1-2	4810-00-575-7781	VALVE BUTTERFLY
398648-1-4		VALVE
398650-1-1	4810-00-575-7789	VALVE,BUTTERFLY
398652-1-1	4810-00-612-9419	VALVE
398654-1-1	4810-00-601-3194	TEMP CONTROL VALVE
398654-1-2	4810-01-039-0459	SHUTOFF VALVE
398654-1-3		AIR VALVE
398654-1-4		AIR VALVE
398854-1		MOTOR VALVE
3A95550-107	4810-00-796-1672	VALVE
3D58770G01	5985-01-387-4414	COUPLER ROTARY RADIO
3S2060DC102D1	6110-00-944-3046	CONTROL GENERATOR
3S2060DR113C2	6110-01-206-9877	REGULATOR VOLTAGE
4000504-0301		Antenna, Radar
4000504-0303		RADAR ANT
4000831-0105		RADAR RT
4001670-2511		INDICATOR RADAR TARGET
4005A	6610-00-557-3030	INDICATOR, ATTITUDE
4020936-903	6615-01-280-4702	SYNCHRONIZER, ELECTR
402306-3		NLG STEERING CYLINDER
402306-5		NLG STEERING CYLINDER
402306-7		NLG STEERING CYLINDER
4024400-7		FLIGHT RECORDER
403-6BX		RELAY VOLTAGE AC
40-621	6695-00-719-7103	TRANSDUCER
40-621-1	6695-00-055-6481	TRANSDUCER, MOTIONAL
4078952-39		TUBE ASSY
4079653-1	5930-01-481-3559	SWITCH ASSEMBLY
4088T42P01	6620-01-328-6973	INDICATOR ELEC TACH



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
41 10004		SUCTION PUMP
411000-1	4320-00-653-5494	PUMP
411000-2	4320-00-050-8205	PUMP HYDRAULIC
411000-4	4320-00-152-1488	Pump, Suction Boost Hydraulic
41-2036-002		VALVE
41-2036-004		VALVE, SOLENOID
41-2036-005		VALVE
41750-3-41BG		CARGO WINCH
41910A1-22	6220-00-453-6968	LIGHT, NAVIGATIONAL
41C220-53	1660-00-822-3344	VALVE AIR
42066-2	5930-01-502-4004	SWITCH, PRESSURE
42-109	1630-00-085-2625	BOX CONTROL ANT-SKI
42-109-1A	1630-00-133-8183	CONTROL UNIT ANTISKID
42-109A	1630-01-104-1015	ANTI-SKID BOX
42G68-2	5930-01-502-4004	SWITCH, PRESSURE
430391A		REGULATOR,VOLTAGE
4344D1-1		BALLSCREW
4344D1-2		BALL SCREW
4344D1-3	1680-01-181-9873	ACTUATOR INBOARD WING FLAP JACKSCREW
4344D1-4	1680-01-181-9874	ACTUATOR INBOARD WING FLAP JACKSCREW
4344D2-1		SCREW AND YOKE, OUTBOARD
4344D2-3		SCREW AND YOKE, OUTBOARD
4344EA-1		ACTUATOR
4344EA2		ACTUATOR
4344EA-2	1680-01-004-2086	SCREW ASSEMBLY INBOARD
4344EA3	3040-01-414-2019	ACTUATOR,MECHANICAL,LINEAR
4344EA-3	3040-01-414-2019	ACTUATOR JACK SCREW
4344EA4		ACTUATOR
4344EA-4		SCREW ASSEMBLY, INBOARD
43932-052	6610-01-074-2819	ALTIMETER
440970-1		FUEL CONTROL UNIT
440970-2	2915-01-113-8557	CONTROL, MAIN
440978-1	2915-01-008-7398	FUEL CONTROL UNIT
443147-2	6620-00-856-8263	INDICATOR, TORQUEMETER
44344EA-4		ACTUATOR ASSY
45-0024-1	6220-00-051-3811	LIGHT LANDING
45-0292-1	6220-01-340-4711	LIGHT, LANDING, AIRCRAFT
451200-02-03		MODE SELECTOR UNIT LTN-92
452080-05-04	6605-01-107-5585	INERTIAL NAV UNIT LTN-72
452080-05-85-15		INU/GPS
452090-02	6605-01-053-5554	CONTROL DISPLAY UNIT
452100-02		LTN-72 MODE SELECTOR
452100-02-03	6605-01-290-5720	MODE SELECT UNIT LTN-51
452574-01	6605-01-048-2000	COMPUTER NAVIGATION LTN-51
454620-01-28-04		INERTIAL NAV UNIT LTN-72
457EA0		ACTUATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
457EA-0		ACTUATOR
457EA1		ACTUATOR MECHANICAL
457EA-1		ACTUATOR
457EA2	1680-00-777-0135	ACTUATOR O/B FLAP JAKSSC
457EA-2		ACTUATOR
457EA3		BALLSCREW ASSEMBLY
457EA-3	1680-00-777-0136	ACTUATOR
457EA4	1680-00-773-2904	GEARBOX WING FLAP
457EA-4		GEAR BOX
457EA-5		ACTUATING ASSY
457EA-6		ACTUATING ASSY
457EA-7		SCREW JACK
458900-06-01	7025-01-290-5721	CONTROL DISPLAY UNIT
458900-08-01		CONTROL CDU UNIT LTN-92
463001-04-05	6605-01-294-6975	INERTIAL NAV UNIT LTN-92
463001-6000-0413		INERTIAL NAVIGATION UNIT
463001-7000-0506	6605-01-425-2022	CONTROL UNIT,NAVIGATION SET (LTN-92)
468100-0-1		RELAY DE-ICING TIMER
482-0061-030	6655-01-283-0303	RADIO MAGNETIC INDICATOR
48285-3-1		MOTOR
48285-3-2		MOTOR
48285-4-1		MOTOR
48285-7-1		MOTOR
48285-7-2		MOTOR
48285-8-1		MOTOR
48285-8-2		MOTOR
4954A		VALVE
4A037-1	4810-00-908-2931	VALVE LINEAR
4K90075-103A	6605-01-078-1701	COUPLER, HEADING
4U4059		AFT CARGO DOORLOCK CYL
4-U-4059		AFT CARGO DOORLOCK CYL
500012-01	6130-01-412-3096	INS (BATTERY)
500702-3021	4140-00-051-2620	FAN, VANEAXIAL
5008-3001		SERVO TEMP INDICATOR TOT
501-1533-51	6610-01-309-1413	INDICATOR, ATTITUDE
50150-20	4810-00-728-3396	VALVE,LINEAR,DIRECTIONAL CONTROL
5021-3001		TURBINE OUTLET TEMPERATURE INDICATOR
50260-1		VALVE
502BL10	6685-00-061-6255	INDICATOR TEMP
502BL10A	6685-00-937-4039	INDICATOR TEMPERATURE
5050051-9	6615-01-397-7980	CONTROLLER, FLIGHT, AUTOPILOT
50680-1	1650-01-087-0956	VALVE
510414-3-2	6610-00-759-7170	COMPUTER, TRUE AIR
51107-003	6110-00-649-8835	REGULATOR VOLTAGE
51509-002R	6110-00-165-3755	VOLT REG & PROT PANEL
51509-009D		GENERATOR CONTROL UNIT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
518-28007-204	6610-01-259-0251	ALTIMETER, ENCODING
518-28007-208	6630-01-071-1654	ENCODING ALT
52.0261.650.00	5865-01-059-4560	IF FILTER
522-0578-005	6610-00-557-0867	INDICATOR, COURSE
522-0579-005	6610-00-557-0868	APPROACH HORIZON INDICATOR
522-1230-00		RECEIVER TRANSMITTER
522-1501-00		HF TRANSCEIVER
522-1658-000		MOUNTING BASE ELECTRIC
522-1747-00	6610-00-830-5832	INDICATOR, HORIZONTAL SITUATION
522-2213-000	5821-00-838-7051	Control Radio Set
522-2412-00	6610-00-830-5832	INDICATOR, HORIZONTAL SITUATION
522-2412-000	6610-00-830-5832	INDICATOR, HORIZONTAL SITUATION
522-2424-004	5821-00-846-6037	OSCILATOR RADIO FR
522-2447-252		CONTROL NAVIGATION
522-2447-556		CONTROL RADIO SET
522-2494-100	5826-00-346-7298	INSTRUMENTATION
522-2702-014		D.M.E.
522-2702-061		D.M.E.
522-2900-057	6615-01-038-7294	CONTROL, SERVO, AUTOMATIC PILOT
522-2996-011	5826-00-114-4063	RECEIVER RADIO NAVIG
522-3195-00	5895-01-106-3765	RECEIVER RADIO
522-3197-00	5826-00-141-3785	INSTRUMENTATION
522-3552-005	5955-00-768-7694	OSCILLATOR
522-3698-003	5826-00-758-4546	ALTIMETER RADIO SET
522-3985-001		VERTICAL GYRO
522-4114-003	5841-00-758-4547	INDICATOR RADIO ALTIM'TR
522-4114-010	5841-00-134-5975	INDICATOR RADIO ALTIMETER
5232105N		FUEL NOZZLE
523EA6		GEAR BOX
523EA-8		FLAP DRIVING MOTOR
528-0113-005	5821-00-868-7528	TRANSLATOR, SIGNAL DATA
528-0598-004		POWER SUPPLY
53150-1	4810-01-066-0321	VALVE LINEAR DIRECTION CONTROL
53150-2		VALVE
53230-1	2995-01-228-8008	VALVE
532-38105-202	6610-01-263-1400	INDICATOR AIRSPEED & DIRECT
532-38105-304		INDICATOR AIRSPEED
53C3794	1660-00-787-3961	PORTABLE OXYGEN BOTTLE
540200-2	1680-00-080-2959	ACTUATOR ELECTRO-MECHAN
540200-3	1680-00-060-2959	ACTUATOR
540538-2-1		ACTUATOR
540906-2-6	4810-00-999-5275	ACTUATOR ELECTRO MECH
540906-3-5	4810-01-083-3603	ACTUATOR ELECTRO MECHANICAL
541214-1-2	1660-00-777-0154	ACTUATOR ELECTRO-MECHAN
544388-6-1		ACTUATOR
544-9291-00	6130-00-019-8398	Power Supply



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
544-9293-00	5896-00-845-8367	RECEIVER TRANSMITTER SUBASSY
546-7273-004	5821-00-818-3738	AMPLIFIER SUBASSEMBLY
548025-5		ACCUMULATOR
549-1680-004	5821-00-019-6291	BOARD ASSY
549460-1		ACCUMULATOR
549460-2		ACCUMULATOR
549460-3		ACCUMULATOR
549460-4		ACCUMULATOR
549460-5		ACCUMULATOR
549460-6		ACCUMULATOR
549460-7		ACCUMULATOR
549460-8		ACCUMULATOR
54H60-117	1610-01-096-7677	Hub & Blade
54H60-91	1610-00-846-8332	PROPELLER,AIRCRAFT
54H60-91/-117		PROPELLERS
5502636-2	5996-01-096-4648	AMPLIFIER,ELECTRONIC CONTROL
5502636-4	2915-01-221-6837	AMPLIFIER,TEMPERATU
551025-1		ACCUMULATOR
551050-1		ACCUMULATOR
551050-10		ACCUMULATOR
551050-12		ACCUMULATOR
551050-3		ACCUMULATOR
551200-1		ACCUMULATOR
551200-10		ACCUMULATOR
551200-11		ACCUMULATOR
551200-13		ACCUMULATOR
551200-17		ACCUMULATOR
551200-18		ACCUMULATOR
551200-22		ACCUMULATOR
551200-25		ACCUMULATOR
551200-26		ACCUMULATOR
551200-28		ACCUMULATOR
551200-3		ACCUMULATOR
551200-5		ACCUMULATOR
551R291G01	6130-01-310-4939	POWER SUPPLY
551R291G02	6130-01-310-4939	POWER SUPPLY
55204-8		VALVE
55204-81		VALVE
552430-1		ACCUMULATOR
552430-3		ACCUMULATOR
560-005	6625-00-235-4782	VOLTMETER
560-707	6625-00-235-4782	VOLTMETER
562A5M5	6615-01-040-0126	COMPUTER,FLIGHT CONTROL
562C-8A	6625-01-038-7297	YAW COMPUTER
56B17A	6685-01-534-1475	SENSOR, AMBIENT TEMPERATURE
56B3A	6685-00-373-9004	TRANSMITTER, TEMPERATURE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
57023932-012		ALTIMETER
570-23932-012	6610-01-074-2819	ALTIMETER BAROMETRIC
571925-1-1		COOLING TURBINE
571925-2-1		COOLING TURBINE
571925-3-1	1660-01-036-5903	TURBINE ACFT COOLING
57-761-04	4820-00-876-9872	VALVE,REGULATING,FLUID PRESSURE
581R481H01	5996-01-036-5639	SOLID STATE AMPLIFIER
581R481H04	5996-01-224-7914	AMPLIFIER ASSEMBLY
583R181H03	5865-01-082-0338	SIGNAL PROCESSOR
583R181H08	5865-01-224-2714	PROCESSOR, COUNTERMEASURES SIGNAL
585R195H03	5996-01-224-8905	RADIO FREQUENCY AMPLIFIER
585R944H01	6130-01-192-6999	POWER SUPPLY
585R944H02	6130-01-361-0655	POWER SUPPLY
590A3J	6615-01-038-7296	CONTROL, AIR DATA
590A3J1	6615-01-477-9209	CONTROL AIR DATA
590A-3J1	6615-01-091-0363	AIR DATA CONTROL
595568-5		CYLINDER
5A527-000	2935-00-966-3321	COOLER AND VALVE
5A835	2935-00-999-5673	COOLER & VALVE ASSY
5A844	4820-00-072-5573	VALVE, REGULATING, TEMPERATURE
5A844-000		VALVE, REGULATING
5C16-42-35K05-1D		INDICATOR AIRSPEED
5C16-42-35K05-1DA		INDICATOR AIRSPEED
5C5786		SWIVEL,JOINT HIDRAULIC
5C5787-3	1650-00-009-6833	VALVE ASSEMBLY HYDR
5C5787-7	1650-00-208-3344	SERVO VALVE HYDRAULIC
5C5788-3	1650-00-007-1027	VALVE ASSY
5C5791	1650-00-257-7934	CYLINDER ASSY ACTUATING LINE
5C5792		BOOSTER ACT
5C5792-1	1650-01-069-2337	CYLINDER ASSY,ACTUATING
5C5819		BUTTON, FEATHER
6014-1		THERMOSTAT OIL TEMP CONTROL
601-4203-003		CIRCUIT CARD ASSY.
601-4204-003		CIRCUIT CARD ASSY.
601-4205-001		CIRCUIT CARD A-5
601-4209-001		CIRCUIT CARD
601-4209-003		CIRCUIT CARD
601-4301-001		CIRCUIT CARD ASSY.
601-5764-001	5998-01-270-1079	CIRCUIT CARD ASSY
601-5779-004		CIRCUIT CARD ASSEMBLY
601-5780-002	5998-01-121-7033	CIRCUIT CARD ASSEMBLY
601-5801-004	5998-01-134-1079	CIRCUIT CARD ASSEMBLY
601696-100	6615-00-515-5392	GYROSCOPE, DISPLACEMENT
601696-106	6615-00-348-3842	GYROSCOPE, DISPLACEMENT
60-331A	2915-00-084-3949	PUMP
60-369A	2915-00-971-9130	PUMP FUEL TANK



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
60-371B	2915-00-971-9131	PUMP SUBMERGED ACFT
60-371C		PUMP
60-371D	2915-01-160-8283	PUMP SUBMERGED AIRCRAFT
60-551	4320-00-631-4859	PUMP UNIT ROTARY
608-6615-001	5999-01-115-1898	CIRCUIT CARD ASSY
609-8479-001		CIRCUIT CARD ASSY
609-8479-013	5998-01-074-3255	CIRCUIT CARD ASSEMBLY
611J781G10	5840-01-182-1110	MATRIX COMBINER
611J870G01	5840-01-182-1107	MATRIX ASSY
616418-166	6615-00-605-8498	ACTUATOR
617-8408-001	6130-01-086-8130	POWER SUPPLY
617-9113-004	5998-01-086-2023	CIRCUIT CARD ASSEMBLY
618-3896-004	5999-01-115-1899	CIRCUIT CARD ASSEMBLY
618-4349-001		SENSOR SUB ASSY
618751A	6615-00-676-3828	CONTROL, ALTITUDE ENCODING
61B3-1A	6115-00-351-5766	DISCONNECT ASSY, GEN. PROP.
61B3-1-A	6115-01-459-1272	DISCONNECT ASSEMBLY
62-052748-01	5985-01-062-8035	RF SWITCH
620577-1	6615-00-550-6628	GYROSCOPE, DISPLACEMENT
620578-1	6615-00-555-3962	GYROSCOPE, RATE
621-0453-003	6625-01-092-5457	SYNTHESIZER ELECTRIC
62201239-001		RECEIVER, VOR/LOC/GS/MB
622-0458-001		COUPLER ANTENNA
622-0507-001	5826-01-012-1938	RECEIVER-TRANSMITTER, RADIO
622-0944-003		MODE SEL
622-0945-007	6615-01-038-7295	MODE SELECTOR
622-1001-001		CONTROL AIR DATA
622-1001-002	6615-01-038-7296	CONTROL AIR DATA
622-1001-022	6615-01-038-7296	CONTROL AIR DATA
622-1239-001		VOR RECEIVER VIR-31
622-1396-002		VHF COM TRANSCEIVER
622-1396-102	5821-01-316-3554	RADIO SET
622-1678-001	5826-01-012-4864	ADAPTER MX 9577A
622-2224-002		ATC TRANSPONDER
622-2224-003		ATC TRANSPONDER
622-2360-001	5826-01-012-7084	CONTROL C-10057A-ARN 118
622-2362-001	5826-01-125-1023	RECEIVER,RADIO
622-2921-002	5826-01-126-6339	DME TRANSCEIVER
622-3016-001	6615-01-168-4952	SERVO PRIMARY
622-3257-001		RECEIVER VOR/ILS
622-3371-001	5820-01-312-2024	TRANSCEIVER (628T-2A)
622-3372-001		RECEIVER - TRANSMITTER
622-3374-002	6610-01-101-1927	INDICATOR ATTITUDE
622-3380-001	5895-01-122-3456	AMPLIFIER RADIO SET
622-3700-001	5821-01-081-0367	RECEIVER TRANSMITTER
622-3702-001		BEARING DIST IND



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
622-3742-001		RECEIVER TRANSMITTER
622-3890-003	5841-01-220-1390	ALTIMETER SET, ELECT
622-3915-001		INDICATOR,RANGE
622-4298-001		HORIZONTAL SITUATION IND
622-4393-002	6615-01-092-0363	CONTROL BOX
622-4394-013		COMPUTER AIR DATA
622-4565-001	6615-01-328-1062	VERTICAL REFERENCE GYRO
622-4956-004	5821-01-286-6543	RECEIVER
622-4956-103	5821-01-258-7579	RECEIVER-TRANSMITTER, RADIO
622-5132-401	5841-01-432-3798	RECEIVER TRANS
622-5146-001		TACAN RT
622-5149-001	6610-01-171-0319	ADAPTER, BEARING
622-5377-001	5895-01-254-2749	RECEIVER TRANSMITTER
622-5486-001	5826-01-188-4493	SELECTOR, MODE
622-5486-001N		MODE SELECTOR
622-5796-399		AP COMP
622-5846-011		MODE SELECTOR
622-6129-001	5985-01-151-5848	COUPLER,ANTENNA
622-6136-002		GYRO
622-6190-204	5895-01-289-5799	COMPUTER
622-6324-002	5821-01-215-3451	V/UHF CONTROL PANEL
622-6376-004		RECEIVER, RADIO
622-6521-015	5895-01-493-3013	NAV CONTROLLER
622-6521-016	5821-01-249-6476	CONTROL INDICATOR
622-6728-213	6610-01-450-2713	INDICATOR AIR SPEED
622-8051-003	6605-01-450-7993	COMPUTER, AIR DATA
622881-09		SERVO AMPLIFIER,MOD 1&2
622-9210-004		TRANSPONDER
622-9722-233	6610-01-450-2710	ALTIT, PRE, AUP, LRU1
622G607	5840-01-088-9011	BALL TRACKER
6-256-251	2915-00-822-3059	VALVE, FLOAT VENT
626125-5	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
630-34960-235	6610-01-312-1580	COMPUTER AIR SPEED
630-37070-235	6610-01-101-1905	COMPUTER AIR SPEED
634065-3	5930-00-961-8507	SWITCH, PRESSURE
6350-A33-CC-C	1660-00-250-0681	CYLINDER VALVE ASSY
6404486J		CONTROL
64141-351-1		ALTIMETER
642-4203-001		CIRCUIT CARD RMI DRIVER
642-4204-001	5998-01-370-9424	CIRCUIT CARD
642-4208-001	5961P*-4208-001	CIRCUIT CARD
642-4214-001		INTERCONNECT BOARD
644131-11	5930-00-996-0388	SWITCH ASSEMBLY
644131-132	5930-00-996-0388	SWITCH ASSEMBLY
644133-11	5930-00-996-0389	SWITCH ASSEMBLY
644133-134	5930-00-996-0389	SWITCH ASSEMBLY



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
6-458-101-1	2915-00-566-0334	FUELING VALVE
645A570A01	5895-01-182-1104	RECEIVER SUB ASSY
645A589A07		AMPLIFIER RADIO FREQUENCY
648R028G02	5995-01-057-0538	CABLE ASSEMBLY
648R195G01	5995-01-056-8526	CABLE ASSEMBLY, W7
656751-2	6986-00-137-0488	DRIVE ANTENNA
657501-1	5895-00-411-3480	NOISE SOURCE, AVALANCHE, SOLID STATE (RCVR - XMITTER)
657565-1	5998-00-411-1682	CORRECTION CIRCUIT CARD ASSEMBLY
657670-2		RECEIVER RADAR
657793-1	5841-00-411-3461	MODULATOR RECEIVER
657828-1	5895-00-411-3464	AMPLIFIER, INTERMEDIATE
658020-1	5841-00-411-3473	OSCILLATOR SOLID STATE
65A27D1	5841-00-900-8081	WARNING SET
66039-01	4320-01-171-0452	HYDRAULIC PUMP
66039-02	4320-00-616-3812	PUMP
662841-14	5985-00-252-3494	SEQUENCER, MOD 1
662845-06		CIRCUIT CARD ASSY.
662845-07	5999-00-153-4123	CIRCUIT CARD ASSEMBLY
662849-01		SYNCHRO REPEATER
662849-06		SYNCHRO REPEATER LTN 51
662849-12		SYNCHRO REPEATER
662853-03	5998-00-153-4126	CIRCUIT CARD ASSEMBLY
662853-6	5998-00-153-4126	CIRCUIT CARD ASSY. LTN-51
662857-12	5975-01-240-3259	MOUNTING BASE ELEC LTN-51
662857-13	5975-01-240-3258	MOUNTING BASE ELEC LTN51
662869-05		INPUT CONVERTER
662873-06		CCA D/A CONVERTER
662881-01	5998-01-319-3886	CIRCUIT CARD ASSEMBLY
662881-01-04		SERVO AMPLIFIER, MOD3
662881-04		SERVO AMPLIFIER UNMODIFY
662881-05		SERVO AMPLIFIER UNMODIFY
662881-06		SERVO AMPLIFIER
662881-17		SERVO AMPLIFIER, MOD 3
662881-18	5975-01-240-3258	SERVO AMPLIFIER MOD3
662889-04		CIRCUIT CARD AMB LTN-51
662889-05		CIRCUIT CARD ASSY
662897-02		CIRCUIT CARD ASSY LTN-51
662897-05		QUANTIZER INERTIAL
662897-06		QUANTIZER
662897-10		CCA QUANTIZER
662897-12	5998-01-240-3681	CIRCUIT CARD ASSY LTN-51
663450-08		51 INU
663454-01	6515-01-313-9905	GIMBAL ASSY LTN-51
663454-03		GIMBAL
663550-04-01	6605-00-124-9447	CDU LTN-51
663570-03	6605-00-165-5888	MODE SELECTOR UNIT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
663604-03	6605-00-152-7238	TRANSFORMER RECTIFIER
663604-04	6605-00-152-7238	TRANSFORMER RECTIFIER
667500-01	6625-01-096-8663	GYROSCOPE
667500-02		GYROSCOPE
667826-17	6615-00-521-4893	CONTROL, ALTITUDE, AUTOMATIC PILOT
66WBD300-1	4320-00-955-3126	PUMP AXL
66WBG300-4		PUMP
66WU300-4	4320-00-955-3125	Pump
67-2734-001		VALVE
67-2735-001		VALVE
67-2790-001		VALVE, BUTTERFLY
67-2790-002	4810-00-003-4369	Valve Butterfly
673443-01		CIRCUIT CARD, DATA
673718-01		POWER SUPPLY LTN-51
673718-03		POWER SUPPLY INU
6782647-J		RELAY IGNITION
6794320(K)		NOZZLE,FUEL SPRAY
6798233L	4920-00-891-3616	TEST SET ELECTRONIC SYSTEMS
6809618-L		FUEL NOZZLE
6809639MX		RELAY BOX
6821493R		SPEED VALVE
683R592G01	6130-01-090-0628	POWER SUPPLY
686R068G01	5865-01-107-0151	POWER SUPPLY SUBASSEMBLY
686R750G01	5998-01-192-2738	BAND 4/5 A10 BOARD ASSEMBLY
6904-2720-1	6625-00-424-4197	TEST SET SUBASSEMBLY
692525-2	5930-01-502-4004	SWITCH, PRESSURE
692751-1	5985-00-252-3494	ANTENNA - LINE 20
692756-1	5841-00-252-3497	RECEIVER TRANSMITTER
692757-1	5841-00-252-3498	CONTROL RADAR
692760-1	5841-00-252-3500	INDICATOR,AZIMUTH-RANGE
692762-1		INDICATOR,RADAR TARGET
692762-3	5841-01-089-1753	INDICATOR RADAR TARGET
692762-4	5841-01-088-8142	INDICATOR, RADAR TARGET
695001-9A		MLG SHOCK STRUT ASSY
695043-1	1650-00-994-8631	CYLINDER ASSEMBLY,ACTUATING,LINEAR
695043-3		NLG UPLOCK CYLINDER
695069-1		VALVE
695069-3		VALVE
695069-3A		VALVE
695187-1	6610-00-580-9363	INDICATOR, FLAP POSITION
695260-1	6625-00-649-2864	AMMETER
695269-1	4820-00-639-9685	REGULATOR
695335-5	6220-00-893-8777	LIGHT, LANDING
695383-1	6685-00-810-6047	GAGE, HYDRAULIC PRESSURE
695422-10	1650-00-626-5728	BRAKE FLAP LH
695422-11	1650-00-626-5729	DISC,BRAKE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
695464-13	1660-00-062-0301	AIR PRESSURE CONT.
695495-3	4810-00-866-8212	VALVE, LINEAR DIRECT
695521-3		LIGHT
695521-5	6220-00-421-9109	LIGHT, ROTATING BEACON
695526-3	4810-00-208-9693	VALVE
695539-3	6620-00-573-7870	THERMOSTAT FLOW CONTROL
695539-4		UNDER FLOOR HEAT THERMOSTAT
695545-5	4320-00-050-8205	PUMP
695547-1	4810-00-208-9709	VALVE
695548-3		NLG STEERING CYLINDER
695561-1		CYLINDER
695568-1	1650-00-570-8688	CYLINDER ASSEMBLY,ACTUATING,LINE
695568-3		CYLINDER ASSY. NOSE LANDING GEAR
695568-5	1650-01-155-6849	CYLINDER NLG HYD
695572-1	6610-00-808-7038	INDICATOR, FLAP POSITION
695579-45	1680-00-373-8044	GEARBOX
695579-69	1620-00-617-9123	GEARBOX
695592-1	4320-00-631-4859	ROTARY PUMP
695592-3	4320-00-631-4859	PUMP
695594-4	1650-00-513-5415	SERVOVALVE,HYDRAULIC
695612-1		CYLINDER
695619-5	2915-00-084-3949	PUMP
695625-1		CYLINDER
695674-1	6685-00-753-7668	INDICATOR, PRESSURE
695674-3	6620-01-394-4042	INDICATOR, PRESSURE
695676-11	1680-01-004-2086	ACTUATOR ASSEMBLY
695676-9	1680-00-615-1335	ACTUATOR
695683-1		SWITCH SIGNAL
695683-3	5930-00-629-6660	SWITCH, PRESSURE
695698-3	2915-00-574-3227	VALVE OUTBOARD VENT
695700-3		ELEVATOR TRIM TAB ACTUATOR
695718-9	1650-00-872-7516	AIR TURBINE DRIVE
695719-1	4140-00-051-2620	FAN
695723-1	1650-00-670-5822	CYLINDER
695745-1	4810-00-653-7572	VALVE
695746-1	2915-00-632-7932	VALVE FUEL SYSTEM
695748-13		VALVE
695748-15		SOLENOID SHUT-OFF VALVE
695755-1	1680-00-733-3491	WINCH
695755-3	1680-01-223-8908	WINCH
695755-5	1680-01-387-6739	WINCH
695762-3	4810-00-566-7114	VALVE LINEAR
695768-1	2915-00-971-9130	PUMP
695769-3	2915-00-083-9373	PUMP SUBMERGED AIRCRAFT
695775-1		ACTUATOR
695775-2	1680-00-981-7652	ACTUATOR,ELECTRO-MECHANICAL,LINE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
695780-1	6625-00-555-4522	INDICATOR, LOADMETER
695789-11	1680-01-114-3119	PANEL, LANDING GEAR CONTROL
695789-19	5930-01-391-8430	SWITCH ASSEMBLY
695797-1	6680-00-580-1247	INDICATOR LIQUID QUANTITY
695798-3	6680-01-099-0790	TOTALIZER, FUEL QUANTITY
695805-1	4810-00-987-3948	VALVE, ANTI-ICING
695807-1	1680-01-208-0174	ACTUATOR ELECTRO-MECHANICAL
695807-3	1680-01-254-6893	ACT ELEC MACH LINE
695807-7		ACTUATOR
695810-3	2915-00-789-1102	HEATER ASSEMBLY,FUEL
695812-2	4810-00-673-2727	VALVE
695812-2C		SHUT-OFF VALVE
695838-3	1680-00-426-5616	ACTUATOR
695906-1	5930-00-615-7340	SWITCH, PRESSURE
695916-1	4810-00-627-5271	VALVE
695943-3	4140-00-814-5758	FAN, RECIRCULATING
695953-13		NUT
695960-1		SCREWJACK
695960-5		SCREWJACK
695974-1	2915-00-775-9195	VALVE
697133-1	1650-01-087-0956	VALVE
697134-1	4810-00-522-4592	VALVE
697149-1	5930-00-727-3638	SWITCH, PRESSURE
697201-1	6115-00-946-8441	GENERATOR
697232-1	1650-00-204-1703	MOTOR HYDRAULIC
697237-7	6615-00-459-9599	REPEATER, SERVO
697244-1	6620-00-856-8263	INDICATOR, TORQUEMETER
697260-1	4820-00-978-8886	VALVE
697283-1	4820-00-063-2438	VALVE
697395-1	1630-00-998-7897	VALVE, BRAKE CONTROL
697396-1	6695-00-719-7103	TRANSMITTER
697397-3	1630-00-908-9999	VALVE
697638-3	4810-01-004-5634	VALVE
697638-9	4810-01-157-2583	VALVE
697749-1	6680-01-220-4090	FUEL QTY DIGITAL INDICATOR
697749-15	6680-01-350-8049	INDICATOR, LIQUID
697749-9		INDICATOR LIQUID QTY
698042-1	6620-01-444-5516	INDICATOR, MULTIPLE
698043-1	6620-01-443-1214	INDICATOR, MULTIPLE
698056-1	6610-01-444-0168	ALTIMETER, SERVO CONTROL
698057-1	6610-01-444-0169	INDICATOR, AIRSPEED
698611-1		TORQUEMETER IND
7000A	6615-00-530-3061	GYROSCOPE, DISPLACEMENT
7000B	6615-00-973-2218	GYROSCOPE, DISPLACEMENT
7000E	6615-00-951-9140	GYROSCOPE
700647-1	5998-00-422-3252	CIRCUIT CARD



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
7006M51G02	2915-00-480-8112	T5 AMPLIFIER
701-2003	5930-01-436-0623	SWITCH ASSEMBLY
701-2605	5930-01-413-8954	SWITCH ASSEMBLY
70262-1		VALVE
703873-2	5985-00-252-3493	PITCH ACTUATOR ASSEMBLY
703874-2	5985-00-252-3492	ANTENNA DRIVE
704175-1	1610-00-895-8588	SPINNER, PROPELLER, AIRCRAFT
704175-2	1610-01-372-0536	SPINNER PROPELLER
705079-1	1610-00-941-4353	BRACKET ASSY
707-5412	5930-01-311-5657	SWITCH ASSEMBLY
7-115945		VALVE ASSY
714325-3	1610-01-038-5779	VALVE HOUSING PROPELLER
714325-5	1610-01-016-2196	VALVE HOUSING
714325-7	1610-01-318-4870	HOUSING ASSEMBLY, VA
714819-1	5895-00-252-3492	ROLL ACTUATOR SUBASSEMBLY
714820-1	5985-00-252-3493	PITCH ACTUATOR ASSEMBLY
716BK-8-036	6610-00-663-4153	INDICATOR
716BU-8-036	6610-00-663-4156	RATE OF CLIMB INDICATOR
722-2032-001		AUDIO ASSY
722-5140-002		SENSOR RATE OF TURN
724BK03M	6610-00-526-4803	INDICATOR, AIRSPEED
724CU-4-012	6610-00-514-5612	INDICATOR, AIRSPEED
724CU-5-011	6610-00-531-4299	INDICATOR, AIRSPEED
724CU5-03M	6610-00-526-4798	INDICATOR, AIRSPEED
724CU8-011	6610-00-531-4296	INDICATOR, AIRSPEED
724DX4-012	6610-00-526-7944	INDICATOR, AIRSPEED
731300-3	2915-00-357-2496	VALVE, FLOAT, AIRCRAFT
733872-2	1610-00-005-8685	HOUSING ASSY PUMP
733872-5	1610-01-350-7769	PUMP HOUSING
733872-6	1610-01-220-6052	PUMP HOUSING
736639-1	5996-00-421-8429	AMPLIFIER ASSEMBLY
736639-2	5895-01-103-5399	AMPLIFIER ASSEMBLY
75-0291-1	6220-01-466-8702	PANEL, INDICATING, LIGHT
751872-3	1660-01-019-8577	AIR CONDITION
75-55132-001	6605-01-122-7891	REPEATER, SERVO
75-55136-001	6605-01-078-6948	REPEATER, SERVO
756LPE50	6220-00-808-3655	PANEL, INDICATING, LIGHT
757R501	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY
757R501G02	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY
759R379G01	6130-01-211-8075	POWER SUPPLY CONTROL
759R379G02	6130-01-211-8075	POWER SUPPLY CONTROL
75J808000-103	6610-01-309-1413	INDICATOR, ATTITUDE
7609-17B5-1	6620-00-526-7917	SSUFDR
7609-37-C5-1	6685-00-526-7864	TRANSMITTER
7609-37H5-1	6685-00-990-5746	TRANSMITTER, PRESSURE
7609-37M5-2	6685-00-954-7417	TRANSMITTER, PRESSURE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
761230-2		SYNCHROPHASER
766840-1	1610-01-097-8728	SYNCHROPHASER
766840-2	1610-01-155-9337	SYNCHRO PHASER
766926-1		CYLINDER
766985-1		CYLINDER
766R023G01	5998-01-246-1704	ANTENNA BOARD ASSEMBLY
7-702755		VALVE
771180-1		CYLINDER
7-716835	2915-00-739-3047	VALVE, FLOAT AIRCRAFT
772-5140-001		RATE SENSOR
772-5140-002	6615-01-134-3127	GYROSCOPE FLIGHT
772-5370-003	5826-01-065-9189	HORIZONTAL SIT.IND.
774474-1	1610-01-112-3771	STOP ASSEMBLY PROPELLER
774800-1	1610-01-128-7400	Synchrophaser
776840-2	1610-01-155-9337	SYNCHRO PHASER
777-1034-001	6615-00-134-5980	RATE OF TURN SENSOR
777-1225-001		CONTROL,RADIO SET
777-1493-006		ADF CONTROL
77D0069-1	6130-01-058-5927	POWER SUPPLY
784755-1	5977-01-209-4979	HOLDER ELECTRICAL
7854687C		SPEED CONTROL
792-6140-001	5985-01-089-3064	MOD. COUPLER
792-6216-004		ADF RECEIVER
792-6221-003		REMOTE SELECTOR
792-6255-005		MODE CPLR
792-6275-002	5826-01-065-1759	CONTROL GAIN ADF
792-6348-005	6615-01-038-7299	CONTROLLER AUTOPILOT
792-6348-005N		AUTO PILOT CONTROLLER
792-6357-002		ATTITUDE DIR IND
792-6657-001		VHF COMM TRANS
792-6694-001	6615-00-348-3874	VERTICAL REFERENCE
792-6703-003	6615-01-040-0126	COMPUTER,FLIGHT CONTROL
792-6781-003	6615-01-037-7780	SERVO UNIT
792-6785-002	6615-01-065-9448	MOUNT, SERVO
794260-1	6610-01-385-8527	INDICATOR, POSITION
797-2445-013	5998-01-074-0568	CIRCUIT CARD ASSY
797-3639-013	5998-01-074-5119	ELECTRONIC COMPONENTS ASSEMBLY
797-7711-001	6615-01-037-7780	SERVO UNIT
798C528G01	6115-01-014-5457	ROTOR
798C635G01		Stator Generator
7MJ1	6685-00-954-7417	TRANSMITTER, PRESSURE
800500-19	4120-01-010-5171	CONTAINER ASSY FIRE
800530-1	4210-01-300-5266	EXTINGUISHER
8037-255		AC MOTOR
8037M1		ACTUATOR
8037M2	1680-01-013-9501	ELE TRIM ACTUATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
806500-1		VALVE
8067-1A	1680-01-009-8293	ELEVATOR SCREW JACK
8067-2A	1680-01-009-8294	SCREW-JACK, ELEVATOR
8067-3A	1680-01-131-0901	SCREW-JACK
8067-4A	1680-01-131-0902	SCREW-JACK
8118A	1680-01-107-2667	ACTUATOR ASSY, DUAL OUTP
81D0240-1	6130-01-192-6999	POWER SUPPLY
82-052759-01	5996-01-060-6746	LOG VIDEO AMPLIFIER
82-052760-01	5865-01-059-4571	IF DISCRIMINATOR
82-052795-01	6130-01-058-5927	POWER SUPPLY
822-0761-001	5826-35-787-5499	RECEIVER TRANSMITTER
822-1046-001	5820-01-474-0840	RECEIVER , 618M-5A
822-1114-001	5821-01-467-8793	VHF COMM TRANS
822-1944-001	6610-01-519-0844	INDICATOR AIRSPEED & DIRECTION
8318-0610	5930-01-216-3233	SELECTOR SWITCH
8318-0610-1	5930-01-216-3233	SELECTOR SWITCH
8347-12	1680-01-257-2445	GEARBOX
8348M1	1620-00-617-9123	LANDING GEARBOX
8353M1		BALL SCREW
8353M2		BALL SCREW
83832-1	1660-00-870-9373	HEAT EXCHANGER
83832-1-2	1660-00-870-9373	HEAT EXCHANGER AIR
839966-1		AMPLIFIER TEMPERATURE
83D0439-1	6130-01-192-6999	POWER SUPPLY
8430M2		BALLSCREW
8430M3		BALL SCREW
8430M4	1620-01-263-6733	BALLSCREW ASSEMBLY
8440-2		VALVE
8445M1	1680-01-324-8157	INBD FLAP ACTUATOR
8446M1	1680-01-324-8158	FLAP ACTUATOR
85027-1	1660-01-468-3917	HEAT EXCHANGER AIR
8545M1		BALLSCREW ASSEMBLY
8546M1	1680-01-222-2551	BALLSCREW ASSEMBLY
8555M1		LANDING LIGHT
8555M2		LANDING LIGHT
8555M3		LANDING LIGHT
8555M4		LANDING LIGHT
8555M5		LANDING LIGHT
8555M6		LIGHT LANDING
8555M7		LIGHT LANDING
8555M9		LIGHT LANDING
8575600G		CONTROL SPEED SENSITIVE
86250-2		OIL COOLER ASSY W/ REGULATOR
8656M2	1680-01-497-7142	ACTUATOR,ELECTRO-MECHANICAL,LINE
880057-1	5895-01-206-7147	ITERROGATOR SET
880T100		ACTUATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
880T100-1		ACTUATOR
880T100-3	1680-01-329-7411	ACTUATOR, ELECTRO-ME
89000-1	6620-00-901-7848	PRESSURE TRANSMITTER
89000-1 / TRU81/A		TRANSMITTER PRESSURE
892541-100	6350-00-015-8049	FIRE CONTROL UNIT
898028-1-1	4820-00-007-7956	STARTER VALVE
89D0834-1	6130-01-361-0655	POWER SUPPLY
8DJ100WAA1	6685-00-897-8400	INDICATOR, TEMPERATURE
8DJ100WAA2	6685-00-897-8400	INDICATOR TEMPERATURE
8DJ100WAD2	6685-00-780-7787	INDICATOR, TEMPERATURE
8DJ100WAD3	6685-00-780-7787	INDICATOR, TEMPERATURE
8DJ100WAD5	6685-00-780-7787	INDICATOR, TEMPERATURE
8DJ135LWB1	6680-01-061-3996	RATE OF FLOW IND
8DJ179WAD1	6685-01-096-6867	TEMP INDICATOR
8DJ179WAD4		TEMP IND
8DJ179WBK1	6685-00-138-1564	INDICATOR TEMPERATURE
8DJ43AAM	6620-00-515-4541	INDICATOR ELECTRICAL TACHOMETER
8DJ43AAM13	6680-00-663-4207	TACHOMETER INDICATOR
8DJ43AAM14	6680-00-663-4271	TACHOMETER INDICATOR
8DJ43BAD		Electric Thermometer
8DJ48FAL2	6610-00-515-4600	FLAP POSITION INDICATOR
8DJ48FAR	6610-00-580-9363	INDICATOR, POSITION
8DJ48FAR2	6610-00-580-9363	INDICATOR, POSITION
8DJ48FCM2	6610-01-392-7980	INDICATOR, POSITION
8DJ49GAW	6610-00-531-5417	INDICATOR, POSITION
8DJ49GAW2	6610-00-808-7037	INDICATOR, POSITION
8DJ49GAY	6610-00-580-9690	INDICATOR, POSITION
8DJ49GAY1	6610-00-580-9690	INDICATOR, POSITION
8DJ49GAY2	6610-00-580-9690	INDICATOR, POSITION
8DJ49GBV2	6610-00-808-7038	INDICATOR, POSITION
8DJ49GEP2	6610-01-393-2386	INDICATOR, POSITION
8DJ49GER2	6610-01-393-4116	INDICATOR, POSITION
8DJ49GET2	6610-01-393-2384	INDICATOR, TRIM, CONTROL
8DJ49LAM2	6610-00-817-8771	DC SELSYN POSITION INDICATOR
8DJ49LAN2	6610-00-817-8772	DC SELSYN POSITION INDICATOR
8DJ64GBC1	6620-01-098-2960	INDICATOR FUEL
8DJ64GBH1	6620-01-038-5769	FUEL FLOW IND
8DJ64GBW1	6620-01-391-2998	INDICATOR, RATE OF FUEL FLOW
8DJ67FCA		Tachometer Indicator
8DJ71GAB	6620-00-551-2631	INDICATOR RATE OF FLOW
8DJ71GAB1	6620-00-551-2631	INDICATOR RATE OF FUEL FLOW
8DJ71GAK2	6620-00-621-2903	INDICATOR, RATE OF FUEL FLOW
8DJ72GAB	6620-00-551-1270	INDICATOR, RATE OF FUEL FLOW
8DJ72GAB1	6620-00-551-1270	INDICATOR, RATE OF FUEL FLOW
8DJ72GAD2	6620-00-621-2904	INDICATOR, RATE OF FUEL FLOW
8DJ81CAA1	6620-00-621-0143	TACHOMETER INDICATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
8DJ81CAA2	6620-00-969-3972	TACHOMETER INDICATOR
8DJ81CAA4	6620-01-063-9636	TACH IND
8DJ81CBD1	6620-00-877-3266	INDICATOR, TACHOMETER
8DJ81CBD2	6620-00-877-3266	INDICATOR, TACHOMETER
8DJ81CBD4	6620-01-157-9266	INDICATOR TACHOMETER
8DJ82CAS1	6620-00-895-0976	INDICATOR, TACHOMETER
8DJ98AAC1	6685-00-621-2906	INDICATOR, TEMPERATURE
8DJ98AAD1	6685-00-621-2906	INDICATOR, TEMPERATURE
8T51GAA5	6130-00-772-8567	POWER SUPPLY ACH
8TJ50(4A5-5)		FUEL FLOW METER
8TJ50GA		FUEL FLOW METER
8TJ50GAA5	6620-00-720-3223	F/F TRANSMITTER
8TJ50GAS5	6620-00-720-3223	F/F TRANSMITTER
8TJ51-GAA		POWER SUPPLY FLOW METER
8TJ51GAA4		FUEL MASS FLOWMETER
8TJ51GAA5		POWER SUPPLY
8TJ64GBW2		TRANSMITTER FLOW METER
8TJ64GBW-2		TRANSMITTER FUEL FLOW
8TJ95GAA4		POWER SUPPLY
907-74	6625-00-199-1879	METER, ELECTRICAL
908-164	6625-00-199-1879	METER ELECTRICAL
9120-1		VALVE
9120-2		VALVE
914858-851		RECEIVER TRANSMITTER
915-38106-001	6130-01-217-5880	POWER SUPPLY REMOTE
9180-1		VALVE
9180-2		VALVE
918476-000	5998-01-269-6978	CIRCUIT CARD ASSEMBLY
918819-801	5998-00-570-4262	CIRCUIT CARD ASSEMBLY
9205-4584		RELAY
92160-01	6610-00-526-4718	INDICATOR, ATTITUDE
92160B	6610-00-526-4718	INDICATOR, ATTITUDE
9235508-10		STRUT ASSY NLG
93-100-90	5835-01-128-7757	RECORDER
93A100-90	5835-01-128-7757	VOICE RECORDER
93-A100-90	5835-01-128-7757	CVR (COCK-PIT RECORDER)
93-A152-16		CONTROL UNIT VOICE RECORDER
9-464-40 / -62		INDICATOR, FUEL FLOW
9-464-40MOD-B	6680-01-484-0254	INDICATOR, FUEL FLOW
948894-4-1		CONTROL OVERTEMP.
9550616-1LC	1630-01-038-5126	WHEEL LANDING GEAR
9560685-1		BRAKE ASSY
9616-03	6685-00-650-0570	AMPLIFIER, ENGINE
9616-38	6625-00-869-5478	AMPLIFIER, SYNCHRO
9616-48	6625-00-839-8678	AMPLIFIER
965-0412-002	6610-01-101-1913	COMPUTER, AIR DATA



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
965-0476-088	6340-01-101-1888	COMPUTER WARNING GPWS
976J215-1	6110-00-689-8602	CONTROL GENERATOR
976J215-2	6110-00-689-9842	PANEL PROTECTION
976J480-1	6115-00-136-6617	GENERATOR
976J480-2	6115-00-997-6517	GENERATOR AC
979470-2-1		SHUTOFF VALVE
980-4120-RXUS		SSUFDR
9817-01	6685-00-642-0533	INDICATOR, TEMPERATURE
9819-08	6610-00-058-9527	ATTITUDE IND
98G41-1	5930-00-463-7442	SWITCH,PRESSURE
98G41-2B		BODY
98G-45		CAP
9900-39		REGULATOR
9A022-1	4810-00-013-7091	VALVE PRESSURE
9A100	6620-01-206-5748	INDICATOR
9A1100	6620-01-206-5748	TORQUEMETER IND
9A2090	6620-01-437-3144	TORQUEMETER INDICATOR
9A2100	6620-01-264-8685	TORQUEMETER IND
9A360	6680-00-900-8356	INDICATOR, LIQUID QUANTITY
9A360HEA	6680-00-937-0429	INDICATOR LIQUID QUANTITY
9A375	5585-00-148-8247	TEMPERATURE INDICATOR
9A-375	6685-00-148-8247	TEMPERATURE INDICATOR
A100		VOICE RECORDER UNIT
A13A	6645-00-403-4947	CLOCK 8 DAY
A13A-2	6645-01-235-9465	CLOCK,PANEL
A1600	6610-00-739-3046	INDICATOR, TURN & SLIP
A1605	6610-00-625-6035	INDICATOR, TURN & SLIP
A25363-10-002	6610-00-531-4582	INDICATOR, VERTICAL VELOCITY
A25363-10-003	6610-00-531-4582	INDICATOR, VERTICAL VELOCITY
A25753-10-001	6610-00-531-4587	INDICATOR, VERTICAL VELOCITY
A40A1750	6110-00-500-0391	VOLT.REG.
A40A1750-2	6110-00-483-9247	REGULATOR VOLTAGE
A451M9A	1680-01-077-3439	LANDING GEAR CONTROL
A487-1		SCREW JACK
A487-2		SCREW JACK
A487-3	1680-00-705-9996	ACTUATOR MECHANICAL
A487-4	1680-00-777-0135	ACTUATOR MECHANICAL
A489-2		GEAR BOX
A489-3		ACTUATOR ELECTROMICHANICAL ROTARY
A489-3/A489-4	1680-00-672-8931	ACTUATOR ELECTRO-MECH
A489-4		ACTUATOR ELECTRO-MECH
A489-5	1680-01-013-3229	ACTUATOR ELECTRIC
A551-1		ACTUATOR
A555-1A	1680-00-822-0170	ACTUATOR,ELECTRO-MECHANICAL,LINEAR
A555-2		ACTUATOR
A555-2A	1680-00-822-0171	ACTUATOR ELECTRO-MECHAN



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
A555-3		ACTUATOR
A555-4		ACTUATOR
A700AQ4		RELAY CURRENT CUT-OUT
A7111D-2	1610-00-482-7947	Blades
A-751NL	5945-00-029-8412	CONTACTOR, POWER
A800530	1680-00-677-6319	EXTINGUISHER SUB ASSY
A800530-1	1680-01-300-5266	EXTINGUISHER FIRE AIRCRAFT
A80-AAU-8/A	6610-00-774-5656	ALTIMETER PRESSURE
A80AAU8A	6610-00-774-5656	ALTIMETER
A-80MA-1	6610-00-691-0874	ALTIMETER, PRESSURE
A846-6	5945-00-628-6484	RELAY HYBRID
AAU-21A	6610-00-168-0797	ENCODER/ALTIMETER
AAU-27/A	6610-00-160-3226	ALTIMETER, PRESSURE
AAU27A	6610-00-468-1958	ALTIMETER, PRESSURE
AAU-31/A	6610-00-110-3368	PRESSURE ALTIMETER
AAU-31/A-1	6610-01-039-5020	ALTIMETER, PRESSURE
AAU-32A	6610-00-134-5625	ALTIMETER
AAU-8/A	6610-00-722-0967	ALTIMETER, PRESSURE
AAU8A	6610-00-722-0967	ALTIMETER PRESSURE
ABU-8A/A	6610-01-391-9062	ACCELEROMETER, MECHANICAL
AC2031-12		FILTER
AC310064		GYROSCOPE VERTICAL
AC410037	6610-01-311-5872	INDICATOR
AC60742		AXLE MAXARET
AE149-016-99	1660-01-130-4645	CONTROL BOX, ELECTRICAL
AEK3B13200	6625-00-229-0582	AMMETER
AEU-13/A	6620-01-172-6946	TORQUEMETER IND.
AF200	6685-00-514-5061	INDICATOR, CABIN ALTITUDE
AF200A	6685-00-514-5061	INDICATOR, CABIN ALTITUDE
AI-803CR	6610-01-461-5251	INDICATOR, ATTITUDE
AL 232AS-PC		AIR SPEED INDICATOR
AM-6639/ALR	5985-01-154-9125	AMPLIFIER DETECTOR
AN3203V30	6625-00-235-4782	VOLTMETER
AN5527-3	6620-00-224-3451	TRANSMITTER, RATIO
AN6012-1A	4820-00-528-3264	VALVE
AN6248-2		HAND PUMP
AN6281-8-10		FUSE HYD.
ANUPM33A	6625-00-539-8587	TEST SET RADAR
AP4V-16-01		E.D.P.
AP4V-18		PUMP
AP4V-18-01		PUMP
AP4V-18-02		PUMP
ARU-14/A	6610-00-854-9166	INDICATOR, ATTITUDE
ARU-4/A	6610-00-585-9160	INDICATOR, ATTITUDE
AT740A	5985-00-673-5831	MODE 'S' ANTENNA
AV 16B1470C		VALVE MOTOR OPERATED FUEL SHUT OFF



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
AV16B1139D		VALVE
AV16B1360C		VALVE
AV16B1361C		VALVE
AV16B1362D		VALVE
AV16B1446C		VALVE
AV16B1451C		VALVE
AV16B1464C	4810-00-627-5271	GATE VALVE
AV16B1467D	2915-00-632-7932	VALVE 1 INCH MOTOR OPERATED FUEL SHUTOFF
AV16B1470C	4810-00-653-7572	GATE VALVE
AV16B1867D	2915-00-632-7932	VALVE FUEL SYSTEM
AV16F1103		HOUSING
AV17B1038D		BUTTERFLY VALVE
AV19E1003-1	4810-01-123-7254	VALVE PRESSURE VENT
AVR743D8	5945-00-729-1244	RELAY UNDER VOLTAGE DC
AVR-743D-8	5945-00-729-1244	RELAY UNDER VOLTAGE DC
AVR869E		PHASE SEQUENCE RELAY
AW1821AC02	6685-00-810-6047	GAGE, HYDRAULIC PRESSURE
AW2017AC01	6685-00-684-1667	GAGE, HYDRAULIC PRESSURE
AW2017AC02	6685-00-972-5920	INDICATOR, BRAKE PRESSURE
AW-2-17-A	6685-00-684-1667	GAGE, PRESSURE
AW-2-17-G	6685-00-684-1667	GAGE, PRESSURE
AW2812AH04	6610-00-798-2241	INDICATOR, AIRSPEED
B0020-14107	6610-00-911-8295	ALTIMETER, PRESSURE
B118-249	6680-00-918-0273	INDICATOR, LIQUID QTY
B-123B	5945-00-675-7413	CONTACTOR, POWER
B123J	5945-00-675-7413	CONTACTOR, ELECTRIC
B-123J	5945-00-675-7413	CONTACTOR, POWER
B123JA	5945-01-250-9675	RELAY,ELECTROMAGNETIC
B-124K	5945-00-675-7412	CONTACTOR, POWER
B15-945-42-05-11N		CLOCK, AIRCRAFT
B1-A	6610-00-526-4718	INDICATOR, ATTITUDE
B44202-10-002	6610-01-091-3701	PRESSURE ALTIMETER
B4515210003	6610-01-038-2081	ALTIMETER, PILOT
B45152-10-003	6610-01-038-2081	ALTIMETER, ENCODING
B45152-10-013	6610-01-477-4148	ALTIMETER
B45152-10-02	6610-01-134-5625	ENCODING ALTIMETER
B4515210103	6610-01-038-2122	ALTIMETER
B45152-10-103	6610-01-038-2122	ALTIMETER, PRESSURE
B-459	5945-01-250-9675	RELAY,ELETROMAGNETIC
B52C22	4810-00-672-1085	VALVE ASSY, WING DUCT P&A
BH187M-4	6685-00-883-4096	INDICATOR
BH187R111	6685-00-573-7407	INDICATOR,TEMPERATURE,SYNCHRO
BTI600-202M	6685-01-356-7401	INDICATOR TEMP
BYLB51044	4810-01-218-2643	VALVE, TEMPERATURE C
BYLB51045	4810-01-219-3417	VALVE TEMP. CONTROL
C12405-00-005	6610-00-073-6828	TRANSMITTER, AIRSPEED



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
C-4808/ARC		SELECTOR ANTENNA
C4808ARC	5985-00-902-9935	SELECTOR,ANTENNA
C52C22	4810-00-670-1111	VALVE BUTTERFLY
C55D	6680-00-790-6839	COUNTER, FUEL FLOW
C-7041		AILERON TRIM TAB ACTUATOR
C7041-1	1860-00-088-6102	ACTUATOR,ELECTRO-MECHANICAL,LINE
C7041-2	1680-00-981-7652	ACTUATOR, ELECTRO-ME
C7088-1A	1680-00-789-9345	WING FLAP GEARBOX
C-823/AIC-10		INTERPHONE CONTROL
C-824A/AIC-10	5831-00-519-5883	INTERCOM CONTROL PANEL
C-826/AIC-10		INTERCOM CONTROL PANEL
CA59100-0011		ACTUATOR
CA75810-0001	3010-33-001-8008	ACTUATOR,HYDRAULIC
CA84500-0010	3010-33-001-9625	ACTUATOR, HYDRAULIC
CB-2100-T4	6605-00-663-5637	COMPASS, MAGNETIC
CG12112	5930-00-642-9386	SWITCH, PRESSURE
CG12313	5930-00-965-7111	SWITCH PRESSURE
CSV4092-3	6110-01-344-0377	GENERATOR GONCORL UNIT
CYLB51055		CHECK VALVE
CYLZ4271-2	1660-00-697-0846	CONTROL BOX, ELECTRICAL
D1093-02-1	6615-00-967-0480	SYNCHRONIZER, ELECTRICAL
D22061-04-004	6610-00-649-8380	ALTIMETER, PRESSURE
D22061-04-010	6610-00-649-8380	ALTIMETER, PRESSURE
D25-05		REGULATOR
D52C22	4810-00-601-3146	WING ISOLATION VALVE
DF-206	6220-01-466-8702	PANEL, INDICATING, LIGHT
DL1326M11		ACTUATOR,ELECTRO-MECHANICAL,LINE
DRA45C8		SWITCH, AIR SPEED
DSL-50	6680-00-828-7610	INDICATOR LOX
DST29-1	6685-00-066-4581	INDICATOR, TEMPERATURE
DST29-2	6685-00-066-4581	INDICATOR TEMPEARTURE
DST-29-2		THERMO TEMP. IND.
DST29-3		TEMP TURBINE INDICATOR
DT-310/AJN	6605-00-632-0667	TRANSMITTER, INDUCTION
DYL26263		VALVE
DYLM43403-2		VALVE
DYLZ3990		VALVE
DYLZ3990-1		VALVE
DYLZ3990-2		VALVE
DYLZ3990-3	1660-00-690-6150	VALVE ENVIRONMENTAL CONTROL
DYLZ-3990-3		VALVE
DYLZ3990A		VALVE
DYLZ3991		VALVE
DYLZ3991-1		VALVE
DYLZ3991-2	4810-05-224-595	VALVE ASSEMBLY
DYLZ3991-3	4810-00-682-5374	VALVE CONTROL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
DYLZ-3991-3		VALVE
DYLZ3991A		VALVE
E0724104003	6610-00-585-1524	INDICATOR, TRUE AIR SPD
E07241-04003	6610-00-585-1524	AIRSPED INDICATOR
E07241-04-003	6610-00-585-1524	INDICATOR, TRUE AIR SPEED
E07241-10-003	6610-00-834-0713	INDICATOR, AIRSPEED
E07241-10-004	6610-01-393-1139	INDICATOR, AIRSPEED
E07243-10-002	6610-00-834-0713	INDICATOR, AIRSPEED
E2206104016		ALTIMETER
E22061-04-016		PRESSURE ALTIMETER
E-384	5945-00-628-6484	RELAY,HYBRID
E6011M13-13	6105-00-698-5927	MOTOR DIRECT CURRENT
E97241-04-003	6680-00-740-7044	INDICATOR
EA100ANH144	6680-00-580-9557	INDICATOR LIQUID
EA100ANH-172	6680-01-394-2556	INDICATOR, LIQUID QTY
EA1045-037-2	4320-00-072-2291	PUMP,AXIAL PISTONS
EA1045-037-2B	4320-00-949-6842	PUMP, HYD ELECT MOTOR
EA1045-837-2B		ELECTRIC MOTOR DRIVE
EA1065AW2315		TRANSMITTER, LIQUID QUANTITY
EA1065AW-2315		FUEL QUANTITY TANK UNIT
EA1205		DUAL RUDDER BOOSTER ACT
EA1205-1		DUAL RUDDER BOOSTER ACT
EA1261-1		CYLINDER
EA1261-2		CYLINDER
EA326-15	6610-00-808-7038	INDICATOR, POSITION
EA326-15A	6610-00-808-7038	INDICATOR, POSITION
EA326-2	6610-00-557-0894	INDICATOR, POSITION
EA326-8	6610-00-580-9690	INDICATOR, POSITION
EA327-3	6610-00-531-5417	INDICATOR, POSITION
EA573A1	6610-00-530-0961	TRANSMITTER, FLAP POSITION
EFU-4/A	6620-00-621-2903	INDICATOR, RATE OF FUEL FLOW
EFU-5/A	6620-00-621-2904	INDICATOR, RATE OF FUEL FLOW
EHU11AA	6685-00-580-4732	EGT, INDICATOR
EHU-15/A	6685-00-897-8400	INDICATOR, TEMPERATURE
EHU-15A/A	6685-00-945-4979	INDICATOR, TEMPERATURE
EHU15AA	6685-00-945-4979	INDICATOR TEMPERATURE THEROCOUPLER
EHU-9/A	6685-00-226-6612	INDICATOR
EKCC18043	6685-00-692-8341	INDICATOR, TEMPERATURE
EKCC-18043	6685-00-692-8341	INDICATOR
EN30-2217-1	6220-01-426-4360	LIGHT, NAVIGATIONAL
F60W0232		VALVE, FUEL
F60W0232M1	2915-00-574-3227	VALVE,FLOAT,AIRCRAFT FUEL TANK
F60W0233		VALVE
F60W0233M1	2915-00-581-0477	VALVE INBOARD FUEL
FG450A52	6680-01-059-3386	COMPENSATOR FUEL
FS20	6105-01-108-2427	MOTOR DIRECT CURRENT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
FS-9506B-4	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
G-10	6685-00-005-9024	INDICATOR, OUTSIDE AIR TEMPERATURE
G5400-1	6220-00-299-4621	LANDING LIGHT ASSY.
G-5400-1		LANDING LIGHT
G5400-3		LANDING LIGHT ASSY
G-5400-3		LANDING LIGHT
G5400-5	6620-00-893-8777	LIGHT, LANDING
G-5400-6		LANDING LIGHT
G6965		LIGHT
G6965-22	6220-00-346-6820	LIGHT, ROTATING BEACON
G6965-6		LIGHT
G6965-8		LIGHT
G-6965-8	6220-00-421-9109	WARNING NAV LIGHT
G7406-10		VHF COMMUNICATION CONTROL PANEL
G7418-13		CONTROL PANEL VHL
GEU7A	6680-00-585-1503	TACHOMETER GENERATOR
GG2479AB01	6615-00-137-6038	GYROSCOPE, RATE
GG2-79	6615-00-137-6038	GYROSCOPE, RATE
GMU-11/A	6680-00-828-6559	INDICATOR
GMU-28	6680-00-105-9527	INDICATOR, LIQUID QUANTITY
GMU-28/A	6680-00-993-3435	INDICATOR, LIQUID QUANTITY
GMU-28A/A	6680-00-937-0429	INDICATOR, LIQUID QUANTITY
GP20-15	6620-01-328-6940	GAUGE, PRESSURE DIAL
GPS MAP 295		GPS MAP 295
GTC85-71A		GAS TURBINE COMPRESSOR
GYLC4369		ACTUATOR
GYLC4369-1		ACTUATOR
GYLC9102		ACTUATOR
GYLC9103		ACTUATOR
H60G0398		VALVE
HIR01987-033-1		NLG STRUT ASSY
HP367100		VALVE
HP558100-1		VALVE
ID-250A/ARN	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
ID-525/ARN	6610-00-851-8727	INDICATOR, ILS, RUNWAY
ID-663/U	5826-00-882-1203	INDICATOR, BEARING DISTANCE
JG3B9	6680-00-526-8284	INDICATOR, LIQUID QUANTITY
JG40242-7	6680-00-580-1247	INDICATOR LIQUID WING
JG402A2	6680-00-580-1247	FUEL QTY IND
JG402A3	6680-00-580-1246	INDICATOR, LIQUID QU
JG402A32	6680-00-866-5116	INDICATOR, LIQUID QUANTITY
JG402A4	6680-00-580-1248	FUEL QTY IND
JG402A52	6680-01-056-1779	FUEL QTY IND
JG402A53	6680-01-060-5228	FUEL QTY IND
JG402A-53	6680-01-060-5228	FUEL QTY IND
JG402A54	6680-01-058-5859	FUEL QTY IND



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
JG402A-54	6680-01-058-5859	INDICATOR
JG402A55	6680-01-058-5860	FUEL QTY IND
JG412A1	6680-00-580-1249	INDICATOR, FUEL QUANTITY
JG412A10	6680-00-849-7809	INDICATOR, FUEL QUANTITY
JG412A11	6680-00-865-7930	INDICATOR, FUEL QUANTITY
JG412A2	6680-00-585-5859	INDICATOR, FUEL QUANTITY
JG412A3		FUEL QTY IND - ROUTINE
JG412A4	6680-00-585-8600	INDICATOR, LIQUID QUANTITY
JG412A-52	6680-01-063-0597	INDICATOR LIQUID QTY
JG412A53		FUEL QTY IND
JG412A-53	6680-01-058-5861	INDICATOR LIQUID QTY
JG412A-54	6680-01-058-5862	INDICATOR LIQUID QTY
JG412A-55	6680-01-342-7698	INDICATOR LIQUID QTY
JG412A56	6680-01-058-5864	FUEL QTY IND
JG412A-56	6680-01-058-5864	INDICATOR LIQUID QTY
JG7044A37	6615-00-556-8024	CAGEABLE VERTICAL GYRO
K-3	6610-01-067-0228	INDICATOR, AIRSPEED
KTD0701K	6680-00-452-6315	INDICATOR, TACHOMETER
L10-107		ACTUATOR
L16-107		ACTUATOR ELECTRO-MECH
L16-8		ACTUATOR
L16-8-1	1680-00-720-5810	ACTUATOR ELECTRO-MECH LINEAR
L16-8-2		ACTUATOR
L16-8-3	1680-00-720-5810	ACTUATOR ELECTRO-MECH
L16-8-5	1680-01-378-1631	ACTUATOR ELECTRO-ME
L8602772-1	2935-01-440-9157	COOLER, LUBRICATING
LE452-0032	5930-01-413-8954	SWITCH ASSEMBLY
LE452-0038-0001	5930-01-436-0623	SWITCH ASSEMBLY
LO3P1	5950-00-880-6005	TRANSFORMER POWER AUTO TRANSFORMER
M1-A	6610-00-585-1524	INDICATOR, AIRSPEED
M-1A	6610-00-557-3096	INDICATOR, AIRSPEED
M2901A-1B	4140-00-814-5758	FAN VANE AXIAL
M3500-5	6610-00-912-3572	INDICATOR, TURN & SLIP
M5921A1B	4140-00-717-5277	FAN, VANE AXIAL
M5921A-1B	4140-00-717-5277	FAN VANE AXIAL
M9201A1B		FAN ASSY
M9201A2A1		FAN ASSY
MA-1	6610-00-684-1666	ACCELEROMETER, MECHANICAL
MA11A1024B	4810-01-237-2269	ACTUATOR
MA-7	6620-01-038-5769	INDICATOR, RATE OF FUEL FLOW
MA-7/A	6620-01-391-2998	INDICATOR, RATE OF FUEL FLOW
MA-8	6620-00-551-1270	INDICATOR, RATE OF FUEL FLOW
MB-1		TRANSMITTER, RATE OF FUEL FLOW
MB-6	6620-00-553-8892	GENERATOR, TACHOMETER
MC-1	6615-00-618-9297	GYROSCOPE, RATE
MD-1	6615-00-973-2218	GYROSCOPE, DISPLACEMENT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
MD-2	6615-01-065-7226	GYROSCOPE, DISPLACEMENT
MF-2	6665-01-080-6508	INDICATOR
MF30-3913-30ZE5	1650-00-204-1703	MOTOR, HYDRAULIC
MF30-3913-30ZE-5	1650-00-204-1703	MOTOR, HYD
MF93911-30ZE	4320-01-224-9869	MOTOR, HYDRAULIC WING FLAP
MF9-3911-30Z-S481	1650-00-815-9387	MOTOR HYDRAULIC
MGE23-340	6125-01-101-3723	INVERTER
MGE23-400	6125-00-020-3217	INVERTER
MGE23-400A	6125-00-020-3217	INVERTER
MIL-C-27336	1660-00-768-5256	CONVERTER LIQUID OXYGEN
MILI5356	6610-00-663-8723	INDICATOR AIRSPEED
MILT38394	6620-00-901-7848	TRANSMITTER, PRESSURE
MJ-1	6685-00-087-8229	TRANSMITTER, PRESSURE
MM-4	6610-00-557-3030	INDICATOR, ATTITUDE
MNI300	6610-00-543-1402	INDICATOR, ILS, RUNWAY
MPEV3-032-2	4320-00-174-5811	HYD AUX ELEC PUMP
MPEV3-032-2A	4320-00-174-5811	HYD AUX ELEC PUMP
MS17983-2	6605-00-551-8187	COMPASS
MS24140-D1		RELAY
MS24182-D1		RELAY
MS24332-1	6625-00-538-9683	VOLTMETER
MS24332M1		VOLTMETER
MS24478-2	6685-00-557-5317	INDICATOR, GAGE PRESSURE
MS24569-1	6685-00-183-0351	INDICATOR, TEMPERATURE
MS25025-1	6625-00-544-5899	INDICATOR, LOADMETER
MS25038-4	6620-00-553-8892	TACH GENERATOR
MS28000-1	6620-00-515-4541	INDICATOR, TACHOMETER
MS28005		TRANSMITTER
MS28005-1		TRANSMITTER
MS28005-3		PRESSURE TRANSMITTER
MS28005-4	6620-00-557-0385	TRANSMITTER, PRESSURE
MS28005-5	6685-00-526-7881	TRANSMITTER, PRESSURE
MS28005-8	6685-00-526-7864	TRANSMITTER, PRESSURE
MS28005-8T		TRANSMITTER, PRESSURE
MS28009-1	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
MS28009-2	6685-00-514-5327	INDICATOR, TEMPERATURE
MS28009-4	6685-00-514-5327	INDICATOR, TEMPERATURE
MS28010-5	6685-00-557-0215	INDICATOR PRESS
MS28023-1	6610-00-515-4600	INDICATOR, POSITION
MS28027-1	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
MS28036-1	6610-01-393-1139	INDICATOR, AIRSPEED
MS28041-1A	6610-00-912-3572	INDICATOR, TURN & SLIP
MS28046-T1	6610-00-899-7445	INDICATOR, AIRSPEED
MS28049-1	6610-00-530-0028	INDICATOR, VERTICAL SPEED
MS28054-2	6620-00-551-3825	GENERATOR, TACHOMETER
MS28075-1	6610-00-473-5046	INDICATOR, VERTICAL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
MS28075-1B	6610-01-346-2795	INDICATOR, VERTICAL
MS28700-1	1650-00-640-8485	ACCUMULATOR, HYD
MS28700-2	1650-00-640-8491	ACCUMULATOR
MS28-700-2		HYDRAULIC ACCUMULATOR
MS28700-4		ACCUMULATOR
MS28700-5		ACCUMULATOR
MS28720-12		FILTER
MS28720-6		FILTER
MU-1	6620-00-557-3023	TACHOMETER
N1335C	5821-01-384-4435	DECODER,AUDIO FREQUENCY
N400-4B3		MOTOR
N400-4B4		MOTOR
NA135		DECODER AUDIO FREQUENCY
PV3-075	4320-00-404-1977	PUMP AXIAL VICKERS
PV3-075-4	4320-00-404-1977	PUMP
PYLB51239-1	4810-01-237-5974	VALVE,SOLENOID
PYLB51239-2	4810-01-237-5974	VALVE,SOLENOID
R5170M34-2		ACTUATOR
R5170M34-3	1680-00-474-3300	ACTUATOR GTC DOOR
R5170M34-4	1680-00-426-5616	ACTUATOR GAS TURBINE COMP
R73-2008-42-1		TENSION REGULATOR
R84-1001-48-4A		REGULATOR CABLE TENSION
RC-60	6610-00-530-0028	INDICATOR, VERTICAL SPEED
RC-60MS	6610-00-291-7040	INDICATOR, VERTICAL SPEED
RC-60-MS		RATE OF CLIMB INDICATOR
RC-60MS-10-3	6610-00-951-4451	INDICATOR, VERTICAL SPEED
RC-60-MS-AAU-9/A	6610-00-804-6312	INDICATOR, RATE OF CLIMB
RCS-60-1L	6610-00-473-5046	INDICATOR, VERTICAL
RD-301A		RADAR TEST SET COLOR BEN
RG14D3		TOTALIZER
RG14D7	6680-00-860-6390	TOTALIZER
RG15A1	6680-00-310-3305	TOTALIZER, FUEL QUANTITY
RG-3-11		RATE OF TURN SENSOR
RG-9680C	4310-00-568-1532	COMPRESSOR WITH ROTARY
RR11620-1	2915-00-983-1001	PUMP SUBMERGED C130
RR11620-3	2915-00-983-1001	FUEL BOOST PUMP
RR11640-1	2915-01-506-2354	Pump, Centrifugal Fuel Booster
RR11640A1	2915-01-196-4362	PUMP SUBMERGED AIRCRAFT
RR11640A3		PUMP, SUBMERGED AIRCRAFT
RR11640-D1	2915-01-196-4362	PUMP, SUB
RR52780A	2915-00-382-9088	PUMP,BOOST
RYLC51046	1680-01-222-3117	ACUTATOR
RYLC51047		ACTUATOR
S369-100		ACCUMULATOR
S369-50		ACCUMULATOR
S462-25		ACCUMULATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
S462-50		ACCUMULATOR
S463-100		ACCUMULATOR
S463-50		ACCUMULATOR
S477-100		ACCUMULATOR
S477-200		ACCUMULATOR
S477-50		ACCUMULATOR
S512-25		ACCUMULATOR
S-512-50-2	1650-00-721-6415	ACCUMULATOR
S513-100		ACCUMULATOR
S513-100-2T		ACCUMULATOR
S513-200		ACCUMULATOR
S513-200-2T		ACCUMULATOR
S513-50		ACCUMULATOR
S513-50-2T		ACCUMULATOR
S618-A		ACCUMULATOR
S65-5366-2L		MODE 'C' ANTENNA
S65-8280-10		VHF ANTENNA LOWER
SBK-8A/24G-1A	6615-00-994-2152	GYROSCOPE, DISPLACEMENT
SK1093	6615-00-967-0480	SYNCHRONIZER, ELECTRICAL
SK-40LC	6610-01-096-4601	INDICATOR, AIRSPEED
SK40LC1	6610-01-109-5105	Max Allowable Airspeed Ind
SLZ3501		TRANSMITTER, ANGLE OF ATTACK
SPL5568-3	3040-00-566-0336	ACTUATOR,MECHANICAL,LINEAR
SR151A	6685-00-515-3996	PRESSURE INDICATOR
SR152A	6685-00-526-5625	PRESSURE INDICATOR
SR-3A	6620-00-557-0362	INDICATOR
SR-3C	6620-00-060-0549	INDICATOR
SR-4A	6620-00-557-0350	INDICATOR
SR-4B	6620-00-557-0363	INDICATOR
SR-5A	6620-00-526-6120	INDICATOR, PRESSURE
SR-6A	6620-00-514-5334	INDICATOR, PRESSURE
SR-7A	6620-00-557-0214	INDICATOR, PRESSURE
SR-8B	6620-00-557-0816	INDICATOR, PRESSURE
SR-9A	6620-00-526-8272	INDICATOR, PRESSURE
SRA-14A	6620-00-526-8273	INDICATOR, TORQUEMETER
SRA-14E	6620-00-581-2278	INDICATOR, TORQUEMETER
SRD-4A	6685-00-678-2948	INDICATOR, DUAL OIL PRESSURE
SRD4B	6685-00-678-2948	INDICATOR PRESSURE
SRD-4B	6685-00-678-2948	DUAL OIL PRESS IND
SRD-4G	6620-00-811-7614	INDICATOR, DUAL OIL PRESSURE
SRD-7C	6685-00-531-2741	INDICATOR, DUAL HYDRAULIC PRESSURE
SSD12042A		Altitude Encoding Digitizer
SSD120-42A		ALTIMETER ENCODE
ST104A	6620-00-901-7848	TRANSMITTER PRESSURE
ST-104A		OIL PRESS TRANS
ST-104A1	6685-00-821-7351	TRANSMITTER, PRESSURE



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
ST-207A	6685-00-087-8229	TRANSMITTER, PRESSURE
ST-6B	6620-00-553-8988	INDICATOR, PRESSURE
ST-6C	6685-00-756-5671	TRANSMITTER, PRESSURE
ST-7C	6685-00-526-7864	TRANSMITTER, PRESSURE
ST-7D		HYD PRESS TRANS
STU-1/A		STARTER
SYLZ50191-000	1660-00-147-1009	CONTROL BOX, ELECTRICAL
SYLZ50212	1660-00-130-0048	CONTROL BOX, ELECTRICAL
SYLZ50683-1	1660-01-126-1784	CONTROL BOX, ELECTRICAL
SYLZ50684	1660-01-121-7386	CONTROL TEMP
SYLZ50685	1660-01-021-4981	CONTROL BOX, ELECTRICAL
T1580S3A	5342-00-881-1719	CLAMP ASSY - ENG TAIL PIPE
TED9-464-40		INDICATOR , FUEL
TG255-007	6680-00-923-8466	TACH GENERATOR
TP25-2A		AIR TURBINE DRIVE
TP25-2B		AIR TURBINE DRIVE
TP25-2C		AIR TURBINE DRIVE
TR-349/A	6685-01-373-2860	TRANSMITTER, PRESSURE
TRK-56/A27J-1	6685-00-526-7864	TRANSMITTER, PRESSURE
TRK56A27J1	6685-00-990-5746	TRANSMITTER, PRESSURE
TS5106UPX	6625-01-156-6940	TEST SET
TS-585/U	6625-00-151-4230	WATTMETER
UA524240-1	2915-00-789-1102	FUEL HEATER
UA534149-19	1650-01-065-3500	COOLER, HYDRAULIC
UA534149-21	1650-01-227-5464	COOLER, HYDRAULIC
UA538795-3	1650-01-228-8118	COOLER, HYDRAULIC OIL
UPX-27N	5895-01-206-7147	INTERROGATOR SET
V3900-11		VALVE SOLENOID
W1206-2		POWER SUPPLY
W33-7545-10	6645-00-089-7903	CLOCK AIRCRAFT
WJ2854-15A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
WJ2854-31A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
X702-102		FAN
XW20058M1		WIPER MOTOR
XW20058-M1		WIPER MOTOR