

Remote Transmitter Matrix

LiftMaster Remotes

Frequency 390Mhtz

61LM (1 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 390
Receiver: 412 HM or 450 (390)

62LM (2 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 390
Receiver: 412 HM or 450 (390)

81LM (1 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 390
Receiver: 412 HM

972LM (2 Button)

Type: (Right) Dip Switch (Left) Cloned
Cloned By: 61 LM
Frequency: 390
Receiver: 412LM

Frequency 315Mhtz

361LM (1 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 315
Receiver: 312 HM or 450

362LM (2 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 315
Receiver: 312 HM or 450

371LM (1 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 315
Receiver: 312 HM or 450

372LM (2 Button)

Type: (1) Rolling & (1) Cloned
Cloned By: 361LM
Frequency: 315
Receiver: 312 HM or 450

375LM (2 Button)

Type: **Universal Remote**
Cloned By: N/A
Frequency: Various
Receiver: Various

*****This is a universal remote that can be programmed with almost any other remote. See specific instructions.

Multi Code Remotes

Mini Multi Code 3070 (1 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 310
Receiver: 1090 or 109950

Mini Multi Code 3083 (2 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 310
Receiver: 1090 or 109950

Multi Code 3089 (1 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 310
Receiver: 1090 or 109950

Multi Code 4120 (2 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 310
Receiver: 1090 or 109950

DELTA 3 REMOTES

Delta 3 (1-Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 310
Receiver: DTC or GRD

Delta 3 (2 Button)

Type: Dip Switch
Cloned By: N/A
Frequency: 310
Receiver: DTC or GRD