

DB-100 Digital Desktop Radio Kit


User Manual Supplement

Introduction

The Cane Wireless DB-100 digital desktop radio kit is designed around the Motorola DLR™ series digital radio and is compatible with both the Motorola DLR™ and DTR™ series radios.

NOTE: This user manual is intended to be used as a supplement to the Motorola DLR™ radio user manual. For radio operational, programming, charging and safety instructions please refer to the Motorola DLR™ radio user manual.

Radio Overview



1. Battery charge status indicator LED
2. Channel / Menu button
3. Volume down / - button
4. Volume up / + button
5. Power Button
6. Push-To-Talk (PTT) button
7. TX/RX indicator LED
8. Audio accessory connector
9. Breakaway mounting tabs

Battery Installation

The DB-100 desktop radio requires the included LiION battery to be installed and fully charged prior to initial use. To install the battery, remove the battery door at the back of the unit by squeezing then pulling up on the latching tab. Insert the battery making sure the contacts are aligned and the pull tab to remove the battery is accessible.

For optimal operation, replace the battery every two years or if a battery or charge fault is noted.

Programming

To customize the radio settings you will need to enter the radio programming mode. Activate and hold the “Volume up/+” and “PTT” buttons simultaneously while powering “ON” the radio. The radio will confirm that it has entered “Programming Mode” via voice announcement. To change the radio default settings, momentarily activate the “Channel/Menu” button and follow the voice prompts. Press and hold the “PTT” button or power “OFF” the radio to exit Programming Mode

You can also program the radio with the Motorola DLR™ radio Computer Programming Software (CPS). The programming cable (Motorola P/N: HKKN4027A) is required to connect your computer to the micro-USB port on the DB-100 when using the CPS tool. Both are available on our website. See the Motorola DLR™ radio user guide for additional programming instructions.

Limited Warranty

This product is warranted against manufacturing and material defects for a period of one year after purchase. Should this product fail to perform normally within the warranty period, it will be replaced or repaired, at the sole discretion of the manufacturer, with the same or functionally equivalent product. This warranty does not apply if the product fails due to damage from shipment, handling, storage, accident, abuse, or if it has been used or maintained in a manner not conforming to product manual instructions, has been modified in any way, or has had any serial number removed or defaced. The maximum liability to the manufacturer under this warranty is limited to the purchase price of the product covered by the warranty.

Cane Wireless Inc.
4301 N Federal Highway, Ste 2A
Pompano Beach, FL 33064
www.canewireless.com