

Cleaning Guidelines

Although DekPro Prestige Railing products are designed to require a minimal amount of maintenance, keeping your railing looking its best is no different than any other item around your home... an occasional cleaning goes a long way. Over time, any painted surface exposed to the elements will start to show signs of weathering such as a slight color change or a dulling of the finish. This is especially true with products exposed to salt, which can be extremely corrosive as any car owner who's experienced winter weather can attest to!

DekPro Prestige Railing Powercoat™ finish offers you some of the best protection available against these elements, but a simple, regular cleaning is necessary to maintain the appearance.

We recommend an occasional wash using warm water and a non-abrasive, pH neutral detergent applied with a soft cloth, sponge or soft bristle brush. Popular household cleaners like *Windex®*, *Fantastik®* and *Simple Green®* are examples of safe cleaners to use. The surface should be thoroughly rinsed after cleaning to remove residue. The use of a pressure washer is not suggested. <u>Do not</u> use solvent-based products to clean your railing.

Although the frequency of cleaning depends on environment and location, in cases of salt water exposure, DekPro Prestige Railing requires these guidelines be followed and recorded every 3-4 months in order to process a warranty claim:

Date of Cleaning	Cleaning Method	Brand of Cleaner
		-
		·