


TCS Hikvision NVR

User Manual

How to Use NVR

Playback / Export to USB

Menu > Playback



1. [✓] Checkmark camera(s) in upper right to select for playback.
2. Click on Month-Day in calendar on lower right.
3. Click Yellow "Play" button lower centre to play timeline.
4. Click on timeline to jump to a point in time of recording (thin yellow or blue bars indicate recordings exist at that time).
5. Click Start/End Clipping button to mark start and end of clip to mark for export.

6. Plug in USB memory stick into front of NVR.
7. Click “gear” button (File Management) to see list of clips you made.
8. Click Export All button. You should now see the files/folders (if any) of the USB stick.
9. Now there’s another Export button so click it and wait until progress bar finishes.
10. You can now remove the USB stick and send it to whomever needs the exported video footage.

File Management / Export to USB


Menu > File Management > Record

This is an alternative method of selecting and exporting footage.



Choose Start and End Times.
Click Search (button).

Click List (tab).



Click a row to select > Click yellow Play button on right side to review clip.
Click Lock/Unlock icon to lock a clip so it's marked for later export.
Continue to find and lock all clips needed for saving to USB drive.
Now [✓] checkmark all clips you locked and click Export (button).
USB Flash Disk 1-1 should be shown next to Device Name.
Click New Folder (button) > Give it a name that describes these clips.
Double-click the new folder you created to move inside it.
Click Export (button).

If you leave File Management and return later, you can find all locked clips by:
Menu > File Management > Record
Set File Type (dropdown) > Locked
Click Search (button)

Reboot

Menu > System Maintenance
Red button icon lower right > Reboot

[END OF "USER MANUAL"]