Hobby Stock

Weight classes – 5,500 / 6,500 / 7,500 / 8,500

50 Years Old and Older - ONLY

Class Rules:

- 6 MPH speed limit
- RPM limit (10% over stock)
- One fuel only
- Must have stock block, crankcase, head, manifolds, injection pump for that model tractor.
- No cut or grooved tires.
- No aluminum parts, front aluminum wheels allowed.
- No turbochargers unless factory equipped.
- No Injectables
- 18.4x38 Max tire size

Safety Equipment:

- Wheelie bars Optional but recommended.
- Any type of safety equipment is recommended (Not required at this time)

General Rules:

- 1. Each tractor may be entered in (2 classes only) Plus King of the Hill.
- 2. Drivers must be 18 years old or 16 with parent's written consent.
- 3. Driver must be present at the Driver's Meeting.
- 4. Tractor may be 100 pounds max over posted class weight with driver.
- 5. No pressurized fuel, nitrous oxide or other oxidizing agents allowed.
- 6. All engine radiator fans must be properly shrouded. All clutches, pressure plates, fly wheels and drive train components must have 360 degree shroud of 3/16 inch or greater metal material.
- 7. Minimum drawbar length 18 inches from center of rear axle to point of hook, and may not pull from two or three-point hitching mechanisms.
- 8. The drawbar is to be stationary in all directions, and not to exceed 20" from top of drawbar.
- 9. No front weight frame or weights may extend more than 11' from the center of the rear axle.
- 10. All weights must be safely secured to the tractor; Rear weight must not interfere with hooking to the sled. If anything falls off during your pull, you will be disqualified.
- 11. Just before pulling, the puller will be weighed and must be on weight and move directly to staging.
- 12. Puller must operate in a safe manner at all times; Operators must remain seated during the pull with at least one hand on the steering wheel.
- 13. Must be in neutral when hooked and unhooked.
- 14. All pulls must start from a tight hitch no jerking permitted.
- 15. Driver is allowed one restart before 100 feet.
- 16. Tractor and skid must remain within boundaries of the contest course during the pull, or disqualified.
- 17. Driver must stop immediately upon signal from judge; Pull is over when forward motion stops
- 18. Failure to allow inspection by judges will result in disqualification.
- 19. Promoters reserve the right to refuse any entry.
- 20. Contest to be governed by judges with all decisions final. Judges have the right to stop and disqualify any tractor or truck if it is not being operated in a manner as would be considered safe.
- 21. NO ALCOHOL IN THE PIT AREA.