



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
025-230-315	HMEC 25-KAP	BOOMSET
025-230-316	HMEC 25-KAP-1	BOOMSET
025-230-325	HMEC 25-CAP	BOOMSET
05939-10	S283N702-10	FLUORESCENT LAMP BALLAST
05939-103	S283N702-103	FLUORESCENT LAMP BALLAST
05939-104	S283N702-104	FLUORESCENT LAMP BALLAST
05939-105	S283N702-105	FLUORESCENT LAMP BALLAST
05939-107	S283N702-107	FLUORESCENT LAMP BALLAST
05939-108	S283N702-108	FLUORESCENT LAMP BALLAST
05939-109	S283N702-109	FLUORESCENT LAMP BALLAST
05939-110	S283N702-110	FLUORESCENT LAMP BALLAST
05939-113	S283N702-113	FLUORESCENT LAMP BALLAST
05939-114	S283N702-114	FLUORESCENT LAMP BALLAST
05939-115	S283N702-115	FLUORESCENT LAMP BALLAST
05939-116	S283N702-116	FLUORESCENT LAMP BALLAST
05939-13	S283N702-13	FLUORESCENT LAMP BALLAST
05939-14	S283N702-14	FLUORESCENT LAMP BALLAST
05939-15	S283N702-15	FLUORESCENT LAMP BALLAST
05939-16	S283N702-16	FLUORESCENT LAMP BALLAST
05939-3	S283N702-3	FLUORESCENT LAMP BALLAST
05939-4	S283N702-4	FLUORESCENT LAMP BALLAST
05939-5	S283N702-5	FLUORESCENT LAMP BALLAST
05939-7	S283N702-7	FLUORESCENT LAMP BALLAST
05939-8	S283N702-8	FLUORESCENT LAMP BALLAST
05939-9	S283N702-9	FLUORESCENT LAMP BALLAST
065-50001-0100		COMMAND SENSOR UNIT
065-50001-0200		COMMAND SENSOR UNIT
066-50001-0100		COMMAND SENSOR UNIT
066-50001-0200		COMMAND SENSOR UNIT
071-01477-0000	CTA-81A	CONTROL UNIT
071-01477-0001	CTA-81A	CONTROL UNIT
071-01477-0002	CTA-81A	CONTROL UNIT
071-01477-0003	CTA-81A	CONTROL UNIT
071-01477-0004	CTA-81A	CONTROL UNIT
071-01477-0005	CTA-81A	CONTROL UNIT
071-01477-0006	CTA-81A	CONTROL UNIT
071-01477-0007	CTA-81A	CONTROL UNIT
071-01477-0008	CTA-81A	CONTROL UNIT
071-01477-0009	CTA-81A	CONTROL UNIT
071-01477-0010	CTA-81A	CONTROL UNIT
071-01477-0011	CTA-81A	CONTROL UNIT
071-01477-0012	CTA-81A	CONTROL UNIT
071-01477-0013	CTA-81A	CONTROL UNIT
071-01477-0014	CTA-81A	CONTROL UNIT
071-01477-0015	CTA-81A	CONTROL UNIT
071-01477-0016	CTA-81A	CONTROL UNIT
071-01477-0017	CTA-81A	CONTROL UNIT
071-01477-0018	CTA-81A	CONTROL UNIT



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
071-01477-0019	CTA-81A	CONTROL UNIT
071-01477-0020	CTA-81A	CONTROL UNIT
071-01477-0021	CTA-81A	CONTROL UNIT
071-01477-0022	CTA-81A	CONTROL UNIT
071-01477-0023	CTA-81A	CONTROL UNIT
071-01477-0024	CTA-81A	CONTROL UNIT
071-01477-0025	CTA-81A	CONTROL UNIT
071-01477-0026	CTA-81A	CONTROL UNIT
071-01477-0027	CTA-81A	CONTROL UNIT
071-01477-0028	CTA-81A	CONTROL UNIT
071-01477-0029	CTA-81A	CONTROL UNIT
071-01477-0030	CTA-81A	CONTROL UNIT
071-01477-0036	CTA-81A	CONTROL UNIT
071-01477-0050	CTA-81A	CONTROL UNIT
071-01477-0051	CTA-81A	CONTROL UNIT
071-01477-0052	CTA-81A	CONTROL UNIT
071-01477-0053	CTA-81A	CONTROL UNIT
071-01477-0054	CTA-81A	CONTROL UNIT
071-01477-0055	CTA-81A	CONTROL UNIT
071-01477-0056	CTA-81A	CONTROL UNIT
071-01477-0057	CTA-81A	CONTROL UNIT
071-01477-0058	CTA-81A	CONTROL UNIT
071-01477-0059	CTA-81A	CONTROL UNIT
071-01477-0060	CTA-81A	CONTROL UNIT
071-01477-0061	CTA-81A	CONTROL UNIT
071-01477-0062	CTA-81A	CONTROL UNIT
071-01477-0063	CTA-81A	CONTROL UNIT
071-01477-0064	CTA-81A	CONTROL UNIT
071-01477-0065	CTA-81A	CONTROL UNIT
071-01477-0066	CTA-81A	CONTROL UNIT
071-01477-0070	CTA-81A	CONTROL UNIT
071-01477-0071	CTA-81A	CONTROL UNIT
071-01477-0072	CTA-81A	CONTROL UNIT
071-01477-0073	CTA-81A	CONTROL UNIT
071-01477-0074	CTA-81A	CONTROL UNIT
071-01477-0075	CTA-81A	CONTROL UNIT
071-01477-0076	CTA-81A	CONTROL UNIT
071-01477-0077	CTA-81A	CONTROL UNIT
071-01503-0101	CTA-81A	CONTROL UNIT
071-01503-0201	CTA-81A	CONTROL UNIT
071-01503-0301	CTA-81A	CONTROL UNIT
071-01503-1301	CTA-81A	CONTROL UNIT
071-01503-1401	CTA-81A	CONTROL UNIT
071-01503-1501	CTA-81A	CONTROL UNIT
071-01503-1601	CTA-81A	CONTROL UNIT
071-01503-2101	CTA-81A	CONTROL UNIT
071-01503-2201	CTA-81A	CONTROL UNIT
071-01503-2301	CTA-81A	CONTROL UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
071-01503-2501	CTA-81A	CONTROL UNIT
071-01503-2601	CTA-81A	CONTROL UNIT
071-01503-2701	CTA-81A	CONTROL UNIT
071-01503-2801	CTA-81A	CONTROL UNIT
071-01503-2901	CTA-81A	CONTROL UNIT
071-01503-3001	CTA-81A	CONTROL UNIT
071-01503-3101	CTA-81A	CONTROL UNIT
071-01503-3201	CTA-81A	CONTROL UNIT
071-01503-3701	CTA-81A	CONTROL UNIT
071-01503-3801	CTA-81A	CONTROL UNIT
071-01503-3901	CTA-81A	CONTROL UNIT
071-01503-4001	CTA-81A	CONTROL UNIT
071-01503-4101	CTA-81A	CONTROL UNIT
071-01503-4201	CTA-81A	CONTROL UNIT
071-01503-4301	CTA-81A	CONTROL UNIT
071-01503-4601	CTA-81A	CONTROL UNIT
071-01503-4701	CTA-81A	CONTROL UNIT
071-01503-5901	CTA-81A	CONTROL UNIT
071-01503-6001	CTA-81A	CONTROL UNIT
071-01503-6101	CTA-81A	CONTROL UNIT
071-01507-0901	KFS 578A	MODE S CONTROL UNIT
071-01507-1001	KFS 578A	MODE S CONTROL UNIT
071-01507-1101	KFS 578A	MODE S CONTROL UNIT
071-01507-1201	KFS 578A	MODE S CONTROL UNIT
071-01507-1301	KFS 578A	MODE S CONTROL UNIT
071-01507-1401	KFS 578A	MODE S CONTROL UNIT
071-01507-1501	KFS 578A	MODE S CONTROL UNIT
071-01507-1601	KFS 578A	MODE S CONTROL UNIT
071-01507-1701	KFS 578A	MODE S CONTROL UNIT
071-01507-1801	KFS 578A	MODE S CONTROL UNIT
071-01507-1901	KFS 578A	MODE S CONTROL UNIT
071-01507-2001	KFS 578A	MODE S CONTROL UNIT
071-01507-2201	KFS 578A	MODE S CONTROL UNIT
071-01507-2301	KFS 578A	MODE S CONTROL UNIT
071-01507-2501	KFS 578A	MODE S CONTROL UNIT
071-01507-2901	KFS 578A	MODE S CONTROL UNIT
071-01507-3201	KFS 578A	MODE S CONTROL UNIT
071-01507-3303	KFS 578A	MODE S CONTROL UNIT
071-01507-3403	KFS 578A	MODE S CONTROL UNIT
071-01507-3502	KFS 578A	MODE S CONTROL UNIT
071-01507-3503	KFS 578A	MODE S CONTROL UNIT
071-01507-3603	KFS 578A	MODE S CONTROL UNIT
071-01507-4102	KFS 578A	MODE S CONTROL UNIT
071-01507-4202	KFS 578A	MODE S CONTROL UNIT
071-01507-4302	KFS 578A	MODE S CONTROL UNIT
071-01507-4304	KFS 578A	MODE S CONTROL UNIT
071-01507-4402	KFS 578A	MODE S CONTROL UNIT
071-01507-4404	KFS 578A	MODE S CONTROL UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
071-01507-4902	KFS 578A	MODE S CONTROL UNIT
071-01507-4903	KFS 578A	MODE S CONTROL UNIT
071-01507-5002	KFS 578A	MODE S CONTROL UNIT
071-01507-5003	KFS 578A	MODE S CONTROL UNIT
071-01507-5102	KFS 578A	MODE S CONTROL UNIT
071-01507-5103	KFS 578A	MODE S CONTROL UNIT
071-01507-5202	KFS 578A	MODE S CONTROL UNIT
071-01507-5203	KFS 578A	MODE S CONTROL UNIT
071-01507-5503	KFS 578A	MODE S CONTROL UNIT
071-01507-5603	KFS 578A	MODE S CONTROL UNIT
071-01507-6503	KFS 578A	MODE S CONTROL UNIT
071-01507-6603	KFS 578A	MODE S CONTROL UNIT
071-01507-6703	KFS 578A	MODE S CONTROL UNIT
071-01507-6803	KFS 578A	MODE S CONTROL UNIT
071-01507-7504	KFS 578A	MODE S CONTROL UNIT
071-01507-7604	KFS 578A	MODE S CONTROL UNIT
071-01507-8103	KFS 578A	MODE S CONTROL UNIT
071-01507-8203	KFS 578A	MODE S CONTROL UNIT
071-01507-8303	KFS 578A	MODE S CONTROL UNIT
071-01507-8403	KFS 578A	MODE S CONTROL UNIT
071-01561-0101	CTA-81D	CONTROL UNIT
071-01561-0201	CTA-81D	CONTROL UNIT
080-20325-01		TRANSFORMER-RECTIFIER POWER SUPPLY
0871BN3-2		DETECTOR
0871BN3-4		DETECTOR
0871BN3-6		DETECTOR
0871BN3-8		DETECTOR
0871DP3		ICE DETECTOR
0871DP4		ICE DETECTOR
09-205-101		POWERED FLIGHT SURFACES INDICATOR
10-0119-1	10-0119-1	EMERGENCY EXIT LIGHT
10-0119-3	10-0119-3	EMERGENCY EXIT LIGHT
10037-1000-0101		FUEL QUANTITY INDICATOR
10037-1000-0102		FUEL QUANTITY INDICATOR
10037-1000-0103		FUEL QUANTITY INDICATOR
10037-1000-0104		FUEL QUANTITY INDICATOR
10037-1000-0105		FUEL QUANTITY INDICATOR
10037-1000-0106		FUEL QUANTITY INDICATOR
10037-1000-0107		FUEL QUANTITY INDICATOR
10037-1000-0108		FUEL QUANTITY INDICATOR
10037-1000-0109		FUEL QUANTITY INDICATOR
10037-1000-0110		FUEL QUANTITY INDICATOR
10037-1000-0111		FUEL QUANTITY INDICATOR
10037-1000-0151		FUEL QUANTITY INDICATOR
10037-1000-0152		FUEL QUANTITY INDICATOR
10037-1000-0153		FUEL QUANTITY INDICATOR
10037-1000-0154		FUEL QUANTITY INDICATOR
10037-1000-0155		FUEL QUANTITY INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
10037-1000-0156		FUEL QUANTITY INDICATOR
10037-1000-0157		FUEL QUANTITY INDICATOR
10037-1000-0158		FUEL QUANTITY INDICATOR
10037-1000-0159		FUEL QUANTITY INDICATOR
10037-1000-0160		FUEL QUANTITY INDICATOR
10037-1000-0161		FUEL QUANTITY INDICATOR
10037-1000-0162		FUEL QUANTITY INDICATOR
10037-1000-0163		FUEL QUANTITY INDICATOR
10037-1000-0164		FUEL QUANTITY INDICATOR
10037-1000-0165		FUEL QUANTITY INDICATOR
10037-1000-0166		FUEL QUANTITY INDICATOR
10066-0000-01		LIQUID QTY INDICATOR
10-1266-1		CABIN EMERGENCY LIGHT
10-1267-1		CABIN EMERGENCY LIGHT (DOOR)
10-1267-11		CABIN EMERGENCY LIGHT (DOOR)
10-1267-13		CABIN EMERGENCY LIGHT (DOOR)
10-1267-15		CABIN EMERGENCY LIGHT (DOOR)
10-1267-17		CABIN EMERGENCY LIGHT (DOOR)
10-1267-19		CABIN EMERGENCY LIGHT (DOOR)
10-1267-2		CABIN EMERGENCY LIGHT (DOOR)
10-1267-21		CABIN EMERGENCY LIGHT (DOOR)
10-1267-23		CABIN EMERGENCY LIGHT (DOOR)
10-1267-25		CABIN EMERGENCY LIGHT (DOOR)
10-1267-27		CABIN EMERGENCY LIGHT (DOOR)
10-1267-29		CABIN EMERGENCY LIGHT (DOOR)
10-1267-3		CABIN EMERGENCY LIGHT (DOOR)
10-1267-31		CABIN EMERGENCY LIGHT (DOOR)
10-1267-33		CABIN EMERGENCY LIGHT (DOOR)
10-1267-35		CABIN EMERGENCY LIGHT (DOOR)
10-1267-37		CABIN EMERGENCY LIGHT (DOOR)
10-1267-39		CABIN EMERGENCY LIGHT (DOOR)
10-1267-4		CABIN EMERGENCY LIGHT (DOOR)
10-1267-41		CABIN EMERGENCY LIGHT (DOOR)
10-1267-5		CABIN EMERGENCY LIGHT (DOOR)
10-1267-7		CABIN EMERGENCY LIGHT (DOOR)
10-1267-9		CABIN EMERGENCY LIGHT (DOOR)
10-1288-1		SEAT MOUNTED EMERGENCY LIGHT
10-1288-11		SEAT MOUNTED EMERGENCY LIGHT
10-1288-12		SEAT MOUNTED EMERGENCY LIGHT
10-1288-13		SEAT MOUNTED EMERGENCY LIGHT
10-1288-14		SEAT MOUNTED EMERGENCY LIGHT
10-1288-15		SEAT MOUNTED EMERGENCY LIGHT
10-1288-25		SEAT MOUNTED EMERGENCY LIGHT
10-1288-3		SEAT MOUNTED EMERGENCY LIGHT
10-1288-5		SEAT MOUNTED EMERGENCY LIGHT
10-1288-7		SEAT MOUNTED EMERGENCY LIGHT
10-1308-1		WALL MOUNTED EMERGENCY LIGHT
10-1308-3		WALL MOUNTED EMERGENCY LIGHT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
10-1308-5		WALL MOUNTED EMERGENCY LIGHT
10-1310-1		EMERGENCY EXIT SIGN
10-1319-1		AREA CALL PANEL
10-1319-3		AREA CALL PANEL
10-1319-5		AREA CALL PANEL
10-1358-1		CALL LIGHT
10-1358-11		CALL LIGHT
10-1358-12		CALL LIGHT
10-1358-13		CALL LIGHT
10-1358-3		CALL LIGHT
10-1358-5		CALL LIGHT
10-1358-6		CALL LIGHT
101435-11719		REPORTING ALTIMETER PRESSURE
101435-11720		REPORTING ALTIMETER PRESSURE
101DPG/4		PRESSURE GAUGE
101SPT/BU/1		SYNCHRO POSITION TRANSMITTER
102150		CABIN AIR PRESSURE OUTFLOW VALVE
102150-0		CABIN AIR PRESSURE OUTFLOW VALVE
102150-0-12		CABIN AIR PRESSURE OUTFLOW VALVE
102150-0-13		CABIN AIR PRESSURE OUTFLOW VALVE
1021PG/CP		DESYNN PRESSURE INDICATOR
1024-4		DIMMER CONTROL UNIT
1024-4A		DIMMER CONTROL UNIT
1024-4B		DIMMER CONTROL UNIT
1024-4C		DIMMER CONTROL UNIT
102936-2		CABIN PRESSURE SELECTOR
102936-3		CABIN PRESSURE SELECTOR
10-3065-277	JG403B15	FUEL QUANTITY INDICATOR
10-3067-3	40057-1	PRESSURE SWITCH
10-3294-4	G9140-5	RETRACTABLE LANDING LIGHT
10-3294-7	G-9140-7	AIRCRAFT RETRACTABLE LANDING LIGHT
103610	980-6100-010	MICROPHONE MONITOR
103610-1	980-6100-001	MICROPHONE MONITOR
103610-2	980-6100-002	MICROPHONE MONITOR
103610-3	980-6100-003	MICROPHONE MONITOR
103610-4	980-6100-004	MICROPHONE MONITOR
103SPT/BU/1		SYNCHRO POSITION TRANSMITTERS
1-040-0001	152LUA31	VIBRATION INDICATOR
1-040-0002	152LUA32	VIBRATION INDICATOR
1-040-0005	152LUA27	VIBRATION INDICATOR
104AMAJA1		MACH-AIRSPEED INDICATOR
104AMAJA10		MACH-AIRSPEED INDICATOR
104AMAJA2		MACH-AIRSPEED INDICATOR
104AMAJA5		MACH-AIRSPEED INDICATOR
104AMAJA6		MACH-AIRSPEED INDICATOR
104AMAJA8		MACH-AIRSPEED INDICATOR
104AMAJA9		MACH-AIRSPEED INDICATOR
104DPG/2		PRESSURE GAUGE



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
1051PG/CP		DESYNN PRESSURE INDICATOR
105DPG/1		PRESSURE GAUGE
105DPG/2		PRESSURE GAUGE
105SPT/BU/1		SYNCHRO POSITION TRANSMITTER
10-60498-13	548376-6	CABIN TEMPERATURE CONTROLLER
10-60552-31	90G235	SWITCH, GAGE PRESSURE
10-60701-3	2-301-3	BATTERY CHARGER
10-60722-11	20041-0000-03	LIQUID QUANTITY ENGINE OIL TRANSMITTER
10-60737-16	2045-08-1	EPR INDICATOR
10-60757-142	114.035	POSITION INDICATOR
10-60757-24	LKCB-18036	DC AMMETER
10-60757-28	124.838	TEMPERATURE INDICATOR
10-60757-29	124-861	TEMPERATURE INDICATOR
10-60757-53	185.076	AC AMMETER
10-60757-55	114.029	POSITION INDICATOR
10-60791-13	18-1299-6	FLAP POSITION INDICATOR
10-61093-181	40-817	WHEEL SPEED TRANSDUCER
10-61219-112	2101-01-1	FUEL QUANTITY REPEATER INDICATOR
10-61219-113	4215-01	DIGITAL CALIBRATION TRIM UNIT
10-61219-170	2120-52-1	FUEL QUANTITY INDICATOR
10-61219-171	2120-62-1	FUEL QUANTITY INDICATOR
10-61219-174	2120-51-1	FUEL QUANTITY INDICATOR
10-61219-175	2120-61-1	FUEL QUANTITY INDICATOR
10-61219-179	2120-54-1	FUEL QUANTITY INDICATOR
10-61219-180	2120-53-1	FUEL QUANTITY INDICATOR
10-61219-2	393026-01840	FUEL QTY INDICATOR
10-61255-19	50483-19	PRESSURE INDICATOR
10-61255-20	50483-20	PRESSURE INDICATOR
10-61366-1	450083-1	LANDING LIGHT ASSY.
10-61366-2	45-0083-2	LANDING LIGHT ASSY.
10-61366-3	45-0083-3	LANDING LIGHT ASSY.
10-61366-5	45-0083-5	LANDING LIGHT ASSY.
10-61366-7	45-0083-7	LANDING LIGHT ASSY.
10-61371-22	393080-122	DUAL TOTAL FUEL AND V-REF INDICATOR
10-61371-23	393080-123	DUAL TOTAL FUEL AND V-REF INDICATOR
10-61472-10		ROTARY ACTUATOR
10-61472-8		ROTARY ACTUATOR
10-61472-9		ROTARY ACTUATOR
10-618126-6	2055-01-1	SERVOED ALTITUDE INDICATOR
10-61818-151	2083-08-1	MACH AIRSPEED INDICATOR
10-61826-10	2057-02-1	SERVOED ALTITUDE INDICATOR
10-61826-7	2056-01-1	SERVOED ALTITUDE INDICATOR
10-61826-8	2057-01-1	SERVOED ALTITUDE INDICATOR
10-61833-1	83000-05601	WINDOW HEAT CONTROL
10-61833-2	83000-05601	WINDOW HEAT CONTROL
10-61833-3	83000-05602	WINDOW HEAT CONTROL
10-61833-4	83000-05603	WINDOW HEAT CONTROL
10-61833-6	83000-05604	WINDOW HEAT CONTROL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
10-61841-52	18-1738-52	FLAP POSITION, STALL WARNING & A/P TRANSMITTER
10-61897-5		SURGE TANK PRESSURE RELIEF VALVE
10-61897-6		SURGE TANK PRESSURE RELIEF VALVE
10-61926-5	2061-15-1	FLAP POSITION INDICATOR
10-62028-2	WL101EED2	N1 PERCENTAGE RPM INDICATOR
10-62028-3	WL101EED3	N1 PERCENTAGE RPM INDICATOR
10-62031-1	WL201EED2	N2 % RPM INDICATOR
10-62032-2	WL202EED3	TEMPERATURE INDICATOR
10-62032-3	WL202EED4	TEMPERATURE INDICATOR
10-62032-5	WL202EED6	TEMPERATURE INDICATOR
10-62033-2		ROTARY ACTUATOR
10-62033-3		ROTARY ACTUATOR
10-62033-4		ROTARY ACTUATOR
10-62058-5	D434-56-001	AUTOFLIGHT ANNUNCIATOR
10-62067-1	522782	VIBRATION MONITOR INDICATOR
10-62081-001	2577D	CDU
10-62081-002	2577D1	CDU
10-62090-24		AUDIO CONTROL PANEL
10-62090-40		AUDIO CONTROL PANEL
10-62090-43		AUDIO CONTROL PANEL
10-62090-44		AUDIO CONTROL PANEL
10-62090-46		AUDIO CONTROL PANEL
10-62090-47		AUDIO CONTROL PANEL
10-62090-48		AUDIO CONTROL PANEL
10-62090-61		AUDIO CONTROL PANEL
10-62090-62		AUDIO CONTROL PANEL
10-62090-63		AUDIO CONTROL PANEL
10-62090-64		AUDIO CONTROL PANEL
10-62090-65		AUDIO CONTROL PANEL
10-62090-70		AUDIO CONTROL PANEL
10-62090-71		AUDIO CONTROL PANEL
10-62153-1	501FAD1-1	AIR DATA COMPUTER
10-62178-101		EIS PRIMARY DISPLAY PANEL
10-62178-102		EIS PRIMARY DISPLAY PANEL
10-62178-103		EIS PRIMARY DISPLAY PANEL
10-62178-104		EIS PRIMARY DISPLAY PANEL
10-62178-105/111	312EDP1-1	EIS PRIMARY DISPLAY PANEL
10-62178-106/112	312EDP2-1	EIS PRIMARY DISPLAY PANEL
10-62178-109		EIS PRIMARY DISPLAY PANEL
10-62178-110		EIS PRIMARY DISPLAY PANEL
10-62178-111	312EDP1-2	EIS PRIMARY DISPLAY PANEL
10-62178-112	312EDP2-2	EIS PRIMARY DISPLAY PANEL
10-62178-113		EIS PRIMARY DISPLAY PANEL
10-62178-114		EIS PRIMARY DISPLAY PANEL
10-62178-115	312EDP1-3	EIS PRIMARY DISPLAY PANEL
10-62178-116	312EDP2-3	EIS PRIMARY DISPLAY PANEL
10-62178-201		E.I.S. SECONDARY DISPLAY PANEL
10-62178-202		E.I.S. SECONDARY DISPLAY PANEL





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
10-62190-1	152LMA18	TEMPERATURE INDICATOR
10-62190-2	152LMA22	TEMPERATURE INDICATOR
10-62190-3	152LMA23	TEMPERATURE INDICATOR
106324		PNEUMATIC AIR SHUTOFF VALVE
106324-1	ATV7-3-1	PNEUMATIC AIR SHUTOFF VALVE
106324-2		PNEUMATIC AIR SHUTOFF VALVE
1071PGM		PRESSURE GAUGE
107484-2		HIGH STAGE REGULATOR
107484-3		HIGH STAGE REGULATOR
107484-4		HIGH STAGE REGULATOR
107484-5		HIGH STAGE REGULATOR
107484-6		HIGH STAGE REGULATOR
107484-7		HIGH STAGE REGULATOR
107494-1		REVERSE FLOW CHECK CONTROL VALVE
107494-2		REVERSE FLOW CHECK CONTROL VALVE
107494-3	S212N101-29	REVERSE FLOW CHECK CONTROL VALVE
107494-4	S212N101-45	REVERSE FLOW CHECK CONTROL VALVE
1092-10000	EPRT100-1	ENGINE PRESSURE RATIO TRANSMITTER
1092-15000	EPRT100-1	ENGINE PRESSURE RATIO TRANSMITTER
109486-1-1		4" PNEUMATIC BUTTERFLY SHUTOFF VALVE
109486-4-1		4" PNEUMATIC BUTTERFLY SHUTOFF VALVE
109486-5-1		4" PNEUMATIC BUTTERFLY SHUTOFF VALVE
109486-6-1		4" PNEUMATIC BUTTERFLY SHUTOFF VALVE
109486-7		4" PNEUMATIC BUTTERFLY SHUTOFF VALVE
109486-8		4" PNEUMATIC BUTTERFLY SHUTOFF VALVE
109612-3		5.5" PNEUMATIC SHUTOFF BUTTERFLY VALVE
109612-4		5.5" PNEUMATIC SHUTOFF BUTTERFLY VALVE
109SPT/BU/1		SYNCHRO POSITION TRANSMITTER
11-0283-2		EMERGENCY EXIT LIGHT SUBASSY
11-0283-3		EMERGENCY EXIT LIGHT SUBASSY
11-0283-5		EMERGENCY EXIT LIGHT SUBASSY
11-0283-6		EMERGENCY EXIT LIGHT SUBASSY
11-0283-7		EMERGENCY EXIT LIGHT SUBASSY
1109PG/CP		DESYNN PRESSURE INDICATOR
1111-577098M1		SWING CHECK VALVE
1134PGM		DIRECT READING PRESSURE GAUGE
114.029	10-60757-55	POSITION INDICATOR
114.035	10-60757-142	POSITION INDICATOR
114.114	780159-1	VALVE POSITION INDICATOR
114.115	780158-1	VALVE POSITION INDICATOR
115.099-5		HYDRAULIC PRESSURE INDICATOR
115.099-6		BRAKE PRESSURE INDICATOR
115.099-7		BRAKE PRESSURE INDICATOR
115.099-8	S231T231-8	BRAKE PRESSURE INDICATOR
115.099-9		BRAKE PRESSURE INDICATOR
115.160		WATER QUANTITY INDICATOR
115.160-1		WATER QUANTITY INDICATOR
115.161		WATER QUANTITY INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
115.216		WATER QUANTITY INDICATOR
115.217		WATER QUANTITY INDICATOR
115.217-1		WATER QUANTITY INDICATOR
1150406-1	S210T130-72	AUXILIARY ZONE TEMPERATURE CONTROLLER
115-160		WATER QUANTITY INDICATOR
115-160-1		WATER QUANTITY INDICATOR
115-161		WATER QUANTITY INDICATOR
115-216		WATER QUANTITY INDICATOR
115-217		WATER QUANTITY INDICATOR
115-217-1		WATER QUANTITY INDICATOR
11-5833-1	S417N512-4	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-11	S417N512-11	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-13	S417N512-12	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-15	S417N512-13	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-17	S417N512-27	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-19	S417N512-28	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-21	S417N512-23	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-23	S417N512-24	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-25	S417N512-26	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-3	S417N512-6	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-5	S417N512-7	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-7	S417N512-8	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
11-5833-9	S417N512-10	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
1158PG		PRESSURE GAUGE
1159PG		PRESSURE GAUGE
1163P0052		DIFFERENTIAL PRESSURE SWITCH
1163P0052-01		DIFFERENTIAL PRESSURE SWITCH
1163P0052-02		DIFFERENTIAL PRESSURE SWITCH
1163P18-1		DIFFERENTIAL PRESSURE SWITCH
1163P18-2		DIFFERENTIAL PRESSURE SWITCH
1170PG		PRESSURE GAUGE
1198PG/CP		DESYNN PRESSURE INDICATOR
1200008-000		SELCAL DECODER
1201-01-00	DA 12L	COFFEE MAKER
120-29967-001		WARNING PANEL
120-34428-001		WARNING PANEL
120-34428-501		WARNING PANEL
120-34428-503		WARNING PANEL
120-34428-505		WARNING PANEL
120-34428-507		WARNING PANEL
120-IN-0068	SEDL-OC2R	TORQUE INDICATOR
1214BX-8-05	L-7A	SENSITIVE MAXIMUM ALLOWABLE AIRSPEED
1214CX-8-05	L-7A	SENSITIVE MAXIMUM ALLOWABLE AIRSPEED
1214DX-8-05	L-7A	SENSITIVE MAXIMUM ALLOWABLE AIRSPEED
1214X-8-05	L-7	SENSITIVE MAXIMUM ALLOWABLE AIRSPEED
121535		MOTOR ACTUATED BUTTERFLY SHUT-OFF VALVE
121535-1		MOTOR ACTUATED BUTTERFLY SHUT-OFF VALVE
121672-01	7000B	ROLL AND PITCH DISPLACEMENT GYRO



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
121672-01-15	7000B	ROLL AND PITCH DISPLACEMENT GYRO
121672-01-16	7000B	ROLL AND PITCH DISPLACEMENT GYRO
121672-01-17	7000B	ROLL AND PITCH DISPLACEMENT GYRO
122400		HORIZONTAL SITUATION INDICATOR
123558-1-1		3.5" CHECK VALVE
123558-1-3		3.5" CHECK VALVE
123558-1-4		3.5" CHECK VALVE
124.013	209-070-262-3	DUAL TEMP. AND PRESSURE IND.
124.014		DUAL TEMP. AND PRESSURE IND.
124.014-111		DUAL TEMP. AND PRESSURE IND.
124.014-121		DUAL TEMP. AND PRESSURE IND.
124.014-13		DUAL TEMP. AND PRESSURE IND.
124.014-15		DUAL TEMP. AND PRESSURE IND.
124.014-17		DUAL TEMP. AND PRESSURE IND.
124.014-19		DUAL TEMP. AND PRESSURE IND.
124.014-23		DUAL TEMP. AND PRESSURE IND.
124.014-25		DUAL TEMP. AND PRESSURE IND.
124.039-3		DUAL AMPERE IND.
124.043		DUAL TEMP. AND PRESSURE IND.
124.044		FUEL PRESSURE IND.
124.044-2		FUEL PRESSURE IND.
124.044-3		FUEL PRESSURE IND.
124.067		ITT INDICATOR
124.067-2		ITT INDICATOR
124.081		FLOW INDICATOR
124.115		DUAL TEMP. AND PRESS. IND.
124.115-3		DUAL TEMP. AND PRESS. IND.
124.115-5		DUAL TEMP. AND PRESS. IND.
124.133	10-60757-144	DC AMMETER
124.444.12		TURBINE OUTLET TEMPERATURE INDICATOR
124.496-3		BLEED AIR PRESSURE INDICATOR
124.832	10-60757-22	AC VOLTMETER
124.833	10-60757-23	DC VOLT
124.834	10-60757-24	DC AMMETER
124.835	10-60757-25	FREQUENCY METER
124.836	10-60757-26	WATTMETER
124.837	10-60757-27	AC AMMETER
124.838	10-60757-28	TEMPERATURE INDICATOR
124.969	124-081	FLOW INDICATOR
124.987-4		INDICATOR,DUAL BRAKE TEMP
124-115-1		DUAL TEMP. AND PRESS. IND.
124623-01	7000E	ROLL AND PITCH DISPLACEMENT GYRO
124623-01-09	7000E	ROLL AND PITCH DISPLACEMENT GYRO
124623-01-10	7000E	ROLL AND PITCH DISPLACEMENT GYRO
124623-01-12	7000E	ROLL AND PITCH DISPLACEMENT GYRO
124623-01-13	7000E	ROLL AND PITCH DISPLACEMENT GYRO
124623-01-14	7000E	ROLL AND PITCH DISPLACEMENT GYRO
124-835		FREQUENCY METER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
1248595-1		GYRO ASSEMBLY
124-861	10-60757-29	TEMPERATURE INDICATOR
130005AU		ELECTRIC MOTOR OPERATED ACTUATOR ASSY.
130005P		ELECTRIC MOTOR OPERATED ACTUATOR ASSY.
130005P-1		ELECTRIC MOTOR OPERATED ACTUATOR ASSY.
1303153-100		8.4 INCH LCD RETRACT MONITOR
1303153-101		8.4 INCH LCD RETRACT MONITOR
1303153-102		8.4 INCH LCD RETRACT MONITOR
1303153-103		8.4 INCH LCD RETRACT MONITOR
1303A0000-01		FLOW CONTROL VALVE
1303A0000-02		FLOW CONTROL VALVE
1303A0000-02 AMDT B		FLOW CONTROL VALVE
1303A0000-03		FLOW CONTROL VALVE
1303A0000-03 AMDT A		FLOW CONTROL VALVE
1303A0000-03 AMDT A#		FLOW CONTROL VALVE
1303A0000-03 AMDT B		FLOW CONTROL VALVE
1303A0000-04		FLOW CONTROL VALVE
1303A0000-04 AMDT A		FLOW CONTROL VALVE
130502-4	S210T160-42	CABIN PRESSURE SELECTOR
130502-5	S210T160-52	CABIN PRESSURE SELECTOR
130502-6	S210T160-62	CABIN PRESSURE SELECTOR
130502-7	S210T160-72	CABIN PRESSURE SELECTOR
1312A0000-01		BYPASS VALVE
1312B0000-01		BYPASS VALVE
1320A0000-01		TRIM AIR VALVE
132VJ1RL13		LINEAR ACTUATOR ASSEMBLY
132VJ1RL13A		LINEAR ACTUATOR ASSEMBLY
1333-613233		ANTI-ICING BUTTERFLY AIR VALVE
1333-613233M1		ANTI-ICING BUTTERFLY AIR VALVE
1339-1		HEATED WINDOW CONTROLLER ASSY
1383M67P04		TURBINE CLEARANCE CONTROL VALVE
1383M67P05		TURBINE CLEARANCE CONTROL VALVE
1383M67P06		TURBINE CLEARANCE CONTROL VALVE
1383M67P07		TURBINE CLEARANCE CONTROL VALVE
139800-01-01	4003T	ATTITUDE INDICATOR
140260-01-01	2171AC	DISPLACEMENT GYROSCOPE ASSEMBLY
140260-01-03	2171AC	DISPLACEMENT GYROSCOPE ASSEMBLY
1407KID02-03		FUEL QUANTITY INDICATOR
1407PG		PRESSURE GAUGE
1409PG		PRESSURE GAUGE
1412KID02-03		FUEL QUANTITY INDICATOR
1422PG		PRESSURE GAUGE
1443PG		PRESSURE GAUGE
144700-01-01	4003AF	ATTITUDE INDICATOR
1452PG		PRESSURE GAUGE
1454PG		PRESSURE GAUGE
1456PG/CP		DESYNN PRESSURE INDICATOR
1457PG/CP		DESYNN PRESSURE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
145974-01-03	9000C	VERTICAL DISPLACEMENT GYROSCOPE
146051-01-01	4003AD	ATTITUDE INDICATOR
146895-01-01	6357A	EPR COMPUTER INDICATOR
147795-01-01	6357C	EPR COMPUTER INDICATOR
147B13		TEMPERATURE INDICATOR
147B13A		TEMPERATURE INDICATOR
147B13B		TEMPERATURE INDICATOR
147B30		TEMPERATURE INDICATOR
147B30A		TEMPERATURE INDICATOR
147B31		TEMPERATURE INDICATOR
147B31A		TEMPERATURE INDICATOR
147B31A3		TEMPERATURE INDICATOR
147B31A4		TEMPERATURE INDICATOR
147B31B		TEMPERATURE INDICATOR
147B31C		TEMPERATURE INDICATOR
147B7		TEMPERATURE INDICATOR
147B7A		TEMPERATURE INDICATOR
147B8		TEMPERATURE INDICATOR
147BDL2		TEMPERATURE INDICATOR
147D2		TEMPERATURE INDICATOR
148000-01-01	6357AU	EPR COMPUTER INDICATOR
148025-01-01	6357CU	EPR COMPUTER INDICATOR
148110-01-01	4003AH	ATTITUDE INDICATOR
1486PG		PRESSURE GAUGE
148700-02-01	4145B	ATTITUDE INDICATOR
148700-04-01	4145B1	ATTITUDE INDICATOR
1487PG		PRESSURE GAUGE
1488PG		PRESSURE GAUGE
1491PG		PRESSURE GAUGE
149270-01-01	2724A	TOTAL AIR TEMP. - ENGINE PRESS. RATIO LIMIT IND.
149270-02-01	2724A1	TOTAL AIR TEMP. - ENGINE PRESS. RATIO LIMIT IND.
149270-03-01	2724A2	TOTAL AIR TEMP. - ENGINE PRESS. RATIO LIMIT IND.
149270-04-01	2724A3	TOTAL AIR TEMP. - ENGINE PRESS. RATIO LIMIT IND.
149270-05-01	2724A4	TOTAL AIR TEMP. - ENGINE PRESS. RATIO LIMIT IND.
1497674-001	3571213-4001	HYDRAULIC PRESSURE INDICATOR
1497674-004	3571213-4002	HYDRAULIC PRESSURE INDICATOR
1497674-005	3571213-4003	HYDRAULIC PRESSURE INDICATOR
1497674-008	3571213-004	HYDRAULIC PRESSURE INDICATOR
1497674-009	3571213-4005	HYDRAULIC PRESSURE INDICATOR
1497674-011	3571213-4008	HYDRAULIC PRESSURE INDICATOR
152530-01-01	2568F	FLIGHT MODE SELECTOR PANEL
152BCL4		EGT INDICATOR
152BCL4A		EGT INDICATOR
152BCL4B		EGT INDICATOR
152BCL4C		EGT INDICATOR
152BCL4D		EGT INDICATOR
152BCL4F		EGT INDICATOR
152BCL4G		EGT INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
152BCL4G2		EGT INDICATOR
152BCL4H		EGT INDICATOR
152BCL4J		EGT INDICATOR
152BCL4J2		EGT INDICATOR
152BCL4J3		EGT INDICATOR
152BCL4P		EGT INDICATOR
152BCL4R		EGT INDICATOR
152BCL4S		EGT INDICATOR
152BCL4W		EGT INDICATOR
152BCL4W2		EGT INDICATOR
152BL702A		THERMOCOUPLE INDICATOR
152BL702C		THERMOCOUPLE INDICATOR
152BL702D		THERMOCOUPLE INDICATOR
152BL702E		THERMOCOUPLE INDICATOR
152BL703		THERMOCOUPLE INDICATOR
152BL704		THERMOCOUPLE INDICATOR
152BL706		THERMOCOUPLE INDICATOR
152BL708		THERMOCOUPLE INDICATOR
152BL708A		THERMOCOUPLE INDICATOR
152BL708B		THERMOCOUPLE INDICATOR
152BL708H		THERMOCOUPLE INDICATOR
152BL709		THERMOCOUPLE INDICATOR
152BL709A		THERMOCOUPLE INDICATOR
152BL722		THERMOCOUPLE INDICATOR
152BL801		THERMOCOUPLE INDICATOR
152BL801A		THERMOCOUPLE INDICATOR
152BL801B		THERMOCOUPLE INDICATOR
152BL801C		THERMOCOUPLE INDICATOR
152BL801D		THERMOCOUPLE INDICATOR
152BL801E		THERMOCOUPLE INDICATOR
152BL802A		THERMOCOUPLE INDICATOR
152BL802B		THERMOCOUPLE INDICATOR
152BL802C		THERMOCOUPLE INDICATOR
152BL802D		THERMOCOUPLE INDICATOR
152BL803		THERMOCOUPLE INDICATOR
152BL803A		THERMOCOUPLE INDICATOR
152BL803B		THERMOCOUPLE INDICATOR
152BL803C		THERMOCOUPLE INDICATOR
152C4		THERMOMETER INDICATOR
152C40A		THERMOMETER INDICATOR
152C40A2		THERMOMETER INDICATOR
152C4A		THERMOMETER INDICATOR
152C4B		THERMOMETER INDICATOR
152LC208H		AC VOLTMETER
152LCV8		AC VOLTMETER
152LCV8A		AC VOLTMETER
152LMA18	10-62190-1	TEMPERATURE INDICATOR
152LMA22	10-62190-2	TEMPERATURE INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
152LMA23	10-62190-3	TEMPERATURE INDICATOR
152LUA7		VIBRATION INDICATOR
157405-01-01	2724B	TOTAL AIR TEMP. - ENGINE N1 LIMIT IND.
157405-02-01	2724B1	TOTAL AIR TEMP. - ENGINE N1 LIMIT IND.
157405-03-01	2724B2	TOTAL AIR TEMP. - ENGINE N1 LIMIT IND.
157409-02-01	2568K1	FLIGHT MODE SELECTOR PANEL
15759-1A		AUTOMATIC PILOT FLIGHT CONTROLLER
15759-3A		AUTOMATIC PILOT FLIGHT CONTROLLER
15759-4A		AUTOMATIC PILOT FLIGHT CONTROLLER
15759-5A		AUTOMATIC PILOT FLIGHT CONTROLLER
15759-6A		AUTOMATIC PILOT FLIGHT CONTROLLER
15768-1A		AUTOMATIC PILOT FLIGHT CONTROLLER
157770-01-01	2724C	TOTAL AIR TEMP. - MAX. ENGINE PRESS. RATIO IND.
157844-01-01	2568N	FLIGHT MODE SELECTOR PANEL
159120-01-01	2568P	FLIGHT MODE SELECTOR PANEL
159120-02-01	2568P1	FLIGHT MODE SELECTOR PANEL
16100-1		DIGITAL ALTITUDE INDICATOR
16100-2		DIGITAL ALTITUDE INDICATOR
16100-5		DIGITAL ALTITUDE INDICATOR
16100-6		DIGITAL ALTITUDE INDICATOR
16100-7		DIGITAL ALTITUDE INDICATOR
16100-8		DIGITAL ALTITUDE INDICATOR
161714-01-01	2568R	FLIGHT MODE SELECTOR PANEL
161714-02-01	2568R1	FLIGHT MODE SELECTOR PANEL
161B101		ELEC. RESISTANCE THERMOMETER
161BCL2		ELEC. RESISTANCE THERMOMETER
161BL302		ELEC. RESISTANCE THERMOMETER
161BL501		ELEC. RESISTANCE THERMOMETER
161C20B		ELEC. RESISTANCE THERMOMETER
161C3		ELEC. RESISTANCE THERMOMETER
161C9		ELEC. RESISTANCE THERMOMETER
1625-1		WINDSHIELD TEMPERATURE CONTROLLER
162B101		ELEC. RESISTANCE THERMOMETER
162B11		ELEC. RESISTANCE THERMOMETER
162B2		ELEC. RESISTANCE THERMOMETER
162B2A		ELEC. RESISTANCE THERMOMETER
162B2G		ELEC. RESISTANCE THERMOMETER
162B3		ELEC. RESISTANCE THERMOMETER
162B3F		ELEC. RESISTANCE THERMOMETER
162B4		ELEC. RESISTANCE THERMOMETER
162BCL10W		ELEC. RESISTANCE THERMOMETER
162BCL10WC		ELEC. RESISTANCE THERMOMETER
162BCL11A		ELEC. RESISTANCE THERMOMETER
162BCL11W		ELEC. RESISTANCE THERMOMETER
162BCL12W		ELEC. RESISTANCE THERMOMETER
162BCL15W		ELEC. RESISTANCE THERMOMETER
162BCL16		ELEC. RESISTANCE THERMOMETER
162BCL16A		ELEC. RESISTANCE THERMOMETER



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
162BCL16B		ELEC. RESISTANCE THERMOMETER
162BCL16W		ELEC. RESISTANCE THERMOMETER
162BCL16WC		ELEC. RESISTANCE THERMOMETER
162BCL17		ELEC. RESISTANCE THERMOMETER
162BCL19		ELEC. RESISTANCE THERMOMETER
162BCL20		ELEC. RESISTANCE THERMOMETER
162BCL20A		ELEC. RESISTANCE THERMOMETER
162BCL20B		ELEC. RESISTANCE THERMOMETER
162BCL20C		ELEC. RESISTANCE THERMOMETER
162BCL21		ELEC. RESISTANCE THERMOMETER
162BCL22		ELEC. RESISTANCE THERMOMETER
162BCL23		ELEC. RESISTANCE THERMOMETER
162BCL27		ELEC. RESISTANCE THERMOMETER
162BCL33		ELEC. RESISTANCE THERMOMETER
162BCL33W		ELEC. RESISTANCE THERMOMETER
162BCL81		ELEC. RESISTANCE THERMOMETER
162BCL81W		ELEC. RESISTANCE THERMOMETER
162BCL82W		ELEC. RESISTANCE THERMOMETER
162BCL9		ELEC. RESISTANCE THERMOMETER
162BL402		ELEC. RESISTANCE THERMOMETER
162BL402A		ELEC. RESISTANCE THERMOMETER
162BL403		ELEC. RESISTANCE THERMOMETER
162BL403A		ELEC. RESISTANCE THERMOMETER
162BL403B		ELEC. RESISTANCE THERMOMETER
162BL403C		ELEC. RESISTANCE THERMOMETER
162BL501		ELEC. RESISTANCE THERMOMETER
162BL502		ELEC. RESISTANCE THERMOMETER
162BL503		ELEC. RESISTANCE THERMOMETER
162BL504		ELEC. RESISTANCE THERMOMETER
162BL505		ELEC. RESISTANCE THERMOMETER
162BL602		ELEC. RESISTANCE THERMOMETER
162BL701		ELEC. RESISTANCE THERMOMETER
162BL701A		ELEC. RESISTANCE THERMOMETER
162BL702		ELEC. RESISTANCE THERMOMETER
162BL703		ELEC. RESISTANCE THERMOMETER
162BL704		ELEC. RESISTANCE THERMOMETER
162BL704A		ELEC. RESISTANCE THERMOMETER
162BL704C		ELEC. RESISTANCE THERMOMETER
162BL704D		ELEC. RESISTANCE THERMOMETER
162BL704F		ELEC. RESISTANCE THERMOMETER
162BL704H		ELEC. RESISTANCE THERMOMETER
162BL704K		ELEC. RESISTANCE THERMOMETER
162BL704L		ELEC. RESISTANCE THERMOMETER
162BL704N		ELEC. RESISTANCE THERMOMETER
162BL708		ELEC. RESISTANCE THERMOMETER
162BL709		ELEC. RESISTANCE THERMOMETER
162BL709A		ELEC. RESISTANCE THERMOMETER
162BL709B		ELEC. RESISTANCE THERMOMETER





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
162BL709C		ELEC. RESISTANCE THERMOMETER
162BL710		ELEC. RESISTANCE THERMOMETER
162BL711		ELEC. RESISTANCE THERMOMETER
162BL801		ELEC. RESISTANCE THERMOMETER
162BL802		ELEC. RESISTANCE THERMOMETER
162BL802A		ELEC. RESISTANCE THERMOMETER
162BL803		ELEC. RESISTANCE THERMOMETER
162BL803A		ELEC. RESISTANCE THERMOMETER
162BL804A		ELEC. RESISTANCE THERMOMETER
162BL901		ELEC. RESISTANCE THERMOMETER
162BL902		ELEC. RESISTANCE THERMOMETER
162BL903		ELEC. RESISTANCE THERMOMETER
162BL906		ELEC. RESISTANCE THERMOMETER
162BL907		ELEC. RESISTANCE THERMOMETER
162C16		ELEC. RESISTANCE THERMOMETER
162C17		ELEC. RESISTANCE THERMOMETER
162C18		ELEC. RESISTANCE THERMOMETER
162C20B		ELEC. RESISTANCE THERMOMETER
162C21		ELEC. RESISTANCE THERMOMETER
162C22		ELEC. RESISTANCE THERMOMETER
162C23		ELEC. RESISTANCE THERMOMETER
162C23B		ELEC. RESISTANCE THERMOMETER
162C25		ELEC. RESISTANCE THERMOMETER
162C26		ELEC. RESISTANCE THERMOMETER
162C27		ELEC. RESISTANCE THERMOMETER
162C28		ELEC. RESISTANCE THERMOMETER
162C30		ELEC. RESISTANCE THERMOMETER
162C31		ELEC. RESISTANCE THERMOMETER
162C38		FLUID TEMPERATURE INDICATOR
162C38A		FLUID TEMPERATURE INDICATOR
162C40A		FLUID TEMPERATURE INDICATOR
162C7		ELEC. RESISTANCE THERMOMETER
162C7A		ELEC. RESISTANCE THERMOMETER
162C9		ELEC. RESISTANCE THERMOMETER
163BL501		THERMOMETER INDICATOR
163BL501C		THERMOMETER INDICATOR
163BL506		THERMOMETER INDICATOR
163BL507		THERMOMETER INDICATOR
163BL507B		THERMOMETER INDICATOR
163BL507H		THERMOMETER INDICATOR
163BL508		THERMOMETER INDICATOR
163BL511		THERMOMETER INDICATOR
163BL511A		THERMOMETER INDICATOR
164472-01-01	2568U	FLIGHT MODE SELECTOR PANEL
164474-01-01	2724E	TOTAL AIR TEMP. - MAX. ENGINE PRESS. RATIO IND.
1646-1-6		DIMMABLE FLUORESCENT LAMP CONTROLLER
1646-1-6 MOD A		DIMMABLE FLUORESCENT LAMP CONTROLLER
1646-1-6 MOD B		DIMMABLE FLUORESCENT LAMP CONTROLLER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
1646-1-7		DIMMABLE FLUORESCENT LAMP CONTROLLER
1646-1-7 MOD A		DIMMABLE FLUORESCENT LAMP CONTROLLER
1646-1-7 MOD B		DIMMABLE FLUORESCENT LAMP CONTROLLER
166891-01-01	2577B	CDU
167173-01-03	.	ARINC I/O ASSY
167550-01-01	2577D	CDU
167550-02-01	2577D1	CDU
16906-1D		CONTROL PANEL
16906-1E		CONTROL PANEL
16906-1F		CONTROL PANEL
16906-1G	10-3056-511	CONTROL PANEL
16906-2C		CONTROL PANEL
16906-2D		CONTROL PANEL
16906-2E		CONTROL PANEL
16906-3C		CONTROL PANEL
16921-1A		CONTROL PANEL
16921-2A		CONTROL PANEL
16921-3A		CONTROL PANEL
16921-4A		CONTROL PANEL
16921-5A		CONTROL PANEL
16921-6A		CONTROL PANEL
16921-7A		CONTROL PANEL
16921-8A		CONTROL PANEL
16928-1A		CONTROL PANEL
16935-1A		CONTROL PANEL
16963-1A		CONTROL PANEL
16963-2A		CONTROL PANEL
16963-3A		CONTROL PANEL
16963-4A		CONTROL PANEL
16963-5A		CONTROL PANEL
16963-6A		CONTROL PANEL
16963-7A		CONTROL PANEL
17201-2-A		DIRECTIONAL GYRO
17209-4-A		DIRECTIONAL GYRO
17216-1A		DIRECTIONAL GYRO
17216-2A		DIRECTIONAL GYRO
17216-3A		DIRECTIONAL GYRO
17223-1A		DIRECTIONAL CONTROL
17223-1D		DIRECTIONAL CONTROL
17237-1A		DIRECTIONAL GYRO
17237-3A		DIRECTIONAL GYRO
17237-5A		DIRECTIONAL GYRO
17238-1A		DIRECTIONAL GYRO
17238-1B		DIRECTIONAL GYRO
17238-2A		DIRECTIONAL GYRO
17240-3A		DIRECTIONAL GYRO
17240-4A		DIRECTIONAL GYRO
17257-1A		DIRECTIONAL GYRO



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
1776167-2		DIRECTIONAL GYRO
1776167-3		DIRECTIONAL GYRO
1776365-201	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-202	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-203	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-204	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-205	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-207	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-208	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-209	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-324	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-325	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-354	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-355	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-358	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-359	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-424	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-425	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-454	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-455	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-458	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-459	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-600	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-601	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-602	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-603	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-604	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-605	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-606	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-607	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-620	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-621	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-622	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-623	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-624	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-625	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-626	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-627	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-700	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-701	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-702	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-703	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-704	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-705	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-706	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-707	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-720	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-721	HZ-4	HORIZON FLIGHT DIRECTOR IND.



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
1776365-722	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-723	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-724	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-725	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-726	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-727	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-824	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-825	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-854	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-855	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-858	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-859	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-924	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-925	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-954	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-955	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-958	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776365-959	HZ-4	HORIZON FLIGHT DIRECTOR IND.
1776366-600	R-4B	PICTORIAL DEVIATION INDICATOR
1776366-601	R-4B	PICTORIAL DEVIATION INDICATOR
1776366-602	R-4B	PICTORIAL DEVIATION INDICATOR
1776366-603	R-4B	PICTORIAL DEVIATION INDICATOR
1776366-610	R-4B	PICTORIAL DEVIATION INDICATOR
1776366-620	R-4B	PICTORIAL DEVIATION INDICATOR
1776366-621	R-4B	PICTORIAL DEVIATION INDICATOR
1777211-520	R-1	PICTORIAL DEVIATION INDICATOR
1777211-600	R-1	PICTORIAL DEVIATION INDICATOR
1777211-601	R-1	PICTORIAL DEVIATION INDICATOR
1777211-620	R-1	PICTORIAL DEVIATION INDICATOR
1777211-621	R-1	PICTORIAL DEVIATION INDICATOR
1777211-622	R-1	PICTORIAL DEVIATION INDICATOR
1777211-623	R-1	PICTORIAL DEVIATION INDICATOR
1777211-700	R-1	PICTORIAL DEVIATION INDICATOR
1777211-701	R-1	PICTORIAL DEVIATION INDICATOR
1777211-704	R-1	PICTORIAL DEVIATION INDICATOR
1777211-720	R-1	PICTORIAL DEVIATION INDICATOR
1777211-721	R-1	PICTORIAL DEVIATION INDICATOR
1777211-722	R-1	PICTORIAL DEVIATION INDICATOR
1777211-723	R-1	PICTORIAL DEVIATION INDICATOR
1777211-724	R-1	PICTORIAL DEVIATION INDICATOR
1777211-754	R-1	PICTORIAL DEVIATION INDICATOR
1777211-804	R-1	PICTORIAL DEVIATION INDICATOR
1777213	C-6	GYROSYN COMPASS INDICATOR
1777214	C-6A	GYROSYN COMPASS INDICATOR
1778007		TO- FROM SENSOR
1778686	C-6D	GYROSYN COMPASS INDICATOR
177BCL2		DUAL THERMOMETER INDICATOR
177BCL3W		DUAL THERMOMETER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
177BCL7		DUAL THERMOMETER INDICATOR
177BCL7A		DUAL THERMOMETER INDICATOR
177BCL7W		DUAL THERMOMETER INDICATOR
177BDL2A		DUAL THERMOMETER INDICATOR
177BDL2B		DUAL THERMOMETER INDICATOR
177BDL2C		DUAL THERMOMETER INDICATOR
177BDL2W		DUAL THERMOMETER INDICATOR
177BDL3A		DUAL THERMOMETER INDICATOR
177BDL3W		DUAL THERMOMETER INDICATOR
177BL100		DUAL THERMOMETER INDICATOR
17810-2AA1		HORIZON AND DIRECTOR INDICATOR
17810-2AA2		HORIZON AND DIRECTOR INDICATOR
17810-2AA3		HORIZON AND DIRECTOR INDICATOR
17810-2AB1		HORIZON AND DIRECTOR INDICATOR
17810-2AB2		HORIZON AND DIRECTOR INDICATOR
17810-2AC1		HORIZON AND DIRECTOR INDICATOR
17810-2AC4		HORIZON AND DIRECTOR INDICATOR
17810-2AC5		HORIZON AND DIRECTOR INDICATOR
17810-2AC6		HORIZON AND DIRECTOR INDICATOR
17810-2BA1		HORIZON AND DIRECTOR INDICATOR
17810-2BB1		HORIZON AND DIRECTOR INDICATOR
17810-2BC1		HORIZON AND DIRECTOR INDICATOR
17810-2CC1		HORIZON AND DIRECTOR INDICATOR
1783662-301	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-305	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-307	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-309	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-311	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-313	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-315	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-317	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-600	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-601	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-602	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-603	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-604	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-605	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-610	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-620	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-621	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-623	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-624	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-650	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-651	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-654	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-655	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-754	R-4A	PICTORIAL DEVIATION INDICATOR
1783662-823	R-4A	PICTORIAL DEVIATION INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
1783662-854	R-4A	PICTORIAL DEVIATION INDICATOR
1783755	C-6H	GYROSYN COMPASS INDICATOR
1783993-302		PICTORIAL DEVIATION INDICATOR
1783993-304		PICTORIAL DEVIATION INDICATOR
1783993-306		PICTORIAL DEVIATION INDICATOR
1783993-314		PICTORIAL DEVIATION INDICATOR
1783993-316		PICTORIAL DEVIATION INDICATOR
1783993-485		PICTORIAL DEVIATION INDICATOR
1783993-600		PICTORIAL DEVIATION INDICATOR
1783993-601		PICTORIAL DEVIATION INDICATOR
1783993-602		PICTORIAL DEVIATION INDICATOR
1783993-603		PICTORIAL DEVIATION INDICATOR
1783993-620		PICTORIAL DEVIATION INDICATOR
1783993-621		PICTORIAL DEVIATION INDICATOR
1783993-622		PICTORIAL DEVIATION INDICATOR
1783993-623		PICTORIAL DEVIATION INDICATOR
1783993-652		PICTORIAL DEVIATION INDICATOR
1783993-685		PICTORIAL DEVIATION INDICATOR
1783993-700		PICTORIAL DEVIATION INDICATOR
1783993-710		PICTORIAL DEVIATION INDICATOR
1783993-722		PICTORIAL DEVIATION INDICATOR
1783993-723		PICTORIAL DEVIATION INDICATOR
1783993-725		PICTORIAL DEVIATION INDICATOR
1783993-754		PICTORIAL DEVIATION INDICATOR
1784389	C-6J	GYROSYN COMPASS INDICATOR
1784460-355	C-6E	COMPASS INDICATOR
1784460-525	C-6E	COMPASS INDICATOR
1784460-555	C-6E	COMPASS INDICATOR
1784460-653	C-6E	COMPASS INDICATOR
1784460-655	C-6E	COMPASS INDICATOR
1784460-656	C-6E	COMPASS INDICATOR
1784460-657	C-6E	COMPASS INDICATOR
1784775-142	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-143	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-242	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-243	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-342	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-343	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-442	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-443	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1784775-444	HZ-6	HORIZON FLIGHT DIRECTOR INDICATOR
1797M32P01	AH2467-02	VALVE, SOLENOID SIGNAL, AIR
18-1105		HYDRAULIC PRESSURE INDICATOR
18-1258	10-60791-1	FLAP POSITION INDICATOR
18-1258-2	10-60791-3	FLAP POSITION INDICATOR
18-1258-3	10-60791-5	FLAP POSITION INDICATOR
18-1299		FLAP POSITION INDICATOR
18-1299-2		FLAP POSITION INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
18-1299-3		FLAP POSITION INDICATOR
18-1299-3-2		FLAP POSITION INDICATOR
18-1299-4		FLAP POSITION INDICATOR
18-1299-4-2		FLAP POSITION INDICATOR
18-1299-5		FLAP POSITION INDICATOR
18-1299-5-2		FLAP POSITION INDICATOR
18-1299-6	10-60791-13	FLAP POSITION INDICATOR
18-1299-6-2		FLAP POSITION INDICATOR
18-1299-7-2		FLAP POSITION INDICATOR
18-1505	10-60791-7	FLAP POSITION INDICATOR
18-1570-13		FLAP POSITION TRANSMITTER
18-1570-14		FLAP POSITION & STALL WARNING TRANSMITTER
18-1570-15		FLAP POSITION, STALL WRN'G & SPEED COMMAND
18-1585-10	60B80039	FLAP POSITION AND STALL WARNING TRANSMITTER
18-1585-11	60B80039	FLAP POSITION AND STALL WARNING TRANSMITTER
18-1585-14	60B80039	FLAP POSITION AND STALL WARNING TRANSMITTER
18-1585-15	60B80036	FLAP POSITION AND STALL WARNING TRANSMITTER
18-1686	1103-ARN	BEARING-DISTANCE HEADING INDICATOR
18-1686-2	1103A-ARN	BEARING-DISTANCE-HEADING INDICATOR
18-1728		PRESSURE INDICATOR
18-1738-1	10-61841-1	FLAP POSITION & STALL WARNING TX
18-1738-3	10-61841-3	FLAP POSITION & STALL WARNING TX
18-1738-5	10-61841-5	FLAP POSITION, STALL WARNING & A/P TRANSMITTER
18-1738-52	10-61841-52	FLAP POSITION, STALL WARNING & A/P TRANSMITTER
18-1738-6	10-61841-6	TRANSMITTER, FLAP POSITION & STALL WARNING
18-1738-7	10-61841-7	TRANSMITTER, FLAP POSITION & STALL WARNING
18-1738-8	10-61841-8	TRANSMITTER, FLAP POSITION
18-1738-9	10-61841-9	TRANSMITTER, FLAP POSITION & STALL WARNING
18-1739-2	10-61841-2	FLAP POSITION, STALL WARNING & A/P TRANSMITTER
18-1739-4	10-61841-4	FLAP POSITION, STALL WARNING & A/P TRANSMITTER
18-1851	10-60791-14	FLAP POSITION INDICATOR
18-1958-10	S256T007-10	FLAP POSITION TRASMMITTER
18-1958-11	S256T007-11	FLAP POSITION TRANSMITTER
18-1958-12	S256T007-12	FLAP POSITION TRASMMITTER
18-1958-13	S256T007-13	FLAP POSITION TRANSMITTER
18-1958-14	S256T007-14	FLAP POSITION TRASMMITTER
18-1958-15	S256T007-15	FLAP POSITION TRANSMITTER
18-1958-16	S256T007-16	FLAP POSITION TRANSMITTER
18-1958-17	S256T007-15	FLAP POSITION TRASMMITTER
18-1958-19	S256T007-19	FLAP POSITION TRANSMITTER
18-1958-20	S256T007-20	FLAP POSITION TRANSMITTER
18-1958-21	S256T007-21	FLAP POSITION TRASMMITTER
18-1968-3	S251N119-3	WHEEL COMMAND TRANSDUCER
18-1968-31	S251N119-31	WHEEL COMMAND TRANSDUCER
18-1969-13	S251N403-13	TRAILING EDGE POSITION TRANSMITTER
18-1969-17	18-1969	POSITION TRANSMITTER, TRAILING EDGE LEFT
18-1969-18	18-1969	POSITION TRANSMITTER, TRAILING EDGE LEFT
181RA71R206	S451T201-10	CARGO SYSTEM POWER DRIVE UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
181RA71R206A	S451T201-11	CARGO SYSTEM POWER DRIVE UNIT
181RA71R206B	S451T201-12	CARGO SYSTEM POWER DRIVE UNIT
181RA71R206C	S451T201-13	CARGO SYSTEM POWER DRIVE UNIT
1822-337LW	522396	HYD. QTY. LEVEL INDICATOR
1825		FIRE/OVERHEAT DETECTOR ASSY.
1825-1		FIRE/OVERHEAT DETECTOR ASSY.
1825-101LW	522540	HYD PRESSURE INDICATOR
1825-2		FIRE/OVERHEAT DETECTOR ASSY.
182770	1862	RUDDER TRIM AND POSITION INDICATOR
182936	1122-19LW	OXYGEN PRESSURE INDICATOR
182972	1122-20	OXYGEN PRESSURE INDICATOR
18300-1AA1		REMOTE ATTITUDE INDICATOR
18300-1AB1		REMOTE ATTITUDE INDICATOR
18300-1BA1		REMOTE ATTITUDE INDICATOR
18300-1BB1		REMOTE ATTITUDE INDICATOR
185.076	10-60757-53	AC AMMETER
1851M36P02	3505945-2	ENGINE AIR TURBINE STARTER
1851M36P03	3505945-3	ENGINE AIR TURBINE STARTER
1851M36P04	3505945-4	ENGINE AIR TURBINE STARTER
1851M36P05	3505945-5	ENGINE AIR TURBINE STARTER
1851M36P06	3505945-6	ENGINE AIR TURBINE STARTER
1851M36P07	3505945-7	ENGINE AIR TURBINE STARTER
1851M36P08	3505945-8	ENGINE AIR TURBINE STARTER
1851M36P09	3505945-9	ENGINE AIR TURBINE STARTER
1851M36P10	3505945-10	ENGINE AIR TURBINE STARTER
189740-2		BLEED AIR
189740-3		BLEED AIR
1903431-1		ENGINE PRESSURE RATIO INDICATOR
1903585-1		RADIO DISTANCE MAGNETIC INDICATOR
1903585-2		RADIO DISTANCE MAGNETIC INDICATOR
1903585-3		RADIO DISTANCE MAGNETIC INDICATOR
19101-2A		RATE GYRO
19102-1C		RATE GYRO
19117-1A		THREE AXIS RATE GYROSCOPE
19118-1A		THREE AXIS RATE GYROSCOPE
1925756-1		ATTITUDE DIRECTOR INDICATOR
1925756-2		ATTITUDE DIRECTOR INDICATOR
195PN01		TRIM POSITION DISPLAY PANEL
195PN01Y01		TRIM POSITION DISPLAY PANEL
1964193-5		LINEAR ACCELEROMETER
1964193-6		LINEAR ACCELEROMETER
1964193-7		LINEAR ACCELEROMETER
1964771-3		ELECTRICAL INVERTER
196PN01Y02		RUDDER TRIM INDICATOR
1978121-1		VERTICAL GYROSCOPE
1978191-1		3" ATTITUDE INDICATOR
1G113		PRESSURE SWITCH
1G309		PRESSURE SWITCH





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
1G386		PRESSURE SWITCH
1X2005012-00		CARGO LOAD AREA LIGHT
1X2005097-00		LOGO LIGHT
200-037-002A		FUEL QUANTITY INDICATOR
20041-0000-03	10-60722-11	LIQUID QUANTITY ENGINE OIL TRANSMITTER
201-004-001		TORQUEMETER INDICATOR
2013-01-1		BAROMETRIC SETTING POTENTIOMETER
2013-02-1		BAROMETRIC SETTING POTENTIOMETER
2022522-1		ELECTROMECHANICAL ACTUATOR COMPONENT
2022522-2		ELECTROMECHANICAL ACTUATOR COMPONENT
2022522-3		ELECTROMECHANICAL ACTUATOR COMPONENT
2022522-4		ELECTROMECHANICAL ACTUATOR COMPONENT
2022522-5		ELECTROMECHANICAL ACTUATOR COMPONENT
2022538-101	S451T201-15	CARGO POWERED DRIVE UNIT
2022538-3		CARGO POWERED DRIVE UNIT
2022538-4	S451T201-4	CARGO POWERED DRIVE UNIT
2022538-5	S451T201-5	CARGO POWERED DRIVE UNIT
2022538-6	S451T201-7	CARGO POWERED DRIVE UNIT
2022538-7	S451T201-7	CARGO POWERED DRIVE UNIT
2022538-8	S451T201-7	CARGO POWERED DRIVE UNIT
203-021-003		FUEL QUANTITY INDICATOR
203-022-005		ENG. OIL TEMPERATURE & PRESSURE INDICATOR
203-022-017		ENG. OIL TEMPERATURE & PRESSURE INDICATOR
2033-02-1	B0652-71108-1	ALTITUDE ALERT CONTROL
204-013-004		TOTALIZER INDICATOR
2041053-8301	PRA-83A	PRESSURE RATE SENSOR
2041220-0401	CON-4B	CONTROL UNIT
2041220-0402	CON-4B	CONTROL UNIT
2041220-0404	CON-4B	CONTROL UNIT
2041220-0405	CON-4B	CONTROL UNIT
2041220-0406	CON-4B	CONTROL UNIT
2041220-0407	CON-4B	CONTROL UNIT
2041220-0408	CON-4B	CONTROL UNIT
2041220-0409	CON-4B	CONTROL UNIT
2041220-0410	CON-4B	CONTROL UNIT
2041220-0411	CON-4B	CONTROL UNIT
2041220-0412	CON-4B	CONTROL UNIT
2041220-0413	CON-4B	CONTROL UNIT
2041220-0414	CON-4B	CONTROL UNIT
2041220-0415	CON-4B	CONTROL UNIT
2041220-0416	CON-4B	CONTROL UNIT
2041220-0417	CON-4B	CONTROL UNIT
2041220-0418	CON-4B	CONTROL UNIT
2041220-0419	CON-4B	CONTROL UNIT
2041220-0424	CON-4B	CONTROL UNIT
2041220-0425	CON-4B	CONTROL UNIT
2041220-0426	CON-4B	CONTROL UNIT
2041220-0427	CON-4B	CONTROL UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2041220-0429	CON-4B	CONTROL UNIT
2041220-0430	CON-4B	CONTROL UNIT
2041220-1405	CON-4B	CONTROL UNIT
2041220-1406	CON-4B	CONTROL UNIT
2041220-1407	CON-4B	CONTROL UNIT
2041220-1409	CON-4B	CONTROL UNIT
2041220-1413	CON-4B	CONTROL UNIT
2041220-3231	CON-4B	CONTROL UNIT
2041223-0401	CON-4A	CONTROL UNIT
2041223-0402	CON-4A	CONTROL UNIT
2041223-0404	CON-4A	CONTROL UNIT
2041223-0407	CON-4A	CONTROL UNIT
2041223-0408	CON-4A	CONTROL UNIT
2041223-0409	CON-4A	CONTROL UNIT
2041223-0410	CON-4A	CONTROL UNIT
2041223-0411	CON-4A	CONTROL UNIT
2041223-0412	CON-4A	CONTROL UNIT
2041223-0413	CON-4A	CONTROL UNIT
2041223-0414	CON-4A	CONTROL UNIT
2041223-0415	CON-4A	CONTROL UNIT
2041223-0416	CON-4A	CONTROL UNIT
2041223-0417	CON-4A	CONTROL UNIT
2041223-0418	CON-4A	CONTROL UNIT
2041223-0419	CON-4A	CONTROL UNIT
2041223-0421	CON-4A	CONTROL UNIT
2041223-0424	CON-4A	CONTROL UNIT
2041223-0425	CON-4A	CONTROL UNIT
2041223-0426	CON-4A	CONTROL UNIT
2041223-0427	CON-4A	CONTROL UNIT
2041223-3131	CON-4A	CONTROL UNIT
2041223-3132	CON-4A	CONTROL UNIT
2041223-3133	CON-4A	CONTROL UNIT
2041223-3134	CON-4A	CONTROL UNIT
2041223-3135	CON-4A	CONTROL UNIT
2041223-3136	CON-4A	CONTROL UNIT
204-1A		EGT/ CHT INDICATOR
2045-05-1		ENGINE PRESSURE RATIO INDICATOR
2045-06	10-60737-14	ENGINE PRESSURE RATIO INDICATOR
2045-06-1	10-60737-14	ENGINE PRESSURE RATIO INDICATOR
2045-08	10-60737-16	ENGINE PRESSURE RATIO INDICATOR
2045-08-1	10-60737-16	ENGINE PRESSURE RATIO INDICATOR
2048-01-1	10-60737-15	ENGINE PRESSURE RATIO INDICATOR
2050-01-1		SERVOED ALTITUDE INDICATOR
2050-04-1		SERVOED ALTITUDE INDICATOR
2050-10-1		SERVOED ALTITUDE INDICATOR
205-1A		EGT/CHT INDICATOR
2054-01-1	10-61826-5	SERVOED ALTITUDE INDICATOR
2055-01-1	10-618126-6	SERVOED ALTITUDE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2056-01-1	10-61826-7	SERVOED ALTITUDE INDICATOR
2057-01-1	10-61826-8	SERVOED ALTITUDE INDICATOR
2057-02-1	10-61826-10	SERVOED ALTITUDE INDICATOR
206-001-001R		MASTER INDICATOR
206-001-001W		MASTER INDICATOR
206-001-002R		MASTER INDICATOR
206-001-002W		MASTER INDICATOR
206-001-003R		MASTER INDICATOR
206-001-003W		MASTER INDICATOR
206-001-004R		MASTER INDICATOR
206-001-004W		MASTER INDICATOR
206-075-185-1	4308-3018	TORQUE METER
206-075-682-105	DL412-57	TACHOMETER INDICATOR, GAS PRODUCER
206-075-682-107	DL412-61	TACHOMETER INDICATOR, GAS PRODUCER
206-075-682-109	DL412-63	TACHOMETER INDICATOR, GAS PRODUCER
2061-11-1	10-61926-1	FLAP POSITION INDICATOR
2061-12-1	10-61926-2	FLAP POSITION INDICATOR
2061-13-1	10-61926-3	FLAP POSITION INDICATOR
2061-14-1	10-61926-4	FLAP POSITION INDICATOR
2061-15-1	10-61926-5	FLAP POSITION INDICATOR
206-1A		EGT/CHT INDICATOR
2067635-0701	INA-51A	ALTIMETER INDICATOR
2067635-0702	INA-51A	ALTIMETER INDICATOR
2067635-0703	INA-51A	ALTIMETER INDICATOR
2067635-0704	INA-51A	ALTIMETER INDICATOR
2067635-0705	INA-51A	ALTIMETER INDICATOR
2067635-0706	INA-51A	ALTIMETER INDICATOR
2067635-0707	INA-51A	ALTIMETER INDICATOR
2067635-0711	INA-51A	ALTIMETER INDICATOR
2067635-5112	INA-51A	ALTIMETER INDICATOR
2067635-5113	INA-51A	ALTIMETER INDICATOR
2067635-5114	INA-51A	ALTIMETER INDICATOR
2067635-5115	INA-51A	ALTIMETER INDICATOR
2067635-5116	INA-51A	ALTIMETER INDICATOR
2067635-5117	INA-51A	ALTIMETER INDICATOR
2067635-5119	INA-51A	ALTIMETER INDICATOR
2067635-5120	INA-51A	ALTIMETER INDICATOR
2067635-5121	INA-51A	ALTIMETER INDICATOR
2067635-5122	INA-51A	ALTIMETER INDICATOR
2067635-5123	INA-51A	ALTIMETER INDICATOR
2067968-0701	INA-51B	ALTIMETER INDICATOR
2067968-5102	INA-51B	ALTIMETER INDICATOR
2070-03-1		VERTICAL SPEED INDICATOR
2070-04-1		VERTICAL SPEED INDICATOR
2070-05-1		VERTICAL SPEED INDICATOR
2070135-5101	INA-51D	ALTIMETER INDICATOR
2070484-5103	INA-51V	ALTIMETER INDICATOR
2070484-5106	INA-51V	ALTIMETER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2070484-5107	INA-51V	ALTIMETER INDICATOR
2070484-5110	INA-51V	ALTIMETER INDICATOR
2083-02		MACH AIRSPEED INDICATOR
2083-05		MACH AIRSPEED INDICATOR
2083-06		MACH AIRSPEED INDICATOR
2083-07		MACH AIRSPEED INDICATOR
2083-08-1	10-61818-151	MACH AIRSPEED INDICATOR
2083-09-1	10-61818-161	MACH AIRSPEED INDICATOR
2083-10-1	10-61818-171	MACH AIRSPEED INDICATOR
2083-11-1	10-61818-18	MACH AIRSPEED INDICATOR
2094-0011		WATER QTY INDICATOR
2101-01-1	10-61219-112	FUEL QUANTITY REPEATER INDICATOR
2101-01-2	10-61219-112	FUEL QUANTITY REPEATER INDICATOR
210-1A		EGT/CHT INDICATOR
2107-01-1		FUEL QUANTITY REPEATER INDICATOR
21071-01AA		ELECTRONIC BOX
21071-02AC		ELECTRONIC BOX
21071-03AC		ELECTRONIC BOX
210TS07		L/G CONTROL LEVER
210TS07Y01		L/G CONTROL LEVER
21140-1120		AIRSPEED INDICATOR
211EDP1-1	10-62178-201	E.I.S. SECONDARY DISPLAY PANEL
211EDP1-2	10-62178-201	E.I.S. SECONDARY DISPLAY PANEL
211EDP1-3	10-62178-201	E.I.S. SECONDARY DISPLAY PANEL
2120-51-1	10-61219-174	FUEL QUANTITY INDICATOR
2120-52-1	10-61219-170	FUEL QUANTITY INDICATOR
2120-53-1	10-61219-180	FUEL QUANTITY INDICATOR
2120-54-1	10-61219-179	FUEL QUANTITY INDICATOR
2120-61-1	10-61219-175	FUEL QUANTITY INDICATOR
2120-62-1	10-61219-171	FUEL QUANTITY INDICATOR
212-070-160-107	18-1838-107	DUAL TORQUE INDICATOR
212-070-160-15	18-1838-15	DUAL TORQUE INDICATOR
212-070-160-17	18-1838-17	DUAL TORQUE INDICATOR
212EDP1-1	10-62178-202	E.I.S. SECONDARY DISPLAY PANEL
212EDP1-2	10-62178-202	E.I.S. SECONDARY DISPLAY PANEL
212EDP1-3	10-62178-202	E.I.S. SECONDARY DISPLAY PANEL
2136-113-8		DC VOLTMETER
2136-213-8		AC VOLTMETER
2136-313-8		DC AMMETER
2136-315-80-11		AMMETER
2136-423-8		AC CHARGE INDICATOR
2136-424-8		AC CHARGE INDICATOR
2136-430-80-11		DE-ICING INDICATOR
2136-713-8		FREQUENCY METER
214C40-1-115		ALTITUDE SWITCH
214C40-1-71		ALTITUDE SWITCH
214C40-1-75		ALTITUDE SWITCH
214C40-1-77		ALTITUDE SWITCH



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
215TS07Y00		L/G CONTROL LEVER
217-01161		TORQUE PRESSURE INDICATOR
217-07241		OIL PRESSURE INDICATOR
217-09261		TORQUE PRESSURE INDICATOR
217-12241		TORQUE PRESSURE INDICATOR
21SN04-123		PRESSURE SWTICH ASSEMBLY
21SN04-124		PRESSURE SWTICH ASSEMBLY
21SN04-148		PRESSURE SWTICH ASSEMBLY
21SN04-149		PRESSURE SWTICH ASSEMBLY
21SN04-19A		PRESSURE SWTICH ASSEMBLY
21SN04-19B		PRESSURE SWTICH ASSEMBLY
21SN04-20A		PRESSURE SWTICH ASSEMBLY
21SN41-13		PRESSURE SWTICH ASSEMBLY
21SN41-1A		PRESSURE SWTICH ASSEMBLY
21SN41-1B		PRESSURE SWITCH ASSEMBLY
21SN41-30		PRESSURE SWTICH ASSEMBLY
21SN41-4		PRESSURE SWTICH ASSEMBLY
21SN41-42		PRESSURE SWTICH ASSEMBLY
21SN41-49		PRESSURE SWITCH ASSEMBLY
21SN41-49A		PRESSURE SWITCH ASSEMBLY
21SN41-4A		PRESSURE SWITCH ASSEMBLY
21SN41-5		PRESSURE SWITCH ASSEMBLY
21SN41-52		PRESSURE SWITCH ASSEMBLY
21SN41-5A		PRESSURE SWITCH ASSEMBLY
21SN41-84		PRESSURE SWITCH ASSEMBLY
220FL		DESYNN POSITION INDICATOR
221D5102-503	325855-1	NACELLE COOLING VALVE
221D5102-505	325855-2	NACELLE COOLING VALVE
221D5102-507	325855-3	NACELLE COOLING VALVE
221FL		DESYNN POSITION INDICATOR
221FLSB		DESYNN POSITION INDICATOR
2290B010000		CHECK VALVE
2290B020000		CHECK VALVE
229165		MOTOR ACTUATED BUTTERFLY SHUTOFF VALVE
2293B010000		CHECK VALVE
2293B020000		CHECK VALVE
2-301		BATTERY CHARGER ASSEMBLY
2-301-3	10-60701-3	BATTERY CHARGER ASSEMBLY
2307-02-1	60B92017-23	FUEL QUANTITY INDICATOR
2307-04-1	60B92017-29	FUEL QUANTITY INDICATOR
2311M69-1	XW20548-M1	WINDSHIELD WIPER MOTOR ASSEMBLY
2311M69-2	XW20548-M1A	WINDSHIELD WIPER MOTOR ASSEMBLY
2311M69-3	XW20548-M1A-1	WINDSHIELD WIPER MOTOR ASSEMBLY
2311M69-4	XW20548-M1A-2	WINDSHIELD WIPER MOTOR ASSEMBLY
2311M69-5	XW20548-M1A-3	WINDSHIELD WIPER MOTOR ASSEMBLY
2311M69-6	XW20548-M1A-4	WINDSHIELD WIPER MOTOR ASSEMBLY
231-2	65-52803-8	WINDSHIELD TEMPERATURE CONTROLLER
233N2220-10		FORWARD PANEL MODULE ASSY, P1-1



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N2220-11		FORWARD PANEL MODULE ASSY, P1-1
233N2220-12		FORWARD PANEL MODULE ASSY, P1-1
233N2220-13		FORWARD PANEL MODULE ASSY, P1-1
233N2220-14		FORWARD PANEL MODULE ASSY, P1-1
233N2220-15		FORWARD PANEL MODULE ASSY, P1-1
233N2220-16		FORWARD PANEL MODULE ASSY, P1-1
233N2220-17		FORWARD PANEL MODULE ASSY, P1-1
233N2220-18		FORWARD PANEL MODULE ASSY, P1-1
233N2220-19		FORWARD PANEL MODULE ASSY, P1-1
233N2220-20		FORWARD PANEL MODULE ASSY, P1-1
233N2220-21		FORWARD PANEL MODULE ASSY, P1-1
233N2220-22		FORWARD PANEL MODULE ASSY, P1-1
233N2220-23		FORWARD PANEL MODULE ASSY, P1-1
233N2220-301		FORWARD PANEL MODULE ASSY, P1-1
233N2220-302		FORWARD PANEL MODULE ASSY, P1-1
233N2220-305		FORWARD PANEL MODULE ASSY, P1-1
233N2220-306		FORWARD PANEL MODULE ASSY, P1-1
233N2220-307		FORWARD PANEL MODULE ASSY, P1-1
233N2220-308		FORWARD PANEL MODULE ASSY, P1-1
233N2220-309		FORWARD PANEL MODULE ASSY, P1-1
233N2220-310		FORWARD PANEL MODULE ASSY, P1-1
233N2220-311		FORWARD PANEL MODULE ASSY, P1-1
233N2220-312		FORWARD PANEL MODULE ASSY, P1-1
233N2220-313		FORWARD PANEL MODULE ASSY, P1-1
233N2220-314		FORWARD PANEL MODULE ASSY, P1-1
233N2220-315		FORWARD PANEL MODULE ASSY, P1-1
233N2220-316		FORWARD PANEL MODULE ASSY, P1-1
233N2221-16		FORWARD PANEL MODULE ASSY, P1-3
233N2221-17		FORWARD PANEL MODULE ASSY, P1-3
233N2221-23		FORWARD PANEL MODULE ASSY, P1-3
233N2221-24		FORWARD PANEL MODULE ASSY, P1-3
233N2221-25		FORWARD PANEL MODULE ASSY, P1-3
233N2221-26		FORWARD PANEL MODULE ASSY, P1-3
233N2221-27		FORWARD PANEL MODULE ASSY, P1-3
233N2221-29		FORWARD PANEL MODULE ASSY, P1-3
233N2221-30		FORWARD PANEL MODULE ASSY, P1-3
233N2221-301		FORWARD PANEL MODULE ASSY, P1-3
233N2221-302		FORWARD PANEL MODULE ASSY, P1-3
233N2221-303		FORWARD PANEL MODULE ASSY, P1-3
233N2221-304		FORWARD PANEL MODULE ASSY, P1-3
233N2221-305		FORWARD PANEL MODULE ASSY, P1-3
233N2221-307		FORWARD PANEL MODULE ASSY, P1-3
233N2221-31		FORWARD PANEL MODULE ASSY, P1-3
233N2221-310		FORWARD PANEL MODULE ASSY, P1-3
233N2221-311		FORWARD PANEL MODULE ASSY, P1-3
233N2221-312		FORWARD PANEL MODULE ASSY, P1-3
233N2221-313		FORWARD PANEL MODULE ASSY, P1-3
233N2221-314		FORWARD PANEL MODULE ASSY, P1-3



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N2221-315		FORWARD PANEL MODULE ASSY, P1-3
233N2221-316		FORWARD PANEL MODULE ASSY, P1-3
233N2221-317		FORWARD PANEL MODULE ASSY, P1-3
233N2221-318		FORWARD PANEL MODULE ASSY, P1-3
233N2221-319		FORWARD PANEL MODULE ASSY, P1-3
233N2221-32		FORWARD PANEL MODULE ASSY, P1-3
233N2222-16		FORWARD PANEL MODULE ASSY,P3-1
233N2222-18		FORWARD PANEL MODULE ASSY,P3-1
233N2222-19		FORWARD PANEL MODULE ASSY,P3-1
233N2222-20		FORWARD PANEL MODULE ASSY,P3-1
233N2222-301		FORWARD PANEL MODULE ASSY,P3-1
233N2222-302		FORWARD PANEL MODULE ASSY,P3-1
233N2222-304		FORWARD PANEL MODULE ASSY,P3-1
233N2222-305		FORWARD PANEL MODULE ASSY,P3-1
233N2222-307		FORWARD PANEL MODULE ASSY,P3-1
233N2222-308		FORWARD PANEL MODULE ASSY,P3-1
233N2222-309		FORWARD PANEL MODULE ASSY,P3-1
233N2222-311		FORWARD PANEL MODULE ASSY,P3-1
233N2222-312		FORWARD PANEL MODULE ASSY,P3-1
233N2222-313		FORWARD PANEL MODULE ASSY,P3-1
233N2222-314		FORWARD PANEL MODULE ASSY,P3-1
233N2222-315		FORWARD PANEL MODULE ASSY,P3-1
233N2222-316		FORWARD PANEL MODULE ASSY,P3-1
233N2222-317		FORWARD PANEL MODULE ASSY,P3-1
233N2222-318		FORWARD PANEL MODULE ASSY,P3-1
233N2222-319		FORWARD PANEL MODULE ASSY,P3-1
233N2222-32		FORWARD PANEL MODULE ASSY,P3-1
233N2222-320		FORWARD PANEL MODULE ASSY,P3-1
233N2222-321		FORWARD PANEL MODULE ASSY,P3-1
233N2222-324		FORWARD PANEL MODULE ASSY,P3-1
233N2222-326		FORWARD PANEL MODULE ASSY,P3-1
233N2222-327		FORWARD PANEL MODULE ASSY,P3-1
233N2223-10		FORWARD PANEL MODULE ASSY,P3-3
233N2223-11		FORWARD PANEL MODULE ASSY,P3-3
233N2223-12		FORWARD PANEL MODULE ASSY,P3-3
233N2223-13		FORWARD PANEL MODULE ASSY,P3-3
233N2223-14		FORWARD PANEL MODULE ASSY,P3-3
233N2223-15		FORWARD PANEL MODULE ASSY,P3-3
233N2223-16		FORWARD PANEL MODULE ASSY,P3-3
233N2223-17		FORWARD PANEL MODULE ASSY,P3-3
233N2223-20		FORWARD PANEL MODULE ASSY,P3-3
233N2223-21		FORWARD PANEL MODULE ASSY,P3-3
233N2223-22		FORWARD PANEL MODULE ASSY,P3-3
233N2223-24		FORWARD PANEL MODULE ASSY,P3-3
233N2223-25		FORWARD PANEL MODULE ASSY,P3-3
233N2223-26		FORWARD PANEL MODULE ASSY,P3-3
233N2223-301		FORWARD PANEL MODULE ASSY,P3-3
233N2223-302		FORWARD PANEL MODULE ASSY,P3-3



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N2223-304		FORWARD PANEL MODULE ASSY,P3-3
233N2223-305		FORWARD PANEL MODULE ASSY,P3-3
233N2223-306		FORWARD PANEL MODULE ASSY,P3-3
233N2223-307		FORWARD PANEL MODULE ASSY,P3-3
233N2223-308		FORWARD PANEL MODULE ASSY,P3-3
233N2223-309		FORWARD PANEL MODULE ASSY,P3-3
233N2223-310		FORWARD PANEL MODULE ASSY,P3-3
233N2223-311		FORWARD PANEL MODULE ASSY,P3-3
233N2223-313		FORWARD PANEL MODULE ASSY,P3-3
233N2223-315		FORWARD PANEL MODULE ASSY,P3-3
233N2223-316		FORWARD PANEL MODULE ASSY,P3-3
233N2223-317		FORWARD PANEL MODULE ASSY,P3-3
233N3209-1012		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1014		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1016		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1018		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1019		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1020		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1022		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1023		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1024		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1025		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1026		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1027		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1028		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1029		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1034		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-12		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1300		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1301		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1302		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1303		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1304		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1305		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1306		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1307		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1308		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1309		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1310		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1311		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1312		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1313		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1314		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-1315		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-14		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-16		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-18		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-19		ELECTRICAL SYSTEM PANEL ASSY, M10063





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N3209-20		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-22		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-23		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-24		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-25		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-26		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-27		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-28		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-29		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-300		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-301		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-302		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-303		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-304		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-305		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-306		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-307		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-308		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-309		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-310		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-311		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-312		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-313		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-314		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3209-34		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N3211-1008		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1011		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1015		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1019		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1020		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1024		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1025		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1026		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1027		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1029		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1030		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1031		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1032		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1033		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1034		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1035		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1036		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1037		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1038		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1039		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1040		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1041		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1042		BATTERY/STANDBY POWER PANEL ASSY, M10062



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N3211-1046		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-11		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1300		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1301		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1302		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1303		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1304		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1305		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1306		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1307		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1308		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1309		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1311		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1312		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1313		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1314		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1315		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1316		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1317		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1318		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-1319		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-15		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-19		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-20		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-24		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-25		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-26		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-27		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-29		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-30		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-300		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-301		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-302		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-303		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-304		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-305		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-306		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-307		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-308		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-309		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-31		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-311		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-312		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-313		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-315		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-316		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-317		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-319		BATTERY/STANDBY POWER PANEL ASSY, M10062



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N3211-32		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-321		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-33		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-34		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-35		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-36		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-37		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-38		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-39		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-40		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-41		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-42		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-46		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3211-8		BATTERY/STANDBY POWER PANEL ASSY, M10062
233N3214-22		LIGHTING CTRL PANEL ASSY, M10056
233N3214-24		LIGHTING CTRL PANEL ASSY, M10056
233N3214-26		LIGHTING CTRL PANEL ASSY, M10056
233N3214-27		LIGHTING CTRL PANEL ASSY, M10056
233N3214-28		LIGHTING CTRL PANEL ASSY, M10056
233N3214-29		LIGHTING CTRL PANEL ASSY, M10056
233N3214-300		LIGHTING CTRL PANEL ASSY, M10056
233N3214-301		LIGHTING CTRL PANEL ASSY, M10056
233N3214-302		LIGHTING CTRL PANEL ASSY, M10056
233N3214-303		LIGHTING CTRL PANEL ASSY, M10056
233N3214-304		LIGHTING CTRL PANEL ASSY, M10056
233N3214-305		LIGHTING CTRL PANEL ASSY, M10056
233N3214-306		LIGHTING CTRL PANEL ASSY, M10056
233N3214-31		LIGHTING CTRL PANEL ASSY, M10056
233N3214-32		LIGHTING CTRL PANEL ASSY, M10056
233N3214-33		LIGHTING CTRL PANEL ASSY, M10056
233N3214-34		LIGHTING CTRL PANEL ASSY, M10056
233N3214-38		LIGHTING CTRL PANEL ASSY, M10056
233N3214-41		LIGHTING CTRL PANEL ASSY, M10056
233N3216-1014		YAW DAMPER PANEL ASSY, M10250
233N3216-1015		YAW DAMPER PANEL ASSY, M10250
233N3216-1018		YAW DAMPER PANEL ASSY, M10250
233N3216-1019		YAW DAMPER PANEL ASSY, M10250
233N3216-1020		YAW DAMPER PANEL ASSY, M10250
233N3216-1021		YAW DAMPER PANEL ASSY, M10250
233N3216-1022		YAW DAMPER PANEL ASSY, M10250
233N3216-1023		YAW DAMPER PANEL ASSY, M10250
233N3216-1024		YAW DAMPER PANEL ASSY, M10250
233N3216-1025		YAW DAMPER PANEL ASSY, M10250
233N3216-1026		YAW DAMPER PANEL ASSY, M10250
233N3216-1027		YAW DAMPER PANEL ASSY, M10250
233N3216-1030		YAW DAMPER PANEL ASSY, M10250
233N3216-1300		YAW DAMPER PANEL ASSY, M10250
233N3216-1301		YAW DAMPER PANEL ASSY, M10250



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N3216-1302		YAW DAMPER PANEL ASSY, M10250
233N3216-1303		YAW DAMPER PANEL ASSY, M10250
233N3216-1304		YAW DAMPER PANEL ASSY, M10250
233N3216-1305		YAW DAMPER PANEL ASSY, M10250
233N3216-1306		YAW DAMPER PANEL ASSY, M10250
233N3216-1307		YAW DAMPER PANEL ASSY, M10250
233N3216-1308		YAW DAMPER PANEL ASSY, M10250
233N3216-1309		YAW DAMPER PANEL ASSY, M10250
233N3216-1310		YAW DAMPER PANEL ASSY, M10250
233N3216-1311		YAW DAMPER PANEL ASSY, M10250
233N3216-1312		YAW DAMPER PANEL ASSY, M10250
233N3216-1313		YAW DAMPER PANEL ASSY, M10250
233N3216-14		YAW DAMPER PANEL ASSY, M10250
233N3216-15		YAW DAMPER PANEL ASSY, M10250
233N3216-18		YAW DAMPER PANEL ASSY, M10250
233N3216-19		YAW DAMPER PANEL ASSY, M10250
233N3216-20		YAW DAMPER PANEL ASSY, M10250
233N3216-21		YAW DAMPER PANEL ASSY, M10250
233N3216-22		YAW DAMPER PANEL ASSY, M10250
233N3216-23		YAW DAMPER PANEL ASSY, M10250
233N3216-24		YAW DAMPER PANEL ASSY, M10250
233N3216-25		YAW DAMPER PANEL ASSY, M10250
233N3216-26		YAW DAMPER PANEL ASSY, M10250
233N3216-27		YAW DAMPER PANEL ASSY, M10250
233N3216-30		YAW DAMPER PANEL ASSY, M10250
233N3216-300		YAW DAMPER PANEL ASSY, M10250
233N3216-301		YAW DAMPER PANEL ASSY, M10250
233N3216-302		YAW DAMPER PANEL ASSY, M10250
233N3216-303		YAW DAMPER PANEL ASSY, M10250
233N3216-304		YAW DAMPER PANEL ASSY, M10250
233N3216-305		YAW DAMPER PANEL ASSY, M10250
233N3216-306		YAW DAMPER PANEL ASSY, M10250
233N3216-307		YAW DAMPER PANEL ASSY, M10250
233N3216-309		YAW DAMPER PANEL ASSY, M10250
233N3218-6		CABIN PRESS/LOW FLOW PANEL ASSY. M10039
233N3222-300		APU START PANEL ASSY M10324
233N3222-8		APU START PANEL ASSY M10324
233N6202-1		RADIO TRANSMIT CONTROL PANEL ASSY, M10370
233N6203-1007		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1009		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1012		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1013		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1021		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1023		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1024		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-103		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1032		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1035		APU & CARGO FIRE CNTRL PANEL ASSY, M10444



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N6203-1036		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-104		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1045		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1046		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1047		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1048		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-105		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1053		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1056		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1067		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1070		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1073		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1075		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1077		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1079		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1081		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1082		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1084		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1085		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1086		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-109		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-110		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1103		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1104		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1105		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1109		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-111		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1110		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1111		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1112		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1114		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1117		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-112		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1120		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1123		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1126		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1129		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1132		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1135		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1138		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-114		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1143		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1144		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1146		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1157		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1161		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1162		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1163		APU & CARGO FIRE CNTRL PANEL ASSY, M10444



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N6203-1164		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1165		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1166		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1169		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-117		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1170		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1171		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1172		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1173		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1174		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1175		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1177		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1178		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1179		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1180		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1181		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1182		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1183		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1184		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1185		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1186		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1187		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1188		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1189		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1190		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1191		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1192		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1193		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1194		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1195		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1196		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1197		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1198		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1199		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-12		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-120		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1200		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1201		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1202		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1203		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1206		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1219		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1220		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1221		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1222		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1226		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-123		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-126		APU & CARGO FIRE CNTRL PANEL ASSY, M10444



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N6203-129		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-13		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1301		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1302		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1303		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1304		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1305		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1306		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-132		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1339		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1340		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1341		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1342		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1343		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1344		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1345		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1347		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1348		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1349		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-135		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1350		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1351		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1352		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1353		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1354		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1355		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1356		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1357		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1358		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1359		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1360		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1361		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1362		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1363		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1364		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1365		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1366		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1367		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1368		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1369		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1370		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1371		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1372		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1373		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1374		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1375		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1376		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1377		APU & CARGO FIRE CNTRL PANEL ASSY, M10444



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N6203-1378		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1379		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-138		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1380		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1381		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1382		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1383		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1384		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1385		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1386		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1387		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1388		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1389		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1390		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1391		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1392		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1393		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1394		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1395		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1396		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1397		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1398		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1399		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1400		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1401		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1402		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1403		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1404		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1405		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1406		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1407		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1408		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1409		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1410		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1411		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1412		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1413		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1414		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1415		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1416		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1417		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1418		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-1419		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-143		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-144		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-146		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-157		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-161		APU & CARGO FIRE CNTRL PANEL ASSY, M10444





**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N6203-162		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-163		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-164		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-165		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-166		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-169		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-170		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-171		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-172		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-173		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-174		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-175		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-177		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-178		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-179		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-180		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-181		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-182		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-183		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-184		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-185		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-186		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-187		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-188		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-189		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-190		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-191		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-192		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-193		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-194		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-195		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-196		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-197		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-198		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-199		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-200		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-201		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-202		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-203		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-206		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-21		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-219		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-220		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-221		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-222		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-226		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-23		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-24		APU & CARGO FIRE CNTRL PANEL ASSY, M10444



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N6203-301		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-302		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-303		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-304		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-305		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-306		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-32		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-339		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-340		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-341		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-342		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-343		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-344		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-345		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-35		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-352		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-353		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-355		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-356		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-357		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-358		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-36		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-360		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-45		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-46		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-47		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-48		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-53		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-56		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-67		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-7		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-70		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-73		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-75		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-77		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-78		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-79		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-80		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-81		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-82		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-83		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-84		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-85		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-86		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6203-9		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233N6252-10		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N6252-11		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N6252-12		ELECTRICAL SYSTEM PANEL ASSY, M10063



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233N6252-13		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N6252-14		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N6252-15		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N6252-16		ELECTRICAL SYSTEM PANEL ASSY, M10063
233N6253-2		APU START PANEL ASSY M10324
233N6253-3		APU START PANEL ASSY M10324
233N7502-1		SERVICE INTERPHONE PANEL ASSY, M10399
233N7514-1		DIGITAL ACCESS RECORDER PANEL ASSY
233N7514-4		DIGITAL ACCESS RECORDER PANEL ASSY
233T2222-301		TWO CREW CTRL PANEL ASSY P
233T2222-302		TWO CREW CTRL PANEL ASSY P
233T2222-303		TWO CREW CTRL PANEL ASSY P
233T2222-31		TWO CREW CTRL PANEL ASSY P
233T2222-320		TWO CREW CTRL PANEL ASSY P
233T2222-321		TWO CREW CTRL PANEL ASSY P
233T2222-322		TWO CREW CTRL PANEL ASSY P
233T2222-323		TWO CREW CTRL PANEL ASSY P
233T2222-67		TWO CREW CTRL PANEL ASSY P
233T2222-73		TWO CREW CTRL PANEL ASSY P
233T2222-80		TWO CREW CTRL PANEL ASSY P
233T2222-81		TWO CREW CTRL PANEL ASSY P
233T2222-82		TWO CREW CTRL PANEL ASSY P
233T2222-83		TWO CREW CTRL PANEL ASSY P
233T2222-84		TWO CREW CTRL PANEL ASSY P
233T2222-85		TWO CREW CTRL PANEL ASSY P
233T2222-86		TWO CREW CTRL PANEL ASSY P
233T2222-87		TWO CREW CTRL PANEL ASSY P
233T2222-88		TWO CREW CTRL PANEL ASSY P
233T2222-89		TWO CREW CTRL PANEL ASSY P
233T2222-90		TWO CREW CTRL PANEL ASSY P
233T2222-91		TWO CREW CTRL PANEL ASSY P
233T2222-92		TWO CREW CTRL PANEL ASSY P
233T2222-93		TWO CREW CTRL PANEL ASSY P
233T3100-123		LIGHTING CTRL PANEL ASSY, M10056
233T3100-130		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-134		EMERGENCY LIGHTS PANEL ASSY, M43
233T3100-135		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-136		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-137		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-140		YAW DAMPER PANEL ASSY, M10250
233T3100-141		YAW DAMPER PANEL ASSY, M10250
233T3100-144		APU CONTROL PANEL ASSY,M1
233T3100-145		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3100-149		APU CONTROL PANEL ASSY,M1
233T3100-153		APU CONTROL PANEL ASSY,M1
233T3100-154		TEMP. CONTROL PANEL ASSY, M14
233T3100-156		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-157		BATTERY/STANDBY POWER PANEL ASSY, M10062



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3100-160		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-162		TEMP. CONTROL PANEL ASSY, M14
233T3100-164		APU CONTROL PANEL ASSY,M1
233T3100-168		TEMP. CONTROL PANEL ASSY, M14
233T3100-170		TEMP. CONTROL PANEL ASSY, M14
233T3100-174		YAW DAMPER PANEL ASSY, M10250
233T3100-175		YAW DAMPER PANEL ASSY, M10250
233T3100-178		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-179		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-180		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-190		LIGHTING CTRL PANEL ASSY, M10056
233T3100-191		LIGHTING CTRL PANEL ASSY, M10056
233T3100-196		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3100-206		TEMP. CONTROL PANEL ASSY, M14
233T3100-211		TEMP. CONTROL PANEL ASSY, M14
233T3100-212		TEMP. CONTROL PANEL ASSY, M14
233T3100-213		TEMP. CONTROL PANEL ASSY, M14
233T3100-214		TEMP. CONTROL PANEL ASSY, M14
233T3100-216		ELECTRICAL SYSTEM PANEL ASSY, M10063
233T3100-217		ELECTRICAL SYSTEM PANEL ASSY, M10063
233T3100-218		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-219		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-225		EMERGENCY LIGHTS PANEL ASSY, M43
233T3100-227		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-232		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-233		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-234		ELECTRICAL SYSTEM PANEL ASSY, M10063
233T3100-235		ELECTRICAL SYSTEM PANEL ASSY, M10063
233T3100-236		EMERGENCY LIGHTS PANEL ASSY, M43
233T3100-238		APU CONTROL PANEL ASSY,M1
233T3100-239		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-248		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-249		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-250		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-252		TEMP. CONTROL PANEL ASSY, M14
233T3100-254		TEMP. CONTROL PANEL ASSY, M14
233T3100-256		TEMP. CONTROL PANEL ASSY, M14
233T3100-257		TEMP. CONTROL PANEL ASSY, M14
233T3100-258		TEMP. CONTROL PANEL ASSY, M14
233T3100-261		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-270		ELECTRICAL SYSTEM PANEL ASSY, M10063
233T3100-273		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-275		ELECTRICAL SYSTEM PANEL ASSY, M10063
233T3100-278		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-280		YAW DAMPER PANEL ASSY, M10250
233T3100-284		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3100-287		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-289		EMERGENCY LIGHTS PANEL ASSY, M43



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3100-290		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-292		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-294		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-295		ELECTRICAL SYSTEM PANEL ASSY, M10063
233T3100-296		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-301		EMERGENCY LIGHTS PANEL ASSY, M43
233T3100-306		LIGHTING CTRL PANEL ASSY, M10056
233T3100-309		YAW DAMPER PANEL ASSY, M10250
233T3100-310		TEMP. CONTROL PANEL ASSY, M14
233T3100-311		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-313		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-314		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-315		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-320		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3100-326		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-327		YAW DAMPER PANEL ASSY, M10250
233T3100-329		EMERGENCY LIGHTS PANEL ASSY, M43
233T3100-330		YAW DAMPER PANEL ASSY, M10250
233T3100-338		EEC CONTROL PANEL ASSY M10761
233T3100-339		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-340		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-341		EEC CONTROL PANEL ASSY M10761
233T3100-342		YAW DAMPER PANEL ASSY, M10250
233T3100-344		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-346		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-347		EEC CONTROL PANEL ASSY M10761
233T3100-348		EEC CONTROL PANEL ASSY M10761
233T3100-353		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-359		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-360		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-361		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-362		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-363		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-373		EEC CONTROL PANEL ASSY M10761
233T3100-374		EEC CONTROL PANEL ASSY M10761
233T3100-375		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-376		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-377		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-378		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-381		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-382		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-383		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-384		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-385		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-386		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-389		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-393		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-396		ENGINE IGNITION & START CTRL PANEL ASSY,M49



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3100-397		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3100-405		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-406		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-407		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-408		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-409		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-415		EMERGENCY LIGHTS PANEL ASSY, M43
233T3100-425		TEMPERATURE CONTROL PANEL ASSY, M14
233T3100-440		YAW DAMPER PANEL ASSY, M10250
233T3100-442		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3100-461		APU CONTROL PANEL ASSY,M1
233T3100-53		APU CONTROL PANEL ASSY,M1
233T3100-55		TEMP. CONTROL PANEL ASSY, M14
233T3100-64		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3100-65		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3100-67		LIGHTING CTRL PANEL ASSY, M10056
233T3100-70		BATTERY/STANDBY POWER PANEL ASSY, M10062
233T3100-72		YAW DAMPER PANEL ASSY, M10250
233T3100-73		YAW DAMPER PANEL ASSY, M10250
233T3100-86		EMERGENCY LIGHTS PANEL ASSY, M43
233T3100-90		TEMP. CONTROL PANEL ASSY, M14
233T3100-91		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3210-1022		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1024		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1025		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1027		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1028		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1029		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1030		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1031		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1033		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1037		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1038		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1300		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1301		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1302		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1303		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1304		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1305		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1306		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1307		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1308		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1309		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-1310		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-22		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-24		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-25		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-27		EMERGENCY LIGHTS PANEL ASSY, M43



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3210-28		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-29		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-30		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-300		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-301		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-302		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-303		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-304		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-305		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-306		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-307		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-31		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-33		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-35		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-37		EMERGENCY LIGHTS PANEL ASSY, M43
233T3210-38		EMERGENCY LIGHTS PANEL ASSY, M43
233T3217-300		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-301		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-302		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-304		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-306		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-307		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-36		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-38		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-40		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-41		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-42		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-44		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-46		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3217-48		LIGHTING, ANTI-COLLISION & LANDING, PANEL
233T3230-1		ENTERTAINMENT PANEL ASSY, M1111
233T3230-14		ENTERTAINMENT PANEL ASSY, M1111
233T3230-15		ENTERTAINMENT PANEL ASSY, M1111
233T3230-18		ENTERTAINMENT PANEL ASSY, M1111
233T3230-20		ENTERTAINMENT PANEL ASSY, M1111
233T3230-22		ENTERTAINMENT PANEL ASSY, M1111
233T3230-23		ENTERTAINMENT PANEL ASSY, M1111
233T3230-24		ENTERTAINMENT PANEL ASSY, M1111
233T3230-300		ENTERTAINMENT PANEL ASSY, M1111
233T3230-301		ENTERTAINMENT PANEL ASSY, M1111
233T3230-302		ENTERTAINMENT PANEL ASSY, M1111
233T3230-303		ENTERTAINMENT PANEL ASSY, M1111
233T3230-304		ENTERTAINMENT PANEL ASSY, M1111
233T3230-305		ENTERTAINMENT PANEL ASSY, M1111
233T3230-307		ENTERTAINMENT PANEL ASSY, M1111
233T3230-308		ENTERTAINMENT PANEL ASSY, M1111
233T3230-309		ENTERTAINMENT PANEL ASSY, M1111
233T3230-32		ENTERTAINMENT PANEL ASSY, M1111



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3230-36		ENTERTAINMENT PANEL ASSY, M1111
233T3230-39		ENTERTAINMENT PANEL ASSY, M1111
233T3230-40		ENTERTAINMENT PANEL ASSY, M1111
233T3230-46		ENTERTAINMENT PANEL ASSY, M1111
233T3230-48		ENTERTAINMENT PANEL ASSY, M1111
233T3230-51		ENTERTAINMENT PANEL ASSY, M1111
233T3230-53		ENTERTAINMENT PANEL ASSY, M1111
233T3230-8		ENTERTAINMENT PANEL ASSY, M1111
233T3232-1		APU CONTROL PANEL ASSY,M1
233T3232-11		APU CONTROL PANEL ASSY,M1
233T3232-12		APU CONTROL PANEL ASSY,M1
233T3232-13		APU CONTROL PANEL ASSY,M1
233T3232-16		APU CONTROL PANEL ASSY,M1
233T3232-17		APU CONTROL PANEL ASSY,M1
233T3232-18		APU CONTROL PANEL ASSY,M1
233T3232-19		APU CONTROL PANEL ASSY,M1
233T3232-20		APU CONTROL PANEL ASSY,M1
233T3232-21		APU CONTROL PANEL ASSY,M1
233T3232-22		APU CONTROL PANEL ASSY,M1
233T3232-23		APU CONTROL PANEL ASSY,M1
233T3232-300		APU CONTROL PANEL ASSY,M1
233T3232-301		APU CONTROL PANEL ASSY,M1
233T3232-302		APU CONTROL PANEL ASSY,M1
233T3232-303		APU CONTROL PANEL ASSY,M1
233T3232-304		APU CONTROL PANEL ASSY,M1
233T3232-305		APU CONTROL PANEL ASSY,M1
233T3232-5		APU CONTROL PANEL ASSY,M1
233T3232-6		APU CONTROL PANEL ASSY,M1
233T3232-9		APU CONTROL PANEL ASSY,M1
233T3235-10		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1005		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1007		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1010		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1011		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1012		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1013		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1015		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-11		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-12		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-13		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1300		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1301		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1302		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1303		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1304		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1305		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1306		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-1307		FUEL MANAGEMENT PANEL ASSEMBLY





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3235-15		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-17		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-20		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-21		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-23		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-300		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-301		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-5		FUEL MANAGEMENT PANEL ASSEMBLY
233T3235-7		FUEL MANAGEMENT PANEL ASSEMBLY
233T3236-1		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-10		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1001		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1005		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1010		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1016		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1020		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1022		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1024		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1026		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1028		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1029		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1031		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1032		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1033		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1035		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1037		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1038		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1039		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1040		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1042		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1044		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1047		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1050		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1053		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1059		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1060		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1062		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1066		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1069		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1070		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1071		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1077		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1079		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1084		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1085		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1087		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1091		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1093		TEMPERATURE CONTROL PANEL ASSY, M14



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3236-1094		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1095		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1096		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1097		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1300		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1301		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1302		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1303		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1304		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1305		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1306		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1307		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1308		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1309		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1310		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1311		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1312		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1313		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1314		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1315		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1316		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1317		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1318		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1319		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1320		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1321		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1322		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1323		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1324		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1325		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1326		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1327		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1328		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1329		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1330		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1331		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1332		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1333		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1334		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1335		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1336		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1337		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1338		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1339		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1340		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1341		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1342		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1343		TEMPERATURE CONTROL PANEL ASSY, M14



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3236-1344		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1345		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1346		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1347		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1348		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1349		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-1350		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-16		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-20		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-22		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-26		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-28		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-29		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-300		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-301		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-302		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-303		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-304		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-305		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-306		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-307		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-308		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-309		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-31		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-310		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-311		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-312		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-313		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-314		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-315		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-316		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-317		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-318		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-319		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-32		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-320		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-321		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-33		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-35		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-37		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-38		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-39		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-40		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-42		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-44		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-47		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-5		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-50		TEMPERATURE CONTROL PANEL ASSY, M14



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3236-53		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-59		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-60		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-62		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-66		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-69		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-70		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-71		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-73		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-77		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-79		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-84		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-85		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-87		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-91		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-93		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-94		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-95		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-96		TEMPERATURE CONTROL PANEL ASSY, M14
233T3236-97		TEMPERATURE CONTROL PANEL ASSY, M14
233T3237-10		BLEED AIR PANEL
233T3237-1005		BLEED AIR PANEL
233T3237-1007		BLEED AIR PANEL
233T3237-1010		BLEED AIR PANEL
233T3237-1013		BLEED AIR PANEL
233T3237-1014		BLEED AIR PANEL
233T3237-1015		BLEED AIR PANEL
233T3237-1016		BLEED AIR PANEL
233T3237-1017		BLEED AIR PANEL
233T3237-1018		BLEED AIR PANEL
233T3237-1019		BLEED AIR PANEL
233T3237-1021		BLEED AIR PANEL
233T3237-1024		BLEED AIR PANEL
233T3237-1025		BLEED AIR PANEL
233T3237-1027		BLEED AIR PANEL
233T3237-1030		BLEED AIR PANEL
233T3237-1032		BLEED AIR PANEL
233T3237-13		BLEED AIR PANEL
233T3237-1300		BLEED AIR PANEL
233T3237-1301		BLEED AIR PANEL
233T3237-1302		BLEED AIR PANEL
233T3237-1304		BLEED AIR PANEL
233T3237-1307		BLEED AIR PANEL
233T3237-1308		BLEED AIR PANEL
233T3237-1309		BLEED AIR PANEL
233T3237-1310		BLEED AIR PANEL
233T3237-1311		BLEED AIR PANEL
233T3237-1312		BLEED AIR PANEL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3237-1313		BLEED AIR PANEL
233T3237-1314		BLEED AIR PANEL
233T3237-1315		BLEED AIR PANEL
233T3237-1316		BLEED AIR PANEL
233T3237-1317		BLEED AIR PANEL
233T3237-1318		BLEED AIR PANEL
233T3237-1319		BLEED AIR PANEL
233T3237-1320		BLEED AIR PANEL
233T3237-1321		BLEED AIR PANEL
233T3237-1322		BLEED AIR PANEL
233T3237-1323		BLEED AIR PANEL
233T3237-1324		BLEED AIR PANEL
233T3237-1325		BLEED AIR PANEL
233T3237-14		BLEED AIR PANEL
233T3237-15		BLEED AIR PANEL
233T3237-16		BLEED AIR PANEL
233T3237-17		BLEED AIR PANEL
233T3237-18		BLEED AIR PANEL
233T3237-19		BLEED AIR PANEL
233T3237-21		BLEED AIR PANEL
233T3237-24		BLEED AIR PANEL
233T3237-25		BLEED AIR PANEL
233T3237-27		BLEED AIR PANEL
233T3237-30		BLEED AIR PANEL
233T3237-300		BLEED AIR PANEL
233T3237-301		BLEED AIR PANEL
233T3237-302		BLEED AIR PANEL
233T3237-304		BLEED AIR PANEL
233T3237-305		BLEED AIR PANEL
233T3237-306		BLEED AIR PANEL
233T3237-307		BLEED AIR PANEL
233T3237-308		BLEED AIR PANEL
233T3237-309		BLEED AIR PANEL
233T3237-310		BLEED AIR PANEL
233T3237-311		BLEED AIR PANEL
233T3237-32		BLEED AIR PANEL
233T3237-5		BLEED AIR PANEL
233T3237-7		BLEED AIR PANEL
233T3241-1		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-10		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1001		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1005		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1008		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1010		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1011		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1012		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1013		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1014		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3241-1015		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1017		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1020		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1039		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1041		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1042		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1043		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1044		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1045		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1046		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1047		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1048		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1049		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1050		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1053		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1054		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1056		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1058		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1060		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1062		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1063		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1067		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1068		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1069		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1070		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-11		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-12		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-13		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1300		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1302		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1303		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1304		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1305		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1306		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1307		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1308		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1309		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1310		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1311		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1312		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1313		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1314		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1315		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1316		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1317		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1318		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1319		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1320		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3241-1321		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1322		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1323		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1324		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1325		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1326		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1327		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1328		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1329		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1330		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1331		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1332		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1333		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1334		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1335		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1336		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-1337		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-14		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-15		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-17		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-20		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-22		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-25		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-28		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-300		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-301		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-302		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-303		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-304		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-305		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-306		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-307		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-308		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-39		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-41		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-42		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-43		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-44		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-45		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-46		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-47		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-48		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-49		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-5		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-50		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-53		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-54		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-56		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3241-58		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-60		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-62		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-63		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-64		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-67		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-68		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-69		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-70		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3241-8		WING & ENGINE ANTI-ICE CTRL PANEL ASSY,M10397
233T3242-1		EEC CONTROL PANEL ASSY M10761
233T3242-10		EEC CONTROL PANEL ASSY M10761
233T3242-1001		EEC CONTROL PANEL ASSY M10761
233T3242-1004		EEC CONTROL PANEL ASSY M10761
233T3242-1006		EEC CONTROL PANEL ASSY M10761
233T3242-1007		EEC CONTROL PANEL ASSY M10761
233T3242-1008		EEC CONTROL PANEL ASSY M10761
233T3242-1010		EEC CONTROL PANEL ASSY M10761
233T3242-1013		EEC CONTROL PANEL ASSY M10761
233T3242-1015		EEC CONTROL PANEL ASSY M10761
233T3242-13		EEC CONTROL PANEL ASSY M10761
233T3242-1300		EEC CONTROL PANEL ASSY M10761
233T3242-1301		EEC CONTROL PANEL ASSY M10761
233T3242-1302		EEC CONTROL PANEL ASSY M10761
233T3242-1303		EEC CONTROL PANEL ASSY M10761
233T3242-1304		EEC CONTROL PANEL ASSY M10761
233T3242-1305		EEC CONTROL PANEL ASSY M10761
233T3242-1306		EEC CONTROL PANEL ASSY M10761
233T3242-1307		EEC CONTROL PANEL ASSY M10761
233T3242-1308		EEC CONTROL PANEL ASSY M10761
233T3242-15		EEC CONTROL PANEL ASSY M10761
233T3242-300		EEC CONTROL PANEL ASSY M10761
233T3242-301		EEC CONTROL PANEL ASSY M10761
233T3242-302		EEC CONTROL PANEL ASSY M10761
233T3242-303		EEC CONTROL PANEL ASSY M10761
233T3242-304		EEC CONTROL PANEL ASSY M10761
233T3242-305		EEC CONTROL PANEL ASSY M10761
233T3242-306		EEC CONTROL PANEL ASSY M10761
233T3242-307		EEC CONTROL PANEL ASSY M10761
233T3242-308		EEC CONTROL PANEL ASSY M10761
233T3242-4		EEC CONTROL PANEL ASSY M10761
233T3242-6		EEC CONTROL PANEL ASSY M10761
233T3242-7		EEC CONTROL PANEL ASSY M10761
233T3242-8		EEC CONTROL PANEL ASSY M10761
233T3244-1		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-10		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1001		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1005		ENGINE IGNITION & START CTRL PANEL ASSY,M49





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T3244-1006		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1007		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1009		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1010		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1011		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1013		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1017		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1018		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1019		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1021		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1023		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1025		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-11		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-13		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1300		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1301		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1302		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1303		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1304		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1305		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1306		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1307		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1308		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1309		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1310		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1311		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-1312		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-17		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-18		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-19		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-21		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-23		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-25		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-300		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-301		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-302		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-303		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-304		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-307		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-308		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-309		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-5		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-6		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-7		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T3244-9		ENGINE IGNITION & START CTRL PANEL ASSY,M49
233T4238-1		ENGINE VIBRATION PANEL ASSY, M1099
233T4241-1		EICAS CONTROL PANEL ASSY M10411
233T4242-1		FLIGHT ENGINEERS LIGHTING PANEL ASSY,M18



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T4247-1		ELT TEST PANEL ASSY, M1184
233T4252-1		HF COMM-CW JACK PANEL ASSY, M1317
233T4259-1		THRUST REVERSER PANEL ASSY
233T6100-100		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-101		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-102		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-15		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-16		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6100-18		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6100-19		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-21		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-26		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6100-27		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-36		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-39		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-42		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-43		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-47		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-49		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-50		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-51		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-53		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-55		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-56		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-58		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-59		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-60		APU & CARGO FIRE CNTRL PANEL ASSY, M10444
233T6100-64		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6100-65		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-66		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-67		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-68		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-69		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-70		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-73		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-74		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-75		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6100-76		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-77		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-78		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-81		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-83		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6100-84		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-85		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-86		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-87		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-88		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-89		APU & CARGO FIRE CTRL PANEL ASSY, M10444



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
233T6100-9		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-90		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-91		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-92		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-95		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-96		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-98		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6100-99		APU & CARGO FIRE CTRL PANEL ASSY, M10444
233T6204-11		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-12		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-13		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-14		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-16		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-22		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-301		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-302		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-315		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-316		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T6204-7		FIRE/OVERHEAT TEST PANEL ASSY, M10445
233T7211-1		AFT DOME LIGHT PANEL ASSY, M973
233T7211-10		AFT DOME LIGHT PANEL ASSY, M973
233T7211-13		AFT DOME LIGHT PANEL ASSY, M973
233T7211-6		AFT DOME LIGHT PANEL ASSY, M973
233T7216-1		SERVICE INTERPHONE PANEL ASSY, M1120
233U4212-1		FUEL TEMP SENSOR/GPWS RA SELECT, M6775 MOD
233U4212-300		FUEL TEMP SENSOR/GPWS RA SELECT, M6775 MOD
233U4212-301		FUEL TEMP SENSOR/GPWS RA SELECT, M6775 MOD
233U4212-302		FUEL TEMP SENSOR/GPWS RA SELECT, M6775 MOD
233U4212-4		FUEL TEMP SENSOR/GPWS RA SELECT, M6775 MOD
233U4212-5		FUEL TEMP SENSOR/GPWS RA SELECT, M6775 MOD
234FL		DESYNN POSITION INDICATOR
234FLSB		DESYNN POSITION INDICATOR
237FL		DESYNN POSITION INDICATOR
238FL		DESYNN POSITION INDICATOR
239FL		DESYNN POSITION INDICATOR
23E59-2		SHUTOFF VALVE ASSEMBLY
23E59-3		SHUTOFF VALVE ASSEMBLY
23E59-4		SHUTOFF VALVE ASSEMBLY
23E59-5		SHUTOFF VALVE ASSEMBLY
23E59-6		SHUTOFF VALVE ASSEMBLY
23E59-7		SHUTOFF VALVE ASSEMBLY
240FL		DESYNN POSITION INDICATOR
241FL		DESYNN POSITION INDICATOR
2426-120-8	60B00111-4	DC AMMETER
2426-523-8	60B00141-2	ACM AIR FLOW IND.
2426-525-8	60B00141-4	ACM AIR FLOW IND.
242FL		DESYNN POSITION INDICATOR
245040	7SC0076	DC LOADMETER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
245050	7SC0092	DE-ICING PRESSURE INSULATOR
248541	1862 TYPE 2LW	ELEVATOR AND RUDDER POSITION INDICATOR
248697	1824	FUEL TEMPERATURE & DUAL LOAD METER INDICATOR
248794	1122-25	OXYGEN PRESSURE INDICATOR
248836	1824	FUEL TEMP. & DUAL LOAD METER INDICATOR
2503148-2		ANNUNCIATOR
25122-A15A-1-A2	3571211-9035	SINGLE SYNCHRO INDICATOR
25122-A17F-2-A3	3571212-0055	SINGLE SYNCHRO INDICATOR
25122-A23F-2-A2	3571211-9039	SINGLE SYNCHRO INDICATOR
25122-A27C-1-A1	3571211-9010	SINGLE SYNCHRO INDICATOR
25122-A27E-2-A3	3571211-9011	SINGLE SYNCHRO INDICATOR
25122-A29B-2-A2	3571212-0052	SINGLE SYNCHRO INDICATOR
25122-A2C-1-A1	3571211-9020	SINGLE SYNCHRO INDICATOR
25122-A30E-1-A1	3571211-9012	SINGLE SYNCHRO INDICATOR
25122-A37A-1-A1	3571211-9014	SINGLE SYNCHRO INDICATOR
25122-A37B-1-A1	3571211-9015	SINGLE SYNCHRO INDICATOR
25122-A37M-2-A2	3571211-9016	SINGLE SYNCHRO INDICATOR
25122-A37R-2-A2	3571211-9040	SINGLE SYNCHRO INDICATOR
25122-B16A-1-A1	3571211-9021	SINGLE SYNCHRO INDICATOR
25122-B25A-2-A2	3571211-9009	SINGLE SYNCHRO INDICATOR
25122-B25B-2-A2	3571212-0006	SINGLE SYNCHRO INDICATOR
25122-B3C-4-A2	371211-9043	SINGLE SYNCHRO INDICATOR
25122-B4A-1-A1	3571211-9001	SINGLE SYNCRHO INDICATOR
25122-B57A-1-A2	3571211-9032	SINGLE SYNCHRO INDICATOR
25122-B5D-2-A2	3571211-9041	SINGLE SYNCHRO INDICATOR
25122-C72A-17-A3	3571211-9028	SINGLE SYNCHRO INDICATOR
253264	1824	FUEL TEMPERATURE & DUAL LOAD METER IND.
253685	1122-213LW	°C FUEL TANK TEMPERATURE
253686	1122-214LW	°C FREE AIR TEMPERATURE
253687	1122-212LW	°F CABIN AIR TEMPERATURE
253884		SURFACE POSITION INDICATOR
254PG		PRESSURE GAUGE
254PGM		PRESSURE GAUGE
254T3001-1		CTRL STAND ENGINE START & STABILIZER CUTOUT
25510A122A8A2	C6SC1089-1	PRESSURE INDICATOR
25510B25B8A3		FUEL FLOW INDICATOR
25514B25A3A3		FUEL FLOW INDICATOR
25516C96C96A14A3		FUEL FLOW INDICATOR
255PG		PRESSURE GAUGE
255PGM		PRESSURE GAUGE
25615-C27A-26-A1	3571220-5002	DUAL AUTOSYN SYNCHRO INDICATOR
25615-C29A-26-A1		DUAL AUTOSYN SYNCHRO INDICATOR
25615-C29C-26-A3	3571220-5004	DUAL AUTOSYN SYNCHRO INDICATOR
25615-C32A-24-A1		DUAL AUTOSYN SYNCHRO INDICATOR
25615-C32A-24-A2	3571220-5001	DUAL AUTOSYN SYNCHRO INDICATOR
25615-C32C-26-A2		DUAL AUTOSYN SYNCHRO INDICATOR
25615-C32D-26-A3	3571220-5005	DUAL AUTOSYN SYNCHRO INDICATOR
25615-C33A-70-A3	3571220-5007	DUAL AUTOSYN SYNCHRO INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
25615-C33B-70-A3	3571220-5008	DUAL AUTOSYN SYNCHRO INDICATOR
25615-C33D-70-A3		DUAL AUTOSYN SYNCHRO INDICATOR
25616-A37V-40-A2	3571220-6003	FUEL PRESSURE DUAL SYNCHRO INDICATOR
256PG		PRESSURE GAUGE
256PGM		PRESSURE GAUGE
2579583-3		GYRO SUBASSEMBLY
257PG		PRESSURE GAUGE
257PGM		PRESSURE GAUGE
2580824-1		GYRO ROTOR
2580825-1		GYRO ROTOR
2585302		DIRECTIONAL GYRO
2585801	RG-122	MINI RATE GYRO
2585802-1		CONTROL PANEL
2585802-10		CONTROL PANEL
2585802-11		CONTROL PANEL
2585802-12		CONTROL PANEL
2585802-13		CONTROL PANEL
2585802-14		CONTROL PANEL
2585802-2		CONTROL PANEL
2585802-3		CONTROL PANEL
2585802-4		CONTROL PANEL
2585802-5		CONTROL PANEL
2585802-6		CONTROL PANEL
2585802-7		CONTROL PANEL
2585802-8		CONTROL PANEL
2585802-9		CONTROL PANEL
2585802-971		CONTROL PANEL
2586073-3		VERTICAL PATH COUPLER
2586137-1	VG-203D	VERTICAL GYRO
2586137-6	VG-203M	VERTICAL GYRO
2586190-3		TRIM COUPLER
2586220		POSITION SENSOR
2586261-1		DIGITAL CONTROLLER
2586261-2		DIGITAL CONTROLLER
2586333-1	C-12	DIRECTIONAL GYRO
2586333-2	C-12	DIRECTIONAL GYRO
2586333-3	C-12	DIRECTIONAL GYRO
2586373		AUTOMATIC STABILIZER TRIM POTENTIOMETER
2586384-1		AMPLIFIER POWER SUPPLY
2586384-2		AMPLIFIER POWER SUPPLY
2586589-1		GYROSCOPE SUBASSEMBLY
2586589-2		GYROSCOPE SUBASSEMBLY
2586589-3		GYROSCOPE SUBASSEMBLY
2586589-4		GYROSCOPE SUBASSEMBLY
2586882-6		ALTITUDE COMPUTER
2586882-7		ALTITUDE COMPUTER
2586882-8		ALTITUDE COMPUTER
2586882-9		ALTITUDE COMPUTER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2586883-1		AIRSPED COMPUTER
2586883-2		AIRSPED COMPUTER
2586883-3		AIRSPED COMPUTER
2586883-4		AIRSPED COMPUTER
2587193-1	C-14	GYROSYN COMPASS
2587193-143	C14A	DIRECTIONAL GYRO
2587193-2	C-14	GYROSYN COMPASS
2587193-21	C-14	GYROSYN COMPASS
2587193-22	C-14	GYROSYN COMPASS
2587193-23	C-14	GYROSYN COMPASS
2587193-24	C-14	GYROSYN COMPASS
2587193-25	C-14	GYROSYN COMPASS
2587193-26	C-14	GYROSYN COMPASS
2587193-3	C-14	GYROSYN COMPASS
2587193-33	C-14	GYROSYN COMPASS
2587193-36	C-14	GYROSYN COMPASS
2587193-4	C-14	GYROSYN COMPASS
2587193-41	C14A	DIRECTIONAL GYRO
2587193-42	C14A	DIRECTIONAL GYRO
2587193-43	C14A	DIRECTIONAL GYRO
2587193-44	C14A	DIRECTIONAL GYRO
2587193-45	C14A	DIRECTIONAL GYRO
2587193-46	C14A	DIRECTIONAL GYRO
2587193-47	C14A	DIRECTIONAL GYRO
2587193-5	C-14	GYROSYN COMPASS
2587193-6	C-14	GYROSYN COMPASS
2587193-7	C-14	GYROSYN COMPASS
2587317-355	C-6L	COMPASS INDICATOR
2587317-653	C-6L	COMPASS INDICATOR
2587317-655	C-6L	COMPASS INDICATOR
2587317-656	C-6L	COMPASS INDICATOR
2587317-657	C-6L	COMPASS INDICATOR
2587317-658	C-6L	COMPASS INDICATOR
2587335-10		VERTICAL GYRO
2587335-11	VG311	VERTICAL GYRO
2587335-111		VERTICAL GYRO
2587335-112		VERTICAL GYRO
2587335-113	VG-113	VERTICAL GYRO
2587335-114		VERTICAL GYRO
2587335-12	VG312	VERTICAL GYRO
2587335-121		VERTICAL GYRO
2587335-122		VERTICAL GYRO
2587335-13	VG313	VERTICAL GYRO
2587335-14		VERTICAL GYRO
2587335-21		VERTICAL GYRO
2587335-211		VERTICAL GYRO
2587335-22		VERTICAL GYRO
2587335-8		VERTICAL GYRO



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2587335-9		VERTICAL GYRO
2587400-109		AIR DATA COMPUTER
2587400-171		AIR DATA COMPUTER
2587400-176		AIR DATA COMPUTER
2587400-178		AIR DATA COMPUTER
2587400-179		AIR DATA COMPUTER
2587400-196		AIR DATA COMPUTER
2587400-274		AIR DATA COMPUTER
2587400-373		AIR DATA COMPUTER
2587400-436		AIR DATA COMPUTER
2587400-437		AIR DATA COMPUTER
2587400-542		AIR DATA COMPUTER
2587400-637		AIR DATA COMPUTER
2587400-745		AIR DATA COMPUTER
2587400-844		AIR DATA COMPUTER
2587400-936		AIR DATA COMPUTER
2587451-2		DIRECTIONAL GYRO
2587451-3		DIRECTIONAL GYRO
2587566-1	DG-206	DIRECTIONAL GYRO
2587567	FID, CI-600	GYROSYN COMPASS INDICATOR
2587567-901	FID, CI-600	GYROSYN COMPASS INDICATOR
2587909-900	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-901	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-902	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-903	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-904	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-905	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-906	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-908	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-909	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-910	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-911	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-912	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-915	HZ-6B	FLIGHT DIRECTOR INDICATOR
2587909-917	HZ-6C	FLIGHT DIRECTOR INDICATOR
2588260-900	HZ-6C	FLIGHT DIRECTOR INDICATOR
2588260-902	HZ-6C	FLIGHT DIRECTOR INDICATOR
2588260-903	HZ-6C	FLIGHT DIRECTOR INDICATOR
2588260-904	HZ-6C	FLIGHT DIRECTOR INDICATOR
2588260-905	HZ-6C	FLIGHT DIRECTOR INDICATOR
2588260-907	HZ-6C	FLIGHT DIRECTOR INDICATOR
2588282-653	C-6M	COMPASS INDICATOR
2588282-655	C-6M	COMPASS INDICATOR
2588282-656	C-6M	COMPASS INDICATOR
2588282-657	C-6M	COMPASS INDICATOR
2588302-1	DG-233	DIRECTIONAL GYRO
2588302-10	DG-236	DIRECTIONAL GYRO
2588302-2	DG-241	DIRECTIONAL GYRO



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2588302-3	DG-242	DIRECTIONAL GYRO
2588302-4	DG-206A	DIRECTIONAL GYRO
2588302-5	DG-234	DIRECTIONAL GYRO
2588302-501	DG-234	DIRECTIONAL GYRO
2588302-6	DG-235	DIRECTIONAL GYRO
2588302-7	DG-243	DIRECTIONAL GYRO
2588302-8	DG-244	DIRECTIONAL GYRO
2588381-901		COMPASS INDICATOR
2588381-902		COMPASS INDICATOR
2588381-903		COMPASS INDICATOR
2588809-901	SP-77	CONTROL PANEL
2588809-902	SP-77	CONTROL PANEL
2588809-903	SP-77	CONTROL PANEL
2588809-904	SP-77	CONTROL PANEL
2588816-901		FLARE COUPLER
2588816-902		FLARE COUPLER
2588817-901		FLARE COUPLER
2588817-903		FLARE COUPLER
2588817-904		FLARE COUPLER
2588824-902	RH-600	RADIO HEADING INDICATOR
2588824-903	RH-600	RADIO HEADING INDICATOR
2588824-904	RH-600	RADIO HEADING INDICATOR
2588838		POSITION SENSOR
2589226-1		AMPLIFIER POWER SUPPLY
2590281-901	HZ-6F	ATTITUDE INDICATOR
2590281-902	HZ-6F	ATTITUDE INDICATOR
2590281-903	HZ-6F	ATTITUDE INDICATOR
2590281-904	HZ-6F	ATTITUDE INDICATOR
2590281-905	HZ-6F	ATTITUDE INDICATOR
2590281-906	HZ-6F	ATTITUDE INDICATOR
2590281-907	HZ-6F	ATTITUDE INDICATOR
2590281-908	HZ-6F	ATTITUDE INDICATOR
2590281-909	HZ-6F	ATTITUDE INDICATOR
2590281-910	HZ-6F	ATTITUDE INDICATOR
2590680-601		MODE SELECTOR SWITCH
2590680-701		MODE SELECTOR SWITCH
2590680-801		MODE SELECTOR SWITCH
2590680-901		MODE SELECTOR SWITCH
2591092-903	AD-350	ATTITUDE DIRECTOR INDICATOR
2591092-904	AD-350	ATTITUDE DIRECTOR INDICATOR
2591411-024	AR-24	ATTITUDE DIRECTOR INDICATOR
2591411-044	AR-44	ATTITUDE DIRECTOR INDICATOR
2591411-144	HZ-144	ATTITUDE DIRECTOR INDICATOR
2591411-244	HZ-244	ATTITUDE DIRECTOR INDICATOR
2591411-245	HZ-245	ATTITUDE DIRECTOR INDICATOR
2591411-264	HZ-264	ATTITUDE DIRECTOR INDICATOR
2591411-265	HZ-265	ATTITUDE DIRECTOR INDICATOR
2591411-444	HZ-444	ATTITUDE DIRECTOR INDICATOR





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2591411-902	HZ-245	ATTITUDE DIRECTOR INDICATOR
2591411-903	HZ-444	ATTITUDE DIRECTOR INDICATOR
2591411-904	HZ-444	ATTITUDE DIRECTOR INDICATOR
2591411-906	HZ-444	ATTITUDE DIRECTOR INDICATOR
2591411-907	HZ-444	ATTITUDE DIRECTOR INDICATOR
2591411-908	HZ-444	ATTITUDE DIRECTOR INDICATOR
2591411-909	HZ-444	ATTITUDE DIRECTOR INDICATOR
2591411-910	HZ-444	ATTITUDE DIRECTOR INDICATOR
2591714-11	2591714	ALTITUDE COMPUTER
2591714-14	2591714	ALTITUDE COMPUTER
2591714-22	2591714	ALTITUDE COMPUTER
2591714-3	2591714	ALTITUDE COMPUTER
2591714-5	2591714	ALTITUDE COMPUTER
2591714-6	2591714	ALTITUDE COMPUTER
2591714-7	2591714	ALTITUDE COMPUTER
2591714-8	2591714	ALTITUDE COMPUTER
2591715-3	2591715	AIRSPEED COMPUTER
2591715-4	2591715	AIRSPEED COMPUTER
2592528-901	DD-390C	DUAL DME INDICATOR
2592639-901	RD-350	HORIZONTAL SITUATION INDICATOR
2592639-903	RD-350	HORIZONTAL SITUATION INDICATOR
2592920-044	RD-44	RADIO DEVIATION INDICATOR
2592920-444	RD-444	RADIO DEVIATION INDICATOR
2592920-445	RD-445	RADIO DEVIATION INDICATOR
2592920-901	RD-44	RADIO DEVIATION INDICATOR
2593191-702	RH-300C	RADIO MAGNETIC INDICATOR
2593191-704	RH-300A	RADIO MAGNETIC INDICATOR
2593191-801	RH-300A	RADIO MAGNETIC INDICATOR
2593191-804	RH-300A	RADIO MAGNETIC INDICATOR
2593191-806	RH-300A	RADIO MAGNETIC INDICATOR
2593191-807	RH-300A	RADIO MAGNETIC INDICATOR
2593191-808	RH-300A	RADIO MAGNETIC INDICATOR
2593191-809	RH-300A	RADIO MAGNETIC INDICATOR
2593191-810	RH-300A	RADIO MAGNETIC INDICATOR
2593691	VG-401	ATTITUDE REFERENCE
2593691-901	VG-401	ATTITUDE REFERENCE
2593742-41	VG-341A	VERTICAL GYRO
2593996-333		TARSYN
2593996-444		TARSYN
2593996-555		TARSYN
2594401-901	DG-207A	DIRECTIONAL GYRO
2594586-912		ATTITUDE HEADING SENSING UNIT
2594617-901		S.A.T. INDICATOR
2594617-909		S.A.T. INDICATOR
2594620-908		BAROMETRIC ALTITUDE INDICATOR
2594621-906		MACH AIRSPEED INDICATOR
2594621-907		MACH AIRSPEED INDICATOR
2594621-908		MACH AIRSPEED INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2594621-910		MACH AIRSPEED INDICATOR
2594621-913		MACH AIRSPEED INDICATOR
2594621-914		MACH AIRSPEED INDICATOR
2594621-915		MACH AIRSPEED INDICATOR
2594621-920		MACH AIRSPEED INDICATOR
2594623-901	AD-300A	ATTITUDE DIRECTOR INDICATOR
2594623-902	AD-300A	ATTITUDE DIRECTOR INDICATOR
2594623-904	AD-300A	ATTITUDE DIRECTOR INDICATOR
2594623-905	AD-300A	ATTITUDE DIRECTOR INDICATOR
2594624-901	RD-350B	HORIZONTAL SITUATION INDICATOR
2594625-901		RADIO MAGNETIC INDICATOR
2594625-902		RADIO MAGNETIC INDICATOR
2594661-704	RH-350C	RADIO MAGNETIC INDICATOR
2594661-801	RH-350A	RADIO MAGNETIC INDICATOR
2594661-803	RH-350A	RADIO MAGNETIC INDICATOR
2594661-903	RH-350B	RADIO MAGNETIC INDICATOR
2594860-901	DG 207	DIRECTIONAL GYRO
2594861-902	VG-341	VERTICAL GYRO
2594862-912		GYRO MOUNTING RACK
259PG		PRESSURE GAUGE
259PGM		PRESSURE GAUGE
2600-03-1	60B00303-103	DIGITAL ELECTRONIC CLOCK
2600-04-1	60B00303-104	DIGITAL ELECTRONIC CLOCK
2600-05-1		DIGITAL ELECTRONIC CLOCK
2600-06-1	S231T120-1	DIGITAL ELECTRONIC CLOCK
2600-08-1		DIGITAL ELECTRONIC CLOCK
2600-09-1		DIGITAL ELECTRONIC CLOCK
260461	60B00120-1	OXYGEN PRESSURE INDICATOR
260462	1825-3LW	COMPARTMENT & DUCT TEMP. IND.
260516	1825-2	OXYGEN PRESSURE IND.
260582		ELEVATOR AND RUDDER POSITION IND.
260589	60B00108-2	TEMPERATURE IND. (F)
260590	60B00108-3	TEMPERATURE COMPRESSOR DISCHARGE (F)
260591	1825-4LW	COMPARTMENT & DUCT TEMP. IND.
260592	60B00108-5	TEMPERATURE IND. ( C )
260593	60B00108-6	TEMPERATURE COMPRESSOR DISCHARGE ( C )
260637	1122-48LW	TURBINE GAS TEMPERATURE
260909	60B00109-1	POSITION INDICATOR
260910	60B00109-3	SYNCHRONIZATION INDICATOR
2610-07-1	60B00303-105	DIGITAL ELECTRONIC CHRONOMETER
2610-08-1	60B00303107	DIGITAL ELECTRONIC CHRONOMETER
2610-10-1	60B00303-108	CHRONOMETER, DIGITAL ELECTRONIC
2610-13-1		DIGITAL ELECTRONIC CHRONOMETER
262-1		75VA DIMMING CONTROL
263-1		150VA DIMMING CONTROL
263-2		150VA DIMMING CONTROL
265FL		DESYNN POSITION INDICATOR
266FL		DESYNN POSITION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2680219M4		MODULAR ASSY
2680219M5		MODULAR ASSY
2680219M6		MODULAR ASSY
2680219M7		MODULAR ASSY
2680220M4		MODULAR ASSY
2680220M5		MODULAR ASSY
2680220M6		MODULAR ASSY
2680220M7		MODULAR ASSY
26930889		SIDE WINDOW TEMPERATURE CONTROLLER
26930889-01		SIDE WINDOW TEMPERATURE CONTROLLER
26930889-02		SIDE WINDOW TEMPERATURE CONTROLLER
270-2196-010	590B-2	AIRSPD SENSOR
270-2196-020	590B-2	AIRSPD SENSOR
2704286-1		ALTERNATING CURRENT MOTOR
27241301		HOT AIR CHECK VALVE
272PG		PRESSURE GAUGE
272PGM		PRESSURE GAUGE
2740166-1		ROTARY ACUATOR
274CH2		AIRCRAFT BATTERY
2758		AIRCRAFT BATTERY
27600-4	778728-4	RECIRCULATION FAN
27600-6	778728-4	RECIRCULATION FAN
27600-7	778728-4	RECIRCULATION FAN
27600-8	778728-6	RECIRCULATION FAN
277FL		DESYNN POSITION INDICATOR
278FL		DESYNN POSITION INDICATOR
27932-C26A17A3		PRESSURE RATIO INDICATOR
2800003-102		SURGE TANK PRESSURE RELIEF VALVE
2800003-103		SURGE TANK PRESSURE RELIEF VALVE
282PG		PRESSURE GAUGE
282PGM		PRESSURE GAUGE
284T0719-1		APU SHUTDOWN PANEL ASSY, P40
284T0719-10		APU SHUTDOWN PANEL ASSY, P40
284T0719-11		APU SHUTDOWN PANEL ASSY, P40
284T0719-12		APU SHUTDOWN PANEL ASSY, P40
284T0719-13		APU SHUTDOWN PANEL ASSY, P40
284T0719-14		APU SHUTDOWN PANEL ASSY, P40
284T0719-15		APU SHUTDOWN PANEL ASSY, P40
284T0719-16		APU SHUTDOWN PANEL ASSY, P40
284T0719-17		APU SHUTDOWN PANEL ASSY P40
284T0719-18		APU SHUTDOWN PANEL ASSY P40
284T0719-19		APU SHUTDOWN PANEL ASSY, P40
284T0719-2		APU SHUTDOWN PANEL ASSY, P40
284T0719-21		APU SHUTDOWN PANEL ASSY P40
284T0719-24		APU SHUTDOWN PANEL ASSY P40
284T0719-25		APU SHUTDOWN PANEL ASSY, P40
284T0719-26		APU SHUTDOWN PANEL ASSY, P40
284T0719-27		APU SHUTDOWN PANEL ASSY P40



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
284T0719-28		APU SHUTDOWN PANEL ASSY, P40
284T0719-29		APU SHUTDOWN PANEL ASSY P40
284T0719-3		APU SHUTDOWN PANEL ASSY, P40
284T0719-30		APU SHUTDOWN PANEL ASSY P40
284T0719-300		APU SHUTDOWN PANEL ASSY, P40
284T0719-301		APU SHUTDOWN PANEL ASSY, P40
284T0719-302		APU SHUTDOWN PANEL ASSY P40
284T0719-303		APU SHUTDOWN PANEL ASSY, P40
284T0719-304		APU SHUTDOWN PANEL ASSY P40
284T0719-307		APU SHUTDOWN PANEL ASSY P40
284T0719-308		APU SHUTDOWN PANEL ASSY, P40
284T0719-309		APU SHUTDOWN PANEL ASSY, P40
284T0719-31		APU SHUTDOWN PANEL ASSY, P40
284T0719-310		APU SHUTDOWN PANEL ASSY, P40
284T0719-311		APU SHUTDOWN PANEL ASSY P40
284T0719-312		APU SHUTDOWN PANEL ASSY P40
284T0719-313		APU SHUTDOWN PANEL ASSY, P40
284T0719-314		APU SHUTDOWN PANEL ASSY, P40
284T0719-316		APU SHUTDOWN PANEL ASSY, P40
284T0719-317		APU SHUTDOWN PANEL ASSY, P40
284T0719-32		APU SHUTDOWN PANEL ASSY, P40
284T0719-328		APU SHUTDOWN PANEL ASSY, P40
284T0719-33		APU SHUTDOWN PANEL ASSY P40
284T0719-34		APU SHUTDOWN PANEL ASSY P40
284T0719-35		APU SHUTDOWN PANEL ASSY, P40
284T0719-350		APU SHUTDOWN PANEL ASSY, P40
284T0719-351		APU SHUTDOWN PANEL ASSY, P40
284T0719-352		APU SHUTDOWN PANEL ASSY, P40
284T0719-353		APU SHUTDOWN PANEL ASSY, P40
284T0719-354		APU SHUTDOWN PANEL ASSY P40
284T0719-355		APU SHUTDOWN PANEL ASSY P40
284T0719-356		APU SHUTDOWN PANEL ASSY, P40
284T0719-357		APU SHUTDOWN PANEL ASSY P40
284T0719-358		APU SHUTDOWN PANEL ASSY, P40
284T0719-359		APU SHUTDOWN PANEL ASSY, P40
284T0719-360		APU SHUTDOWN PANEL ASSY, P40
284T0719-361		APU SHUTDOWN PANEL ASSY, P40
284T0719-362		APU SHUTDOWN PANEL ASSY, P40
284T0719-363		APU SHUTDOWN PANEL ASSY P40
284T0719-364		APU SHUTDOWN PANEL ASSY, P40
284T0719-365		APU SHUTDOWN PANEL ASSY, P40
284T0719-366		APU SHUTDOWN PANEL ASSY, P40
284T0719-367		APU SHUTDOWN PANEL ASSY, P40
284T0719-37		APU SHUTDOWN PANEL ASSY, P40
284T0719-69		APU SHUTDOWN PANEL ASSY, P40
284T0719-7		APU SHUTDOWN PANEL ASSY, P40
284T0719-8		APU SHUTDOWN PANEL ASSY, P40
284T0719-9		APU SHUTDOWN PANEL ASSY, P40



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
285A1840-1		MODULE
285A1840-2		MODULE
285A1840-3		MODULE
285A1840-4		MODULE
285A1840-7		MODULE
285A1840-8		MODULE
285T0017-102		CSEU POWER SUPPLY
285T0017-103		CSEU POWER SUPPLY
285T0020-10		ILS CONTROL PANEL ASSEMBLY
285T0020-8		ILS CONTROL PANEL ASSEMBLY
285T0020-9		ILS CONTROL PANEL ASSEMBLY
285T0024-18		PILOT CALL PANEL MODULE ASSY
285T0024-19		PILOT CALL PANEL MODULE ASSY
285T0024-20		PILOT CALL PANEL MODULE ASSY
285T0024-21		PILOT CALL PANEL MODULE ASSY
285T0024-22		PILOT CALL PANEL MODULE ASSY
285T0024-23		PILOT CALL PANEL MODULE ASSY
285T0024-24		PILOT CALL PANEL MODULE ASSY
285T0024-25		PILOT CALL PANEL MODULE ASSY
285T0024-26		PILOT CALL PANEL MODULE ASSY
285T0024-27		PILOT CALL PANEL MODULE ASSY
285T0024-28		PILOT CALL PANEL MODULE ASSY
285T0024-29		PILOT CALL PANEL MODULE ASSY
285T0024-30		PILOT CALL PANEL MODULE ASSY
285T0024-41		PILOT CALL PANEL MODULE ASSY
285T0024-9		PILOT CALL PANEL MODULE ASSY
285T0027-14		ADF CONTROL PANEL
285T0035-10		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-10 MOD A		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-10 MOD AB		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-11		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-11 MOD A		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-11 MOD AB		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-3		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-3 MOD A		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-9		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-9 MOD A		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0035-9 MOD AB		WARNING ELECTRONICS UNIT POWER SUPPLY ASSY
285T0554-3		PANEL E.I.C.A.S.
285T0554-4		PANEL E.I.C.A.S.
285T0554-5		PANEL E.I.C.A.S.
285T0554-6		PANEL E.I.C.A.S.
285T0557-1		DUAL ADF CONTROL PANEL ASSEMBLY
285T0557-2		DUAL ADF CONTROL PANEL ASSEMBLY
285T0628-1008		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1017		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1019		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1021		FORWARD ATTENDANT'S PANEL ASSY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
285T0628-1029		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1033		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1056		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1060		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1061		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1062		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1077		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1078		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1080		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1081		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1083		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1085		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1086		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1087		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1088		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1089		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1090		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1091		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1092		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1095		FORWARD ATTENDANT'S PANEL ASSY
285T0628-1096		FORWARD ATTENDANT'S PANEL ASSY
285T0628-21		FORWARD ATTENDANT'S PANEL ASSY
285T0628-22		FORWARD ATTENDANT'S PANEL ASSY
285T0628-23		FORWARD ATTENDANT'S PANEL ASSY
285T0628-24		FORWARD ATTENDANT'S PANEL ASSY
285T0628-25		FORWARD ATTENDANT'S PANEL ASSY
285T0628-26		FORWARD ATTENDANT'S PANEL ASSY
285T0628-27		FORWARD ATTENDANT'S PANEL ASSY
285T0628-28		FORWARD ATTENDANT'S PANEL ASSY
285T0628-29		FORWARD ATTENDANT'S PANEL ASSY
285T0628-30		FORWARD ATTENDANT'S PANEL ASSY
285T0628-32		FORWARD ATTENDANT'S PANEL ASSY
285T0628-33		FORWARD ATTENDANT'S PANEL ASSY
285T0628-34		FORWARD ATTENDANT'S PANEL ASSY
285T0628-35		FORWARD ATTENDANT'S PANEL ASSY
285T0628-36		FORWARD ATTENDANT'S PANEL ASSY
285T0628-37		FORWARD ATTENDANT'S PANEL ASSY
285T0628-39		FORWARD ATTENDANT'S PANEL ASSY
285T0628-40		FORWARD ATTENDANT'S PANEL ASSY
285T0628-41		FORWARD ATTENDANT'S PANEL ASSY
285T0628-43		FORWARD ATTENDANT'S PANEL ASSY
285T0628-44		FORWARD ATTENDANT'S PANEL ASSY
285T0628-45		FORWARD ATTENDANT'S PANEL ASSY
285T0628-46		FORWARD ATTENDANT'S PANEL ASSY
285T0628-47		FORWARD ATTENDANT'S PANEL ASSY
285T0628-48		FORWARD ATTENDANT'S PANEL ASSY
285T0628-49		FORWARD ATTENDANT'S PANEL ASSY
285T0628-50		FORWARD ATTENDANT'S PANEL ASSY



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
285T0628-51		FORWARD ATTENDANT'S PANEL ASSY
285T0628-52		FORWARD ATTENDANT'S PANEL ASSY
285T0628-53		FORWARD ATTENDANT'S PANEL ASSY
285T0628-56		FORWARD ATTENDANT'S PANEL ASSY
285T0628-57		FORWARD ATTENDANT'S PANEL ASSY
285T0628-58		FORWARD ATTENDANT'S PANEL ASSY
285T0628-59		FORWARD ATTENDANT'S PANEL ASSY
285T0628-60		FORWARD ATTENDANT'S PANEL ASSY
285T0628-61		FORWARD ATTENDANT'S PANEL ASSY
285T0628-71		FORWARD ATTENDANT'S PANEL ASSY
285T0628-72		FORWARD ATTENDANT'S PANEL ASSY
285T0628-73		FORWARD ATTENDANT'S PANEL ASSY
285W0024-5B		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD AB		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD ABC		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD AC		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD AC1		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD AC1		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD AD		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5B MOD D		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-5M MOD AC		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7B		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7B MOD A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7B MOD AE		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7G		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7G MOD A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7G MOD AE		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7H		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7H MOD A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7H MOD AE		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7L		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7L MOD A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-7L MOD AE		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-8A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-8A MOD A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-8A MOD AE		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-9G		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-9G MOD A		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
285W0024-9G MOD AE		CABIN ATTENDANT/FLIGHT DECK HANDSET MODULE
286PG		PRESSURE GAUGE
286PGM		PRESSURE GAUGE
287PG		PRESSURE GAUGE
287PGM		PRESSURE GAUGE
28V100-1	G-1	TRANSFORMER-RECTIFIER
28V100-5	G-1	TRANSFORMER-RECTIFIER
290AS3		AIRSPD INDICATOR
295FL		DESYNN POSITION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
295FLSB		DESYNN POSITION INDICATOR
296-01731		TORQUE PRESSURE INDICATOR
29680		ELECTRICALLY DRIVEN AXIAL FAN
2980292100000		WATER FAUCET ASSY
2980302100000		WATER FAUCET ASSY
2980312100000		WATER FAUCET ASSY
2980322100000		WATER FAUCET ASSY
2980332100000		WATER FAUCET ASSY
2980342100000		WATER FAUCET ASSY
2CM9AAA6		TACHOMETER GENERATOR
2CM9AAC6		TACHOMETER GENERATOR
2CM9AAH4		TACHOMETER GENERATOR
2CM9AAV6		TACHOMETER GENERATOR
2CM9AAZ6		TACHOMETER GENERATOR
2CM9ABE6		TACHOMETER GENERATOR
2CM9ABH7		TACHOMETER GENERATOR
2CM9ABK7		TACHOMETER GENERATOR
2CM9ABY7		TACHOMETER GENERATOR
2CM9ABZ7		TACHOMETER GENERATOR
2CM9ACE7		TACHOMETER GENERATOR
2CM9ACF8		TACHOMETER GENERATOR
2CM9ACH7		TACHOMETER GENERATOR
2CM9ADB9		TACHOMETER GENERATOR
2CM9ADE8		TACHOMETER GENERATOR
2CM9ADT6		TACHOMETER GENERATOR
2LA002606-01		INSPECTION LIGHT
2LA002606-08		INSPECTION LIGHT
2LA003544-00		EMERGENCY LIGHT
2LA003544-10		EMERGENCY LIGHT
2LA003544-30		EMERGENCY LIGHT
2LA003544-35		EMERGENCY LIGHT
2LA004891-00		READING LIGHT
2LA004891-00 Amdt A		READING LIGHT
2LA004892-00		READING LIGHT
2LA004892-00 Amdt A		READING LIGHT
2LA005127-00		OVERWING EMERGENCY LIGHT
2LA005127-01		OVERWING EMERGENCY LIGHT
2LA005128-00		OVERWING EMERGENCY LIGHT
2LA005128-01		OVERWING EMERGENCY LIGHT
2LA005303-01		TAIL STROBE LIGHT
2LA005303-05		TAIL STROBE LIGHT
2LA005308-01		WING STROBE LIGHT
2LA005308-05		WING STROBE LIGHT
2LA005413-00		OVERWING EMERGENCY LIGHT
2LA005413-01		OVERWING EMERGENCY LIGHT
2LA005414-00		OVERWING EMERGENCY LIGHT
2LA005414-01		OVERWING EMERGENCY LIGHT
2LA005467-00		WARNING LIGHT





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2LA005469-00		WARNING LIGHT
2LA005469-01		WARNING LIGHT
2LA005469-10		WARNING LIGHT
2LA005469-21		WARNING LIGHT
2LA005541-10		FLOOD LIGHT UNIT
2LA005541-11		FLOOD LIGHT UNIT
2LA005542-20		FLOOD LIGHT UNIT
2LA005542-50		FLOOD LIGHT UNIT
2LA005543-10		FLOOD LIGHT UNIT
2LA005543-11		FLOOD LIGHT UNIT
2LA005776-00		READING LIGHT
2LA005776-00 Amdt A		READING LIGHT
2LA006482-00		READING LIGHT
2LA006482-05		READING LIGHT
2LA006482-10		READING LIGHT
2LA006483-00		READING LIGHT
2LA006483-05		READING LIGHT
2LA006483-10		READING LIGHT
2LA007307-00		WARNING LIGHT
2LA403700-01		REAR NAVIGATION LIGHT
2LA403700-02		REAR NAVIGATION LIGHT
2LA403702-01		REAR NAVIGATION LIGHT
2LA403702-02		REAR NAVIGATION LIGHT
2LA405367-00		REAR NAVIGATION LIGHT
2LA408353-00		LIGHT ASSEMBLY
2LA408353-80		LED MAP READING LIGHT
2LA455010-00		STROBE LIGHT
2LA455010-06		STROBE LIGHT
2LA455010-21		STROBE LIGHT
2LA455226-00		READING LIGHT
2LA455226-05		READING LIGHT
2LA455226-06		READING LIGHT
2LA455226-07		READING LIGHT
2LA455226-08		READING LIGHT
2LA455226-09		READING LIGHT
2LA455226-10		READING LIGHT
2LA455226-11		READING LIGHT
2LA455226-12		READING LIGHT
2LA455226-13		READING LIGHT
2LA455226-30		READING LIGHT
2LA455226-31		READING LIGHT
2LA455226-32		READING LIGHT
2LA455226-33		READING LIGHT
2LA455226-35		READING LIGHT
2LA455226-40		READING LIGHT
2LA455226-60		READING LIGHT
2LA455226-61		READING LIGHT
2LA455226-62		READING LIGHT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
2LA455226-63		READING LIGHT
2LA455226-64		READING LIGHT
2LA455226-65		READING LIGHT
2LA455226-66		READING LIGHT
2LA455226-67		READING LIGHT
2LA455226-68		READING LIGHT
2LA455226-75		READING LIGHT
30 0437-1		ANTI COLLISION STROBE LIGHT
30 0437-100		ANTI COLLISION STROBE LIGHT
30 0437-101		ANTI COLLISION STROBE LIGHT
30 0437-102		ANTI COLLISION STROBE LIGHT
30 0437-103		ANTI COLLISION STROBE LIGHT
30 0437-104		ANTI COLLISION STROBE LIGHT
30 0437-105		ANTI COLLISION STROBE LIGHT
30 0437-106		ANTI COLLISION STROBE LIGHT
30 0437-107		ANTI COLLISION STROBE LIGHT
30 0437-108		ANTI COLLISION STROBE LIGHT
30 0437-109		ANTI COLLISION STROBE LIGHT
30 0437-11		ANTI COLLISION STROBE LIGHT
30 0437-110		ANTI COLLISION STROBE LIGHT
30 0437-111		ANTI COLLISION STROBE LIGHT
30 0437-7		ANTI COLLISION STROBE LIGHT
30 0437-9		ANTI COLLISION STROBE LIGHT
30-0025-1		NAVIGATIONAL LIGHT
30-0025-10		NAVIGATIONAL LIGHT
30-0025-2		NAVIGATIONAL LIGHT
30-0025-3		NAVIGATIONAL LIGHT
30-0025-4		NAVIGATIONAL LIGHT
30-0025-5		NAVIGATIONAL LIGHT
30-0025-6		NAVIGATIONAL LIGHT
30-0025-7		NAVIGATIONAL LIGHT
30-0025-8		NAVIGATIONAL LIGHT
30-0025-9		NAVIGATIONAL LIGHT
30-0418-3		EMERGENCY EXIT LIGHT
30-0418-5	60B50042-3	EMERGENCY EXIT LIGHT
30-0418-7	60B50042-4	EMERGENCY EXIT LIGHT
30-0431-1		EMERGENCY EXIT LIGHT
30-0431-3		EMERGENCY EXIT LIGHT
30-0431-5		EMERGENCY EXIT LIGHT
30-0431-7		EMERGENCY EXIT LIGHT
30-0431-9		EMERGENCY EXIT LIGHT
30-0626-11		TAIL POSITION LIGHT
30-0626-3		TAIL POSITION LIGHT
30-0626-5		TAIL POSITION LIGHT
30-0626-7		TAIL POSITION LIGHT
30-0626-9		TAIL POSITION LIGHT
30-0809-11		TAIL POSITION LIGHT
30-0809-3		TAIL POSITION LIGHT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
30-0809-7		TAIL POSITION LIGHT
30-0809-9		TAIL POSITION LIGHT
30-0837-1		ANTICOLLISION STROBE LIGHT
30-0837-11		ANTICOLLISION STROBE LIGHT
30-0837-13		ANTICOLLISION STROBE LIGHT
30-0837-15		ANTICOLLISION STROBE LIGHT
30-0837-17		ANTICOLLISION STROBE LIGHT
30-0837-19		ANTICOLLISION STROBE LIGHT
30-0837-21		ANTICOLLISION STROBE LIGHT
30-0837-23		ANTICOLLISION STROBE LIGHT
30-0837-25		ANTICOLLISION STROBE LIGHT
30-0837-27		ANTICOLLISION STROBE LIGHT
30-0837-29		ANTICOLLISION STROBE LIGHT
30-0837-3		ANTICOLLISION STROBE LIGHT
30-0837-31		ANTICOLLISION STROBE LIGHT
30-0837-33		ANTICOLLISION STROBE LIGHT
30-0837-35		ANTICOLLISION STROBE LIGHT
30-0837-37		ANTICOLLISION STROBE LIGHT
30-0837-39		ANTICOLLISION STROBE LIGHT
30-0837-41		ANTICOLLISION STROBE LIGHT
30-0837-43		ANTICOLLISION STROBE LIGHT
30-0837-45		ANTICOLLISION STROBE LIGHT
30-0837-47		ANTICOLLISION STROBE LIGHT
30-0837-5		ANTICOLLISION STROBE LIGHT
30-0837-7		ANTICOLLISION STROBE LIGHT
30-0837-9		ANTICOLLISION STROBE LIGHT
30-0863-1		NAVIGATIONAL LIGHT
30-0863-10		NAVIGATIONAL LIGHT
30-0863-11		NAVIGATIONAL LIGHT
30-0863-12		NAVIGATIONAL LIGHT
30-0863-13		NAVIGATIONAL LIGHT
30-0863-14		NAVIGATIONAL LIGHT
30-0863-15		NAVIGATIONAL LIGHT
30-0863-16		NAVIGATIONAL LIGHT
30-0863-17		NAVIGATIONAL LIGHT
30-0863-18		NAVIGATIONAL LIGHT
30-0863-2		NAVIGATIONAL LIGHT
30-0863-3		NAVIGATIONAL LIGHT
30-0863-4		NAVIGATIONAL LIGHT
30-0863-5		NAVIGATIONAL LIGHT
30-0863-6		NAVIGATIONAL LIGHT
30-0863-7		NAVIGATIONAL LIGHT
30-0863-8		NAVIGATIONAL LIGHT
30-0863-9		NAVIGATIONAL LIGHT
30-0866-10		RECOGNITION LIGHT
30-0866-11		RECOGNITION LIGHT
30-0866-12		RECOGNITION LIGHT
30-0866-13		RECOGNITION LIGHT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
30-0866-3		RECOGNITION LIGHT
30-0866-4		RECOGNITION LIGHT
30-0866-5		RECOGNITION LIGHT
30-0866-6		RECOGNITION LIGHT
30-0866-7		RECOGNITION LIGHT
30-0866-8		RECOGNITION LIGHT
30-0866-9		RECOGNITION LIGHT
30-0904-1		RECOGNITION LIGHT
30-0904-101		RECOGNITION LIGHT
30-0904-103		RECOGNITION LIGHT
30-0904-105		RECOGNITION LIGHT
30-0904-107		RECOGNITION LIGHT
30-0904-3		RECOGNITION LIGHT
30-0904-5		RECOGNITION LIGHT
30-0904-7		RECOGNITION LIGHT
30-0906-1		RECOGNITION LIGHT
30-0906-10		RECOGNITION LIGHT
30-0906-101		RECOGNITION LIGHT
30-0906-103		RECOGNITION LIGHT
30-0906-104		RECOGNITION LIGHT
30-0906-105		RECOGNITION LIGHT
30-0906-106		RECOGNITION LIGHT
30-0906-107		RECOGNITION LIGHT
30-0906-109		RECOGNITION LIGHT
30-0906-11		RECOGNITION LIGHT
30-0906-110		RECOGNITION LIGHT
30-0906-111		RECOGNITION LIGHT
30-0906-113		RECOGNITION LIGHT
30-0906-115		RECOGNITION LIGHT
30-0906-116		RECOGNITION LIGHT
30-0906-117		RECOGNITION LIGHT
30-0906-118		RECOGNITION LIGHT
30-0906-119		RECOGNITION LIGHT
30-0906-121		RECOGNITION LIGHT
30-0906-122		RECOGNITION LIGHT
30-0906-123		RECOGNITION LIGHT
30-0906-124		RECOGNITION LIGHT
30-0906-125		RECOGNITION LIGHT
30-0906-126		RECOGNITION LIGHT
30-0906-128		RECOGNITION LIGHT
30-0906-129		RECOGNITION LIGHT
30-0906-13		RECOGNITION LIGHT
30-0906-131		RECOGNITION LIGHT
30-0906-15		RECOGNITION LIGHT
30-0906-16		RECOGNITION LIGHT
30-0906-17		RECOGNITION LIGHT
30-0906-18		RECOGNITION LIGHT
30-0906-19		RECOGNITION LIGHT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
30-0906-21		RECOGNITION LIGHT
30-0906-22		RECOGNITION LIGHT
30-0906-23		RECOGNITION LIGHT
30-0906-24		RECOGNITION LIGHT
30-0906-25		RECOGNITION LIGHT
30-0906-26		RECOGNITION LIGHT
30-0906-3		RECOGNITION LIGHT
30-0906-4		RECOGNITION LIGHT
30-0906-5		RECOGNITION LIGHT
30-0906-6		RECOGNITION LIGHT
30-0906-7		RECOGNITION LIGHT
30-0906-9		RECOGNITION LIGHT
30-0909-1		A/C TAIL POSITION LIGHT
30-0909-101		A/C TAIL POSITION LIGHT
30-0909-103		A/C TAIL POSITION LIGHT
30-0909-107		A/C TAIL POSITION LIGHT
30-0909-201		A/C TAIL POSITION LIGHT
30-0909-203		A/C TAIL POSITION LIGHT
30-0909-207		A/C TAIL POSITION LIGHT
30-1033-1		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-11		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-13		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-15		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-17		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-19		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-21		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-23		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-25		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-27		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-29		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-3		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-31		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-33		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-35		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-37		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-39		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-41		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-43		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-45		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-49		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-5		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-51		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-53		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-55		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-57		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-59		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-61		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-63		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
30-1033-65		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-67		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1033-7		AIRCRAFT NAV LIGHT ANTI-COLLISION, FLASHTUBE
30-1401-1		NAV LIGHT
30-1401-11		NAV LIGHT
30-1401-13		NAV LIGHT
30-1401-15		NAV LIGHT
30-1401-3		NAV LIGHT
30-1401-5		NAV LIGHT
30-1401-7		NAV LIGHT
30-1401-9		NAV LIGHT
30-1588-5		AIRCRAFT NAVIGATIONAL LIGHT
30-1588-6		AIRCRAFT NAVIGATIONAL LIGHT
30-1706-1		REFUELING INDICATOR LIGHT
301-781-201-0	3505582-1	AIR TURBINE ENGINE STARTER
301-781-202-0	3505582-2	AIR TURBINE ENGINE STARTER
301-781-203-0	3505582-40	AIR TURBINE ENGINE STARTER
301-781-204-0	3505582-43	AIR TURBINE ENGINE STARTER
301-781-602-0	3505582-41	AIR TURBINE ENGINE STARTER
301-790-902-0	3505582-12	AIR TURBINE ENGINE STARTER
301-790-903-0	3505582-60	AIR TURBINE ENGINE STARTER
301-790-904-0	3505582-63	AIR TURBINE ENGINE STARTER
301-806-601-0	3505582-3	AIR TURBINE ENGINE STARTER
301-806-603-0	3505582-44	AIR TURBINE ENGINE STARTER
301-806-701-0	3505582-14	AIR TURBINE ENGINE STARTER
301-806-702-0	3505582-61	AIR TURBINE ENGINE STARTER
301-806-703-0	3505582-64	AIR TURBINE ENGINE STARTER
301-806-801-0	3505582-4	AIR TURBINE ENGINE STARTER
301-806-802-0	3505582-42	AIR TURBINE ENGINE STARTER
301-806-803-0	3505582-45	AIR TURBINE ENGINE STARTER
301-806-901-0	3505582-15	AIR TURBINE ENGINE STARTER
301-806-902-0	3505582-62	AIR TURBINE ENGINE STARTER
301-806-903-0	3505582-65	AIR TURBINE ENGINE STARTER
301-807-002-0	3505582-22	AIR TURBINE ENGINE STARTER
301-807-003-0	3505582-23	AIR TURBINE ENGINE STARTER
301-807-004-0	3505582-24	AIR TURBINE ENGINE STARTER
301-807-005-0	3505582-25	AIR TURBINE ENGINE STARTER
301-807-006-0	3505582-26	AIR TURBINE ENGINE STARTER
301-812-401-0	3505582-27	AIR TURBINE ENGINE STARTER
30-1883-3		WING AND NACELLE INSPECTION FLOODLIGHT
30-1883-4		WING AND NACELLE INSPECTION FLOODLIGHT
30-1883-5		WING AND NACELLE INSPECTION FLOODLIGHT
30-1883-6		WING AND NACELLE INSPECTION FLOODLIGHT
302FL		DESYNN POSITION INDICATOR
302FLBR		DESYNN POSITION INDICATOR
304FL		DESYNN POSITION INDICATOR
304FLSB		DESYNN POSITION INDICATOR
305FL		DESYNN POSITION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
305FLSB		DESYNN POSITION INDICATOR
311EDP1-1	10-62178-101	EIS PRIMARY DISPLAY PANEL
311EDP2-1	10-62178-102	EIS PRIMARY DISPLAY PANEL
311EDP3-1	10-62178-101	EIS PRIMARY DISPLAY PANEL
311EDP3-2	10-62178-103/109	EIS PRIMARY DISPLAY PANEL
311EDP3-3	10-62178-109	EIS PRIMARY DISPLAY PANEL
311EDP3-4	10-62178-113	EIS PRIMARY DISPLAY PANEL
311EDP4-1	10-62178-102	EIS PRIMARY DISPLAY PANEL
311EDP4-2	10-62178-104-110	EIS PRIMARY DISPLAY PANEL
311EDP4-3	10-62178-110	EIS PRIMARY DISPLAY PANEL
311EDP4-4	10-62178-114	EIS PRIMARY DISPLAY PANEL
311EDP5-2	10-62178-103/109	EIS PRIMARY DISPLAY PANEL
311EDP5-3	10-62178-109	EIS PRIMARY DISPLAY PANEL
311EDP5-4	10-62178-113	EIS PRIMARY DISPLAY PANEL
311EDP6-2	10-62178-104-/110	EIS PRIMARY DISPLAY PANEL
311EDP6-3	10-62178-110	EIS PRIMARY DISPLAY PANEL
311EDP6-4	10-62178-114	EIS PRIMARY DISPLAY PANEL
312EDP1-1	10-62178-105/111	EIS PRIMARY DISPLAY PANEL
312EDP1-2	10-62178-111	EIS PRIMARY DISPLAY PANEL
312EDP1-3	10-62178-115	EIS PRIMARY DISPLAY PANEL
312EDP2-1	10-62178-106/112	EIS PRIMARY DISPLAY PANEL
312EDP2-2	10-62178-112	EIS PRIMARY DISPLAY PANEL
312EDP2-3	10-62178-116	EIS PRIMARY DISPLAY PANEL
31-5268-3		LIGHT SUBASSEMBLY
31-5268-4		LIGHT SUBASSEMBLY
315PG		PRESSURE GAUGE
315PGM		PRESSURE GAUGE
316FL		DESYNN POSITION INDICATOR
317FL		DESYNN POSITION INDICATOR
317FLSB		DESYNN POSITION INDICATOR
318-01030		FUEL PRESSURE TRANSMITTER
318-01130		FUEL PRESSURE TRANSMITTER
318-65C-D1		FUEL PRESSURE TRANSMITTER
318-65-D1		FUEL PRESSURE TRANSMITTER
318FL		DESYNN POSITION INDICATOR
318FLSB		DESYNN POSITION INDICATOR
319FL		DESYNN POSITION INDICATOR
319FLSB		DESYNN POSITION INDICATOR
320115		MOTOR ACTUATED BUTTERFLY SHUTOFF VALVE
3201KGA/CP/1	3200 KGA	GENERATOR, TACHOMETER
3202 KGA/MS/1	3200 KGA	GENERATOR, TACHOMETER
3202618-2		INTERMEDIATE PRESSURE CHECK VALVE
3202854-1		APU CHECK VALVE
320FL		DESYNN POSITION INDICATOR
3213722-1-1		3 IN PRESSURE REGULATOR
3213722-2-1		3 IN PRESSURE REGULATOR
3213754-1		REGULATING VALVE
3213754-2		REGULATING VALVE



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
3214446-1		HIGH STAGE VALVE
3214446-2		HIGH STAGE VALVE
3214446-3		HIGH STAGE VALVE
3214446-4		HIGH STAGE VALVE
3214-52		EMERGENCY POWER SUPPLY UNIT
3214-54		EMERGENCY POWER SUPPLY UNIT
3214-54-10		EMERGENCY POWER SUPPLY UNIT
3214-54-20		EMERGENCY POWER SUPPLY UNIT
3214-55		EMERGENCY POWER SUPPLY UNIT
3214-55-10		EMERGENCY POWER SUPPLY UNIT
3214888-1		REGULATING VALVE
3214888-2		REGULATING VALVE
321942-1-1		BUTTERFLY SHUTOFF VALVE
323PG		PRESSURE GAUGE
323PGM		PRESSURE GAUGE
3250-20-10		BALLAST UNIT
3250-30		BALLAST UNIT
3250-31		BALLAST UNIT
3250-70		BALLAST UNIT
3250-70-10		BALLAST UNIT
3250-80		BALLAST UNIT
3250-81		BALLAST UNIT
3252013-0101		ALTIMETER - ENCODER
3252013-0201		ALTIMETER - ENCODER
3252013-0401		ALTIMETER - ENCODER
3252013-0501		ALTIMETER - ENCODER
3252013-0601		ALTIMETER - ENCODER
3252013-0701		ALTIMETER - ENCODER
3252013-0801		ALTIMETER - ENCODER
3252013-0901		ALTIMETER - ENCODER
325855-1	221D5102-503	NACELLE COOLING VALVE
325855-2	221D5102-505	NACELLE COOLING VALVE
325855-3	221D5102-507	NACELLE COOLING VALVE
325RGS/2		MINI. RATE GYRO
326FL		DESYNN POSITION INDICATOR
326PG		PRESSURE GAUGE
326PGM		PRESSURE GAUGE
3289562-1		4" PRECOOLER CONTROL VALVE
3289562-2		4" PRECOOLER CONTROL VALVE
3289562-3		4" PRECOOLER CONTROL VALVE
3289562-4		4" PRECOOLER CONTROL VALVE
3289562-5		4" PRECOOLER CONTROL VALVE
3289562-6		4" PRECOOLER CONTROL VALVE
3289562-7		4" PRECOOLER CONTROL VALVE
3289630-1		3" DIAMETER STARTER CONTROL VALVE
3289630-2		3" DIAMETER STARTER CONTROL VALVE
3289630-3		3" DIAMETER STARTER CONTROL VALVE
3290272-3		HIGH STAGE VALVE





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
3290272-6		HIGH STAGE VALVE
3290280-3		PYLON PRESSURE REGULATOR VALVE
3290280-4		PYLON PRESSURE REGULATOR VALVE
3290662-1		NOSE COWL THERMAL ANTI-ICE VALVE
3290662-2		NOSE COWL THERMAL ANTI-ICE VALVE
3291214-2		3.5" APU BLEED AIR VALVE
3291432-1		3.5 INCH LOAD CONTROL VALVE
329PG		PRESSURE GAUGE
329PGM		PRESSURE GAUGE
32D37-1		DIFFERENTIAL PRESSURE SWITCH
330FL		DESYNN POSITION INDICATOR
331FL		DESYNN POSITION INDICATOR
335PG		PRESSURE GAUGE
336FL		DESYNN POSITION INDICATOR
3399046-1		HIGH STAGE PILOT VALVE
3399046-2		HIGH STAGE PILOT VALVE
3399048-2		PYLON PRESSURE REGULATOR PILOT
3399048-3		PYLON PRESSURE REGULATOR PILOT
34146-1AM30B1		RADIO MAGNETIC DIRECTION INDICATOR
342B040000		TEMPERATURE CONTROL THERMOSTAT
342B050000		TEMPERATURE CONTROL THERMOSTAT
342FL		DESYNN POSITION INDICATOR
343FL		DESYNN POSITION INDICATOR
344FL		DESYNN POSITION INDICATOR
345A-7	772-5140-001	RATE OF TURN
345A-7A	777-1034-001	RATE OF TURN
346FL		DESYNN POSITION INDICATOR
349PG		PRESSURE GAUGE
35000-00-01	S231W130-3	ELECTRONIC CLOCK
35000-22-01	S231W130-4	ELECTRONIC CLOCK
3505582-1	301-781-201-0	AIR TURBINE ENGINE STARTER
3505582-12	301-790-902-0	AIR TURBINE ENGINE STARTER
3505582-14	301-806-701-0	AIR TURBINE ENGINE STARTER
3505582-15	301-806-901-0	AIR TURBINE ENGINE STARTER
3505582-2	301-781-202-0	AIR TURBINE ENGINE STARTER
3505582-22	301-807-002-0	AIR TURBINE ENGINE STARTER
3505582-23	301-807-003-0	AIR TURBINE ENGINE STARTER
3505582-24	301-807-004-0	AIR TURBINE ENGINE STARTER
3505582-25	301-807-005-0	AIR TURBINE ENGINE STARTER
3505582-26	301-807-006-0	AIR TURBINE ENGINE STARTER
3505582-27	301-812-401-0	AIR TURBINE ENGINE STARTER
3505582-3	301-806-601-0	AIR TURBINE ENGINE STARTER
3505582-4	301-806-801-0	AIR TURBINE ENGINE STARTER
3505582-40	301-781-203-0	AIR TURBINE ENGINE STARTER
3505582-41	301-781-602-0	AIR TURBINE ENGINE STARTER
3505582-42	301-806-802-0	AIR TURBINE ENGINE STARTER
3505582-43	301-781-204-0	AIR TURBINE ENGINE STARTER
3505582-44	301-806-603-0	AIR TURBINE ENGINE STARTER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
3505582-45	301-806-803-0	AIR TURBINE ENGINE STARTER
3505582-60	301-790-903-0	AIR TURBINE ENGINE STARTER
3505582-61	301-806-702-0	AIR TURBINE ENGINE STARTER
3505582-62	301-806-902-0	AIR TURBINE ENGINE STARTER
3505582-63	301-790-904-0	AIR TURBINE ENGINE STARTER
3505582-64	301-806-703-0	AIR TURBINE ENGINE STARTER
3505582-65	301-806-903-0	AIR TURBINE ENGINE STARTER
3505945-10	1851M36P10	ENGINE AIR TURBINE STARTER
3505945-2	1851M36P02	ENGINE AIR TURBINE STARTER
3505945-3	1851M36P03	ENGINE AIR TURBINE STARTER
3505945-4	1851M36P04	ENGINE AIR TURBINE STARTER
3505945-5	1851M36P05	ENGINE AIR TURBINE STARTER
3505945-6	1851M36P06	ENGINE AIR TURBINE STARTER
3505945-7	1851M36P07	ENGINE AIR TURBINE STARTER
3505945-8	1851M36P08	ENGINE AIR TURBINE STARTER
3505945-9	1851M36P09	ENGINE AIR TURBINE STARTER
35-0F5-1000		ANNUNCIATOR LIGHT TEST BOARD
35-0L0-1001-03		ECAM CONTROL PANEL
35-0L0-1001-04		ECAM CONTROL PANEL
35-0L0-1002-05		ECAM CONTROL PANEL
35-0L0-1003-06		ECAM CONTROL PANEL
35-0L5-1003-05		BATTERY CHARGER LIMITER
35-0L5-1003-06		BATTERY CHARGER LIMITER
35-0L5-1004-07		BATTERY CHARGER LIMITER
35-0L5-1005-08		BATTERY CHARGER LIMITER
35-0L5-1006-08		BATTERY CHARGER LIMITER
35-1H5-1001		BRAKE TEMPERATURE MONITORING UNIT
35-1H5-1002		BRAKE TEMPERATURE MONITORING UNIT
352FL		DESYNN POSITION INDICATOR
3550PG		PRESSURE GAUGE
3559PG		PRESSURE GAUGE
3562101-0020	CK-1006-7-B1	LOW INERTIA MOTOR
3563100-0025	AY503-5A1	CONTROL TRANSFORMER SYNCHRO
3563100-0026	AY503-5A2	CONTROL TRANSFORMER SYNCHRO
3563100-0042	AY508B-26A1	CONTROL TRANSFORMER SYNCHRO
3563100-0096	AY100AZ-5A2	CONTROL TRANSFORMER SYNCHRO
3563100-0127	AY-100ZZ-102A2	CONTROL TRANSFORMER SYNCHRO
3563150-0350	AY-203S-2-E	TORQUE RECEIVER SYNCHRO
3563150-0428	AY-203S-2-B	TORQUE RECEIVER SYNCHRO
3567400-3001		OIL PRESSURE TRANSMITTER
3567401-4002		OIL PRESSURE TRANSMITTER
3571211-3001		PRESSURE RATIO INDICATOR
3571211-9001	25122-B4A-1-A1	SINGLE SYNCHRO INDICATOR
3571211-9009	25122-B25A-2-A2	SINGLE SYNCHRO INDICATOR
3571211-9010	25122-A27C-1-A1	SINGLE SYNCHRO INDICATOR
3571211-9011	25122-A27E-2-A3	SINGLE SYNCHRO INDICATOR
3571211-9012	25122-A30E-1-A1	SINGLE SYNCHRO INDICATOR
3571211-9014	25122-A37A-1-A1	SINGLE SYNCHRO INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
3571211-9015	25122-A37B-1-A1	SINGLE SYNCHRO INDICATOR
3571211-9016	25122-A37M-2-A2	SINGLE SYNCHRO INDICATOR
3571211-9020	25122-A2C-1-A1	SINGLE SYNCHRO INDICATOR
3571211-9021	25122-B16A-1-A1	SINGLE SYNCHRO INDICATOR
3571211-9028	25122-C72A-17-A1	SINGLE SYNCHRO INDICATOR
3571211-9032	25122-B57A-1-A2	SINGLE SYNCHRO INDICATOR
3571211-9035	25122-A15A-1-A2	SINGLE SYNCHRO INDICATOR
3571211-9039	25122-A23F-2-A2	SINGLE SYNCHRO INDICATOR
3571211-9040	25122-A37R-2-A2	SINGLE SYNCHRO INDICATOR
3571211-9041	25122-B5D-2-A2	SINGLE SYNCHRO INDICATOR
3571211-9043	25122-B3C-4-A2	SINGLE SYNCRHO INDICATOR
3571211-9054		SINGLE SYNCHRO INDICATOR
3571212-0006	25122-B25B-2-A2	SINGLE SYNCHRO INDICATOR
3571212-0010		TORQUE INDICATOR
3571212-0011		TORQUE INDICATOR
3571212-0052	25122-A29B-2-A2	SINGLE SYNCHRO INDICATOR
3571212-0055	25122-A17F-2-A3	SINGLE SYNCHRO INDICATOR
3571213-4001	1497674-001	HYDRAULIC PRESSURE INDICATOR
3571213-4002	1497674-004	HYDRAULIC PRESSURE INDICATOR
3571213-4003	1497674-005	HYDRAULIC PRESSURE INDICATOR
3571213-4004	1497674-008	HYDRAULIC PRESSURE INDICATOR
3571213-4005	1497674-009	HYDRAULIC PRESSURE INDICATOR
3571213-4008	1497674-011	HYDRAULIC PRESSURE INDICATOR
3571220-5001	25615-C32A-24-A2	DUAL AUTOSYN SYNCHRO INDICATOR
3571220-5002	25615-C27A-26-A1	DUAL AUTOSYN SYNCHRO INDICATOR
3571220-5003	25615-C29A-26-A1	DUAL AUTOSYN SYNCHRO INDICATOR
3571220-5004	25615-C29C-26-A3	DUAL AUTOSYN SYNCHRO INDICATOR
3571220-5005	25615-C32D-26-A3	DUAL AUTOSYN SYNCHRO INDICATOR
3571220-5007	25615-C33A-70-A3	DUAL AUTOSYN SYNCHRO INDICATOR
3571220-5008	25615-C33B-70-A3	DUAL AUTOSYN SYNCHRO INDICATOR
3571220-6003	25616-A37V-40-A2	FUEL PRESSURE DUAL SYNCHRO INDICATOR
3571220-6012		FUEL PSI INDICATOR
3571220-6013		OIL PSI INDICATOR
3571220-6015		OIL PSI INDICATOR
3571251-9127		TURBINE OUTLET TEMPERATURE INDICATOR
3571251-9129		TURBINE OUTLET TEMPERATURE INDICATOR
3571251-9131		MEASURED GAS TEMPERATURE INDICATOR
3571260-8001	34108C1AF13-1A3	TACHOMETER INDICATOR
3571260-8002	34108C1AL13-1A3	TACHOMETER INDICATOR
3571260-8003		TACHOMETER INDICATOR
3571810-0003	25510B25B8A3	FUEL FLOW INDICATOR
3571810-0007	25510A122A8A2	PRESSURE INDICATOR
3571810-2001	25514B25A3A3	FUEL FLOW INDICATOR
3571810-2002		FUEL FLOW INDICATOR
3571810-8001	25516C96A14A3	FUEL FLOW INDICATOR
3581400-0001		FUEL FLOW INDICATOR
358PG		DIRECT READING PRESSURE GAUGE
36105-1AA-15C1		RADIO MAGNETIC COMPASS



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
36105-1AA-20C1		RADIO MAGNETIC COMPASS
36105-1AA-20CI		RADIO MAGNETIC COMPASS
36105-1AB-15C1		RADIO MAGNETIC COMPASS
36105-1AC-14C1		RADIO MAGNETIC COMPASS
36105-1AE-14C		RADIO MAGNETIC COMPASS
36105-1AE-14C1		RADIO MAGNETIC COMPASS
36105-1AR-14C1		RADIO MAGNETIC COMPASS
36105-1G-10C1		RADIO MAGNETIC COMPASS
36105-1G-16C1		RADIO MAGNETIC COMPASS
36105-1G-21C1		RADIO MAGNETIC COMPASS
36105-1J-15C1		RADIO MAGNETIC COMPASS
36105-1J-20CI		RADIO MAGNETIC COMPASS
36105-1K-16C1		RADIO MAGNETIC COMPASS
36105-1K18C1		RADIO MAGNETIC COMPASS
36105-1K-21C1		RADIO MAGNETIC COMPASS
36105-1N-14C1		RADIO MAGNETIC COMPASS
36105-1N-14C2		RADIO MAGNETIC COMPASS
36105-1N-19C1		RADIO MAGNETIC COMPASS
36105-1N-19C2		RADIO MAGNETIC COMPASS
36105-1N-21C1		RADIO MAGNETIC COMPASS
36105-1P-16C1		RADIO MAGNETIC COMPASS
36105-1R-15C1		RADIO MAGNETIC COMPASS
36105-1R-9C1		RADIO MAGNETIC COMPASS
36105-1S-14C1		RADIO MAGNETIC COMPASS
36105-1S-19C1		RADIO MAGNETIC COMPASS
36105-1S-19C2		RADIO MAGNETIC COMPASS
36105-1U-14C1		RADIO MAGNETIC COMPASS
36105-1W-19C1		RADIO MAGNETIC COMPASS
36105-1Z-16C1		RADIO MAGNETIC COMPASS
36126-1AF-25-A1		RADIO MAGNETIC INDICATOR
36126-1AF-25-B1		RADIO MAGNETIC INDICATOR
36126-1AH-25-A1		RADIO MAGNETIC INDICATOR
36126-1AP-25-A1		RADIO MAGNETIC INDICATOR
36146-1AM25A1		RADIO MAGNETIC INDICATOR
36148-1AJ25A1		RADIO MAGNETIC INDICATOR
36148-1AJ25A2		RADIO MAGNETIC INDICATOR
36150-1L-11-A1		RADIO MAGNETIC INDICATOR
36154-1AF25A1		RADIO MAGNETIC INDICATOR
36154-1AF25B1		RADIO MAGNETIC INDICATOR
36154-1AJ25A1		RADIO MAGNETIC INDICATOR
36154-1AJ25B1		RADIO MAGNETIC INDICATOR
36154-1AJ33B1		RADIO MAGNETIC INDICATOR
36155-1AF25A1		RADIO MAGNETIC INDICATOR
36155-1AF25A2		RADIO MAGNETIC INDICATOR
36155-1AJ25A1		RADIO MAGNETIC INDICATOR
36158-1AF-25-A1		RADIO MAGNETIC INDICATOR
36158-1AJ-25-B1		RADIO MAGNETIC INDICATOR
36159-1AF-25A1		RADIO MAGNETIC INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
36159-1AF-25A2		RADIO MAGNETIC INDICATOR
36159-1AJ-25A1		RADIO MAGNETIC INDICATOR
36159-1AJ-25A2		RADIO MAGNETIC INDICATOR
36162-1AJ25A1		RADIO MAGNETIC INDICATOR
362PG		PRESSURE GAUGE
362PGM		PRESSURE GAUGE
363PG		PRESSURE GAUGE
363PGM		PRESSURE GAUGE
367-027-003		MONITOR HYDRAULIC QTY CTL
367-027-004		MONITOR HYDRAULIC QTY CTL
367-027-006		MONITOR HYDRAULIC QTY CTL
372PG		PRESSURE GAUGE
372PGM		PRESSURE GAUGE
375FL		DESYNN POSITION INDICATOR
376FL		DESYNN POSITION INDICATOR
381PG		PRESSURE GAUGE
383222-1-1		AIR TURBINE ENGINE STARTER
383222-2-1		AIR TURBINE ENGINE STARTER
383222-4-1		AIR TURBINE ENGINE STARTER
383222-5-1		AIR TURBINE ENGINE STARTER
383222-6-1		AIR TURBINE ENGINE STARTER
383222-9-1		AIR TURBINE ENGINE STARTER
383342-1-1		AIR TURBINE ENGINE STARTER
383342-13		AIR TURBINE ENGINE STARTER
383342-14		AIR TURBINE ENGINE STARTER
383342-2-1		AIR TURBINE ENGINE STARTER
383342-3-1		AIR TURBINE ENGINE STARTER
383342-4-1		AIR TURBINE ENGINE STARTER
383342-5-1		AIR TURBINE ENGINE STARTER
383342-7-1		AIR TURBINE ENGINE STARTER
383342-8-1		AIR TURBINE ENGINE STARTER
384369-01488		FUEL LOAD LIMIT CONTROL
384369-01825		FUEL LOAD LIMIT CONTROL
384369-020		FUEL LOAD LIMIT CONTROL
384369-023		FUEL LOAD LIMIT CONTROL
384453-001		VOLUMETRIC TOP-OFF DEVICE
391012-01001		LIQUID QTY ENGINE OIL TRANSMITTER
3911213-9002		MEASURED GAS TEMP. INDICATOR
3911213-9005		MEASURED GAS TEMP. INDICATOR
3911213-9009		MEASURED GAS TEMP. INDICATOR
39-20V4	A 300B	RATE GYRO
39-20V5		RATE GYRO
392678-1-1		1.5" TURBOFAN CONTROL SHUTOFF DIFF. PRESS.
392678-3-1		1.5" TURBOFAN CONTROL SHUTOFF DIFF. PRESS.
392716-1-1		3" PNEUMATIC SHUTOFF & MODULATING BUTTERFLY
392716-3-1		3" PNEUMATIC SHUTOFF & MODULATING BUTTERFLY
393004-060		FUEL QUANTITY INDICATOR
393004-061		FUEL QUANTITY INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
393004-131		FUEL QUANTITY INDICATOR
393004-132		FUEL QUANTITY INDICATOR
393007-07869		FUEL QTY INDICATOR
393020-003		LIQUID QTY INDICATOR
393020-012		LIQUID QTY INDICATOR
393020-01789		LIQUID QTY INDICATOR
393026-001		FUEL QTY INDICATOR
393026-002		FUEL QTY INDICATOR
393026-003		FUEL QTY INDICATOR
393026-01837		FUEL QTY INDICATOR
393026-01838		FUEL QTY INDICATOR
393026-01840	10-61219-2	FUEL QTY INDICATOR
393026-01841		FUEL QTY INDICATOR
393026-01880		FUEL QTY INDICATOR
393026-03235		FUEL QTY INDICATOR
393026-03236		FUEL QTY INDICATOR
393026-03334		FUEL QTY INDICATOR
393026-03335		FUEL QTY INDICATOR
393026-03508		FUEL QTY INDICATOR
393026-03569		FUEL QTY INDICATOR
393026-036		FUEL QTY INDICATOR
393026-037		FUEL QTY INDICATOR
393026-038		FUEL QTY INDICATOR
393026-039		FUEL QTY INDICATOR
393026-040		FUEL QTY INDICATOR
393026-042		FUEL QTY INDICATOR
393026-04237		FUEL QTY INDICATOR
393026-043		FUEL QTY INDICATOR
393026-04337		FUEL QTY INDICATOR
393026-044		FUEL QTY INDICATOR
393026-04510		FUEL QTY INDICATOR
393026-04568		FUEL QTY INDICATOR
393026-047		FUEL QTY INDICATOR
393026-048		FUEL QTY INDICATOR
393026-052		FUEL QTY INDICATOR
393026-053		FUEL QTY INDICATOR
393026-054		FUEL QTY INDICATOR
393026-064		FUEL QTY INDICATOR
393026-065		FUEL QTY INDICATOR
393026-071		FUEL QTY INDICATOR
393026-072		FUEL QTY INDICATOR
393026-073		FUEL QTY INDICATOR
393026-074		FUEL QTY INDICATOR
393080-117		DUAL TOTAL FUEL & V-REFERENCE INDICATOR
393080-118		DUAL TOTAL FUEL & V-REFERENCE INDICATOR
393080-121		DUAL TOTAL FUEL & V-REFERENCE INDICATOR
393080-122	10-61371-22	DUAL TOTAL FUEL AND V-REF INDICATOR
393080-123	10-61371-23	DUAL TOTAL FUEL AND V-REF INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
393084-031		FUEL QUANTITY INDICATOR
393084-036		FUEL QUANTITY INDICATOR
393084-04359		LIQUID QTY INDICATOR
393084-04408		LIQUID QTY INDICATOR
393084-04596		LIQUID QTY INDICATOR
393084-054		FUEL QUANTITY INDICATOR
393084-22488		FUEL QUANTITY INDICATOR
393084-22825		FUEL QUANTITY INDICATOR
393086-01235		FUEL QTY INDICATOR
393086-01236		FUEL QTY INDICATOR
393086-01334		FUEL QTY INDICATOR
393086-01335		FUEL QTY INDICATOR
393086-01508		FUEL QTY INDICATOR
393086-01569		FUEL QTY INDICATOR
393086-02237		FUEL QTY INDICATOR
393086-02337		FUEL QTY INDICATOR
393086-02510		FUEL QTY INDICATOR
393086-02568		FUEL QTY INDICATOR
3942333-9001		DUAL TACHOMETER INDICATOR
3942333-9002		DUAL TACHOMETER INDICATOR
3942333-9003	206-075-681-113	DUAL TACHOMETER INDICATOR
394473-121		SIGNAL CONDITIONER ASSY.
394473-123		SIGNAL CONDITIONER ASSY.
394473-125		SIGNAL CONDITIONER ASSY.
394473-127		SIGNAL CONDITIONER ASSY.
394473-129		SIGNAL CONDITIONER ASSY.
394473-137		SIGNAL CONDITIONER ASSY.
394473-139		SIGNAL CONDITIONER ASSY.
394PG		PRESSURE GAUGE
396-00740	396-100S1	OIL PRESSURE INDICATOR
396-01640	396-100P1D1	OIL PRESSURE INDICATOR
396-01730		FUEL PRESSURE INDICATOR
396-01740	396-100S1-D1	OIL PRESSURE INDICATOR
396-100S1	396-00740	OIL PRESSURE INDICATOR
396-100S1-D1	396-01740	OIL PRESSURE INDICATOR
396-100S1D2	396-02740	OIL PRESSURE INDICATOR
396-100S1-D2	396-02740	OIL PRESSURE INDICATOR
396520-2		FLOW CONTROL VALVE ASSEMBLY
396-65S1-D1		FUEL PRESSURE INDICATOR
396FL		DESYNN POSITION INDICATOR
397FL		DESYNN POSITION INDICATOR
398396-2		TRIM AIR VALVE
398396-3		TRIM AIR VALVE
398396-4		TRIM AIR VALVE
398396-5		TRIM AIR VALVE
398396-6		TRIM AIR VALVE
398398-2		TRIM AIR VALVE
398398-3		TRIM AIR VALVE



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
398504-2		PNEUMATIC SYSTEM ISOLATION VALVE
398946-1		TURBINE BYPASS VALVE
398946-2		TURBINE BYPASS VALVE
398PG		PRESSURE GAUGE
398PGM		PRESSURE GAUGE
399FL		DESYNN POSITION INDICATOR
40-0061-1		TAIL POSITION LIGHT
40-0061-5		TAIL POSITION LIGHT
40-0070-2		NAVIGATIONAL LIGHT
40-0070-4		NAVIGATIONAL LIGHT
40-0075-10		OSCILLATING NAVIGATIONAL LIGHT
40-0075-7		OSCILLATING NAVIGATIONAL LIGHT
40-0075-8		OSCILLATING NAVIGATIONAL LIGHT
40-0075-9		OSCILLATING NAVIGATIONAL LIGHT
40-0076-5		OSCILLATING NAVIGATIONAL LIGHT
40-0076-7		OSCILLATING NAVIGATIONAL LIGHT
40-0100-1		NAVIGATIONAL LIGHT
40-0100-11		NAVIGATIONAL LIGHT
40-0100-13		NAVIGATIONAL LIGHT
40-0100-17		NAVIGATIONAL LIGHT
40-0100-19		NAVIGATIONAL LIGHT
40-0100-21		NAVIGATIONAL LIGHT
40-0100-23		NAVIGATIONAL LIGHT
40-0100-25		NAVIGATIONAL LIGHT
40-0100-27		NAVIGATIONAL LIGHT
40-0100-3		NAVIGATIONAL LIGHT
40-0100-5		NAVIGATIONAL LIGHT
40-0100-7		NAVIGATIONAL LIGHT
40-0100-9		NAVIGATIONAL LIGHT
40-0135-1		NAVIGATIONAL LIGHT
40-0135-10		NAVIGATIONAL LIGHT
40-0135-2		NAVIGATIONAL LIGHT
40-0135-3		NAVIGATIONAL LIGHT
40-0135-4		NAVIGATIONAL LIGHT
40-0135-5		NAVIGATIONAL LIGHT
40-0135-6		NAVIGATIONAL LIGHT
40-0135-7		NAVIGATIONAL LIGHT
40-0135-8		NAVIGATIONAL LIGHT
40-0135-9		NAVIGATIONAL LIGHT
4001808-901	VG-14	VERTICAL GYRO
40-0196-11		NAVIGATIONAL WARNING LIGHT
40-0196-13		NAVIGATIONAL WARNING LIGHT
4002531-454	HZ-454	ATTITUDE DIRECTOR INDICATOR
4002531-901	HZ-454	ATTITUDE DIRECTOR INDICATOR
4002531-902	HZ-454	ATTITUDE DIRECTOR INDICATOR
4002531-903	HZ-454	ATTITUDE DIRECTOR INDICATOR
4002531-904	HZ-454	ATTITUDE DIRECTOR INDICATOR
4002531-905	HZ-454	ATTITUDE DIRECTOR INDICATOR





**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
4002963-404	RH-404	RADIO MAGNETIC INDICATOR
4002963-405	RH-405	RADIO MAGNETIC INDICATOR
4002963-444	RH-444	RADIO MAGNETIC INDICATOR
4002963-445	RH-445	RADIO MAGNETIC INDICATOR
4002963-454	RH-454	RADIO MAGNETIC INDICATOR
4002963-464	RH-464	RADIO MAGNETIC INDICATOR
4002963-901	RH-901	RADIO MAGNETIC INDICATOR
4002963-902	RH-902	RADIO MAGNETIC INDICATOR
4002963-903	RH-903	RADIO MAGNETIC INDICATOR
4004257-902	RD-350D	HORIZONTAL SITUATION INDICATOR
4004257-903	RD-350D	HORIZONTAL SITUATION INDICATOR
40057-1		PRESSURE SWITCH
4010317-901		AIR DATA COMPUTER
4010317-902		AIR DATA COMPUTER
4010657-464	HZ-464	ATTITUDE DIRECTOR INDICATOR
4010657-901	HZ-464	ATTITUDE DIRECTOR INDICATOR
4014267-901	RA-215	RADIO ALTIMETER INDICATOR
4014267-902	RA-235	RADIO ALTIMETER INDICATOR
4014267-903	RA-215	RADIO ALTIMETER INDICATOR
4014879-901		RADIO DIGITAL DISTANCE MAGNETIC INDICATOR
4016341-901	BA-141	BAROMETRIC ALTITUDE INDICATOR
4016341-902	BA-141	BAROMETRIC ALTITUDE INDICATOR
4016341-903	BA-141	BAROMETRIC ALTITUDE INDICATOR
4016341-904	BA-141	BAROMETRIC ALTITUDE INDICATOR
4016341-905	BA-141	BAROMETRIC ALTITUDE INDICATOR
4016341-906	BA-141	BAROMETRIC ALTITUDE INDICATOR
4016341-907	BA-141	BAROMETRIC ALTITUDE INDICATOR
4018285-901		ALTITUDE ALERT CONTROLLER
4018285-902		ALTITUDE ALERT CONTROLLER
4018285-903		ALTITUDE ALERT CONTROLLER
4018285-904		ALTITUDE ALERT CONTROLLER
4018285-905		ALTITUDE ALERT CONTROLLER
4018285-908		ALTITUDE ALERT CONTROLLER
4019286-901		VERTICAL GYRO
4019286-902		VERTICAL GYRO
4019286-903		VERTICAL GYRO
4019953-904		ALTITUDE INDICATOR
4019953-905		ALTITUDE INDICATOR
401PG		PRESSURE GAUGE
4020547-901	AD-600	ATTITUDE DIRECTOR INDICATOR
4020547-904	AD-600	ATTITUDE DIRECTOR INDICATOR
4020547-905	AD-600B	ATTITUDE DIRECTOR INDICATOR
4020547-906	AD-600A	ATTITUDE DIRECTOR INDICATOR
4020547-907	AD-600A	ATTITUDE DIRECTOR INDICATOR
4020547-908	AD-600B	ATTITUDE DIRECTOR INDICATOR
4020550-901	AD-300D	ATTITUDE DIRECTOR INDICATOR
4020550-903	AD-300D	ATTITUDE DIRECTOR INDICATOR
4020550-904	AD-300H	ATTITUDE DIRECTOR INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
4020553-901	RD-600	HORIZONTAL SITUATION INDICATOR
4020553-902	RD-600	HORIZONTAL SITUATION INDICATOR
4020553-904	RD-600	HORIZONTAL SITUATION INDICATOR
4020577-3	C-14D	DIRECTIONAL GYRO
4020577-6	C-14D	DIRECTIONAL GYRO
4020577-8	C-14D	DIRECTIONAL GYRO
4022211-100	GH-14B	GYRO HORIZON
4024130-901		RAM AIR TEMP/THRUST RATING INDICATOR
4024130-902		RAM AIR TEMP/THRUST RATING INDICATOR
4024130-903		RAM AIR TEMP/THRUST RATING INDICATOR
4024130-904		RAM AIR TEMP/THRUST RATING INDICATOR
40252	LKCB-18041	D.C. AMMETER
4025782-901	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-902	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-903	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-904	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-905	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-906	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-907	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-908	RD-600A	HORIZONTAL SITUATION INDICATOR
4025782-909	RD-600A	HORIZONTAL SITUATION INDICATOR
4026667-901		YAW RATE GYRO
402EED1-1	S231N001-6	STANDBY ENGINE INDICATOR
402EED1-3	S231N001-15	STANDBY ENGINE INDICATOR
402EED2-1	S231N001-11	STANDBY ENGINE INDICATOR
402EED3-2	S231N001-14	STANDBY ENGINE INDICATOR
402FL		DESYNN POSITION INDICATOR
40-300-1		STATIC AIR TEMPERATURE INDICATOR
40-302-1		TOTAL AIR TEMPERATURE INDICATOR
40-302-3	60B 40013-3	TOTAL AIR TEMPERATURE INDICATOR
40-302-4		TOTAL AIR TEMPERATURE INDICATOR
40-309-1		TRUE AIRSPEED INDICATOR
4030949-901		CONTROL PANEL
4030949-902		CONTROL PANEL
4030949-903		CONTROL PANEL
4030949-904		CONTROL PANEL
4030949-905		CONTROL PANEL
4030949-906		CONTROL PANEL
4030949-907		CONTROL PANEL
4030949-908		CONTROL PANEL
4030949-930		CONTROL PANEL
4030949-931		CONTROL PANEL
4030949-932		CONTROL PANEL
4030949-933		CONTROL PANEL
4030949-935		CONTROL PANEL
4030B		ALTITUDE ALERTING SYSTEM
4031B		ALTITUDE ALERTING SYSTEM
4033169-901	RD-700	HORIZONTAL SITUATION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
4033169-902	RD-700	HORIZONTAL SITUATION INDICATOR
4034559-901	DB-100	DISTANCE BEARING INDICATOR
4034559-902	DB-100	DISTANCE BEARING INDICATOR
4034559-908	DB-100	DISTANCE BEARING INDICATOR
4034559-909	DB-100	DISTANCE BEARING INDICATOR
4034559-910	DB-100	DISTANCE BEARING INDICATOR
4038170-904		CONTROL DISPLAY UNIT
4038170-905		CONTROL DISPLAY UNIT
4038890-910		MODE CONTROL PANEL
4038890-912		MODE CONTROL PANEL
4038890-913		MODE CONTROL PANEL
4038890-916		MODE CONTROL PANEL
4038890-917		MODE CONTROL PANEL
4038890-918		MODE CONTROL PANEL
4038890-919		MODE CONTROL PANEL
4038890-920		MODE CONTROL PANEL
4038890-921		MODE CONTROL PANEL
4038890-922		MODE CONTROL PANEL
4038890-927		MODE CONTROL PANEL
4038890-928		MODE CONTROL PANEL
4038890-930		MODE CONTROL PANEL
4038890-931		MODE CONTROL PANEL
4038890-932		MODE CONTROL PANEL
4038890-937		MODE CONTROL PANEL
4038890-938		MODE CONTROL PANEL
4038890-940		MODE CONTROL PANEL
4038890-941		MODE CONTROL PANEL
4038890-947		MODE CONTROL PANEL
4038890-948		MODE CONTROL PANEL
4038890-950		MODE CONTROL PANEL
4038890-951		MODE CONTROL PANEL
4039891-903	SI-800	AIRSPEED/MACH INDICATOR
4039891-904	SI-800	AIRSPEED/MACH INDICATOR
4039891-905	SI-800	AIRSPEED/MACH INDICATOR
4039891-906	SI-800	AIRSPEED/MACH INDICATOR
4039891-907	SI-800	AIRSPEED/MACH INDICATOR
4039892-904	BA-800	BAROMETRIC ALTIMETER
4039892-905	BA-800	BAROMETRIC ALTIMETER
4039892-906	BA-800	BAROMETRIC ALTIMETER
4039892-907	BA-800	BAROMETRIC ALTIMETER
4039892-908	BA-800	BAROMETRIC ALTIMETER
4039892-909	BA-800	BAROMETRIC ALTIMETER
4039892-910	BA-800	BAROMETRIC ALTIMETER
4039893-902	VS-800	VERTICAL SPEED INDICATOR
4039893-903	VS-800	VERTICAL SPEED INDICATOR
4040800-902		AIR DATA COMPUTER
4040800-904		AIR DATA COMPUTER
4040800-905		AIR DATA COMPUTER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
4040800-906		AIR DATA COMPUTER
4040800-907		AIR DATA COMPUTER
4040800-908		AIR DATA COMPUTER
4040800-909		AIR DATA COMPUTER
4040800-911		AIR DATA COMPUTER
4040800-912		AIR DATA COMPUTER
4040800-915		AIR DATA COMPUTER
4045053-903		AIR DATA COMPUTER
4045053-910		AIR DATA COMPUTER
4045053-912		AIR DATA COMPUTER
4045053-914		AIR DATA COMPUTER
4045147-902	RD-700M	HORIZONTAL SITUATION INDICATOR
4051601-911		MODE CONTROL PANEL
4051601-912		MODE CONTROL PANEL
4051601-913		MODE CONTROL PANEL
4051601-915		MODE CONTROL PANEL
4051601-916		MODE CONTROL PANEL
4051601-917		MODE CONTROL PANEL
4051601-918		MODE CONTROL PANEL
4051601-919		MODE CONTROL PANEL
4051601-920		MODE CONTROL PANEL
4051601-925		MODE CONTROL PANEL
4051601-926		MODE CONTROL PANEL
4051601-932		MODE CONTROL PANEL
4051601-935		MODE CONTROL PANEL
4051601-936		MODE CONTROL PANEL
4051601-937		MODE CONTROL PANEL
4051601-938		MODE CONTROL PANEL
4051601-939		MODE CONTROL PANEL
4051601-940		MODE CONTROL PANEL
4051601-999		MODE CONTROL PANEL
40-533		SPEED TRANSDUCER
40-575		HYTROL WHEEL SPEED TRANSDUCER ASSEMBLY
4059005-901		ELEVATOR LOAD FEEL/FLAP LIMITER DUPLEX
4061100-901	HG480E1	DIGITAL AIR DATA COMPUTER
40-618	S253T405	STABILIZER TRIM IND.
40-618-11	S253T405-11	STABILIZER TRIM INDICATOR
40-618-12	S253T405-12	STABILIZER TRIM INDICATOR
40-618-14	S253T405-14	STABILIZER TRIM INDICATOR
40-618-2	S253T405	STABILIZER TRIM INDICATOR
40-618-4	S253T405	STABILIZER TRIM INDICATOR
40-618-5	S523T405-5	STABILIZER TRIM INDICATOR
40-618-6	S253T405-6	STABILIZER TRIM INDICATOR
40-618-7	SS253T405-7	STABILIZER TRIM INDICATOR
40-618-8	S253T405-8	STABILIZER TRIM INDICATOR
40705BX-1A		OSCILLATING NAVIGATIONAL LIGHT
40705BX-1A-4614		OSCILLATING NAVIGATIONAL LIGHT
40705BX-1B		OSCILLATING NAVIGATIONAL LIGHT



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
40705BX-1B-4614		OSCILLATING NAVIGATIONAL LIGHT
40705BX-2A		OSCILLATING NAVIGATIONAL LIGHT
40705BX-2A-4614		OSCILLATING NAVIGATIONAL LIGHT
40705BX-2B		OSCILLATING NAVIGATIONAL LIGHT
40705BX-2B-4614		OSCILLATING NAVIGATIONAL LIGHT
40705BX-A		OSCILLATING NAVIGATIONAL LIGHT
40705BX-B		OSCILLATING NAVIGATIONAL LIGHT
40-817	10-61093-181	WHEEL SPEED TRANSDUCER
4082260-937		MODE CONTROL PANEL
4082260-939		MODE CONTROL PANEL
40-835	10-61853-21	WHEEL SPEED TRANSDUCER
409PG		PRESSURE GAUGE
409PGM		PRESSURE GAUGE
40D18		DIFFERENTIAL PRESSURE SWITCH
40D33-1		DIFFERENTIAL PRESSURE SWITCH
4101415		AVIONICS COOLING FAN
410PG		PRESSURE GAUGE
410PGM		PRESSURE GAUGE
415PG	4145B1	ATTITUDE INDICATOR
415PG/SB		DESYNN PRESSURE INDICATOR
417PG		DIRECT READING PRESSURE GAUGE
417T3051-130SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-178SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-181SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-182SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-183SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-184SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-185SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-186SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-187SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-196SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-197SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-198SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-330SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-378SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-380SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-381SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-382SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-383SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-384SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-385SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-386SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-387SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-396SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-397SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-398SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-399SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-428SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
417T3051-438SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-444SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-448SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-457SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-467SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-476SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-478SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-480SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-481SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-484SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-485SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-486SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-487SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-488SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-492SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-494SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-495SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-496SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-497SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-498SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-499SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-501B		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-502B		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-600SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-64SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-65SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-70SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-71SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-73SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-74SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-75SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-78SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-79SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-80SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-81SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-82SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-83SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-84SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-85SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-86SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-87SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-96SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3051-97SP		INBOARD PSU OXYGEN/LIGHT PANEL ASSY
417T3052-133SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-141SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-143SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-144SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-146SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
417T3052-147SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-151SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-153SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-155SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-157SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-160SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-163SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-164SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-165SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-166SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-33SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-341SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-347SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-34SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-355SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-357SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-363SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-364SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-365SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-366SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-37SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-38SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-41SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-43SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-441SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-445SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-447SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-44SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-455SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-457SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-463SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-464SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-465SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-466SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-467SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-468SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-469SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-46SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-470SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-472B		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-473B		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-474B		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3052-47SP		OUTBOARD PASS. SERVICE UNIT OXY/LIGHT PANEL
417T3053-10		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-102		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-104		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-109		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-110		PSU OXYGEN/LIGHT PANEL ASSY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
417T3053-119		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-129		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-130		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-151		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-19		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-2		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-202		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-204		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-209		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-210		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-230		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-241		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-245		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-251		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-29		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-30		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-4		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-41		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-43		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-45		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-46		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-49		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-50		PSU OXYGEN/LIGHT PANEL ASSY
417T3053-9		PSU OXYGEN/LIGHT PANEL ASSY
417T3057-11		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-12		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-13		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-15		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-22		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-23		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-25		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-42		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-43		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-45		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-7		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T3057-8		PASSENGER SERVICE UNIT SPEAKER PANEL ASSY
417T6008-16		FORWARD ATTENDANTS PANEL ASSY
417T6008-17		FORWARD ATTENDANTS PANEL ASSY
417T6008-18		FORWARD ATTENDANTS PANEL ASSY
417T6008-20		FORWARD ATTENDANTS PANEL ASSY
417T6008-22		FORWARD ATTENDANTS PANEL ASSY
417T6008-23		FORWARD ATTENDANTS PANEL ASSY
417T6008-24		FORWARD ATTENDANTS PANEL ASSY
417T6008-26		FORWARD ATTENDANTS PANEL ASSY
417T6008-27		FORWARD ATTENDANTS PANEL ASSY
417T6008-29		FORWARD ATTENDANTS PANEL ASSY
417T6008-30		FORWARD ATTENDANTS PANEL ASSY
417T6008-31		FORWARD ATTENDANTS PANEL ASSY





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
417T6008-32		FORWARD ATTENDANTS PANEL ASSY
417T6008-33		FORWARD ATTENDANTS PANEL ASSY
417T6008-34		FORWARD ATTENDANTS PANEL ASSY
417T6008-35		FORWARD ATTENDANTS PANEL ASSY
417T6008-36		FORWARD ATTENDANTS PANEL ASSY
417T6008-37		FORWARD ATTENDANTS PANEL ASSY
417T6008-38		FORWARD ATTENDANTS PANEL ASSY
417T6008-39		FORWARD ATTENDANTS PANEL ASSY
417T6008-40		FORWARD ATTENDANTS PANEL ASSY
417T6008-41		FORWARD ATTENDANTS PANEL ASSY
417T6708-6		FORWARD ATTENDANTS PANEL ASSY
417T6708-7		FORWARD ATTENDANTS PANEL ASSY
418-00041		OIL PRESSURE TRANSMITTER
41800044		OIL PRESSURE TRANSMITTER
418-00141		OIL PRESSURE TRANSMITTER
418-01031		FUEL PRESSURE TRANSMITTER
418-01034		FUEL PRESSURE TRANSMITTER
418-01131		FUEL PRESSURE TRANSMITTER
418-02084		OIL PRESSURE TRANSMITTER
418-17054	1031026 ©	FUEL PRESSURE TRANSMITTER
418-24044		OIL PRESSURE TRANSMITTER
4188-00		STATIC INVERTER
4191695		RETRACTABLE LANDING LIGHT
419FL		DESYNN POSITION INDICATOR
41SG118-1		PRESSURE TRANSDUCER
41SG118-2		PRESSURE TRANSDUCER
41SG265-1		PRESSURE TRANSDUCER
420035-1	S210T170-20	MOTOR ACTUATED FLAPPER SELECTOR VALVE
420035-2	S210T170-30	MOTOR ACTUATED FLAPPER SELECTOR VALVE
420035-3	S210T170-40	MOTOR ACTUATED FLAPPER SELECTOR VALVE
4213989		LANDING LIGHT
4215-01	10-61219-113	DIGITAL CALIBRATION TRIM UNIT
4215-02	60B92017-8	DIGITAL CALIBRATION TRIM UNIT
4215-04	60B92017-6	DIGITAL CALIBRATION TRIM UNIT
4215-05	60B92017-7	DIGITAL CALIBRATION TRIM UNIT
4215-07	60B92017-5	DIGITAL CALIBRATION TRIM UNIT
4215-08	60B92017-9	DIGITAL CALIBRATION TRIM UNIT
421FL		DESYNN POSITION INDICATOR
422FL		DESYNN POSITION INDICATOR
42-31-11-038		ROTOR
4233488		TAKE OFF LIGHT
4236534		RUNWAY TURN-OFF LIGHT
4236564		TAXI LIGHT
423FL		DESYNN POSITION INDICATOR
4260-10		CARGO COMPARTMENT LIGHT
4260-10-01		CARGO COMPARTMENT LIGHT
4260-10-02		CARGO COMPARTMENT LIGHT
426FL		DESYNN POSITION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
4274-10-06		DOME LED LIGHT
4275-00-20000		DOME LED LIGHT
4275-10-00000		DOME LED LIGHT
4275-12-10000		DOME LED LIGHT
4275-21-10280		DOME LED LIGHT
427FL		DESYNN POSITION INDICATOR
42895A		TANDEM OSCILLATING LIGHT
42895A16870		TANDEM OSCILLATING LIGHT
42895A17-16870		TANDEM OSCILLATING LIGHT
42895A3		TANDEM OSCILLATING LIGHT
42895A3-16870		TANDEM OSCILLATING LIGHT
42895A5		TANDEM OSCILLATING LIGHT
42895A5-16870		TANDEM OSCILLATING LIGHT
42895A7		TANDEM OSCILLATING LIGHT
42895A7-16870		TANDEM OSCILLATING LIGHT
42-903	903BD	GYROSCOPIC HORIZON
42-903BDV21	903BDV21	GYROSCOPIC HORIZON
42-903BDV4	903BDV4	GYROSCOPIC HORIZON
42-903BDV5	903BDV5	GYROSCOPIC HORIZON
42-904	904	GYROSCOPIC HORIZON
4292915		LANDING LIGHT
42D107A1	10-3269-8	PRESSURE SWITCH
42D107A2		PRESSURE SWITCH
42D185		PRESSURE SWITCH
42D275		PRESSURE SWITCH
42D275-1		PRESSURE SWITCH
42D362		DIFFERENTIAL PRESSURE SWITCH
42D394		DIFFERENTIAL PRESSURE SWITCH
42D395		DIFFERENTIAL PRESSURE SWITCH
42D49C		PRESSURE SWITCH
4315542		RETRACTABLE LANDING LIGHT
4319586		LANDING LIGHT
4331772		RETRACTABLE LANDING LIGHT
43325-10		TANTEM OSCILLATING LIGHT
43325-10-16870		TANDEM OSCILLATING LIGHT
43325-11-16870		TANDEM OSCILLATING LIGHT
435FL		DESYNN POSITION INDICATOR
443FL		DESYNN POSITION INDICATOR
448FL		DESYNN POSITION INDICATOR
449-1		0-5 VDC LAMP POWER SUPPLY
449-2		0-5 VDC LAMP POWER SUPPLY
449-3		0-5 VDC LAMP POWER SUPPLY
449-4		0-5 VDC LAMP POWER SUPPLY
449FL		DESYNN POSITION INDICATOR
45-0057-1		LANDING LIGHT ASSY
45-0057-11		LANDING LIGHT ASSY
45-0057-3		LANDING LIGHT ASSY
45-0057-9		LANDING LIGHT ASSY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
45-0060-10		RETRACTABLE AIRCRAFT LANDING LIGHT
45-0060-11		RETRACTABLE AIRCRAFT LANDING LIGHT
45-0060-12		RETRACTABLE AIRCRAFT LANDING LIGHT
45-0060-13		RETRACTABLE AIRCRAFT LANDING LIGHT
45-0060-6		RETRACTABLE AIRCRAFT LANDING LIGHT
45-0060-7		RETRACTABLE AIRCRAFT LANDING LIGHT
45-0083-1	10-61366-1	LANDING LIGHT ASSY.
45-0083-2	10-61366-2	LANDING LIGHT ASSY.
45-0083-3	10-61366-3	LANDING LIGHT ASSY.
45-0083-5	10-61366-5	LANDING LIGHT ASSY.
45-0083-7	10-61366-7	LANDING LIGHT ASSY.
4510-31LF-00		BEVERAGE MAKER
4510-31LG-00		BEVERAGE MAKER
4510-31UF-00		BEVERAGE MAKER
4510-31UG-00		BEVERAGE MAKER
4510-32LF-00		BEVERAGE MAKER
4510-32LG-00		BEVERAGE MAKER
4510-32UF-00		BEVERAGE MAKER
4510-32UG-00		BEVERAGE MAKER
4510-33LF-00		BEVERAGE MAKER
4510-33LG-00		BEVERAGE MAKER
4510-33UF-00		BEVERAGE MAKER
4510-33UG-00		BEVERAGE MAKER
4510-34LF-00		BEVERAGE MAKER
4510-34LG-00		BEVERAGE MAKER
4510-34UF-00		BEVERAGE MAKER
4510-34UG-00		BEVERAGE MAKER
4510-35LF-00		BEVERAGE MAKER
4510-35LG-00		BEVERAGE MAKER
4510-35UF-00		BEVERAGE MAKER
4510-35UG-00		BEVERAGE MAKER
4510-36LF-00		BEVERAGE MAKER
4510-36LG-00		BEVERAGE MAKER
4510-36UF-00		BEVERAGE MAKER
4510-36UG-00		BEVERAGE MAKER
4510-37LF-00		BEVERAGE MAKER
4510-37LG-00		BEVERAGE MAKER
4510-37UF-00		BEVERAGE MAKER
4510-37UG-00		BEVERAGE MAKER
4510-38LF-00		BEVERAGE MAKER
4510-38LG-00		BEVERAGE MAKER
4510-38UF-00		BEVERAGE MAKER
4510-38UG-00		BEVERAGE MAKER
4510-41LF-00		BEVERAGE MAKER
4510-41LG-00		BEVERAGE MAKER
4510-41UF-00		BEVERAGE MAKER
4510-41UG-00		BEVERAGE MAKER
4510-42LF-00		BEVERAGE MAKER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
4510-42LG-00		BEVERAGE MAKER
4510-42UF-00		BEVERAGE MAKER
4510-42UG-00		BEVERAGE MAKER
4510-43LF-00		BEVERAGE MAKER
4510-43LG-00		BEVERAGE MAKER
4510-43UF-00		BEVERAGE MAKER
4510-43UG-00		BEVERAGE MAKER
4510-44LF-00		BEVERAGE MAKER
4510-44LG-00		BEVERAGE MAKER
4510-44UF-00		BEVERAGE MAKER
4510-44UG-00		BEVERAGE MAKER
4510-45LF-00		BEVERAGE MAKER
4510-45LG-00		BEVERAGE MAKER
4510-45UF-00		BEVERAGE MAKER
4510-45UG-00		BEVERAGE MAKER
4510-46LF-00		BEVERAGE MAKER
4510-46LG-00		BEVERAGE MAKER
4510-46UF-00		BEVERAGE MAKER
4510-46UG-00		BEVERAGE MAKER
4510-47LF-00		BEVERAGE MAKER
4510-47LG-00		BEVERAGE MAKER
4510-47UF-00		BEVERAGE MAKER
4510-47UG-00		BEVERAGE MAKER
4510-48LF-00		BEVERAGE MAKER
4510-48LG-00		BEVERAGE MAKER
4510-48UF-00		BEVERAGE MAKER
4510-48UG-00		BEVERAGE MAKER
452FL		DESYNN POSITION INDICATOR
454PG		PRESSURE GAUGE
457574		DIFFERENTIAL PRESSURE SWITCH
457PG		PRESSURE GAUGE
45D16		GAGE PRESSURE SWITCH
45D16-1		GAGE PRESSURE SWITCH
45D31-2		DIFFERENTIAL PRESSURE SWITCH
45D32		DIFFERENTIAL PRESSURE SWITCH
45D34		DIFFERENTIAL PRESSURE SWITCH
46155		EGT INDICATOR
46157		CHT INDICATOR
461FL		DESYNN POSITION INDICATOR
46362-1		ALTERNATING CURRENT MOTOR
46362-2		ALTERNATING CURRENT MOTOR
46366-1		ALTERNATING CURRENT MOTOR
46366-2		ALTERNATING CURRENT MOTOR
467FL		DESYNN POSITION INDICATOR
467PG		PRESSURE GAUGE
473FL		DESYNN POSITION INDICATOR
474FL		DESYNN POSITION INDICATOR
4-8020-04		DIRECTIONAL GYRO



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
4-8020-05		DIRECTIONAL GYRO
4-8020-06		DIRECTIONAL GYRO
482-0011-010	332C-8	RADIO MAGNETIC HEADING INDICATOR
482-0011-020	332C-8	RADIO MAGNETIC HEADING INDICATOR
487PG		PRESSURE GAUGE
489PG		PRESSURE GAUGE
490PG		PRESSURE GAUGE
494FL		DESYNN POSITION INDICATOR
496-01740		OIL PRESSURE INDICATOR
496-02740	496-02740	OIL PRESSURE INDICATOR
498392-0001		CRT MONITOR
498392-0002		CRT MONITOR
498392-0003		CRT MONITOR
498392-0004		CRT MONITOR
498392-0006		CRT MONITOR
498926-0001		CRT MONITOR
498926-0002		CRT MONITOR
499FL		DESYNN POSITION INDICATOR
50086-001		CIRCUIT BREAKER
50086-002		CIRCUIT BREAKER
50086-003		CIRCUIT BREAKER
501-1075-01	PS-823A	EMERGENCY POWER SUPPLY
501-1075-02	PS-823B	EMERGENCY POWER SUPPLY
501-1075-03	PS-823C	EMERGENCY POWER SUPPLY
501-1075-04	PS-823D	EMERGENCY POWER SUPPLY
501-1075-05	PS-823A/T	EMERGENCY POWER SUPPLY
501-1075-06	PS-823B/T	EMERGENCY POWER SUPPLY
501-1075-07	PS-823C/T	EMERGENCY POWER SUPPLY
501-1075-08	PS-823D/T	EMERGENCY POWER SUPPLY
501-1075-09	PS-823E	EMERGENCY POWER SUPPLY
501-1075-10	PS-823F	EMERGENCY POWER SUPPLY
501-1075-11	PS-823G	EMERGENCY POWER SUPPLY
501-1075-12	PS-823H	EMERGENCY POWER SUPPLY
501-1075-13	PS-823E/T	EMERGENCY POWER SUPPLY
501-1075-14	PS-823F/T	EMERGENCY POWER SUPPLY
501-1075-15	PS-823G/T	EMERGENCY POWER SUPPLY
501-1075-16	PS-823H/T	EMERGENCY POWER SUPPLY
501-1539-01		ATTITUDE INDICATOR
501-1539-02		ATTITUDE INDICATOR
5018-110-00-10		ENGINE SHUTDOWN DETECTOR
501FAD1-1	10-62153-1	AIR DATA COMPUTER
501FL		DESYNN POSITION INDICATOR
50-2-3100-00		HYDRAULIC PRESSURE SWITCH
502B10D		TURBINE TEMP. INDICATOR
502FL		DESYNN POSITION INDICATOR
5034-1		AUDIO SELECTOR PANEL
503FAD1-1		AIR DATA COMPUTER
503FAD1-2		AIR DATA COMPUTER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
503PG		DIRECT READING PRESSURE GAUGE
504-0033-921	305-1A	ATTITUDE GYRO
504-0033-922	305-1AL	ATTITUDE GYRO
504-0033-923	305-1B	ATTITUDE GYRO
504-0033-924	305-1BL	ATTITUDE GYRO
504-0033-925	305-1C	ATTITUDE GYRO
504-0033-926	305-1CL	ATTITUDE GYRO
504-0033-927	305-2A	ATTITUDE GYRO
504-0033-928	305-2AL	ATTITUDE GYRO
504-0033-929	305-2B	ATTITUDE GYRO
504-0033-930	305-2BL	ATTITUDE GYRO
504-0033-931	305-2C	ATTITUDE GYRO
504-0033-932	305-2CL	ATTITUDE GYRO
504-0033-933	305-2BC	ATTITUDE GYRO
504-0033-934	305-2BLS	ATTITUDE GYRO
50483-19	10-61255-19	PRESSURE INDICATOR
50483-20	10-61255-20	PRESSURE INDICATOR
50550	SBU-23A/A	GYROSCOPE, DISPLACEMENT
50579		HYDRAULIC PRESSURE TRANSMITTER IND.
510784-1		ENGINE PRESSURE RATIO IND.
5126-220-80-11		FUEL TEMPERATURE INDICATOR
5126-223-80-11		FUEL TEMPERATURE INDICATOR
513FL		DESYNN POSITION INDICATOR
5145-1-24	10-62090-24	AUDIO CONTROL PANEL
5145-1-24A	10-62090-24	AUDIO CONTROL PANEL
5145-1-40	10-62090-40	AUDIO CONTROL PANEL
5145-1-40A	10-62090-40	AUDIO CONTROL PANEL
5145-1-43	10-62090-43	AUDIO CONTROL PANEL
5145-1-43A	10-62090-43	AUDIO CONTROL PANEL
5145-1-44	10-62090-44	AUDIO CONTROL PANEL
5145-1-44A	10-62090-44	AUDIO CONTROL PANEL
5145-1-46	10-62090-46	AUDIO CONTROL PANEL
5145-1-46A	10-62090-46	AUDIO CONTROL PANEL
5145-1-47	10-62090-47	AUDIO CONTROL PANEL
5145-1-47A	10-62090-47	AUDIO CONTROL PANEL
5145-1-48	10-62090-48	AUDIO CONTROL PANEL
5145-1-48A	10-62090-48	AUDIO CONTROL PANEL
5145-1-60	10-62090-60	AUDIO CONTROL PANEL
5145-1-60A	10-62090-60	AUDIO CONTROL PANEL
5145-1-61	10-62090-61	AUDIO CONTROL PANEL
5145-1-61A	10-62090-61	AUDIO CONTROL PANEL
5145-1-62A	10-62090-62	AUDIO CONTROL PANEL
5145-1-62B	10-62090-62	AUDIO CONTROL PANEL
5145-1-63	10-62090-63	AUDIO CONTROL PANEL
5145-1-63A	10-62090-63	AUDIO CONTROL PANEL
5145-1-64	10-62090-64	AUDIO CONTROL PANEL
5145-1-64A	10-62090-64	AUDIO CONTROL PANEL
5145-1-65	10-62090-65	AUDIO CONTROL PANEL



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
5145-1-65A	10-62090-65	AUDIO CONTROL PANEL
5145-1-70	10-62090-70	AUDIO CONTROL PANEL
5145-1-70A	10-62090-70	AUDIO CONTROL PANEL
5145-1-71	10-62090-71	AUDIO CONTROL PANEL
5145-1-71A	10-62090-71	AUDIO CONTROL PANEL
516FL		DESYNN POSITION INDICATOR
517PG		DIRECT READING PRESSURE GAUGE
520192	1122-50LW	APU, % RPM INDICATOR
520425	1825-202LW	DC VOLT/AMMETER
520445	1838-101LW	ENGINE VIBRATION MONITORING IND.
520467	1825-12LW	COMPARTMENT & DUCT TEMP. IND.
520580		N1 TACHOMETER, APU INDICATOR
520586	60B00109-4	QUANTITY INDICATOR
520678	60B00130-3	ENGINE OIL TEMPERATURE IND.
520749	60B00130-5	ENGINE OIL TEMPERATURE IND.
520750		TEMPERATURE INDICATOR
520773	1834-6LW	TEMPERATURE INDICATOR
520774	1834-7LW	TEMPERATURE INDICATOR
520775		VIBRATION INDICATOR
520FL		DESYNN POSITION INDICATOR
521159		EGT APU INDICATOR
521214	1822-122LW	OIL TEMP INDICATOR
521236	1838-106LW	APU RPM SHAFT SPEED INDICATOR
521313	60B00117-4	OIL TEMP. INDICATOR
521314	1822-122LW	OIL TEMP. INDICATOR
521389		AIR TEMPERATURE INDICATOR
521603	60B00130-102	ENGINE OIL TEMP. INDICATOR
521615	1825-28LW	COMPTMNT & SUPPLY DUCT TEMP. IND.
521636		WATT/VAR INDICATOR
521677		TRIM INDICATOR
521679		TRIM INDICATOR
521688	1834-17LW	TEMPERATURE INDICATOR
521689	1834-18LW	TEMPERATURE INDICATOR
521701	1812-14LW	LUBE OIL TEMPERATURE INDICATOR
521874	1822-118LW	WATT/VAR INDICATOR
521952		OIL TEMPERATURE INDICATOR
521FL		DESYNN POSITION INDICATOR
522-0690-003	331C-4	BEARING-DISTANCE-HEADING INDICATOR
522-0974-003	331C-4A	BEARING-DISTANCE-HEADING INDICATOR
522105	1812-18LW	OIL TEMPERATURE INDICATOR
522-1859-003	339D-1	DISTANCE INDICATOR
522-1859-013	339D-1	DISTANCE INDICATOR
522-1859-023	339D-1	DISTANCE INDICATOR
522-1859-033	339D-1	DISTANCE INDICATOR
522-1859-043	339D-1	DISTANCE INDICATOR
522-1859-053	339D-1	DISTANCE INDICATOR
522-1859-063	339D-1	DISTANCE INDICATOR
522-1859-064	339D-1	DISTANCE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
522-1859-065	339D-1	DISTANCE INDICATOR
522-1859-066	339D-1	DISTANCE INDICATOR
522-1859-067	339D-1	DISTANCE INDICATOR
522-1859-068	339D-1	DISTANCE INDICATOR
522-1859-069	339D-1	DISTANCE INDICATOR
522-1859-070	339D-1	DISTANCE INDICATOR
522-1859-071	339D-1	DISTANCE INDICATOR
522231	1829-16LW	POSITION INDICATOR
522-2604-003	339D-1A	DISTANCE INDICATOR
522-2604-013	339D-1A	DISTANCE INDICATOR
522-2604-023	339D-1A	DISTANCE INDICATOR
522-2604-024	339D-1A	DISTANCE INDICATOR
522-2604-025	339D-1A	DISTANCE INDICATOR
522-2604-026	339D-1A	DISTANCE INDICATOR
522-2638-000	331A-3G	COURSE INDICATOR
522-2638-001	331A-3G	COURSE INDICATOR
522-2638-002	331A-3G	COURSE INDICATOR
522-2638-003	331A-3G	COURSE INDICATOR
522-2638-005	331A-3G	COURSE INDICATOR
522-2638-006	331A-3G	COURSE INDICATOR
522-2638-007	331A-3G	COURSE INDICATOR
522-2638-008	331A-3G	COURSE INDICATOR
522-2638-009	331A-3G	COURSE INDICATOR
522-2638-010	331A-3G	COURSE INDICATOR
522274		FUEL TEMPERATURE INDICATOR
522-2782-004	331A-6A	COURSE INDICATOR
522-2782-014	331A-6	COURSE INDICATOR
522-2782-024	331A-6A	COURSE INDICATOR
522-2782-034	311A-6A	COURSE INDICATOR
522-2782-037	331A-6A	COURSE INDICATOR
522-2919-003	339D-3B	DISTANCE INDICATOR
522-2919-013	339D-3B	DISTANCE INDICATOR
522-2919-015	339D-3B	DISTANCE INDICATOR
522-2919-016	339D-3B	DISTANCE INDICATOR
522-2920-003	339D-3C	DISTANCE INDICATOR
522-3073-000	331A-6D	COURSE INDICATOR
522-3073-012	331A-6D	COURSE INDICATOR
522-3122-004	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-005	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-006	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-007	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-008	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-009	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-010	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-011	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-012	329B-7	FLIGHT DIRECTOR INDICATOR
522-3122-013	329B-7	FLIGHT DIRECTOR INDICATOR
522-3138-004	331A-7	COURSE INDICATOR





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
522-3138-007	331A-7	COURSE INDICATOR
522-3138-008	331A-7	COURSE INDICATOR
522-3206-004	329B-7A	FLIGHT DIRECTOR INDICATOR
522-3206-005	329B-7A	FLIGHT DIRECTOR INDICATOR
522-3206-006	329B-7A	FLIGHT DIRECTOR INDICATOR
522-3206-007	329B-7A	FLIGHT DIRECTOR INDICATOR
522-3206-008	329B-7A	FLIGHT DIRECTOR INDICATOR
522-3206-009	329B-7A	FLIGHT DIRECTOR INDICATOR
522-3241-000	332E-4	DIRECTIONAL GYRO
522327	1829-18LW	VALVE POSITION INDICATOR
522-3342-001	331A-6E	COURSE INDICATOR
522-3342-002	331A-6A	COURSE INDICATOR
522-3342-003	331A-6E	COURSE INDICATOR
522-3342-004	331A-6E	COURSE INDICATOR
522-3342-005	331A-6E	COURSE INDICATOR
522-3343-000	339D-3C	DISTANCE INDICATOR
522-3343-011	339D-3C	DISTANCE INDICATOR
522-3343-012	339D-3C	DISTANCE INDICATOR
522-3343-013	339D-3C	DISTANCE INDICATOR
522-3487-001	329B-7C	FLIGHT DIRECTOR INDICATOR
522-3487-002	329B-7C	FLIGHT DIRECTOR INDICATOR
522-3487-003	329B-7C	FLIGHT DIRECTOR INDICATOR
522-3487-004	329B-7C	FLIGHT DIRECTOR INDICATOR
522-3487-007	329B-7C	FLIGHT DIRECTOR INDICATOR
522-3487-009	329B-7C	FLIGHT DIRECTOR INDICATOR
522-3487-010	329B-7C	FLIGHT DIRECTOR INDICATOR
522-3550-004	331A-7A	COURSE INDICATOR
522-3618-001	329B-7F	FLIGHT DIRECTOR INDICATOR
522-3618-003	329B-7F	FLIGHT DIRECTOR INDICATOR
522-3667-001	329B-7G	FLIGHT DIRECTOR INDICATOR
522-3700-004	329B-8A	FLIGHT DIRECTOR INDICATOR
522-3700-009	329B-8A	FLIGHT DIRECTOR INDICATOR
522-3752-001	329B-7F	FLIGHT DIRECTOR INDICATOR
522-3752-002	329B-7F1	FLIGHT DIRECTOR INDICATOR
522-3867-001	329B-7J	FLIGHT DIRECTOR INDICATOR
522-3867-002	329B-7J	FLIGHT DIRECTOR INDICATOR
522-3867-003	329B-7J	FLIGHT DIRECTOR INDICATOR
522-3875-001	331A-6K	COURSE INDICATOR
522-3877-001	329B-7K	FLIGHT DIRECTOR INDICATOR
522-3877-002	329B-7K	FLIGHT DIRECTOR INDICATOR
522-3908-001	329B-7M	FLIGHT DIRECTOR INDICATOR
522-3908-002	329B-7M	FLIGHT DIRECTOR INDICATOR
522-3908-003	329B-7M	FLIGHT DIRECTOR INDICATOR
522396	1822-337LW	HYD QTY LEVEL INDICATOR
522-3985-001	332D-11	VERTICAL GYRO
522403		OIL TEMP. INDICATOR
522406	1825-81LW	DC VOLT/ AMMETER
522-4063-001	329B-8C	FLIGHT DIRECTOR INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
522-4063-003	329B-8C	FLIGHT DIRECTOR INDICATOR
522409	60B00117-7	OIL TEMP. INDICATOR
522-4114-002	339H-1	RADIO ALTITUDE INDICATOR
522-4114-003	339H-1	RADIO ALTITUDE INDICATOR
522-4114-004	339H-1	RADIO ALTITUDE INDICATOR
522-4114-006	339H-1	RADIO ALTITUDE INDICATOR
522-4114-008	339H-1	RADIO ALTITUDE INDICATOR
522-4114-012	399H-1	RADIO ALTITUDE INDICATOR
522-4194-001	329B-8B	FLIGHT DIRECTOR INDICATOR
522-4279-001	331A6A1	COURSE INDICATOR
522-4279-003	331A-6A1	COURSE INDICATOR
522-4353-001	346D-1A	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
522-4354-002	339H-1A	RADIO ALTITUDE INDICATOR
522-4363-004	339H-1B	RADIO ALTITUDE INDICATOR
522-4430-001	329B-8F	FLIGHT DIRECTOR INDICATOR
522-4430-002	329B-8F	FLIGHT DIRECTOR INDICATOR
522-4430-005	329B-8F	FLIGHT DIRECTOR INDICATOR
522-4529-001	329B-8G	FLIGHT DIRECTOR INDICATOR
522-4529-002	329B-8G	FLIGHT DIRECTOR INDICATOR
522-4529-004	329B-8G	FLIGHT DIRECTOR INDICATOR
522453	1838-111LW	ENGINE VIBRATION MONITORING IND.
522-4538-002	346D-1B	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
522-4538-003	346D-1B	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
522-4538-004	346D-1B	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
522-4538-005	346D-1B	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
522-4825-001	339H-2	RADIO ALTITUDE INDICATOR
522484	1812-217LW	RUDDER TRIM INDICATOR
522540	1825-101LW	HYD. PRESSURE INDICATOR
522541	18259-102LW	VOLTAMMETER IND.
522543		APU/EGT INDICATOR
522545	1822-362LW	BATTERY TEMPERATURE INDICATOR
522560	60B00130-7	OIL TEMPERATURE INDICATOR
522561		TEMPERATURE INDICATOR
522690	1829-18L	VALVE POSITION INDICATOR
522782	10-62067-1	VIBRATION MONITOR INDICATOR
522783	S9302350-002	CABIN PRESSURIZATION INDICATOR
522792		PROPELLER SPEED (RPM) INDICATOR
522794		OIL PRESSURE/TEMPERATURE INDICATOR
522795		PROPELLER OIL PRESS/TEMP INDICATOR
522823		TORQUE INDICATOR
522834	1837-211LW	TRIM POSITION INDICATOR
522849		LOW PRESSURE ROTOR SPEED INDICATOR
522861		INTER-TURBINE TEMPERATURE INDICATOR
522948		TORQUE INDICATOR
522FL		DESYNN POSITION INDICATOR
523029	1888 10-5LW	EXHAUST GAS TEMPERATURE INDICATOR
523245		OXYGEN PRESSURE INDICATOR
523271	1822-397LW	BATTERY TEMPERATURE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
523347		INTER-TURBINE TEMPERATURE INDICATOR
523402		INTER-TURBINE TEMPERATURE INDICATOR
523466		INTER-TURBINE TEMPERATURE INDICATOR
523FL		DESYNN POSITION INDICATOR
523PG		DESYNN PRESSURE INDICATOR
523PG/CP		DESYNN PRESSURE INDICATOR
523PG/SB		DESYNN PRESSURE INDICATOR
524PG		PRESSURE GAUGE
525FL		DESYNN POSITION INDICATOR
526FL		DESYNN POSITION INDICATOR
527FL		DESYNN POSITION INDICATOR
528-20		WING TIP NAVIGATION LIGHT
528-30		WING TIP NAVIGATION LIGHT
528-70		WING TIP NAVIGATION LIGHT
528-80		WING TIP NAVIGATION LIGHT
530FL		DESYNN POSITION INDICATOR
530PG		PRESSURE GAUGE
535FL		DESYNN POSITION INDICATOR
540-0712-1		SHUTOFF VALVE ASSEMBLY
541674-1-1	541674	LINEAR ELECTROMECHANICAL ACTUATOR
541674-3	541674	LINEAR ELECTROMECHANICAL ACTUATOR
541674-4	541674	LINEAR ELECTROMECHANICAL ACTUATOR
541674-5	541674	LINEAR ELECTROMECHANICAL ACTUATOR
541674-6	541674	LINEAR ELECTROMECHANICAL ACTUATOR
541932-1-1		ROTARY ACTUATOR
5420-01		FIRE/OVERHEAT DETECTOR
5420-02		FIRE/OVERHEAT DETECTOR
5420-03		FIRE/OVERHEAT DETECTOR
5420-04		FIRE/OVERHEAT DETECTOR
5421-01		FIRE/OVERHEAT DETECTOR
5421-02		FIRE/OVERHEAT DETECTOR
5421-03		FIRE/OVERHEAT DETECTOR
5421-04		FIRE/OVERHEAT DETECTOR
5421-05		FIRE/OVERHEAT DETECTOR
5421-06		FIRE/OVERHEAT DETECTOR
5421-07		FIRE/OVERHEAT DETECTOR
5421-08		FIRE/OVERHEAT DETECTOR
5421-09		FIRE/OVERHEAT DETECTOR
5421-10		FIRE/OVERHEAT DETECTOR
5421-12		FIRE/OVERHEAT DETECTOR
5421-13		FIRE/OVERHEAT DETECTOR
5421-14		FIRE/OVERHEAT DETECTOR
5421-18		FIRE/OVERHEAT DETECTOR
5421-19		FIRE/OVERHEAT DETECTOR
5421-20		FIRE/OVERHEAT DETECTOR
5421-21		FIRE/OVERHEAT DETECTOR
5426-234-8	60B00117-6	CSD OIL TEMP. INDICATOR
5426-241-8	60B00117-8	CSD OIL TEMP. INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
5426-252-8	60B00117-10	CSD OIL TEMP. INDICATOR
5427-404-80-10		DUCT INDICATOR
5428-553-80-10		INTERSTAGE TURBINE TEMP INDICATOR
5428-555-80-10		INTERSTAGE TURBINE TEMP INDICATOR
5428-559-80-10		INTERSTAGE TURBINE TEMP INDICATOR
5428-701-80-10		N1 RPM INDICATOR
5428-706-80-10		N1 RPM INDICATOR
544654-2		ROTARY ELECTROMECHANICAL ACTUATOR
544654-3		ROTARY ELECTROMECHANICAL ACTUATOR
544654-4		ROTARY ELECTROMECHANICAL ACTUATOR
544654-5		ROTARY ELECTROMECHANICAL ACTUATOR
544654-6		ROTARY ELECTROMECHANICAL ACTUATOR
544964-1	70210	ROTARY ELECTRO-MECHANICAL ACTUATOR
548376-4		TEMPERATURE CONTROL
548376-5		TEMPERATURE CONTROL
548376-6	10-60498-13	CABIN TEMPERATURE CONTROLLER
548380-2		TEMPERATURE SELECTOR
548380-3		TEMPERATURE SELECTOR
548382-2		TEMPERATURE SELECTOR
548620-1		THERMOSTATIC SWITCH
548620-2		THERMOSTATIC SWITCH
548620-3		THERMOSTATIC SWITCH
554214-1		DISPLACEMENT GYROSCOPE ASSEMBLY
561FL1		DESYNN POSITION INDICATOR
566FL		DESYNN POSITION INDICATOR
5677-406-80-13		DUAL OIL PRESS/TEMP INDICATOR
5677-407-80-14		DUAL OIL PRESS/TEMP INDICATOR
5677-409-80-10		DUAL OIL PRESS/TEMP INDICATOR
5677-420-80-10		DUAL OIL PRESS/TEMP INDICATOR
5677-421-80-10		DUAL OIL PRESS/TEMP INDICATOR
5677-705-80-10		NH, NL SPEED INDICATOR
5678-552-80-11		TURBINE TEMPERATURE INDICATOR.
5678-553-80-12		TURBINE TEMPERATURE INDICATOR.
5678-710-80-12		NP INDICATOR
5678-711-80-10		NP INDICATOR
5678-713-80-10		NP INDICATOR
5678-715-80-10		NP INDICATOR
5678-716-80-10		NP INDICATOR
570-487		FREQUENCY METER
5773		OVEN
5776-1		EMERGENCY EGRESS LIGHTING POWER SUPPLY
579FL		DESYNN POSITION INDICATOR
579FLCP		DESYNN POSITION INDICATOR
579FLSB		DESYNN POSITION INDICATOR
581FL		DESYNN POSITION INDICATOR
5822-21		EMERGENCY EGRESS LIGHTING POWER SUPPLY W/
5830203-101		HIGH PRESSURE TURBINE CASE COOLING VALVE
5830203-102		HIGH PRESSURE TURBINE CASE COOLING VALVE



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
5830203-103		HIGH PRESSURE TURBINE CASE COOLING VALVE
5830203-104		HIGH PRESSURE TURBINE CASE COOLING VALVE
5-84049-11		FLAP DRIVE BALL SCREW
5-84049-12		FLAP DRIVE BALL SCREW
5-84049-13		FLAP DRIVE BALL SCREW
5-84049-3041		FLAP DRIVE BALL SCREW
5-84049-3042		FLAP DRIVE BALL SCREW
5-84049-3045		FLAP DRIVE BALL SCREW
5-84049-3046		FLAP DRIVE BALL SCREW
5-84049-7		FLAP DRIVE BALL SCREW
5-84049-9		FLAP DRIVE BALL SCREW
5860040-104		TURBINE CLEARANCE CONTROL VALVE
5860040-105		TURBINE CLEARANCE CONTROL VALVE
5860040-106		TURBINE CLEARANCE CONTROL VALVE
5860040-107		TURBINE CLEARANCE CONTROL VALVE
586FL		DESYNN POSITION INDICATOR
588FL		DESYNN POSITION INDICATOR
591FLSB		DESYNN POSITION INDICATOR
593FL		DESYNN POSITION INDICATOR
59500000-1		DME INDICATOR
59500000-1SB16		DME INDICATOR
59500000-2		DME INDICATOR
59500000-2SB16		DME INDICATOR
59500000-3		DME INDICATOR
59500000-3SB16		DME INDICATOR
5956890-1		INSTRUMENT PANEL LIGHTING CONTROL ASSY
5956890-501		INSTRUMENT PANEL LIGHTING CONTROL ASSY
5956890-503		INSTRUMENT PANEL LIGHTING CONTROL ASSY
5956890-505		INSTRUMENT PANEL LIGHTING CONTROL ASSY
5956890-507		INSTRUMENT PANEL LIGHTING CONTROL ASSY
5956890-509		INSTRUMENT PANEL LIGHTING CONTROL ASSY
5956890-511		INSTRUMENT PANEL LIGHTING CONTROL ASSY
5956890-513		INSTRUMENT PANEL LIGHTING CONTROL ASSY
595FL		DESYNN POSITION INDICATOR
597FL		DESYNN POSITION INDICATOR
597FL1		DESYNN POSITION INDICATOR
597FLBR		DESYNN POSITION INDICATOR
597FLSB		DESYNN POSITION INDICATOR
5XA005032-01		LIGHTING CONTROLLER
5XA005033-00		LIGHTING CONTROLLER
5XA455805-01		LIGHTING CONTROLLER
5XA455806-00		LIGHTING CONTROLLER
600748	K-6	ROLL AND PITCH GYRO CONTROL
600958-0001		CRT MONITOR
600958-0002		CRT MONITOR
600958-0003		CRT MONITOR
600958-0004		CRT MONITOR
600958-0005		CRT MONITOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
600PG		DIRECT READING PRESSURE GAUGE
60-1321-1		EMERGENCY EXIT LIGHT POWER SUPPLY
60-1321-1LB		EMERGENCY EXIT LIGHT POWER SUPPLY
60-1321-5		EMERGENCY EXIT LIGHT POWER SUPPLY
60-1321-5LB		EMERGENCY EXIT LIGHT POWER SUPPLY
60-1321-7		EMERGENCY EXIT LIGHT POWER SUPPLY
60-1321-7LB		EMERGENCY EXIT LIGHT POWER SUPPLY
601696-100	K-6	ROLL AND PITCH GYRO CONTROL
601696-106	K-6A	ROLL AND PITCH GYRO CONTROL
601PG		DIRECT READING PRESSURE GAUGE
601PGM		DIRECT READING PRESSURE GAUGE
602PG		DIRECT READING PRESSURE GAUGE
60-3895-1		BATTERY POWER SUPPLY
603PG		DIRECT READING PRESSURE GAUGE
60-4983-3	S283A305-101	STROBE POWER SUPPLY
604PG		PRESSURE GAUGE
605PG		PRESSURE GAUGE
606PG		PRESSURE GAUGE
606PGM		PRESSURE GAUGE
607152-1-1		TEMPERATURE SELECTOR
607316-0001		CRT MONITOR
607316-0002		CRT MONITOR
607316-0006		CRT MONITOR
607400-1		TEMPERATURE SELECTOR
607400-1-1		TEMPERATURE SELECTOR
607400-2		TEMPERATURE SELECTOR
607400-2-1		TEMPERATURE SELECTOR
607400-3		TEMPERATURE SELECTOR
607400-3-1		TEMPERATURE SELECTOR
607510-2 SERIES 1		TEMPERATURE CONTROL
607510-2 SERIES 2		TEMPERATURE CONTROL
607510-2 SERIES 3		TEMPERATURE CONTROL
607518-2 SERIES 2	607518	TEMPERATURE CONTROL
607518-2 SERIES 3	607518	TEMPERATURE CONTROL
607518-2 SERIES 4	607518	TEMPERATURE CONTROL
607PG		DIRECT READING PRESSURE GAUGE
608PG		DIRECT READING PRESSURE GAUGE
609PG		DIRECT READING PRESSURE GAUGE
60B00021-9	21SN41	PRESSURE SWITCH
60B00117-5		OIL TEMPERATURE INDICATOR
60B00133-162		EXHAUST GAS TEMP. IND.
60B00133-163		EXHAUST GAS TEMP. IND.
60B00133-164		EXHAUST GAS TEMP. IND.
60B00133-211		EXHAUST GAS TEMP. IND.
60B00133-212		EXHAUST GAS TEMP. IND.
60B00133-31		EXHAUST GAS TEMP. IND.
60B00133-32		EXHAUST GAS TEMP. IND.
60B00133-33		EXHAUST GAS TEMP. IND.



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
60B00133-34		EXHAUST GAS TEMP. IND.
60B00133-35		EXHAUST GAS TEMP. IND.
60B00133-36		EXHAUST GAS TEMP. IND.
60B00133-37		EXHAUST GAS TEMP. IND.
60B00133-38		EXHAUST GAS TEMP. IND.
60B00133-39		EXHAUST GAS TEMP. IND.
60B00257-5	98B302B/C	HYDRAULIC FLUID TEMPERATURE DETECTOR
60B00257-6	98B304A/B/C/D	HYDRAULIC FLUID TEMPERATURE DETECTOR
60B00257-7	98B302D	HYDRAULIC FLUID TEMPERATURE DETECTOR
60B00303-103	2600-03-1	DIGITAL ELECTRONIC CLOCK
60B00303-104	2600-04-1	DIGITAL ELECTRONIC CLOCK
60B00303-105	2610-07-1	DIGITAL ELECTRONIC CHRONOMETER
60B00303107	2610-08-1	DIGITAL ELECTRONIC CHRONOMETER
60B00303-108	2610-10-1	CHRONOMETER, DIGITAL ELECTRONIC
60B50058-3	TD1514-1002	TOILET TIMER SWITCH
60B50058-4	TD1535-1002	TOILET TIMER SWITCH
60B50058-5	TD1715-1002	TOILET TIMER SWITCH
60B50058-6	TD1702-1002	TOILET TIMER SWITCH
60B92017-23	2307-02-1	FUEL QUANTITY INDICATOR
60B92017-29	2307-04-1	FUEL QUANTITY INDICATOR
60B92017-5	4215-07	DIGITAL CALIBRATION TRIM UNIT
60B92017-6	4215-04	DIGITAL CALIBRATION TRIM UNIT
60B92017-7	4215-05	DIGITAL CALIBRATION TRIM UNIT
60B92017-8	4215-02	DIGITAL CALIBRATION TRIM UNIT
60B92017-9	4215-08	DIGITAL CALIBRATION TRIM UNIT
610BL24B		TEMPERATURE INDICATOR
610BL29		TEMPERATURE INDICATOR
610BL3		TEMPERATURE INDICATOR
610BL3B		TEMPERATURE INDICATOR
610BL4		TEMPERATURE INDICATOR
610BL4B		TEMPERATURE INDICATOR
610BL4D		TEMPERATURE INDICATOR
610BL4E		TEMPERATURE INDICATOR
610BL4H		TEMPERATURE INDICATOR
610BL9		TEMPERATURE INDICATOR
610PG		PRESSURE GAUGE
61111-14		RPM INDICATOR
611PG		PRESSURE GAUGE
612PG		PRESSURE GAUGE
613260-1		DIRECTIONAL GYRO
613260-2		DIRECTIONAL GYRO
613262		GYRO UNIT ASSY
613PG		PRESSURE GAUGE
614PG		PRESSURE GAUGE
615039-100		VERTICAL GYRO CONTROL
615039-101		VERTICAL GYRO CONTROL
615039-102		VERTICAL GYRO CONTROL
615039-103		VERTICAL GYRO CONTROL



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
615039-104		VERTICAL GYRO CONTROL
615039-105		VERTICAL GYRO CONTROL
615039-106		VERTICAL GYRO CONTROL
615039-107		VERTICAL GYRO CONTROL
615039-108		VERTICAL GYRO CONTROL
615039-109		VERTICAL GYRO CONTROL
615743-09		SERVO DRIVE
615743-11		SERVO DRIVE
615PG		PRESSURE GAUGE
616PG		PRESSURE GAUGE
617179		TO-FROM SENSOR
617-6231-001	617-6231	8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-002		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-003		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-004		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-011		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-012		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-013		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-014		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-015		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-016		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-017		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-018		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-021		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-022		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-023		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6231-024		8.4-/8.6-INCH RETRACT MONITOR ASSY.
617-6265-001		8.6 INCH LCD RETRACT ASSEMBLY
617-6265-002		8.6 INCH LCD RETRACT ASSEMBLY
617PG		PRESSURE GAUGE
618PG		PRESSURE GAUGE
619PG		PRESSURE GAUGE
620PG		PRESSURE GAUGE
622-0181-001	345A-7B	RATE OF TURN SENSOR
622-0181-002	345A-7B	RATE OF TURN SENSOR
622-0181-003	345A-7B	RATE OF TURN SENSOR
622-0224-001	ADI-85	ATTITUDE DIRECTOR INDICATOR
622-0224-002	ADI-85	ATTITUDE DIRECTOR INDICATOR
622-0224-003	ADI-85	ATTITUDE DIRECTOR INDICATOR
622-0224-004	ADI-85	ATTITUDE DIRECTOR INDICATOR
622-0224-005	ADI-85	ATTITUDE DIRECTOR INDICATOR
622-0224-006	ADI-85	ATTITUDE DIRECTOR INDICATOR
622-0835-001	329B-7R-1	FLIGHT DIRECTOR INDICATOR
622-0835-002	329B-7B-1	FLIGHT DIRECTOR INDICATOR
622-0836-001	329B-7R-2	FLIGHT DIRECTOR INDICATOR
622-0836-002	329B-7R-2	FLIGHT DIRECTOR INDICATOR
622-0836-003	329B-7R-2	FLIGHT DIRECTOR INDICATOR
622-0837-001	329B-7R-3	FLIGHT DIRECTOR INDICATOR





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
622-0837-002	329B-7R-3	FLIGHT DIRECTOR INDICATOR
622-0837-003	329B-7R-3	FLIGHT DIRECTOR INDICATOR
622-0855-001	329B-7R-4	FLIGHT DIRECTOR INDICATOR
622-0855-002	329B-7R-4	FLIGHT DIRECTOR INDICATOR
622-0856-001	329B-7R-5	FLIGHT DIRECTOR INDICATOR
622-0856-002	329B-7R-5	FLIGHT DIRECTOR INDICATOR
622-0944-003	614E-20R	FLIGHT MODE SELECTOR
622-0944-006	614E-20R	FLIGHT MODE SELECTOR
622-0944-007	614E-20R	FLIGHT MODE SELECTOR
622-0945-003	614E-23R	FLIGHT MODE SELECTOR
622-0945-006	614E-23R	FLIGHT MODE SELECTOR
622-0945-007	614E-23R	FLIGHT MODE SELECTOR
622-0945-008	614E-23R	FLIGHT MODE SELECTOR
622-0945-017	614E-23R	FLIGHT MODE SELECTOR
622-0950-001	614E-37	FLIGHT MODE SELECTOR
622-0950-002	614E-37	FLIGHT MODE SELECTOR
622-1001-001	590A-3J	AIR DATA CONTROL
622-1001-002	590A-3J	AIR DATA CONTROL
622-1001-019	590A-3K	AIR DATA CONTROL
622-1024-001	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-001	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-002	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-003	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-004	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-005	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-006	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-007	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-008	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1204-010	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1205-001	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1205-002	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1205-003	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1205-004	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1205-005	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1205-006	339H-4/4A	RADIO ALTITUDE INDICATOR
622-1234-012	339F-12	DME INDICATOR
622-1234-013	339F-12	DME INDICATOR
622-1234-016	339F-12	DME INDICATOR
622-1234-017	339F-12	DME INDICATOR
622-1234-113	339F-12	DME INDICATOR
622-1234-207	339F-12	DME INDICATOR
622-1234-313	339F-12	DME INDICATOR
622-1377-001	332D-12	VERTICAL GYRO
622-1406-001	614E-22F	REMOTE HEADING & COURSE SELECTOR
622-2012-011	339F-12A	DME INDICATOR
622-2012-012	339F-12A	DME INDICATOR
622-2012-013	339F-12A	DME INDICATOR
622-2012-014	339F-12A	DME INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
622-2012-201	339F-12A	DME INDICATOR
622-2175-001	339F-12B	DME INDICATOR
622-2175-002	339F-12B	DME INDICATOR
622-2175-003	339F-12B	DME INDICATOR
622-2175-004	339F-12B	DME INDICATOR
622-2175-201	339F-12B	DME INDICATOR
622-2176-001	339F-12C	DME INDICATOR
622-2176-002	339F-12C	DME INDICATOR
622-2176-201	339F-12C	DME INDICATOR
622-2177-001	339F-12D	DME INDICATOR
622-2506-001	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-002	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-003	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-004	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-005	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-006	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-007	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-008	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-009	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-010	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-011	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-012	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-013	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-014	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-101	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-102	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-103	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-104	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-105	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-106	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-107	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-108	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-109	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-110	RMI-36	RADIO MAGNETIC INDICATOR
622-2506-111	RMI-36	RADIO MAGNETIC INDICATOR
622-3001-001	339F-12E	DME INDICATOR
622-3046-001	332C-10B	RADIO MGNIETIC INDICATOR
622-3204-001	590A-3K	AIR DATA CONTROLS
622-3204-042	590A-3K	AIR DATA CONTROLS
622-3329-001	332D-12A	VERTICAL GYRO
622-3343-001	ADI-55V	ATTITUDE DIRECTOR INDICATOR
622-3343-002	ADI-55V	ATTITUDE DIRECTOR INDICATOR
622-3344-002	ADI-55V	ATTITUDE DIRECTOR INDICATOR
622-3374-002	ADI-55V	ATTITUDE DIRECTOR INDICATOR
622-3594-001	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-002	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-003	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-004	ADI-84	FLIGHT DIRECTOR INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
622-3594-005	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-006	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-007	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-008	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-011	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-012	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-013	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-014	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-015	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-016	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-017	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3594-018	ADI-84	FLIGHT DIRECTOR INDICATOR
622-3702-001	BDI-36	BEARING DISTANCE INDICATOR
622-3702-002	BDI-36	BEARING DISTANCE INDICATOR
622-3702-003	BDI-36	BEARING DISTANCE INDICATOR
622-3702-004	BDI-36	BEARING DISTANCE INDICATOR
622-3702-005	BDI-36	BEARING DISTANCE INDICATOR
622-3702-006	BDI-36	BEARING DISTANCE INDICATOR
622-3702-007	BDI-36	BEARING DISTANCE INDICATOR
622-3702-008	BDI-36	BEARING DISTANCE INDICATOR
622-3702-009	BDI-36	BEARING DISTANCE INDICATOR
622-3702-010	BDI-36	BEARING DISTANCE INDICATOR
622-3702-011	BDI-36	BEARING DISTANCE INDICATOR
622-3702-012	BDI-36	BEARING DISTANCE INDICATOR
622-3702-013	BDI-36	BEARING DISTANCE INDICATOR
622-3702-014	BDI-36	BEARING DISTANCE INDICATOR
622-3702-015	BDI-36	BEARING DISTANCE INDICATOR
622-3702-016	BDI-36	BEARING DISTANCE INDICATOR
622-4096-001	346D-2B	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
622-4096-002	346D-2B	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
622-4096-003	346D-2B	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
622-4298-001	HSI-45	HORIZONTAL SITUATION INDICATOR
622-4393-001	590A-3J1	AIR DATA CONTROL
622-4393-002	590A-3J1	AIR DATA CONTROL
622-4393-019	590A-3J1	AIR DATA CONTROL
622-4394-001	590A-3K1	AIR DATA CONTROL
622-4394-002	590A-3K1	AIR DATA CONTROL
622-4394-004	590A-3K1	AIR DATA CONTROL
622-4394-005	590A-3K1	AIR DATA CONTROL
622-4394-008	590A-3K1	AIR DATA CONTROL
622-4394-009	590A-3K1	AIR DATA CONTROL
622-4394-013	590A-3K1	AIR DATA CONTROL
622-4394-019	590A-3K1	AIR DATA CONTROL
622-4394-025	590A-3K1	AIR DATA CONTROL
622-4394-042	590A-3K1	AIR DATA CONTROL
622-4424-001	332D-11V	VERTICAL GYRO
622-4481-001	IND-30	INDICATOR
622-4481-002	IND-30	INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
622-4482-001	IND-31	INDICATOR
622-4482-002	IND-31	INDICATOR
622-4483-001	IND-31C	INDICATOR
622-4483-002	IND-31C	INDICATOR
622-4483-003	IND-31C	INDICATOR
622-4487-001	346D-2	AIRCRAFT PASSENGER ADDRESS AMPLIFIER
622-4488-001	332D-11B	VERTICAL GYRO
622-4507-001	ADI-55V-2	ATTITUDE DIRECTOR INDICATOR
622-4507-002	ADI-55V-2	ATTITUDE DIRECTOR INDICATOR
622-4563-001	339H-6	RADIO ALTITUDE INDICATOR
622-4563-002	339H-6	RADIO ALTITUDE INDICATOR
622-4563-004	339H-6	RADIO ALTITUDE INDICATOR
622-4563-005	339H-6	RADIO ALTITUDE INDICATOR
622-4563-006	339H-6	RADIO ALTITUDE INDICATOR
622-4563-007	339H-6	RADIO ALTITUDE INDICATOR
622-4563-008	339H-6	RADIO ALTITUDE INDICATOR
622-4563-011	339H-6	RADIO ALTITUDE INDICATOR
622-4565-001	332D-11T	VERTICAL GYRO
622-4565-002	332D-11T	VERTICAL GYRO
622-4570-001	ADI-70C	ALTITUDE DIRECTOR INDICATOR
622-4570-002	ADI-70C	ALTITUDE DIRECTOR INDICATOR
622-4571-001	ADI-84	FLIGHT DIRECTOR INDICATOR
622-4572-001	HSI-70( )	HORIZONTAL SITUATION INDICATOR
622-4572-002	HSI-70( )	HORIZONTAL SITUATION INDICATOR
622-4808-001	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-002	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-003	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-004	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-005	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-006	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-007	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-008	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-009	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-010	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-011	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-012	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4808-013	ADI-85A	ATTITUDE DIRECTOR INDICATOR
622-4912-001	ADI-70	ALTITUDE DIRECTOR INDICATOR
622-4912-002	ADI-70	ALTITUDE DIRECTOR INDICATOR
622-4913-001	HSI-70( )	HORIZONTAL SITUATION INDICATOR
622-4913-002	HSI-70( )	HORIZONTAL SITUATION INDICATOR
622-4924-001	614E-22M	REMOTE HEADING & COURSE SELECTOR
622-4938-001	RMI-30	RADIO MAGNETIC INDICATOR
622-4938-002	RMI-30	RADIO MAGNETIC INDICATOR
622-4938-003	RMI-30	RADIO MAGNETIC INDICATOR
622-4938-004	RMI-30	RADIO MAGNETIC INDICATOR
622-4938-005	RMI-30	RADIO MAGNETIC INDICATOR
622-4938-006	RMI-30	RADIO MAGNETIC INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
622-4938-007	RMI-30	RADIO MAGNETIC INDICATOR
622-5001-003	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-104	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-106	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-107	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-108	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-109	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-110	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-111	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-112	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-113	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-114	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-501	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-502	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-503	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-504	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-601	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-602	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5001-701	RDMI-743	RADIO DISTANCE MAGNETIC INDICATOR
622-5002-203	RMI-733	RADIO MAGNETIC INDICATOR
622-5002-205	RMI-733	RADIO MAGNETIC INDICATOR
622-5002-206	RMI-733	RADIO MAGNETIC INDICATOR
622-5002-207	RMI-733	RADIO MAGNETIC INDICATOR
622-5002-501	RMI-733	RADIO MAGNETIC INDICATOR
622-5002-502	RMI-733	RADIO MAGNETIC INDICATOR
622-5002-503	RMI-733	RADIO MAGNETIC INDICATOR
622-5002-701	RMI-733	RADIO MAGNETIC INDICATOR
622-5048-101	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5048-103	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5048-104	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5048-341	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5048-343	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5048-344	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5048-361	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5048-381	EFIC-701	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-5130-004	WCP-702	CONTROL PANEL
622-5130-005	WCP-702	CONTROL PANEL
622-5130-006		CONTROL PANEL
622-5130-112	WCP-702	CONTROL PANEL
622-5130-115	WCP-702	CONTROL PANEL
622-5130-116	WCP-702	CONTROL PANEL
622-5130-119	WCP-702	CONTROL PANEL
622-5130-122	WCP-702	CONTROL PANEL
622-5130-123	WCP-702	CONTROL PANEL
622-5130-124		CONTROL PANEL
622-5130-125	WCP-702	CONTROL PANEL
622-5130-126	WCP-702	CONTROL PANEL
622-5130-128	WCP-702	CONTROL PANEL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
622-5139-001	ADI-44V	ATTITUDE DIRECTOR INDICATOR
622-5139-002	ADI-44V	ATTITUDE DIRECTOR INDICATOR
622-5139-003	ADI-44V	ATTITUDE DIRECTOR INDICATOR
622-5139-004	ADI-44V	ATTITUDE DIRECTOR INDICATOR
622-5342-001	PAU-700	PASSENGER ADDRESS UNIT
622-5342-101	PAU-700	PASSENGER ADDRESS UNIT
622-5374-002	ASA-701	AUTOLAND STATUS ANNUNCIATOR
622-5374-003	ASA-701	AUTOLAND STATUS ANNUNCIATOR
622-5374-004	ASA-701	AUTOLAND STATUS ANNUNCIATOR
622-5486-001	614E-20S	FLIGHT MODE SELECTOR
622-5486-011	614E-20S	FLIGHT MODE SELECTOR
622-5773-001	RAI-742	RADIO ALTITUDE INDICATOR
622-5818-001	RDMI-743A	RADIO DISTANCE MAGNETIC INDICATOR
622-5990-001	DDI-713	DUAL DISTANCE INDICATOR
622-5990-302	DDI-713	DUAL DISTANCE INDICATOR
622-6084-001	RMI-733A	RADIO MAGNETIC INDICATOR
622-6089-101	DSP-701A	DISPLAY SELECT PANEL
622-6089-102	DSP-701A	DISPLAY SELECT PANEL
622-6136-001	DGS-65	DIRECTIONAL GYRO
622-6136-002	DGS-65	DIRECTIONAL GYRO
622-6827-001	HFP-712	HF COMM FREQUENCY PANEL
622-6827-002	HFP-712	HF COMM FREQUENCY PANEL
622-6827-003	HFP-712	HF COMM FREQUENCY PANEL
622-6827-011	HFP-712	HF COMM FREQUENCY PANEL
622-6827-012	HFP-712	HF COMM FREQUENCY PANEL
622-6827-021	HFP-712	HF COMM FREQUENCY PANEL
622-6827-022	HFP-712	HF COMM FREQUENCY PANEL
622-6831-001	VFP-712	VHF COMM FREQUENCY PANEL
622-6831-002	VFP-712	VHF COMM FREQUENCY PANEL
622-6831-011	VFP-712	VHF COMM FREQUENCY PANEL
622-6831-012	VFP-712	VHF COMM FREQUENCY PANEL
622-6831-021	VFP-712	VHF COMM FREQUENCY PANEL
622-6831-022	VFP-712	VHF COMM FREQUENCY PANEL
622-8001-001	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-002	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-003	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-330	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-331	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-332	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-350	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-351	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-352	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-353	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622-8001-370	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
622814-2		PACK/ZONE TEMPERATURE CONTROLLER
622814-2 SERIES 1		PACK/ZONE TEMPERATURE CONTROLLER
622814-2 SERIES 2		PACK/ZONE TEMPERATURE CONTROLLER
622814-3		PACK/ZONE TEMPERATURE CONTROLLER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
622814-3 SERIES 1		PACK/ZONE TEMPERATURE CONTROLLER
622814-3 SERIES 2		PACK/ZONE TEMPERATURE CONTROLLER
622814-3 SERIES 3		PACK/ZONE TEMPERATURE CONTROLLER
622814-4	10-62091-17	PACK/ZONE TEMPERATURE CONTROLLER
622814-4 SERIES 1		PACK/ZONE TEMPERATURE CONTROLLER
622814-4 SERIES 2		PACK/ZONE TEMPERATURE CONTROLLER
622814-4 SERIES 3		PACK/ZONE TEMPERATURE CONTROLLER
622814-5		PACK/ZONE TEMPERATURE CONTROLLER
622814-5 SERIES 1		PACK/ZONE TEMPERATURE CONTROLLER
622814-5 SERIES 2		PACK/ZONE TEMPERATURE CONTROLLER
622814-5 SERIES 3		PACK/ZONE TEMPERATURE CONTROLLER
622814-5 SERIES 4		PACK/ZONE TEMPERATURE CONTROLLER
622814-5 SERIES 5		PACK/ZONE TEMPERATURE CONTROLLER
622814-5 SERIES 6		PACK/ZONE TEMPERATURE CONTROLLER
622814-5 SERIES 7		PACK/ZONE TEMPERATURE CONTROLLER
622-8594-001	DTP-722	TRANSPONDER PANEL
622-8594-011	DTP-722	TRANSPONDER PANEL
622-8594-021	DTP-722	TRANSPONDER PANEL
622-8594-022	DTP-722	TRANSPONDER PANEL
622-8594-023	DTP-722	TRANSPONDER PANEL
622-8594-101	DTP-722	TRANSPONDER PANEL
622-8594-111	DTP-722	TRANSPONDER PANEL
622-8594-121	DTP-722	TRANSPONDER PANEL
624066-5 SERIES 3		WINDOW HEAT CONTROL UNIT
624284-1		CONTROL STANDBY
625934-6 SERIES 1		CABIN ZONE TEMPERATURE CONTROLLER
625934-6 SERIES 2		CABIN ZONE TEMPERATURE CONTROLLER
625934-6 SERIES 3		CABIN ZONE TEMPERATURE CONTROLLER
625946-8 SERIES1	S210T130-66	PACK TEMPERATURE CONTROL
625946-8 SERIES2	S210T130-66	PACK TEMPERATURE CONTROL
625946-8 SERIES3	S210T130-66	PACK TEMPERATURE CONTROL
625946-8 SERIES4	S210T130-66	PACK TEMPERATURE CONTROL
625946-8 SERIES5	S210T130-66	PACK TEMPERATURE CONTROL
625946-9 SERIES1	S210T130-69	PACK TEMPERATURE CONTROL
625946-9 SERIES2	S210T130-69	PACK TEMPERATURE CONTROL
625946-9 SERIES3	S210T130-69	PACK TEMPERATURE CONTROL
625946-9 SERIES4	S210T130-69	PACK TEMPERATURE CONTROL
625946-9 SERIES5	S210T130-69	PACK TEMPERATURE CONTROL
625992-2		TEMPERATURE CONTROL
625PG		PRESSURE GAUGES
627088-7 SERIES 1		PNEUMATIC SYSTEM CONTROLLER
627088-7 SERIES 2		PNEUMATIC SYSTEM CONTROLLER
627454-3 SERIES 1		PNEUMATIC SYSTEM CONTROLLER
627454-3 SERIES 2		PNEUMATIC SYSTEM CONTROLLER
630PG		PRESSURE GAUGE
631PG		PRESSURE GAUGE
63543-150-2		DDRMI INDICATOR
63543-150-3		DDRMI INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
63543-150-4		DDRMI INDICATOR
63543-150-5		DDRMI INDICATOR
63543-270-1		DISTANCE BEARING INDICATOR
63999-000		MICROPHONE
63999-001		MICROPHONE
63999-002		MICROPHONE
63999-003		MICROPHONE
63999-004		MICROPHONE
63999-005		MICROPHONE
63999-006		MICROPHONE
64032-220-1		MACH AIRSPEED INDICATOR
64040-560-1		AIRSPEED INDICATOR
64050-860-1		AIRSPEED INDICATOR
64050-862-1		AIRSPEED INDICATOR
64050-866-1		AIRSPEED INDICATOR
64050-868-1		AIRSPEED INDICATOR
64060-890-1		MAX. ALLOW AIRSPEED INDICATOR
64111-940-1		ALTIMETER
64141-580-1		ALTIMETER
64141-582-1		ALTIMETER
64141-590-1		ALTIMETER
64142-523-1		ALTIMETER
641PG		PRESSURE GAUGE
642PG		PRESSURE GAUGE
645055-2		MOTOR DRIVEN FAN
645055-3		MOTOR DRIVEN FAN
64530-068-4		TACHOMETER INDICATOR
64769-001-001		COFFEE MAKER
64769-001-003		COFFEE MAKER
64878-000-1		DUAL HYDRAULIC PRESSURE IND.
64882-203-1		TRIPLE PRESSURE INDICATOR
64882-206-1		TRIPLE PRESSURE INDICATOR
64891-001-1		CONTROL SURFACE POSITION
64891-002-1		CONTROL SURFACE POSITION
64891-002-2		CONTROL SURFACE POSITION
64891-002-3		CONTROL SURFACE POSITION
64891-002-4		CONTROL SURFACE POSITION
64902-002-2		HYDRAULIC QUANTITY INDICATOR
64902-012-1		HYDRAULIC QUANTITY IND.
651PG		PRESSURE GAUGE
65-24917-115		AUTOPILOT ACCESSORY UNIT
65-24917-137		AUTOPILOT ACC. UNIT
65-24917-182		AUTOPILOT ACCESSORY UNIT
65-24917-194		AUTOPILOT ACC. UNIT
65-24917-204		AUTOPILOT ACCESSORY UNIT
65-24917-233		AUTOPILOT ACCESSORY UNIT
65-24917-252		AUTOPILOT ACC. UNIT
65-24917-254		AUTOPILOT ACC. UNIT





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
65-24917-276		AUTOPILOT ACC. UNIT
65-24917-281		AUTOPILOT ACC. UNIT
65-24917-284		AUTOPILOT ACC. UNIT
65-24917-290		AUTOPILOT ACC. UNIT
65-24917-295		AUTOPILOT ACC. UNIT
65-24917-308		AUTOPILOT ACC. UNIT
65-24917-332		AUTOPILOT ACC. UNIT
65-24917-35		AUTOPILOT ACC. UNIT
65-24917-355		AUTOPILOT ACC. UNIT
65-24917-359		AUTOPILOT ACC. UNIT
65-24917-363		AUTOPILOT ACC. UNIT
65-24917-374		AUTOPILOT ACC. UNIT
65-24917-68		AUTOPILOT ACCESSORY UNIT
65-24917-86		AUTOPILOT ACCESSORY UNIT
65-24920-1		FIRE& OVERHEAT DETECTION ACC.UNIT ASSY.
65-24920-3		FIRE& OVERHEAT DETECTION ACC. UNIT ASSY.
65-24920-6		FIRE& OVERHEAT DETECTION ACC. UNIT ASSY.
65-24920-7		FIRE& OVERHEAT DETECTION ACC. UNIT ASSY.
65-52801-12		APU CONTROL UNIT
65-52801-12 MOD A		APU CONTROL UNIT
65-52801-18		APU CONTROL UNIT
65-52801-18 MOD A		APU CONTROL UNIT
65-52801-20		APU CONTROL UNIT
65-52801-24		APU CONTROL UNIT
65-52801-24 MOD A		APU CONTROL UNIT
65-52801-27		APU CONTROL UNIT
65-52801-27 MOD A		APU CONTROL UNIT
65-52801-31		APU CONTROL UNIT
65-52801-31 MOD A		APU CONTROL UNIT
65-52801-31 MOD AB		APU CONTROL UNIT
65-52801-31 MOD B		APU CONTROL UNIT
65-52801-33		APU CONTROL UNIT
65-52801-33 MOD A		APU CONTROL UNIT
65-52801-39		APU CONTROL UNIT
65-52801-39 MOD A		APU CONTROL UNIT
65-52801-40		APU CONTROL UNIT
65-52801-40 MOD A		APU CONTROL UNIT
65-52801-43		APU CONTROL UNIT
65-52801-43 MOD A		APU CONTROL UNIT
65-52801-43 MOD AB		APU CONTROL UNIT
65-52801-43 MOD B		APU CONTROL UNIT
65-52801-47		APU CONTROL UNIT
65-52801-47 MOD A		APU CONTROL UNIT
65-52801-47 MOD AB		APU CONTROL UNIT
65-52801-49		APU CONTROL UNIT
65-52801-49 MOD A		APU CONTROL UNIT
65-52801-49 MOD AB		APU CONTROL UNIT
65-52801-49 MOD B		APU CONTROL UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
65-52801-56		APU CONTROL UNIT
65-52801-56 MOD A		APU CONTROL UNIT
65-52801-58		APU CONTROL UNIT
65-52801-58 MOD A		APU CONTROL UNIT
65-52801-60		APU CONTROL UNIT
65-52801-61		APU CONTROL UNIT
65-52801-61 MOD A		APU CONTROL UNIT
65-52801-63		APU CONTROL UNIT
65-52801-63 MOD A		APU CONTROL UNIT
65-52803-1		WINDOW HEAT ACCESSORY UNIT ASSEMBLY
65-52803-10		WINDOW HEAT ACCESSORY UNIT ASSEMBLY
65-52803-2		WINDOW HEAT ACCESSORY UNIT ASSEMBLY
65-52803-6		WINDOW HEAT ACCESSORY UNIT ASSEMBLY
65-52803-8		WINDOW HEAT ACCESSORY UNIT ASSEMBLY
65-52804-223		AUDIO ACCESSORY UNIT
65-52804-223 MOD A		AUDIO ACCESSORY UNIT
65-52804-227		AUDIO ACCESSORY UNIT
65-52804-227 MOD A		AUDIO ACCESSORY UNIT
65-52804-229		AUDIO ACCESSORY UNIT
65-52804-229 MOD A		AUDIO ACCESSORY UNIT
65-52804-241		AUDIO ACCESSORY UNIT
65-52804-241 MOD A		AUDIO ACCESSORY UNIT
65-52804-243		AUDIO ACCESSORY UNIT
65-52804-243 MOD A		AUDIO ACCESSORY UNIT
65-52804-253		AUDIO ACCESSORY UNIT
65-52804-253 MOD A		AUDIO ACCESSORY UNIT
65-52804-258		AUDIO ACCESSORY UNIT
65-52804-258 MOD A		AUDIO ACCESSORY UNIT
65-52804-260		AUDIO ACCESSORY UNIT
65-52804-260 MOD A		AUDIO ACCESSORY UNIT
65-52804-262		AUDIO ACCESSORY UNIT
65-52804-262 MOD A		AUDIO ACCESSORY UNIT
65-52806-171		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-173		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-175		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-177		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-183		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-185		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-187		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-189		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-191		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-193		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-198		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-204		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-213		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-215		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-217		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-225		MISCELLANEOUS SOLID STATE SWITCHING ACC.



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
65-52806-228		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-406		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-408		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52806-413		MISCELLANEOUS SOLID STATE SWITCHING ACC.
65-52807-12		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-13		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-14		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-15		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-16		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-18		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-50		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-52		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-54		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-55		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-56		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-57		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-58		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-59		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-60		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-62		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-7		FLAG AND SLAT POS. IND ACC. UNIT
65-52807-9		FLAG AND SLAT POS. IND ACC. UNIT
65-52808-3		COMPARTMENT OVERHEAT ACC. UNIT ASSY.
65-52808-6		COMPARTMENT OVERHEAT ACC. UNIT ASSY.
65-52808-7		COMPARTMENT OVERHEAT ACC. UNIT ASSY.
65-52809-13		FIRE DETECTION ACC. UNIT ASS.
65-52809-15		FIRE DETECTION ACC. UNIT ASS.
65-52810-1		AIR CONDITIONING ACCESSORY UNIT ASSY, M324
65-52810-21		AIR CONDITIONING ACCESSORY UNIT ASSY, M324
65-52810-22		AIR CONDITIONING ACCESSORY UNIT ASSY, M324
65-52810-23		AIR CONDITIONING ACCESSORY UNIT ASSY, M324
65-52810-8		AIR CONDITIONING ACCESSORY UNIT ASSY, M324
65-52822-1		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-52822-1 MOD A		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-52822-1 MOD B		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-52822-3		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-52822-3 MOD A		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-52822-5		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-52822-7		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-52822-7 MOD A		STALL MANAGEMENT COMPUTER MODULE ASSY.
65-54499-12		AURAL WARNING BOX ASSY
65-54499-15		AURAL WARNING BOX ASSY
65-54499-17		AURAL WARNING BOX ASSY
65-54499-21		AURAL WARNING BOX ASSY
65-54499-23		AURAL WARNING BOX ASSY
65-54499-25		AURAL WARNING BOX ASSY
65-54499-26		AURAL WARNING BOX ASSY
65-54499-27		AURAL WARNING BOX ASSY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
65-54499-28		AURAL WARNING BOX ASSY
65-54499-29		AURAL WARNING BOX ASSY
65-54499-32		AURAL WARNING BOX ASSY
65-54499-34		AURAL WARNING BOX ASSY
65-54499-36		AURAL WARNING BOX ASSY
65-54499-38		AURAL WARNING BOX ASSY
65-54499-40		AURAL WARNING BOX ASSY
65-54499-41		AURAL WARNING BOX ASSY
65-54499-42		AURAL WARNING BOX ASSY
65-57448-1		FIRE DETECTOR PRINTER CIRCUIT ASSY.
65-57448-13		FIRE DETECTION CIRCUIT ASSY.
65-57448-16		FIRE DETECTION PRINTED CIRCUIT ASSY.
65-57448-18		FIRE DETECTION PRINTED CIRCUIT ASSY.
65-57448-3		FIRE DETECTION PRINTED CIRCUIT ASSY.
65-60210-24	M769	AUDIO ACCESSORY UNIT ASSEMBLY
65-60210-26	M769	AUDIO ACCESSORY UNIT ASSEMBLY
65-60210-26 MODEL A	M769	AUDIO ACCESSORY UNIT ASSEMBLY
65-60210-28	M769	AUDIO ACCESSORY UNIT ASSEMBLY
65-60210-30	M769	AUDIO ACCESSORY UNIT ASSEMBLY
65-60210-32	M769	AUDIO ACCESSORY UNIT ASSEMBLY
65-60214-127		FLIGHT INSTRUMENTAL ACCESSORY UNIT
65-60214-133		FLIGHT INSTRUMENTAL ACCESSORY UNIT
65-60214-138		FLIGHT INSTRUMENTAL ACCESSORY UNIT
65-60214-14		FLIGHT INSTRUMENTAL ACCESSORY UNIT
65-60214-151		FLIGHT INSTRUMENTAL ACCESSORY UNIT
65-62758-1		ENGINE FIRE DETECTION CONTROL
65-62758-11		ENGINE FIRE DETECTION CONTROL
65-62758-13		ENGINE FIRE DETECTION CONTROL
65-62758-15		ENGINE FIRE DETECTION CONTROL
65-62758-5		ENGINE FIRE DETECTION CONTROL
65-64960-3		ANNUNCIATOR LIGHTS MODULE ASSY.
65-64960-5		ANNUNCIATOR LIGHTS MODULE ASSY.
65-64960-7		ANNUNCIATOR LIGHTS MODULE ASSY.
65-65181-2		AUTOPILOT ACCESSORY UNIT
65-65181-5		AUTOPILOT ACCESSORY UNIT
6577-1		VANEAXIAL FAN ASSY.
6577-2		VANEAXIAL FAN ASSY.
6577-7		VANEAXIAL FAN ASSY.
657PG		DIRECT READING PRESSURE GAUGE
65-80021-3		AIR CONDITIONING ACCESSORY UNIT ASSY, M324
65-80021-4		AIR CONDITIONING ACCESSORY UNIT ASSY, M324
65-84131-1		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1
65V10739-1		TELEPHONE ASSEMBLY
65V10739-11		TELEPHONE ASSEMBLY
65V10739-2		TELEPHONE ASSEMBLY
65V10739-3		TELEPHONE ASSEMBLY
65V10739-4		TELEPHONE ASSEMBLY
65V10739-5		TELEPHONE ASSEMBLY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
65V10739-6		TELEPHONE ASSEMBLY
65V11226-1		TELEPHONE ASSEMBLY
65V11226-2		TELEPHONE ASSEMBLY
65V11226-3		TELEPHONE ASSEMBLY
65V11226-41		TELEPHONE ASSEMBLY
65V11226-55		TELEPHONE ASSEMBLY
660PG		DESYNN PRESSURE INDICATOR
660PG/CP		DESYNN PRESSURE INDICATOR
660PG/SB		DESYNN PRESSURE INDICATOR
6664287-0	RSTG 107	WINDOW HEAT COMPUTER
6664287-0 AMENDMEN	RSTG 107	WINDOW HEAT COMPUTER
667857	K-6	ROLL AND PITCH GYRO CONTROL
6730A02		FAN AIR VALVE
6730B01		FAN AIR VALVE
6730C010000		FAN AIR VALVE
6730C010000 Amdt A		FAN AIR VALVE
6730C010000 Amdt B		FAN AIR VALVE
6730C010000 Amdt C		FAN AIR VALVE
6730F010000		FAN AIR VALVE
6730F010000 AMDT A		FAN AIR VALVE
6740B03		OVERPRESSURE VALVE
6740B03 AMDT A		OVERPRESSURE VALVE
6740B04		OVERPRESSURE VALVE
6740B04 AMDT A		OVERPRESSURE VALVE
6740B050000		OVERPRESSURE VALVE
6740E010000		OVERPRESSURE VALVE
6740E010000 AMDT. A		OVERPRESSURE VALVE
6740F010000		OVERPRESSURE VALVE
6773E010000		HP BLEED VALVE
6773E010000 AMDT A		HP BLEED VALVE
6773E010000 AMDT AB		HP BLEED VALVE
6773E010000 AMDT B		HP BLEED VALVE
6774E010000		BLEED VALVE
6774E010000 AMDT A		BLEED VALVE
6774E010000 AMDT AB		BLEED VALVE
6774E010000 AMDT AB		BLEED VALVE
6774E010000 AMDT AC		BLEED VALVE
6774E010000 AMDT C		BLEED VALVE
6821493		SPEED SENSITIVE VALVE
6829274	AF33/600/42144	TORQUEMETER INDICATOR
6829276	438023-2	TORQUEMETER INDICATOR
6852536	505458-1	TORQUEMETER INDICATOR
69-37307-100		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-102		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-103		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1
69-37307-104		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-105		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-108		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
69-37307-114		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1
69-37307-116		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-117		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-118		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-119		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-40		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1
69-37307-53		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1
69-37307-57		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1
69-37307-59		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-60		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-64		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-68		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-71		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-74		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-76		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-77		ENGINE & APU FIRE CONTROL MODULE ASSY P8-1
69-37307-79		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-81		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37307-91		ENGINE AND APU FIRE CONTROL MODULE ASSY.
69-37312-13		FUEL SYSTEM MODULE ASSY P5-2
69-37312-13K		FUEL SYSTEM MODULE ASSY P5-2
69-37312-13M		FUEL SYSTEM MODULE ASSY P5-2
69-37312-15		FUEL SYSTEM MODULE ASSY P5-2
69-37312-17		FUEL SYSTEM MODULE ASSY P5-2
69-37312-18		FUEL SYSTEM MODULE ASSY P5-2
69-37312-21		FUEL SYSTEM MODULE ASSY P5-2
69-37312-22		FUEL SYSTEM MODULE ASSY P5-2
69-37312-30		FUEL SYSTEM MODULE ASSY P5-2
69-37312-9		FUEL SYSTEM MODULE ASSY P5-2
69-37312-9K		FUEL SYSTEM MODULE ASSY P5-2
69-37312-9M		FUEL SYSTEM MODULE ASSY P5-2
69-37313-105	95-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-107	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-109	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-110	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-111	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-112	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-113	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-114	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-115	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-116	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-117	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-118	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-119	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-120	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-121	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-122	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-123	P5-3	FLIGHT CONTROL MODULE ASSEMBLY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
69-37313-124	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-125	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-126	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-300	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-301	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37313-302	P5-3	FLIGHT CONTROL MODULE ASSEMBLY
69-37314-12		AC SYSTEM GENERATOR AND APU MODULE
69-37314-13		AC SYSTEM GENERATOR AND APU MODULE
69-37314-15		AC SYSTEM GENERATOR AND APU MODULE
69-37314-16		AC SYSTEM GENERATOR AND APU MODULE
69-37314-18		AC SYSTEM GENERATOR AND APU MODULE
69-37314-19		AC SYSTEM GENERATOR AND APU MODULE
69-37314-20		AC SYSTEM GENERATOR AND APU MODULE
69-37314-22		AC SYSTEM GENERATOR AND APU MODULE
69-37314-23		AC SYSTEM GENERATOR AND APU MODULE
69-37314-24		AC SYSTEM GENERATOR AND APU MODULE
69-37314-28		AC SYSTEM GENERATOR AND APU MODULE
69-37314-30		AC SYSTEM GENERATOR AND APU MODULE
69-37314-31		AC SYSTEM GENERATOR AND APU MODULE
69-37314-35		AC SYSTEM GENERATOR AND APU MODULE
69-37314-38		AC SYSTEM GENERATOR AND APU MODULE
69-37314-40		AC SYSTEM GENERATOR AND APU MODULE
69-37314-41		AC SYSTEM GENERATOR AND APU MODULE
69-37314-42		AC SYSTEM GENERATOR AND APU MODULE
69-37314-43		AC SYSTEM GENERATOR AND APU MODULE
69-37314-44		AC SYSTEM GENERATOR AND APU MODULE
69-37314-45	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-46	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-47	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-48	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-49		AC SYSTEM GENERATOR AND APU MODULE
69-37314-50		AC SYSTEM GENERATOR AND APU MODULE
69-37314-53		AC SYSTEM GENERATOR AND APU MODULE
69-37314-54		AC SYSTEM GENERATOR AND APU MODULE
69-37314-55	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-56	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-57	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-58	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-59	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-60	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-61	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-62	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-63	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-64	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-65	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-66	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-67	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-68	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
69-37314-71	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-72	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-81	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37314-82	P5-4	AC SYSTEM GENERATOR AND APU MODULE ASSY
69-37315-18		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-19		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-23		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-25		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-26		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-27		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-30		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-31		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-32		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-33		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-35		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-36		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-37		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-38		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-41		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-43		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-45		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-46		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-47		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-48		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-49		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-50		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-51		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-52		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-53		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-54		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-55		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-601		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-602		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-603		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-604		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-605		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-63		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-65		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-66		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-67		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-68		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-70		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-71		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-72		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-73		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-75		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-76		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-77		GENERATOR DRIVE AND STANDBY POWER MODULE





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
69-37315-79		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-81		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37315-82		GENERATOR DRIVE AND STANDBY POWER MODULE
69-37320-17		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-18		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-20		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-21		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-24		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-25		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-27		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-30		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-31		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-32		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-33		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-36		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-37		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-39		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-40		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-41		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-42		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-60		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-61		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-62		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-63		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-64		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-65		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-66		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-67		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-68		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-69		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-70		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-71		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-72		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-73		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-74		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37320-75		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-37335-13		FUEL SYSTEM MODULE
69-37335-13K		FUEL SYSTEM MODULE
69-37335-13M		FUEL SYSTEM MODULE
69-37335-14		FUEL SYSTEM MODULE
69-37335-14K		FUEL SYSTEM MODULE
69-37335-14M		FUEL SYSTEM MODULE
69-37335-18		FUEL SYSTEM MODULE
69-37335-18K		FUEL SYSTEM MODULE
69-37335-18M		FUEL SYSTEM MODULE
69-37335-19		FUEL SYSTEM MODULE
69-37335-21		FUEL SYSTEM MODULE
69-37335-22		FUEL SYSTEM MODULE



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
69-37335-23		FUEL SYSTEM MODULE
69-37335-24		FUEL SYSTEM MODULE
69-37335-25		FUEL SYSTEM MODULE
69-37335-25K		FUEL SYSTEM MODULE
69-37335-34		FUEL SYSTEM MODULE
69-37335-42		FUEL SYSTEM MODULE
69-37335-44		FUEL SYSTEM MODULE
69-37335-46		FUEL SYSTEM MODULE
69-37335-50		FUEL SYSTEM MODULE
69-37335-54		FUEL SYSTEM MODULE
69-37335-55		FUEL SYSTEM MODULE
69-37335-61		FUEL SYSTEM MODULE
69-37346-104	P5-9	WINDOW & COMBINED PITOT-STATIC HEAT MODULE
69-37346-111	P5-9	WINDOW & COMBINED PITOT-STATIC HEAT MODULE
69-37346-113	P5-9	WINDOW & COMBINED PITOT-STATIC HEAT MODULE
69-37346-97	P5-9	WINDOW & COMBINED PITOT-STATIC HEAT MODULE
69-37377-1		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-37377-11		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-37377-14		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-37377-24		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-37377-27		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-37377-7		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-42933-5		COMPARTMENT OVERHEAT UNIT PRINTED CIRCUIT
69-42933-7		COMPARTMENT OVERHEAT UNIT PRINTED CIRCUIT
694PG		PRESSURE GAUGE
69-55179-47		INDICATOR LIGHT DIMMING MODULE ASSY
69-55179-53		INDICATOR LIGHT DIMMING MODULE ASSY
69-55179-55		INDICATOR LIGHT DIMMING MODULE ASSY
69-55179-58		INDICATOR LIGHT DIMMING MODULE ASSY
69-55179-63		INDICATOR LIGHT DIMMING MODULE ASSY
69-55179-64		INDICATOR LIGHT DIMMING MODULE ASSY
69-55179-65		INDICATOR LIGHT DIMMING MODULE ASSY
69-55179-67		INDICATOR LIGHT DIMMING MODULE ASSY
69-66290-1		ENGINE HI-TEMP APU PRINTED CIRCUIT ASSY.
69-66290-3		ENGINE HI-TEMP APU PRINTED CIRCUIT ASSY.
69-68134-2		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-68134-3		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-68134-4		ENIGNE & WING ANTI-ICE MODULE ASSY P5-11
69-68561-11		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-68561-14		VIP COMMUNICATIONS MODULE ASSY. M771, P5-45, P5-
69-76497-1		BROADCAST RADIO CONTROL MODULE ASSY.
698611-1		UNITIZED TORQUEMETER INDICATOR
7000466-901	AD-650A	ATTITUDE DIRECTOR INDICATOR
7000466-902	AD-650A	ATTITUDE DIRECTOR INDICATOR
7000466-903	AD-600A	ATTITUDE DIRECTOR INDICATOR
7000466-904	AD-600A	ATTITUDE DIRECTOR INDICATOR
7000466-905	AD-650B	ATTITUDE DIRECTOR INDICATOR
7000466-906	AD-650B	ATTITUDE DIRECTOR INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
7000466-907	AD-600B	ATTITUDE DIRECTOR INDICATOR
7000466-908	AD-600B	ATTITUDE DIRECTOR INDICATOR
7000466-909	AD-650C	ATTITUDE DIRECTOR INDICATOR
7000466-910	AD-650C	ATTITUDE DIRECTOR INDICATOR
7000466-911	AD-600C	ATTITUDE DIRECTOR INDICATOR
7000466-912	AD-600C	ATTITUDE DIRECTOR INDICATOR
7000466-913	AD-600H	ATTITUDE DIRECTOR INDICATOR
7000466-914	AD-600H	ATTITUDE DIRECTOR INDICATOR
7000466-915	AD-650H	ATTITUDE DIRECTOR INDICATOR
7000466-916	AD-650H	ATTITUDE DIRECTOR INDICATOR
7000466-917	AD-650A	ATTITUDE DIRECTOR INDICATOR
7000466-918	AD-650A	ATTITUDE DIRECTOR INDICATOR
7000466-920	AD-650C	ATTITUDE DIRECTOR INDICATOR
7000466-925	AD-650H	ATTITUDE DIRECTOR INDICATOR
7000466-926	AD-650B	ATTITUDE DIRECTOR INDICATOR
7000466-935	AD-650H	ATTITUDE DIRECTOR INDICATOR
7000466-936	AD-650H	ATTITUDE DIRECTOR INDICATOR
7000466-945	AD-650H	ATTITUDE DIRECTOR INDICATOR
7000466-946	AD-650B	ATTITUDE DIRECTOR INDICATOR
7000466-951	AD-650A	ATTITUDE DIRECTOR INDICATOR
7000466-953	AD-600A	ATTITUDE DIRECTOR INDICATOR
7000466-955	AD-650B	ATTITUDE DIRECTOR INDICATOR
7000466-957	AD-600B	ATTITUDE DIRECTOR INDICATOR
7000466-959	AD-650C	ATTITUDE DIRECTOR INDICATOR
7000466-961	AD-600C	ATTITUDE DIRECTOR INDICATOR
7000466-966	AD-650B	ATTITUDE DIRECTOR INDICATOR
7000466-986	AD-650B	ATTITUDE DIRECTOR INDICATOR
7000836-901		ATTITUDE DIRECTOR INDICATOR
7000836-902		ATTITUDE DIRECTOR INDICATOR
7000836-903		ATTITUDE DIRECTOR INDICATOR
7000836-904		ATTITUDE DIRECTOR INDICATOR
7000836-905		ATTITUDE DIRECTOR INDICATOR
7000836-906		ATTITUDE DIRECTOR INDICATOR
7000836-907		ATTITUDE DIRECTOR INDICATOR
7000836-908		ATTITUDE DIRECTOR INDICATOR
7000836-909		ATTITUDE DIRECTOR INDICATOR
7000836-910		ATTITUDE DIRECTOR INDICATOR
7000836-911		ATTITUDE DIRECTOR INDICATOR
7000836-912		ATTITUDE DIRECTOR INDICATOR
7000836-913		ATTITUDE DIRECTOR INDICATOR
7000836-914		ATTITUDE DIRECTOR INDICATOR
7000836-915		ATTITUDE DIRECTOR INDICATOR
7000836-916		ATTITUDE DIRECTOR INDICATOR
7000836-917		ATTITUDE DIRECTOR INDICATOR
7000836-918		ATTITUDE DIRECTOR INDICATOR
7000836-919		ATTITUDE DIRECTOR INDICATOR
7000836-920		ATTITUDE DIRECTOR INDICATOR
7000836-921		ATTITUDE DIRECTOR INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
7000836-922		ATTITUDE DIRECTOR INDICATOR
7000836-923		ATTITUDE DIRECTOR INDICATOR
7000836-924		ATTITUDE DIRECTOR INDICATOR
7000836-925		ATTITUDE DIRECTOR INDICATOR
7000836-926		ATTITUDE DIRECTOR INDICATOR
7000839-901	RA-315	RADIO ALTIMETER INDICATOR
7000839-902	RA-315	RADIO ALTIMETER INDICATOR
7000839-903	RA-315	RADIO ALTIMETER INDICATOR
7000839-904	RA-335	RADIO ALTIMETER INDICATOR
7000839-905	RA-335	RADIO ALTIMETER INDICATOR
7000839-906	RA-315	RADIO ALTIMETER INDICATOR
7000839-922	RA-315	RADIO ALTIMETER INDICATOR
7000839-923	RA-335	RADIO ALTIMETER INDICATOR
7001182-901	AD-550A	ATTITUDE DIRECTOR INDICATOR
7001182-902	AD-550A	ATTITUDE DIRECTOR INDICATOR
7001182-903	AD-550B	ATTITUDE DIRECTOR INDICATOR
7001182-904	AD-550B	ATTITUDE DIRECTOR INDICATOR
7001182-905	AD-550C	ATTITUDE DIRECTOR INDICATOR
7001182-906	AD-550C	ATTITUDE DIRECTOR INDICATOR
7001182-907	AD-550H	ATTITUDE DIRECTOR INDICATOR
7001182-909	AD-550A	ATTITUDE DIRECTOR INDICATOR
7001182-910	AD-550A	ATTITUDE DIRECTOR INDICATOR
7001182-911	AD-550B	ATTITUDE DIRECTOR INDICATOR
7001182-912	AD-550B	ATTITUDE DIRECTOR INDICATOR
7001182-913	AD-550C	ATTITUDE DIRECTOR INDICATOR
7001182-914	AD-550C	ATTITUDE DIRECTOR INDICATOR
7001182-915	AD-550H	ATTITUDE DIRECTOR INDICATOR
7001182-916	AD-550H	ATTITUDE DIRECTOR INDICATOR
7001182-917	AD-550C	ATTITUDE DIRECTOR INDICATOR
7001182-918	AD-550C	ATTITUDE DIRECTOR INDICATOR
7001182-919	AD-550C	ATTITUDE DIRECTOR INDICATOR
700-1545-001		SMART VIDEO DISTRIBUTION UNIT
700-1589-001		SIXTEEN-INCH COLOR MONITOR
700-1589-002	PVM-1600ALB	SIXTEEN-INCH COLOR MONITOR
700-1589-003		SIXTEEN-INCH COLOR MONITOR
700-1589-004		SIXTEEN-INCH COLOR MONITOR
700-1589-007		SIXTEEN-INCH COLOR MONITOR
700-1590-001		14" MONITOR
700-1590-002		14" MONITOR
700-1590-003		14" MONITOR
700-1590-004		14" MONITOR
700-1590-005		14" MONITOR
700-2004-001		8.6 INCH LIQUID CRYSTAL DISPLAY MONITOR
700-2004-002		8.6 INCH LIQUID CRYSTAL DISPLAY MONITOR
700-2004-003		8.6 INCH LIQUID CRYSTAL DISPLAY MONITOR
700-2004-004		8.6 INCH LIQUID CRYSTAL DISPLAY MONITOR
700-2061-001		8.6-INCH LIQUID CRYSTAL DISPLAY MONITOR
700-2061-002		8.6-INCH LIQUID CRYSTAL DISPLAY MONITOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
700-2061-003		8.6-INCH LIQUID CRYSTAL DISPLAY MONITOR
700-2061-005		8.6-INCH LIQUID CRYSTAL DISPLAY MONITOR
701363		FORWARD STROBE LIGHT
701364		FORWARD STROBE LIGHT
702084		FORWARD STROBE LIGHT
705-15V1		HORIZON GYRO
705-15V10		HORIZON GYRO
705-15V1M1		HORIZON GYRO
705-15V3		HORIZON GYRO
705-15V4		HORIZON GYRO
705-15V9		HORIZON GYRO
705-16		HORIZON GYRO
705-19		HORIZON GYRO
705-20V1		HORIZON GYRO
705-7		HORIZON GYRO
705-7V4		HORIZON GYRO
705-7V42		HORIZON GYRO
705-7V42M1		HORIZON GYRO
705-7V4M1		HORIZON GYRO
705-7V81		HORIZON GYRO
705-7V81M1		HORIZON GYRO
705-7V86		HORIZON GYRO
705-7V9		HORIZON GYRO
705-7V91M1		HORIZON GYRO
705-7V92		HORIZON GYRO
705-7V92M1		HORIZON GYRO
705-7V98		HORIZON GYRO
705-7V9M1		HORIZON GYRO
708780-2		STATIC INVERTER
710204-7		CABIN PRESSURE CONTROLLER
710204-8		CABIN PRESSURE CONTROLLER
711002-3		PRESSURE CONTROL PANEL
711002-4		PRESSURE CONTROL PANEL
711002-5		PRESSURE CONTROL PANEL
711003-3		OUTFLOW VALVE
711003-5		OUTFLOW VALVE
71700-10		TURBINE TEMPERATURE INDICATOR
71701-29		TURBINE TEMPERATURE INDICATOR
71701-40		TURBINE TEMPERATURE INDICATOR
72011240	DA 12L	COFFE MAKER
7202-1A-1-A2	ID-249A/ARN	COURSE INDICATOR
7202-1A-4-A1	ID-387/ARN	COURSE INDICATOR
7202-1A-4-B1	ID-249A/ARN	COURSE INDICATOR
7202-1A-4-C1	ID-249A/ARN	COURSE INDICATOR
7204-1A-4-D1	ID-387/ARN	COURSE INDICATOR
7209-11-9-A1	ID-249/ARN-193	COURSE INDICATOR
72180131	DR6-2B	WATER HEATER
72180132	DR6-2B	WATER HEATER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
72180133	DR6-2B	WATER HEATER
72180134	DR6-2B	WATER HEATER
72180135	DR6-2B	WATER HEATER
72180137	DR6-2B	WATER HEATER
72180138	DR6-2B	WATER HEATER
72303102-3		WINGTIP POSITION LIGHT ASSEMBLY
72303102-4		WINGTIP POSITION LIGHT ASSEMBLY
723-4056-01		ILLUMINATED PANELS
723-4057-01		ILLUMINATED PANELS
723-4058-01		ILLUMINATED PANELS
723-4058-02		ILLUMINATED PANELS
723-4058-03		ILLUMINATED PANELS
723-4058-04		ILLUMINATED PANELS
723-4059-01		ILLUMINATED PANELS
723-4059-02		ILLUMINATED PANELS
723-4059-03		ILLUMINATED PANELS
723-4059-04		ILLUMINATED PANELS
723-4059-05		ILLUMINATED PANELS
723-4059-06		ILLUMINATED PANELS
723-4059-07		ILLUMINATED PANELS
723-4059-08		ILLUMINATED PANELS
723-4059-09		ILLUMINATED PANELS
723-4059-10		ILLUMINATED PANELS
723-4059-11		ILLUMINATED PANELS
723-4059-12		ILLUMINATED PANELS
723-4059-13		ILLUMINATED PANELS
723-4059-14		ILLUMINATED PANELS
723-4059-15		ILLUMINATED PANELS
723-4059-16		ILLUMINATED PANELS
723-4059-17		ILLUMINATED PANELS
723-4059-18		ILLUMINATED PANELS
723-4059-19		ILLUMINATED PANELS
723-4059-20		ILLUMINATED PANELS
723-4059-21		ILLUMINATED PANELS
723-4059-22		ILLUMINATED PANELS
723-4059-23		ILLUMINATED PANELS
723-4059-24		ILLUMINATED PANELS
723-4059-25		ILLUMINATED PANELS
723-4059-26		ILLUMINATED PANELS
723-4059-28		ILLUMINATED PANELS
723-4059-29		ILLUMINATED PANELS
723-4059-30		ILLUMINATED PANELS
723-4059-31		ILLUMINATED PANELS
723-4059-32		ILLUMINATED PANELS
723-4059-33		ILLUMINATED PANELS
723-4059-34		ILLUMINATED PANELS
723-4059-35		ILLUMINATED PANELS
723-4059-36		ILLUMINATED PANELS



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
723-4059-37		ILLUMINATED PANELS
723-4059-38		ILLUMINATED PANELS
723-4059-39		ILLUMINATED PANELS
723-4059-40		ILLUMINATED PANELS
723-4059-52		ILLUMINATED PANELS
723-4059-53		ILLUMINATED PANELS
723-4059-54		ILLUMINATED PANELS
723-4059-55		ILLUMINATED PANELS
723-4059-56		ILLUMINATED PANELS
723-4059-57		ILLUMINATED PANELS
723-4059-58		ILLUMINATED PANELS
723-4059-59		ILLUMINATED PANELS
723-4059-60		ILLUMINATED PANELS
723-4059-61		ILLUMINATED PANELS
723-4059-62		ILLUMINATED PANELS
723-4059-63		ILLUMINATED PANELS
723-4059-64		ILLUMINATED PANELS
723-4059-65		ILLUMINATED PANELS
723-4059-66		ILLUMINATED PANELS
723-4059-68		ILLUMINATED PANELS
723-4059-69		ILLUMINATED PANELS
723-4059-70		ILLUMINATED PANELS
723-4059-72		ILLUMINATED PANELS
723-4059-73		ILLUMINATED PANELS
723-4060-01		ILLUMINATED PANELS
723-4060-02		ILLUMINATED PANELS
723-4060-03		ILLUMINATED PANELS
723-4060-04		ILLUMINATED PANELS
723-4060-05		ILLUMINATED PANELS
723-4061-01		ILLUMINATED PANELS
723-4061-02		ILLUMINATED PANELS
723-4062-01		ILLUMINATED PANELS
723-4062-02		ILLUMINATED PANELS
723-4063-01		ILLUMINATED PANELS
723-4064-01		ILLUMINATED PANELS
723-4064-02		ILLUMINATED PANELS
723-4064-03		ILLUMINATED PANELS
723-4064-04		ILLUMINATED PANELS
723-4064-05		ILLUMINATED PANELS
723-4064-06		ILLUMINATED PANELS
723-4064-07		ILLUMINATED PANELS
723-4064-08		ILLUMINATED PANELS
723-4064-09		ILLUMINATED PANELS
723-4064-10		ILLUMINATED PANELS
723-4064-11		ILLUMINATED PANELS
723-4064-12		ILLUMINATED PANELS
723-4064-13		ILLUMINATED PANELS
723-4064-14		ILLUMINATED PANELS



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
723-4064-15		ILLUMINATED PANELS
723-4064-16		ILLUMINATED PANELS
723-4064-17		ILLUMINATED PANELS
723-4064-18		ILLUMINATED PANELS
723-4064-19		ILLUMINATED PANELS
723-4064-20		ILLUMINATED PANELS
723-4065-01		ILLUMINATED PANELS
723-4065-02		ILLUMINATED PANELS
723-4065-03		ILLUMINATED PANELS
723-4065-04		ILLUMINATED PANELS
723-4066-01		ILLUMINATED PANELS
723-4066-02		ILLUMINATED PANELS
723-4066-03		ILLUMINATED PANELS
723-4066-04		ILLUMINATED PANELS
723-4066-05		ILLUMINATED PANELS
723-4067-01		ILLUMINATED PANELS
723-4067-02		ILLUMINATED PANELS
723-4067-03		ILLUMINATED PANELS
723-4067-04		ILLUMINATED PANELS
723-4067-05		ILLUMINATED PANELS
723-4068-01		ILLUMINATED PANELS
723-4068-02		ILLUMINATED PANELS
723-4068-03		ILLUMINATED PANELS
723-4068-04		ILLUMINATED PANELS
723-4069-01		ILLUMINATED PANELS
723-4069-02		ILLUMINATED PANELS
723-4069-03		ILLUMINATED PANELS
723-4069-04		ILLUMINATED PANELS
723-4069-05		ILLUMINATED PANELS
723-4069-06		ILLUMINATED PANELS
723-4069-07		ILLUMINATED PANELS
723-4069-08		ILLUMINATED PANELS
723-4069-09		ILLUMINATED PANELS
723-4069-10		ILLUMINATED PANELS
723-4069-11		ILLUMINATED PANELS
723-4069-12		ILLUMINATED PANELS
723-4069-13		ILLUMINATED PANELS
723-4069-14		ILLUMINATED PANELS
723-4069-15		ILLUMINATED PANELS
723-4069-16		ILLUMINATED PANELS
723-4069-17		ILLUMINATED PANELS
723-4069-18		ILLUMINATED PANELS
723-4069-19		ILLUMINATED PANELS
723-4069-20		ILLUMINATED PANELS
723-4069-21		ILLUMINATED PANELS
723-4069-22		ILLUMINATED PANELS
723-4069-23		ILLUMINATED PANELS
723-4069-24		ILLUMINATED PANELS





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
723-4069-25		ILLUMINATED PANELS
723-4069-26		ILLUMINATED PANELS
723-4069-27		ILLUMINATED PANELS
723-4069-28		ILLUMINATED PANELS
723-4069-29		ILLUMINATED PANELS
723-4069-30		ILLUMINATED PANELS
723-4069-31		ILLUMINATED PANELS
723-4069-32		ILLUMINATED PANELS
723-4069-33		ILLUMINATED PANELS
723-4069-34		ILLUMINATED PANELS
723-4069-35		ILLUMINATED PANELS
723-4069-36		ILLUMINATED PANELS
723-4069-37		ILLUMINATED PANELS
723-4069-38		ILLUMINATED PANELS
723-4069-39		ILLUMINATED PANELS
723-4069-40		ILLUMINATED PANELS
723-4069-41		ILLUMINATED PANELS
723-4069-42		ILLUMINATED PANELS
723-4069-43		ILLUMINATED PANELS
723-4069-44		ILLUMINATED PANELS
723-4069-45		ILLUMINATED PANELS
723-4069-46		ILLUMINATED PANELS
723-4069-47		ILLUMINATED PANELS
723-4069-48		ILLUMINATED PANELS
723-4069-49		ILLUMINATED PANELS
723-4069-50		ILLUMINATED PANELS
723-4069-51		ILLUMINATED PANELS
723-4069-52		ILLUMINATED PANELS
723-4069-54		ILLUMINATED PANELS
723-4069-55		ILLUMINATED PANELS
723-4070-01		ILLUMINATED PANELS
723-4070-02		ILLUMINATED PANELS
723-4070-03		ILLUMINATED PANELS
723-4070-04		ILLUMINATED PANELS
723-4070-05		ILLUMINATED PANELS
723-4070-06		ILLUMINATED PANELS
723-4070-07		ILLUMINATED PANELS
723-4070-08		ILLUMINATED PANELS
723-4070-09		ILLUMINATED PANELS
723-4070-10		ILLUMINATED PANELS
723-4071-01		ILLUMINATED PANELS
723-4071-02		ILLUMINATED PANELS
723-4071-03		ILLUMINATED PANELS
723-4071-04		ILLUMINATED PANELS
723-4072-01		ILLUMINATED PANELS
723-4072-02		ILLUMINATED PANELS
723-4072-03		ILLUMINATED PANELS
723-4072-04		ILLUMINATED PANELS



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
723-4072-05		ILLUMINATED PANELS
723-4072-06		ILLUMINATED PANELS
723-4073-01		ILLUMINATED PANELS
723-4074-01		ILLUMINATED PANELS
723-4074-02		ILLUMINATED PANELS
723-4075-01		ILLUMINATED PANELS
723-4075-02		ILLUMINATED PANELS
723-4075-03		ILLUMINATED PANELS
723-4075-04		ILLUMINATED PANELS
723-4075-05		ILLUMINATED PANELS
723-4076-01		ILLUMINATED PANELS
723-4077-01		ILLUMINATED PANELS
723-4077-02		ILLUMINATED PANELS
723-4078-01		ILLUMINATED PANELS
723-4079-01		ILLUMINATED PANELS
723-4080-01		ILLUMINATED PANELS
723-4081-01		ILLUMINATED PANELS
723-4082-01		ILLUMINATED PANELS
723-4082-02		ILLUMINATED PANELS
723-4082-03		ILLUMINATED PANELS
723-4082-04		ILLUMINATED PANELS
723-4082-06		ILLUMINATED PANELS
723-4082-07		ILLUMINATED PANELS
723-4082-09		ILLUMINATED PANELS
723-4082-10		ILLUMINATED PANELS
723-4082-11		ILLUMINATED PANELS
723-4082-12		ILLUMINATED PANELS
723-4082-13		ILLUMINATED PANELS
723-4082-14		ILLUMINATED PANELS
723-4082-15		ILLUMINATED PANELS
723-4082-16		ILLUMINATED PANELS
723-4082-17		ILLUMINATED PANELS
723-4082-18		ILLUMINATED PANELS
723-4082-20		ILLUMINATED PANELS
723-4082-21		ILLUMINATED PANELS
723-4082-22		ILLUMINATED PANELS
723-4082-23		ILLUMINATED PANELS
723-4082-24		ILLUMINATED PANELS
723-4082-25		ILLUMINATED PANELS
723-4082-27		ILLUMINATED PANELS
723-4083-01		ILLUMINATED PANELS
723-4093-01		ILLUMINATED PANELS
723-4093-02		ILLUMINATED PANELS
723-4093-03		ILLUMINATED PANELS
723-4093-04		ILLUMINATED PANELS
723-4093-05		ILLUMINATED PANELS
723-4093-06		ILLUMINATED PANELS
723-4093-07		ILLUMINATED PANELS



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
723-4093-08		ILLUMINATED PANELS
723-4093-09		ILLUMINATED PANELS
723-4093-10		ILLUMINATED PANELS
723-4093-11		ILLUMINATED PANELS
723-4093-12		ILLUMINATED PANELS
723-4093-13		ILLUMINATED PANELS
723-4093-14		ILLUMINATED PANELS
723-4093-15		ILLUMINATED PANELS
723-4093-16		ILLUMINATED PANELS
723-4191-01		ILLUMINATED PANELS
723-4207-01		ILLUMINATED PANELS
723-4355-01		ILLUMINATED PANELS
723-4355-02		ILLUMINATED PANELS
723-4418-01		ILLUMINATED PANELS
723-4418-02		ILLUMINATED PANELS
723-4418-03		ILLUMINATED PANELS
723-4418-04		ILLUMINATED PANELS
723-4418-05		ILLUMINATED PANELS
723-4418-06		ILLUMINATED PANELS
723-4418-07		ILLUMINATED PANELS
723-4418-08		ILLUMINATED PANELS
723-4418-09		ILLUMINATED PANELS
723-4418-10		ILLUMINATED PANELS
723-4418-11		ILLUMINATED PANELS
723-4418-12		ILLUMINATED PANELS
723-4418-13		ILLUMINATED PANELS
723-4418-14		ILLUMINATED PANELS
723-4418-15		ILLUMINATED PANELS
723-4418-16		ILLUMINATED PANELS
723-4418-17		ILLUMINATED PANELS
723-4418-18		ILLUMINATED PANELS
723-4418-21		ILLUMINATED PANELS
723-4418-22		ILLUMINATED PANELS
723-4418-23		ILLUMINATED PANELS
723-4418-24		ILLUMINATED PANELS
723-4419-01		ILLUMINATED PANELS
723-4420-01		ILLUMINATED PANELS
723-4420-02		ILLUMINATED PANELS
723-4453-01		ILLUMINATED PANELS
723-4453-02		ILLUMINATED PANELS
723-4453-03		ILLUMINATED PANELS
723-4453-04		ILLUMINATED PANELS
723-4453-05		ILLUMINATED PANELS
723-4453-06		ILLUMINATED PANELS
723-4458-01		ILLUMINATED PANELS
723-4458-02		ILLUMINATED PANELS
723-4471-01		ILLUMINATED PANELS
723-4499-01		ILLUMINATED PANELS



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
723-4499-02		ILLUMINATED PANELS
723-4691-01		ILLUMINATED PANELS
723-4807-01		ILLUMINATED PANELS
723-4807-02		ILLUMINATED PANELS
723-4807-03		ILLUMINATED PANELS
723-4807-04		ILLUMINATED PANELS
723-4855-01		ILLUMINATED PANELS
723-4855-02		ILLUMINATED PANELS
723-4901-01		ILLUMINATED PANELS
723-4927-01		ILLUMINATED PANELS
723-4927-02		ILLUMINATED PANELS
723-4927-03		ILLUMINATED PANELS
723-4927-04		ILLUMINATED PANELS
723-4960-01		ILLUMINATED PANELS
723-5033-02		ILLUMINATED PANELS
723-5269-01		ILLUMINATED PANELS
723-5276-01		ILLUMINATED PANELS
723-5276-03		ILLUMINATED PANELS
723-5276-04		ILLUMINATED PANELS
723-5315-01		ILLUMINATED PANELS
723-5334-01		ILLUMINATED PANELS
723-5334-02		ILLUMINATED PANELS
723-5334-03		ILLUMINATED PANELS
723-5335-01		ILLUMINATED PANELS
723-5346-01		ILLUMINATED PANELS
723-5352-01		ILLUMINATED PANELS
723-5362-01		ILLUMINATED PANELS
723-5446-01		ILLUMINATED PANELS
723-5446-02		ILLUMINATED PANELS
7236-2A12A2		COURSE DEVIATION INDICATOR
7236-2A14A2		COURSE DEVIATION INDICATOR
7237-3B-14-A1		FLIGHT PATH DEVIATION INDICATOR
7237-3B-14-B1		FLIGHT PATH DEVIATION INDICATOR
727MV/BU/1		TEMPERATURE INDICATOR
727MV/BU/10		TEMPERATURE INDICATOR
727MV/BU/11		TEMPERATURE INDICATOR
727MV/BU/12		TEMPERATURE INDICATOR
727MV/BU/14		TEMPERATURE INDICATOR
727MV/BU/15		TEMPERATURE INDICATOR
727MV/BU/16		TEMPERATURE INDICATOR
727MV/BU/17/580		TEMPERATURE INDICATOR
727MV/BU/17/600		TEMPERATURE INDICATOR
727MV/BU/17/640		TEMPERATURE INDICATOR
727MV/BU/18/580		TEMPERATURE INDICATOR
727MV/BU/18/610		TEMPERATURE INDICATOR
727MV/BU/18/620		TEMPERATURE INDICATOR
727MV/BU/18/640		TEMPERATURE INDICATOR
727MV/BU/19		TEMPERATURE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
727MV/BU/2		TEMPERATURE INDICATOR
727MV/BU/20/500		TEMPERATURE INDICATOR
727MV/BU/20/560		TEMPERATURE INDICATOR
727MV/BU/21/500		TEMPERATURE INDICATOR
727MV/BU/22		TEMPERATURE INDICATOR
727MV/BU/24		TEMPERATURE INDICATOR
727MV/BU/25/640		TEMPERATURE INDICATOR
727MV/BU/26		TEMPERATURE INDICATOR
727MV/BU/28/580		TEMPERATURE INDICATOR
727MV/BU/3		TEMPERATURE INDICATOR
727MV/BU/30		TEMPERATURE INDICATOR
727MV/BU/32		TEMPERATURE INDICATOR
727MV/BU/33/580		TEMPERATURE INDICATOR
727MV/BU/34/700		TEMPERATURE INDICATOR
727MV/BU/37		TEMPERATURE INDICATOR
727MV/BU/38		TEMPERATURE INDICATOR
727MV/BU/39/700		TEMPERATURE INDICATOR
727MV/BU/4		TEMPERATURE INDICATOR
727MV/BU/42/690		TEMPERATURE INDICATOR
727MV/BU/43/550		TEMPERATURE INDICATOR
727MV/BU/44/700	C6SC1085-5	TEMPERATURE INDICATOR
727MV/BU/46/650		TEMPERATURE INDICATOR
727MV/BU/47/580		TEMPERATURE INDICATOR
727MV/BU/48		TEMPERATURE INDICATOR
727MV/BU/5		TEMPERATURE INDICATOR
727MV/BU/50		TEMPERATURE INDICATOR
727MV/BU/51/700		TEMPERATURE INDICATOR
727MV/BU/52/640		TEMPERATURE INDICATOR
727MV/BU/53/750		TEMPERATURE INDICATOR
727MV/BU/54/690		TEMPERATURE INDICATOR
727MV/BU/56/730		TEMPERATURE INDICATOR
727MV/BU/57/740		TEMPERATURE INDICATOR
727MV/BU/59/720		TEMPERATURE INDICATOR
727MV/BU/6		TEMPERATURE INDICATOR
727MV/BU/60/720		TEMPERATURE INDICATOR
727MV/BU/61/750		TEMPERATURE INDICATOR
727MV/BU/62/700		TEMPERATURE INDICATOR
727MV/BU/63		TEMPERATURE INDICATOR
727MV/BU/64/660		TEMPERATURE INDICATOR
727MV/BU/65/720		TEMPERATURE INDICATOR
727MV/BU/66/660		TEMPERATURE INDICATOR
727MV/BU/7		TEMPERATURE INDICATOR
727MV/BU/8		TEMPERATURE INDICATOR
727MV/BU53/650		TEMPERATURE INDICATOR
731376		AXIAL FLOW FAN ASSY.
731376A		AXIAL FLOW FAN ASSY.
743-0215-030		SYSTEM CONTROL UNIT
743-0238-001	EVP-90	HI8 VIDEO CASSETTE PLAYER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
743-0238-201	EVP-90	HI8 VIDEO CASSETTE PLAYER
743-0293-001		HI8 VIDEO REPRODUCER UNIT
75-0148-1		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-11		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-13		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-15		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-17		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-19		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-21		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-23		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-25		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-27		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-29		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-3		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-31		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-33		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-35		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-5		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-7		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0148-9		EXTERNAL DOOR WARNING ANNUNCIATOR PANNEL
75-0149-1		INDICATOR LIGHT ASSEMBLY
75-0149-10		INDICATOR LIGHT ASSEMBLY
75-0149-11		INDICATOR LIGHT ASSEMBLY
75-0149-12		INDICATOR LIGHT ASSEMBLY
75-0149-13		INDICATOR LIGHT ASSEMBLY
75-0149-14		INDICATOR LIGHT ASSEMBLY
75-0149-15		INDICATOR LIGHT ASSEMBLY
75-0149-16		INDICATOR LIGHT ASSEMBLY
75-0149-17		INDICATOR LIGHT ASSEMBLY
75-0149-18		INDICATOR LIGHT ASSEMBLY
75-0149-19		INDICATOR LIGHT ASSEMBLY
75-0149-2		INDICATOR LIGHT ASSEMBLY
75-0149-20		INDICATOR LIGHT ASSEMBLY
75-0149-21		INDICATOR LIGHT ASSEMBLY
75-0149-25		INDICATOR LIGHT ASSEMBLY
75-0149-26		INDICATOR LIGHT ASSEMBLY
75-0149-27		INDICATOR LIGHT ASSEMBLY
75-0149-28		INDICATOR LIGHT ASSEMBLY
75-0149-29		INDICATOR LIGHT ASSEMBLY
75-0149-3		INDICATOR LIGHT ASSEMBLY
75-0149-30		INDICATOR LIGHT ASSEMBLY
75-0149-31		INDICATOR LIGHT ASSEMBLY
75-0149-32		INDICATOR LIGHT ASSEMBLY
75-0149-33		INDICATOR LIGHT ASSEMBLY
75-0149-34		INDICATOR LIGHT ASSEMBLY
75-0149-35		INDICATOR LIGHT ASSEMBLY
75-0149-36		INDICATOR LIGHT ASSEMBLY
75-0149-37		INDICATOR LIGHT ASSEMBLY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
75-0149-38		INDICATOR LIGHT ASSEMBLY
75-0149-39		INDICATOR LIGHT ASSEMBLY
75-0149-4		INDICATOR LIGHT ASSEMBLY
75-0149-40		INDICATOR LIGHT ASSEMBLY
75-0149-41		INDICATOR LIGHT ASSEMBLY
75-0149-42		INDICATOR LIGHT ASSEMBLY
75-0149-43		INDICATOR LIGHT ASSEMBLY
75-0149-44		INDICATOR LIGHT ASSEMBLY
75-0149-45		INDICATOR LIGHT ASSEMBLY
75-0149-46		INDICATOR LIGHT ASSEMBLY
75-0149-47		INDICATOR LIGHT ASSEMBLY
75-0149-48		INDICATOR LIGHT ASSEMBLY
75-0149-49		INDICATOR LIGHT ASSEMBLY
75-0149-5		INDICATOR LIGHT ASSEMBLY
75-0149-50		INDICATOR LIGHT ASSEMBLY
75-0149-51		INDICATOR LIGHT ASSEMBLY
75-0149-52		INDICATOR LIGHT ASSEMBLY
75-0149-53		INDICATOR LIGHT ASSEMBLY
75-0149-54		INDICATOR LIGHT ASSEMBLY
75-0149-55		INDICATOR LIGHT ASSEMBLY
75-0149-56		INDICATOR LIGHT ASSEMBLY
75-0149-57		INDICATOR LIGHT ASSEMBLY
75-0149-58		INDICATOR LIGHT ASSEMBLY
75-0149-59		INDICATOR LIGHT ASSEMBLY
75-0149-6		INDICATOR LIGHT ASSEMBLY
75-0149-60		INDICATOR LIGHT ASSEMBLY
75-0149-61		INDICATOR LIGHT ASSEMBLY
75-0149-62		INDICATOR LIGHT ASSEMBLY
75-0149-63		INDICATOR LIGHT ASSEMBLY
75-0149-64		INDICATOR LIGHT ASSEMBLY
75-0149-65		INDICATOR LIGHT ASSEMBLY
75-0149-66		INDICATOR LIGHT ASSEMBLY
75-0149-67		INDICATOR LIGHT ASSEMBLY
75-0149-68		INDICATOR LIGHT ASSEMBLY
75-0149-69		INDICATOR LIGHT ASSEMBLY
75-0149-7		INDICATOR LIGHT ASSEMBLY
75-0149-70		INDICATOR LIGHT ASSEMBLY
75-0149-71		INDICATOR LIGHT ASSEMBLY
75-0149-72		INDICATOR LIGHT ASSEMBLY
75-0149-73		INDICATOR LIGHT ASSEMBLY
75-0149-8		INDICATOR LIGHT ASSEMBLY
75-0149-9		INDICATOR LIGHT ASSEMBLY
751PG/SB		DESYNN PRESSURE INDICATOR
761260-7		CABIN PRESSURE CONTROLLER
761260-8		CABIN PRESSURE CONTROLLER
762MV/BM/31/810		TEMPERATURE INDICATOR
762MV/BU/1/740		TEMPERATURE INDICATOR
762MV/BU/10/700		TEMPERATURE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
762MV/BU/11		TEMPERATURE INDICATOR
762MV/BU/12		TEMPERATURE INDICATOR
762MV/BU/15/725		TEMPERATURE INDICATOR
762MV/BU/16/580		TEMPERATURE INDICATOR
762MV/BU/18/740		TEMPERATURE INDICATOR
762MV/BU/18/750		TEMPERATURE INDICATOR
762MV/BU/19/700		TEMPERATURE INDICATOR
762MV/BU/2/580		TEMPERATURE INDICATOR
762MV/BU/20/860		TEMPERATURE INDICATOR
762MV/BU/21/860		TEMPERATURE INDICATOR
762MV/BU/22/680		TEMPERATURE INDICATOR
762MV/BU/23/860		TEMPERATURE INDICATOR
762MV/BU/24/790		TEMPERATURE INDICATOR
762MV/BU/25/720		TEMPERATURE INDICATOR
762MV/BU/26/700		TEMPERATURE INDICATOR
762MV/BU/27/860		TEMPERATURE INDICATOR
762MV/BU/28/800		TEMPERATURE INDICATOR
762MV/BU/3/520		TEMPERATURE INDICATOR
762MV/BU/3/560		TEMPERATURE INDICATOR
762MV/BU/30/770		TEMPERATURE INDICATOR
762MV/BU/33/700		TEMPERATURE INDICATOR
762MV/BU/34/700		TEMPERATURE INDICATOR
762MV/BU/36/860		TEMPERATURE INDICATOR
762MV/BU/37/800		TEMPERATURE INDICATOR
762MV/BU/38/790		TEMPERATURE INDICATOR
762MV/BU/40/860		TEMPERATURE INDICATOR
762MV/BU/41/805		TEMPERATURE INDICATOR
762MV/BU/5/590		TEMPERATURE INDICATOR
762MV/BU/5/600		TEMPERATURE INDICATOR
762MV/BU/6/580		TEMPERATURE INDICATOR
762MV/BU/7		TEMPERATURE INDICATOR
762MV/BU/8/550		TEMPERATURE INDICATOR
762MV/BU/9/550		TEMPERATURE INDICATOR
762MV-BU42-900		TEMPERATURE INDICATOR
762MV-BU43-900		TEMPERATURE INDICATOR
763810-1		CABIN PRESSURE CONTROLLER
763810-2		CABIN PRESSURE CONTROLLER
763810-3		CABIN PRESSURE CONTROLLER
763810-4		CABIN PRESSURE CONTROLLER
763810-5		CABIN PRESSURE CONTROLLER
763810-6		CABIN PRESSURE CONTROLLER
763810-7		CABIN PRESSURE CONTROLLER
763810-8		CABIN PRESSURE CONTROLLER
772-5005-001	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-002	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-003	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-004	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-005	329B-8J	FLIGHT DIRECTOR INDICATOR





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
772-5005-006	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-007	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-009	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-011	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-012	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5005-013	329B-8J	FLIGHT DIRECTOR INDICATOR
772-5006-001	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-003	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-005	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-006	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-007	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-009	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-010	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-011	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5006-012	329B-9A	FLIGHT DIRECTOR INDICATOR
772-5025-001	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-002	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-004	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-006	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-008	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-009	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-010	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-011	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-012	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-013	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5025-014	331A-8A	HORIZONTAL SITUATION INDICATOR
772-5140-001	345A-7	RATE OF TURN SENSOR
772-5140-002	345A-7	RATE OF TURN SENSOR
772-5299-001	329B-8G	FLIGHT DIRECTOR INDICATOR
772-5370-001	331A-8G	COURSE INDICATOR
772-5370-002	331A-8G	COURSE INDICATOR
772-5370-003	331A-8G	COURSE INDICATOR
772-5370-004	331A-8G	COURSE INDICATOR
772-5370-005		COURSE INDICATOR
772-5431-001	329B-8N	FLIGHT DIRECTOR INDICATOR
774300-1	EPRC102-1	SOLID STATE IEPR TRANSMITTER
774300-2	EPRC102-1	SOLID STATE IEPR TRANSMITTER
774860A1	PS700-5	PNEUMATIC STARTER
774860A10	PS700-5	PNEUMATIC STARTER
774860A11	PS700-5	PNEUMATIC STARTER
774860A2	PS700-5	PNEUMATIC STARTER
774860A3	PS700-5	PNEUMATIC STARTER
774860A4	PS700-5	PNEUMATIC STARTER
774860A5	PS700-5	PNEUMATIC STARTER
774860A6	PS700-5	PNEUMATIC STARTER
774860A7	PS700-5	PNEUMATIC STARTER
774860A8	PS700-5	PNEUMATIC STARTER
774860A9	PS700-5	PNEUMATIC STARTER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
775538-10		STARTER CONTROL VALVE
775538-11		STARTER CONTROL VALVE
775538-12		STARTER CONTROL VALVE
775538-13		STARTER CONTROL VALVE
775538-15		STARTER CONTROL VALVE
775538-16		STARTER CONTROL VALVE
775538-9		STARTER CONTROL VALVE
775550-2		PNEUMATIC STARTER
775550-3		PNEUMATIC STARTER
775550-4		PNEUMATIC STARTER
775550-5		PNEUMATIC STARTER
775550-6		PNEUMATIC STARTER
775550-7		PNEUMATIC STARTER
776/1PG/SB		DESYNN PRESSURE INDICATOR
776PG/SB		DESYNN PRESSURE INDICATOR
777-1026-004	331A-8H	HORIZONTAL SITUATION INDICATOR
777-1034-001	345A-7A	RATE OF TURN SENSOR
777-1083-001	331A-8D	HORIZONTAL SITUATION INDICATOR
777-1083-002	331A-8D	HORIZONTAL SITUATION INDICATOR
777-1083-003	331A-8D	HORIZONTAL SITUATION INDICATOR
777-1083-006	331A-8D	HORIZONTAL SITUATION INDICATOR
777-1083-007	331A-8D	HORIZONTAL SITUATION INDICATOR
777-1083-011	331A-8D	HORIZONTAL SITUATION INDICATOR
777-1083-012	331A-8D	HORIZONTAL SITUATION INDICATOR
777-1224-001	329B-8G	FLIGHT DIRECTOR INDICATOR
777-1224-002	329B-8G	FLIGHT DIRECTOR INDICATOR
777-1224-003	329B-8G	FLIGHT DIRECTOR INDICATOR
777-1224-004	329B-8G	FLIGHT DIRECTOR INDICATOR
777-1258-001	331A-6K1	COURSE INDICATOR
777-1397-001	331A-8K	HORIZONTAL SITUATION INDICATOR
777-1397-002	331A-8K	HORIZONTAL SITUATION INDICATOR
777-1397-003	331A-8K	HORIZONTAL SITUATION INDICATOR
777-1397-004	331A-8K	HORIZONTAL SITUATION INDICATOR
777-1397-008	331A-8K	HORIZONTAL SITUATION INDICATOR
777-1397-010	331A-8K	HORIZONTAL SITUATION INDICATOR
777-1555-001	332E-5	DIRECTIONAL GYROSCOPE
777-1555-002	332E-5	DIRECTIONAL GYROSCOPE
777-1825-001	331A-8L	HORIZONTAL SITUATION INDICATOR
777-1825-002	331A-8L	HORIZONTAL SITUATION INDICATOR
778728-4		RECIRCULATION FAN
778728-6		RECIRCULATION FAN
77B203		THERMOMETER INDICATOR
77B203A		THERMOMETER INDICATOR
77B203B		THERMOMETER INDICATOR
77B204		THERMOMETER INDICATOR
77B205		THERMOMETER INDICATOR
780A0000-01		COMMAND SENSOR UNIT
780A0000-02		COMMAND SENSOR UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
780B0000-01		COMMAND SENSOR UNIT
78200000-01	782	TRIPLE TACHOMETER INDICATOR
78200000-03	782	TRIPLE TACHOMETER INDICATOR
782449-4	778728-4	RECIRCULATION FAN
782449-6	778728-4	RECIRCULATION FAN
782449-7	778728-4	RECIRCULATION FAN
782449-8	778728-6	RECIRCULATION FAN
787-6034-001	345 A-9	RATE GYRO
787-6171-001	329B-8R	ATTITUDE DIRECTOR INDICATOR
787-6171-002	329B-8R	ATTITUDE DIRECTOR INDICATOR
787-6171-003	329B-8R	ATTITUDE DIRECTOR INDICATOR
787-6173-001	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-002	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-003	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-004	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-005	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-006	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-007	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-008	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-011	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-012	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-013	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-014	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-015	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-016	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-017	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-018	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-201	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-202	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-203	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-204	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-205	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-206	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-207	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-208	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-211	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-212	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-213	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-214	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-215	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-216	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-217	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6173-218	ADI-84	FLIGHT DIRECTOR INDICATOR
787-6226-001	339F-8B	DME INDICATOR
787-6226-002	339F-8B	DME INDICATOR
787-6380-001	350X-3	MOUNT
787-6385-001	331A-6P	COURSE INDICATOR
787-6385-002	331A-6P	COURSE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
787-6385-003	331A-6P	COURSE INDICATOR
787-6385-004	331A-6P	COURSE INDICATOR
787-6385-005	331A-6P	COURSE INDICATOR
787-6385-006	331A-6P	COURSE INDICATOR
787-6766-001	329B-8U	ATTITUDE DIRECTOR INDICATOR
787-6892-001	329B-8V	ATTITUDE DIRECTOR INDICATOR
787-6892-002	329B-8V	ATTITUDE DIRECTOR INDICATOR
787-6892-003	329B-8V	ATTITUDE DIRECTOR INDICATOR
789830-1	EPRC102-1	SOLID STATE IEPR TRANSMITTER
790960-1		CABIN PRESSURE CONTROLLER
790960-2		CABIN PRESSURE CONTROLLER
792-6091-001	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-002	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-005	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-006	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-007	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-008	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-009	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-010	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-012	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-013	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-014	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-015	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-016	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-017	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-019	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-020	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-021	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6091-022	331A-9G	HORIZONTAL SITUATION INDICATOR
792-6221-001	614E-22B	REMOTE HEADING & COURSE SELECTOR
792-6221-002	614E-22B	REMOTE HEADING & COURSE SELECTOR
792-6221-003	614E-22B	REMOTE HEADING & COURSE SELECTOR
792-6221-004	614E-22B	REMOTE HEADING & COURSE SELECTOR
792-6221-005	614E-22B	REMOTE HEADING & COURSE SELECTOR
792-6221-006	614E-22B	REMOTE HEADING & COURSE SELECTOR
792-6221-011	614E-22B	REMOTE HEADING & COURSE SELECTOR
792-6348-001	614E-5A	AUTOPILOT CONTROLLER
792-6348-002	614E-5A	AUTOPILOT CONTROLLER
792-6348-003	614E-5A	AUTOPILOT CONTROLLER
792-6348-004	614E-5A	AUTOPILOT CONTROLLER
792-6348-005	614E-5A	AUTOPILOT CONTROLLER
792-6348-015	614E-5A	AUTOPILOT CONTROLLER
792-6348-101	614E-5A	AUTOPILOT CONTROLLER
792-6348-102	614E-5A	AUTOPILOT CONTROLLER
792-6348-103	614E-5A	AUTOPILOT CONTROLLER
792-6348-104	614E-5A	AUTOPILOT CONTROLLER
792-6348-105	614E-5A	AUTOPILOT CONTROLLER
792-6355-001	329B-7R	FLIGHT DIRECTOR INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
792-6355-002	329B-7R	FLIGHT DIRECTOR INDICATOR
792-6355-003	329B-7R	FLIGHT DIRECTOR INDICATOR
792-6355-004	329B-7R	FLIGHT DIRECTOR INDICATOR
792-6356-002	331A-6R	COURSE INDICATOR
792-6356-003	331A-6R	COURSE INDICATOR
792-6356-004	331A-6R	COURSE INDICATOR
792-6357-001	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-002	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-003	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-005	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-006	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-007	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-008	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-009	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6357-011	329B-8Y	ATTITUDE DIRECTOR INDICATOR
792-6672-001	590A-3H	AIR DATA CONTROL
792-6672-002	590A-3H	AIR DATA CONTROL
792-6672-004	590A-3H	AIR DATA CONTROL
792-6672-005	590A-3H	AIR DATA CONTROL
792-6672-008	590A-3H	AIR DATA CONTROL
792-6672-019	590A-3H	AIR DATA CONTROL
792-6694-001	332D-11A	VERTICAL GYRO
792-6694-002	332D-11A	VERTICAL GYRO
792-6694-004	332D-11A	VERTICAL GYRO
792999-1	S210T120-103	PRESSURE REGULATING AND SHUTOFF VALVE
792999-10	S210T120-143	PRESSURE REGULATING AND SHUTOFF VALVE
792999-11	S210T120-153	PRESSURE REGULATING AND SHUTOFF VALVE
792999-2	S210T120-113	PRESSURE REGULATING AND SHUTOFF VALVE
792999-3	S210T120-133	PRESSURE REGULATING AND SHUTOFF VALVE
792999-4	S210T120-113	PRESSURE REGULATING AND SHUTOFF VALVE
792999-5	S210T120-133	PRESSURE REGULATING AND SHUTOFF VALVE
792999-6	S210T120-143	PRESSURE REGULATING AND SHUTOFF VALVE
792999-7	S210T120-153	PRESSURE REGULATING AND SHUTOFF VALVE
792999-8	S210T120-143	PRESSURE REGULATING AND SHUTOFF VALVE
792999-9	S210T120-153	PRESSURE REGULATING AND SHUTOFF VALVE
8000281Y00		RUNWAY TURN-OFF LIGHT
8000282Y00		TAXI LIGHT
8000283Y00		TAKE OFF LIGHT
8000306Y00		RUNWAY TURN-OFF LIGHT
80-0538-3		OVERHEAD CAUTION ANNUNCIATOR CONTROL
802FL		DESYNN POSITION INDICATOR
803-2		GYROSCOPIC HORIZON
803FL		DESYNN POSITION INDICATOR
804FL		DESYNN POSITION INDICATOR
806FL		DESYNN POSITION INDICATOR
807FL		DESYNN POSITION INDICATOR
8107-140-00-10		ENGINE SHUTDOWN DETECTOR
812FL		DESYNN POSITION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
816FL		DESYNN POSITION INDICATOR
817FL		DESYNN POSITION INDICATOR
8184-1	S283U008-16	ELECTRONIC BALLAST
8184-1 MOD A	S283U008-16 MOD A	ELECTRONIC BALLAST
818709		ROTOR
822-0918-001	RDMI-743B	RADIO DISTANCE MAGNETIC INDICATOR
822-0918-100	RDMI-743B	RADIO DISTANCE MAGNETIC INDICATOR
822FL		DESYNN POSITION INDICATOR
823T0003-1		FUEL TEMP SENSOR/GPWS RA SELECT, M6775 MOD
825FL		DESYNN POSITION INDICATOR
83000-05601	10-61833-1	WINDOW HEAT CONTROL
83000-05602	10-61833-3	WINDOW HEAT CONTROL
83000-05603	10-61833-4	WINDOW HEAT CONTROL
83000-05604	10-61833-6	WINDOW HEAT CONTROL
830FL		DESYNN POSITION INDICATOR
831FL		DESYNN POSITION INDICATOR
832FL		DESYNN POSITION INDICATOR
835760-401		ALTERNATING CURRENT MOTOR
836FL		DESYNN POSITION INDICATOR
837900-401		ALTERNATING CURRENT MOTOR
843FL		DESYNN POSITION INDICATOR
843FLSB		DESYNN POSITION INDICATOR
846FLCP		DESYNN POSITION INDICATOR
848FL		DESYNN POSITION INDICATOR
849FL		DESYNN POSITION INDICATOR
85-16-06343-05		HAND HELD MICROPHONE
85-16-06961-05		HAND HELD MICROPHONE
85-16-08836-05		HAND HELD MICROPHONE
85-16-09502-05		HAND HELD MICROPHONE
85-16-11494-05		HAND HELD MICROPHONE
85-16-12022-05		HAND HELD MICROPHONE
8555M1		RETRACTABLE LANDING LIGHT ACTUATOR
8555M2		RETRACTABLE LANDING LIGHT ACTUATOR
8555M3		RETRACTABLE LANDING LIGHT ACTUATOR
8555M4		RETRACTABLE LANDING LIGHT ACTUATOR
8555M5		RETRACTABLE LANDING LIGHT ACTUATOR
8555M6		RETRACTABLE LANDING LIGHT ACTUATOR
8555M7		RETRACTABLE LANDING LIGHT ACTUATOR
856FL		DESYNN POSITION INDICATOR
859FLBR		DESYNN POSITION INDICATOR
861CAS3	10-62047-5	ANGLE OF ATTACK SENSOR
862FL		DESYNN POSITION INDICATOR
864-001		LIGHTED ICING INDICATOR
87000-1105		MECHANICAL AIRCRAFT CLOCK
87000-1106		MECHANICAL AIRCRAFT CLOCK
870FLBR		DESYNN POSITION INDICATOR
873FLBR		DESYNN POSITION INDICATOR
874FLBR		DESYNN POSITION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
878FL		DESYNN POSITION INDICATOR
881FLBR		DESYNN POSITION INDICATOR
884FL		DESYNN POSITION INDICATOR
89-01-07000	D9240	TELEPHONE HANDSET
89-01-07002	D9240	TELEPHONE HANDSET
89-01-07010	D9240	TELEPHONE HANDSET
89-01-07020	D9240	TELEPHONE HANDSET
89-01-07030	D9240	TELEPHONE HANDSET
89-01-07032	D9240	TELEPHONE HANDSET
89-01-07035	D9240	TELEPHONE HANDSET
89-01-07040	D9240	TELEPHONE HANDSET
89-01-07042	D9240	TELEPHONE HANDSET
89-01-07045	D9240	TELEPHONE HANDSET
89-01-07052	D9240	TELEPHONE HANDSET
89-01-07062	D9240	TELEPHONE HANDSET
89-01-07065	D9240	TELEPHONE HANDSET
89-01-07067	D9240	TELEPHONE HANDSET
89-01-07112	D9240	TELEPHONE HANDSET
89-01-07117	D9240	TELEPHONE HANDSET
89-01-07122	D9240	TELEPHONE HANDSET
89-01-07125	D9240	TELEPHONE HANDSET
89-01-07126	D9240	TELEPHONE HANDSET
89-01-07127	D9240	TELEPHONE HANDSET
89-01-07130	D9240	TELEPHONE HANDSET
89-01-07142	D9240	TELEPHONE HANDSET
89-01-07147	D9240	TELEPHONE HANDSET
89-01-07152	D9240	TELEPHONE HANDSET
89-01-07154	D9240	TELEPHONE HANDSET
89-01-07155	D9240	TELEPHONE HANDSET
89-01-07157	D9240	TELEPHONE HANDSET
89-01-07162	D9240	TELEPHONE HANDSET
89-01-07172	D9240	TELEPHONE HANDSET
89-01-07182	D9240	TELEPHONE HANDSET
89-01-07185	D9240	TELEPHONE HANDSET
89-01-07187	D9240	TELEPHONE HANDSET
89-01-07202	D9240	TELEPHONE HANDSET
89-01-07212	D9240	TELEPHONE HANDSET
89-01-07222	D9240	TELEPHONE HANDSET
89-01-07232	D9240	TELEPHONE HANDSET
89-01-07235	D9240	TELEPHONE HANDSET
89-01-07237	D9240	TELEPHONE HANDSET
89-01-07240	D9240	TELEPHONE HANDSET
89-01-07250	D9240	TELEPHONE HANDSET
89-01-07260	D9240	TELEPHONE HANDSET
89-01-07270	D9240	TELEPHONE HANDSET
89-01-07282	D9240	TELEPHONE HANDSET
89-01-07285	D9240	TELEPHONE HANDSET
89-01-07292	D9240	TELEPHONE HANDSET



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
89-01-07295	D9240	TELEPHONE HANDSET
89-01-07332	D9240	TELEPHONE HANDSET
89-01-07335	D9240	TELEPHONE HANDSET
89-01-07337	D9240	TELEPHONE HANDSET
89-01-07340	D9240	TELEPHONE HANDSET
89-01-07350	D9240	TELEPHONE HANDSET
89-01-07360	D9240	TELEPHONE HANDSET
89-01-07375	D9240	TELEPHONE HANDSET
89-01-07377	D9240	TELEPHONE HANDSET
89-01-07390	D9240	TELEPHONE HANDSET
89-01-07405	D9240	TELEPHONE HANDSET
89-01-07410	D9240	TELEPHONE HANDSET
89-01-07420	D9240	TELEPHONE HANDSET
89-01-07430	D9240	TELEPHONE HANDSET
89-01-07462	D9240	TELEPHONE HANDSET
89-01-07465	D9240	TELEPHONE HANDSET
89-01-27000		TELEPHONE HANDSET
89-01-27042		TELEPHONE HANDSET
89-01-27122		TELEPHONE HANDSET
89-01-27152		TELEPHONE HANDSET
89-01-27155		TELEPHONE HANDSET
89-01-27157		TELEPHONE HANDSET
89-01-27182		TELEPHONE HANDSET
89-01-27187		TELEPHONE HANDSET
89-01-27360		TELEPHONE HANDSET
8921082G1		LAVATORY WATER HEATER
8921082G2		LAVATORY WATER HEATER
8921082G5		LAVATORY WATER HEATER
8921082G6		LAVATORY WATER HEATER
893229		CONTROL UNIT
895FL		DESYNN POSITION INDICATOR
898230-1		TRIM AIR PRESSURE REGULATOR VALVE
898396-2		FLUID PRESSURE REGULATING VALVE
898396-3		FLUID PRESSURE REGULATING VALVE
898626-3		PNEUMATIC PRESSURE REGULATOR VALVE
898626-4		PNEUMATIC PRESSURE REGULATOR VALVE
899-0850-002	RMP 850	RADIO MANAGEMENT PANEL
899-0850-003	RMP 850	RADIO MANAGEMENT PANEL
899-0850-004	RMP 850	RADIO MANAGEMENT PANEL
899315		FIRE DETECTOR MODULE
899315-01		FIRE DETECTOR MODULE
899315-02		FIRE DETECTOR MODULE
899315-03		FIRE DETECTOR MODULE
899315-04		FIRE DETECTOR MODULE
899315-05		FIRE DETECTOR MODULE
899315-06		FIRE DETECTOR MODULE
899315-07		FIRE DETECTOR MODULE
899315-08		FIRE DETECTOR MODULE





**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
899315-09		FIRE DETECTOR MODULE
899FL1		DESYNN POSITION INDICATOR
8AW59FAA1	8AW59	FREQUENCY METER
8AW59FAC1	8AW59	FREQUENCY METER
8AW60F1AA1	8AW59	FREQUENCY METER
8AW60F2AA1	8AW60	FREQUENCY METER
8AW60LFA1	8AW60	FREQUENCY METER
8AW60LFD2	8AW60	FREQUENCY METER
8AW60LFE1	8AW60	FREQUENCY METER
8AW60LFZ1	8AW60	FREQUENCY METER
8AW61A1AA1	8AW61	AC AMMETER AND VOLTMETER
8AW61A1AD1	8AW61	AC LOAD METER
8AW61A1AG1	8AW61	AC AMMETER AND VOLTMETER
8AW61A1AH1	8AW61	AC LOAD METER
8AW61A1AR1	8AW61	AC AMMETER AND VOLTMETER
8AW61A1AS1	8AW61	AC AMMETER AND VOLTMETER
8AW61A2AA1	8AW61	AC AMMETER AND VOLTMETER
8AW61LAA1	8AW61	AC AMMETER AND VOLTMETER
8AW61LAA210	8AW61	AC AMMETER AND VOLTMETER
8AW61LAA211	8AW61	AC AMMETER AND VOLTMETER
8AW61LAB1	8AW61	AC AMMETER AND VOLTMETER
8AW61LAC2	8AW61	AC AMMETER AND VOLTMETER
8AW61LAD2	8AW61	AC AMMETER AND VOLTMETER
8AW61LAH1	8AW61	AC AMMETER AND VOLTMETER
8AW61LAH214	8AW61	AC AMMETER AND VOLTMETER
8AW61LAH215	8AW61	AC AMMETER AND VOLTMETER
8AW61LAH216	8AW61	AC AMMETER AND VOLTMETER
8AW61LAL3	8AW61	AC FAULT INDICATOR
8AW61LAM1	8AW61	AC AMMETER AND VOLTMETER
8AW61LAS1	8AW61	AC LOAD METER
8AW61LAT1	8AW61	AC AMMETER AND VOLTMETER
8AW61LAT213	8AW61	AC AMMETER AND VOLTMETER
8AW61LAT221	8AW61	AC AMMETER AND VOLTMETER
8AW61LAZ1	8AW61	AC AMMETER AND VOLTMETER
8AW61LBA1	8AW61	AC LOAD METER
8AW61LVA1	8AW61	AC AMMETER AND VOLTMETER
8AW61LVA218	8AW61	AC AMMETER AND VOLTMETER
8AW61LVA221	8AW61	AC AMMETER AND VOLTMETER
8AW61LVD211	8AW61	AC AMMETER AND VOLTMETER
8AW61LVD220	8AW61	AC LOAD METER, FAULT IND., VOLTMETER
8AW61LVF1	8AW61	AC VOLTMETER
8AW61LVK1	8AW61	AC AMMETER AND VOLTMETER
8AW61LVZ1	8AW61	AC AMMETER AND VOLTMETER
8AW61V1AA1	8AW61	AC VOLTMETER
8AW61V5AA1	8AW61	AC AMMETERS AND VOLTMETER
8AW61VA218	8AW61	AC VOLT METER
8D1274		GAGE PRESSURE SWITCH
8D1494		GAGE PRESSURE SWITCH



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8D1495		GAGE PRESSURE SWITCH
8D1496	S332T004-37	SWITCH, GAGE PRESSURE
8DJ100AAA1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100AAF1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100AAK1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100AAS4	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAB1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAC1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAE1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAF1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAK1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAR1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAT1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAV1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAW1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LAY1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100LBA1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WAA1	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WAA2	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WAE4	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WAG2	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WAH4	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WAM4	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WAS2	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ100WBD2	DJ-100	SERVO TEMPERATURE INDICATOR
8DJ120AAE1	DJ-120	TACHOMETER INDICATOR
8DJ120AAP1	DJ-120	TACHOMETER INDICATOR
8DJ125LWB5	8DJ125	FUEL FLOW INDICATOR
8DJ125LXD5	8DJ125	FUEL FLOW INDICATOR
8DJ125LXF5	8DJ125	FUEL FLOW INDICATOR
8DJ125LXG5	8DJ125	FUEL FLOW INDICATOR
8DJ125LXV5	8DJ125	FUEL FLOW RATE INDICATOR
8DJ125LXW5	8DJ125	FUEL FLOW RATE INDICATOR
8DJ125LXX5	8DJ125	FUEL FLOW RATE INDICATOR
8DJ125LXY5	8DJ125	FUEL FLOW RATE INDICATOR
8DJ125LYA5	8DJ125	FUEL FLOW INDICATOR
8DJ125LYB5	8DJ125	FUEL FLOW INDICATOR
8DJ125MWA4	8DJ125	FUEL FLOW INDICATOR
8DJ130GAR1	8DJ130	OIL QTY INDICATOR
8DJ130LAC1	8DJ130	OIL QTY INDICATOR
8DJ130LWA1	8DJ130	OIL QTY INDICATOR
8DJ130LWM1	8DJ130	OIL QTY INDICATOR
8DJ130LWP1	8DJ130	OIL QTY INDICATOR
8DJ130LWS1	8DJ130	OIL QTY INDICATOR
8DJ130LWT1	8DJ130	OIL QTY INDICATOR
8DJ130LWX1	8DJ130	OIL QTY INDICATOR
8DJ131AAG1	8DJ131	TOCHOMETER INDICATOR
8DJ131AAG2	8DJ131	TACHOMETER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ131AAJ1	8DJ131	TACHOMETER INDICATOR
8DJ131AAT2	8DJ131	TACHOMETER INDICATOR
8DJ131LAE1	8DJ131	TACHOMETER INDICATOR
8DJ131LAF2	8DJ131	TACHOMETER INDICATOR
8DJ131LAN1	8DJ131	TACHOMETER INDICATOR
8DJ131LAV1	8DJ131	TACHOMETER INDICATOR
8DJ131LAW1	8DJ131	TACHOMETER INDICATOR
8DJ131LAZ1	8DJ131	TACHOMETER INDICATOR
8DJ131LBA1	8DJ131	TACHOMETER INDICATOR
8DJ131LBK2	8DJ131	TACHOMETER INDICATOR
8DJ131LBT2	8DJ131	TACHOMETER INDICATOR
8DJ142GAC2	8DJ142	FLOWMETER IND.
8DJ142GAD2	8DJ142	FLOWMETER IND.
8DJ142GAH2	8DJ142	FLOWMETER IND.
8DJ142GAT2	8DJ142	FLOWMETER IND.
8DJ142GAX2	8DJ142	FLOWMETER IND.
8DJ142GBB2	8DJ142	FLOWMETER IND.
8DJ142GBC2	8DJ142	FLOWMETER IND.
8DJ142GBD2	8DJ142	FLOWMETER IND.
8DJ142GBG2	8DJ142	FLOWMETER IND.
8DJ142GBL2	8DJ142	FLOWMETER IND.
8DJ142LAA2	8DJ142	FLOWMETER IND.
8DJ142LAD2	8DJ142	FLOWMETER IND.
8DJ142LAH2	8DJ142	FLOWMETER IND.
8DJ142LAS2	8DJ142	FLOWMETER IND.
8DJ142LWA2	8DJ142	FLOWMETER IND.
8DJ142LWB2	8DJ142	FLOWMETER IND.
8DJ142LWE2	8DJ142	FLOWMETER IND.
8DJ142LWH2	8DJ142	FLOWMETER IND.
8DJ142LWM2	8DJ142	FLOWMETER IND.
8DJ142LWN2	8DJ142	FLOWMETER IND.
8DJ148CAB1	DJ-148	TACHOMETER INDICATOR
8DJ148WAC2	DJ-148	TACHOMETER INDICATOR
8DJ148WAC3	DJ-148	TACHOMETER INDICATOR
8DJ148WAD2	DJ-148	TACHOMETER INDICATOR
8DJ148WAD3	DJ-148	TACHOMETER INDICATOR
8DJ149LAA1	DJ-149	EPR INDICATOR
8DJ150LAC1	214-075-242-001	DUAL TACHOMETER INDICATOR
8DJ150LAD1		DUAL TACHOMETER INDICATOR
8DJ150LAE1	214-075-242-005	DUAL TACHOMETER INDICATOR
8DJ150WAA1		DUAL TACHOMETER INDICATOR
8DJ150WAC1		DUAL TACHOMETER INDICATOR
8DJ150WAD1		DUAL TACHOMETER INDICATOR
8DJ150WAE1		DUAL TACHOMETER INDICATOR
8DJ150WAF1		DUAL TACHOMETER INDICATOR
8DJ150WAG1		DUAL TACHOMETER INDICATOR
8DJ150WAH1		DUAL TACHOMETER INDICATOR
8DJ162LWM2	8DJ162	TACHOMETER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ162LXE2	8DJ162	TACHOMETER INDICATOR
8DJ162LXF2	8DJ162	TACHOMETER INDICATOR
8DJ162LXG2	8DJ162	TACHOMETER INDICATOR
8DJ162LXH2	8DJ162	TACHOMETER INDICATOR
8DJ162LXP2	8DJ162	TACHOMETER INDICATOR
8DJ162LXR2	8DJ162	TACHOMETER INDICATOR
8DJ162LXV2	8DJ162	TACHOMETER INDICATOR
8DJ162LYB2	8DJ162	PROP SPEED INDICATOR
8DJ162LYC2	8DJ162	TACHOMETER INDICATOR
8DJ162LYD2	8DJ162	TACHOMETER INDICATOR
8DJ162LYM2	8DJ162	TACHOMETER INDICATOR
8DJ162LYZ2	8DJ162	TACHOMETER INDICATOR
8DJ162LZB2	8DJ162	TACHOMETER INDICATOR
8DJ162LZC2	8DJ162	PROP SPEED INDICATOR
8DJ162LZD2	8DJ162	TACHOMETER INDICATOR
8DJ162LZK2	8DJ162	TACHOMETER INDICATOR
8DJ162LZL2	8DJ162	TACHOMETER INDICATOR
8DJ162LZP2	8DJ162	TACHOMETER INDICATOR
8DJ162LZR2	8DJ162	TACHOMETER INDICATOR
8DJ162LZZ2	8DJ162	PROP SPEED INDICATOR
8DJ162WAB2	8DJ162	TACHOMETER INDICATOR
8DJ162WAC2	8DJ162	TACHOMETER INDICATOR
8DJ163LWT2		GAS TEMPERATURE IND.
8DJ163LWV2		GAS TEMPERATURE IND.
8DJ163LWY2		GAS TEMPERATURE IND.
8DJ163LWY3		GAS TEMPERATURE IND.
8DJ163LWY4		GAS TEMPERATURE IND.
8DJ163LWZ2		GAS TEMPERATURE IND.
8DJ163LWZ3		GAS TEMPERATURE IND.
8DJ163LXB2		GAS TEMPERATURE IND.
8DJ163LXB3		GAS TEMPERATURE IND.
8DJ163LXB4		GAS TEMPERATURE IND.
8DJ163LXC2		GAS TEMPERATURE IND.
8DJ163LXC3		GAS TEMPERATURE IND.
8DJ163LXD2		GAS TEMPERATURE IND.
8DJ163LXD3		GAS TEMPERATURE IND.
8DJ163LXD4		GAS TEMPERATURE IND.
8DJ163LXE2		GAS TEMPERATURE IND.
8DJ163LXE3		GAS TEMPERATURE IND.
8DJ163LXE4		GAS TEMPERATURE IND.
8DJ163LXF2		GAS TEMPERATURE IND.
8DJ163LXF3		GAS TEMPERATURE IND.
8DJ163LXF4		GAS TEMPERATURE IND.
8DJ163LXG2		GAS TEMPERATURE IND.
8DJ163LXG3		GAS TEMPERATURE IND.
8DJ163LXG4		GAS TEMPERATURE IND.
8DJ163LXH4		GAS TEMPERATURE IND.
8DJ163LXK4		GAS TEMPERATURE IND.



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ163LXKM4		GAS TEMPERATURE IND.
8DJ163LXP4		GAS TEMPERATURE IND.
8DJ163LXR4		GAS TEMPERATURE IND.
8DJ163LXY4		GAS TEMPERATURE IND.
8DJ163LXZ4		GAS TEMPERATURE IND.
8DJ163LYA4		GAS TEMPERATURE IND.
8DJ163LYC4		GAS TEMPERATURE IND.
8DJ163LYD4		GAS TEMPERATURE IND.
8DJ163LYH4		GAS TEMPERATURE IND.
8DJ163LYK4		GAS TEMPERATURE IND.
8DJ163LYL4		GAS TEMPERATURE IND.
8DJ163LYM4		GAS TEMPERATURE IND.
8DJ163LYN4		GAS TEMPERATURE IND.
8DJ163LYP4		GAS TEMPERATURE IND.
8DJ163LYR4		GAS TEMPERATURE IND.
8DJ163LYS4		GAS TEMPERATURE IND.
8DJ163LYT4		GAS TEMPERATURE IND.
8DJ163LYV4		GAS TEMPERATURE IND.
8DJ163LYW4		GAS TEMPERATURE IND.
8DJ163LYX4		GAS TEMPERATURE IND.
8DJ163LYY4		GAS TEMPERATURE IND.
8DJ163LYZ4		GAS TEMPERATURE IND.
8DJ163LZB4		GAS TEMPERATURE IND.
8DJ163LZC4		EGT INDICATOR
8DJ163LZD4		EGT INDICATOR
8DJ164LWA2		FUEL FLOW INDICATOR
8DJ164LWG2		FUEL FLOW INDICATOR
8DJ164LWM2		FUEL FLOW INDICATOR
8DJ164LWN2		FUEL FLOW INDICATOR
8DJ164LWP2		FUEL FLOW INDICATOR
8DJ164LWR2		FUEL FLOW INDICATOR
8DJ164LWS2		FUEL FLOW INDICATOR
8DJ164LWT2		FUEL FLOW INDICATOR
8DJ164LWT3		FUEL FLOW INDICATOR
8DJ164LWV2		FUEL FLOW INDICATOR
8DJ164LWX2		FUEL FLOW INDICATOR
8DJ164LWX3		FUEL FLOW INDICATOR
8DJ164LXB3		FUEL FLOW INDICATOR
8DJ170LWA1	8DJ170	FUEL FLOW RATE INDICATOR
8DJ170LWG1	8DJ170	FUEL FLOW RATE INDICATOR
8DJ173LWA1	8DJ173	OIL QUANTITY INDICATOR
8DJ173LWC1	8DJ173	OIL QUANTITY INDICATOR
8DJ173LWD1	8DJ173	OIL QUANTITY INDICATOR
8DJ173LWE1	8DJ173	OIL QUANTITY INDICATOR
8DJ174LWE1	8DJ174	EPR INDICATOR
8DJ174LWG1	8DJ174	EPR INDICATOR
8DJ174LWK1	8DJ176	EPR INDICATOR
8DJ175LWL1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ175LWR1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR
8DJ175LWX1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR
8DJ175LXA1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR
8DJ175LXC2	8DJ175	ENGINE EXHAUST GAS TEMP. INDICATOR
8DJ175LXH1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR
8DJ175LXK1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR
8DJ175LXR2	8DJ175	ENGINE EXHAUST GAS TEMP. INDICATOR
8DJ175LXT1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR
8DJ175LXV1	8DJ175	TURBINE GAS TEMPERATURE INDICATOR
8DJ176LWX1	8DJ176	ENGINE SPEED INDICATOR
8DJ176LWY1	8DJ176	ENGINE SPEED INDICATOR
8DJ176LZB1	8DJ176	ENGINE SPEED INDICATOR
8DJ176LZC1	8DJ176	ENGINE SPEED INDICATOR
8DJ176LZP1	8DJ176	ENGINE SPEED INDICATOR
8DJ176LZR1	8DJ176	ENGINE SPEED INDICATOR
8DJ176LZT2	8DJ176	ENGINE FAN SPEED INDICATOR
8DJ176LZV3	8DJ176	ENGINE CORE SPEED INDICATOR
8DJ176LZY1	8DJ176	ENGINE SPEED INDICATOR
8DJ176LZZ1	8DJ176	ENGINE SPEED INDICATOR
8DJ176WAD1	8DJ176	ENGINE SPEED INDICATOR
8DJ176WAE1	8DJ176	ENGINE SPEED INDICATOR
8DJ176WAH3	8DJ176	ENGINE CORE SPEED INDICATOR
8DJ176WAK3	8DJ176	ENGINE CORE SPEED INDICATOR
8DJ176WAV1	8DJ176	ENGINE SPEED INDICATOR
8DJ176WAZ2	8DJ176	ENGINE FAN SPEED INDICATOR
8DJ176WBG1	8DJ176	ENGINE SPEED INDICATOR
8DJ176WBH1	8DJ176	ENGINE SPEED INDICATOR
8DJ176WBN1	8DJ176	ENGINE SPEED INDICATOR
8DJ176WBP1	8DJ176	ENGINE SPEED INDICATOR
8DJ179KDA1	8DJ179	EGT INDICATOR
8DJ179LAD4	8DJ179	TEMPERATURE INDICATOR
8DJ179WAD1	8DJ179	TEMPERATURE INDICATOR
8DJ179WAD4	8DJ179	TEMPERATURE INDICATOR
8DJ181LWC2	8DJ181	ENGINE TORQUE INDICATOR
8DJ181LWD2	8DJ181	ENGINE TORQUE INDICATOR
8DJ186LWF1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWG1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWH1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWK1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWL1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWM1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWN1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWS1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWT1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWW1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LWZ1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LXA1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LXB1	8DJ186	ENGINE SPEED INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ186LXC1	8DJ186	ENGINE SPEED INDICATOR
8DJ186LXD1	8DJ186	ENGINE SPEED INDICATOR
8DJ215WAT1		SPEED INDICATOR
8DJ258LWA2	8DJ258	ENGINE FAN SPEED (N1) INDICATOR
8DJ258LWB1	8DJ258	TACHOMETER INDICATOR
8DJ258LWC2	8DJ258	ENGINE FAN SPEED (N1) INDICATOR
8DJ258LWD1	8DJ258	TACHOMETER INDICATOR
8DJ258LWG2	8DJ258	ENGINE FAN SPEED (N1) INDICATOR
8DJ261WAA1	8DJ261	ENGINE FAN SPEED N1
8DJ261WAB1	8DJ261	ENGINE CORE SPEED N2
8DJ339WAG1	S231N001-13	STANDBY ENGINE IND.
8DJ49GAW1		POSITION INDICATOR
8DJ49GAW2		POSITION INDICATOR
8DJ49GAX1		POSITION INDICATOR
8DJ49GAX2		POSITION INDICATOR
8DJ49GAY1		POSITION INDICATOR
8DJ49GAY2		POSITION INDICATOR
8DJ49GBV2		POSITION INDICATOR
8DJ49GEP2		POSITION INDICATOR
8DJ49GER2		POSITION INDICATOR
8DJ49GET2		POSITION INDICATOR
8DJ49LAL2		POSITION INDICATOR
8DJ49LAM2		POSITION INDICATOR
8DJ49LAN2		POSITION INDICATOR
8DJ49LAV2		POSITION INDICATOR
8DJ64GAF1	8DJ64	FLOWMETER INDICATOR
8DJ64GAS1	8DJ64	FLOWMETER INDICATOR
8DJ64GAT1	8DJ64	FLOWMETER INDICATOR
8DJ64GAX1	8DJ64	FLOWMETER INDICATOR
8DJ64GBA1	8DJ64	FLOWMETER INDICATOR
8DJ64GBC1	8DJ64	FLOWMETER INDICATOR
8DJ64GBH1	8DJ64	FLOWMETER INDICATOR
8DJ64GBW1	8DJ64	FLOWMETER INDICATOR
8DJ67FAB1	9DJ67	TACHOMETER INDICATOR
8DJ67FAT1	8DJ67	TACHOMETER INDICATOR
8DJ81AAA1	8DJ81	TACHOMETER
8DJ81AAB1	8DJ81	TACHOMETER
8DJ81AAC1	8DJ81	TACHOMETER
8DJ81BAA1	8DJ81	TACHOMETER
8DJ81BLB4	8DJ81	TACHOMETER
8DJ81BLB4-U	8DJ81	TACHOMETER
8DJ81BLC4	8DJ81	TACHOMETER
8DJ81BLC4-U	8DJ81	TACHOMETER
8DJ81CAA1	8DJ81	TACHOMETER
8DJ81CAA2	8DJ81	TACHOMETER
8DJ81CAA2U	8DJ81	TACHOMETER
8DJ81CAA4	8DJ81	TACHOMETER
8DJ81CAB2	8DJ81	TACHOMETER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ81CAC1	8DJ81	TACHOMETER
8DJ81CAC2	8DJ81	TACHOMETER
8DJ81CAE1	8DJ81	TACHOMETER
8DJ81CAE2	8DJ81	TACHOMETER
8DJ81CAF1	8DJ81	TACHOMETER
8DJ81CAF2	8DJ81	TACHOMETER
8DJ81CAH1	8DJ81	TACHOMETER
8DJ81CAH2	8DJ81	TACHOMETER
8DJ81CAK1	8DJ81	TACHOMETER
8DJ81CAK2	8DJ81	TACHOMETER
8DJ81CAL1	8DJ81	TACHOMETER
8DJ81CAM1	8DJ81	TACHOMETER
8DJ81CAM2	8DJ81	TACHOMETER
8DJ81CAN1	8DJ81	TACHOMETER
8DJ81CAN2	8DJ81	TACHOMETER
8DJ81CAN4	8DJ81	TACHOMETER
8DJ81CAS2	8DJ81	TACHOMETER
8DJ81CAX2	8DJ81	TACHOMETER
8DJ81CAY2	8DJ81	TACHOMETER
8DJ81CAZ2	8DJ81	TACHOMETER
8DJ81CBA2	8DJ81	TACHOMETER
8DJ81CBB2	8DJ81	TACHOMETER
8DJ81CBD4	8DJ81	TACHOMETER
8DJ81CBK2	8DJ81	TACHOMETER
8DJ81CBX2	8DJ81	TACHOMETER
8DJ81CCK2	8DJ81	TACHOMETER
8DJ81CCL2	8DJ81	TACHOMETER
8DJ81CCM2	8DJ81	TACHOMETER
8DJ81CDC2	8DJ81	TACHOMETER
8DJ81CDE2	8DJ81	TACHOMETER
8DJ81CDF4	8DJ81	TACHOMETER
8DJ81CDG4	8DJ81	TACHOMETER
8DJ81CDH2	8DJ81	TACHOMETER
8DJ81CDR4	8DJ81	TACHOMETER
8DJ81CDS4	8DJ81	TACHOMETER
8DJ81CDW4	8DJ81	TACHOMETER
8DJ81CDX4	8DJ81	TACHOMETER
8DJ81CDY2	8DJ81	TACHOMETER
8DJ81CDY4	8DJ81	TACHOMETER
8DJ81CDZ4	8DJ81	TACHOMETER
8DJ81CER4	8DJ81	TACHOMETER
8DJ81CFA4	8DJ81	TACHOMETER
8DJ81FAA1	8DJ81	TACHOMETER
8DJ81FAA2	8DJ81	TACHOMETER
8DJ81LAA1	8DJ81	TACHOMETER
8DJ81LAA2	8DJ81	TACHOMETER
8DJ81LAA4	8DJ81	TACHOMETER
8DJ81LAA4-U	8DJ81	TACHOMETER





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ81LAB2	8DJ81	TACHOMETER
8DJ81LAC1	8DJ81	TACHOMETER
8DJ81LAC2	8DJ81	TACHOMETER
8DJ81LAD1	8DJ81	TACHOMETER
8DJ81LAD2	8DJ81	TACHOMETER
8DJ81LAE1	8DJ81	TACHOMETER
8DJ81LAE2	8DJ81	TACHOMETER
8DJ81LAK1	8DJ81	TACHOMETER
8DJ81LAK2	8DJ81	TACHOMETER
8DJ81LAN2	8DJ81	TACHOMETER
8DJ81LAT1	8DJ81	TACHOMETER
8DJ81LAT2	8DJ81	TACHOMETER
8DJ81LAV2	8DJ81	TACHOMETER
8DJ81LAW1	8DJ81	TACHOMETER
8DJ81LAW2	8DJ81	TACHOMETER
8DJ81LAX2	8DJ81	TACHOMETER
8DJ81LAY2	8DJ81	TACHOMETER
8DJ81LAZ2	8DJ81	TACHOMETER
8DJ81LBC2	8DJ81	TACHOMETER
8DJ81LBD2	8DJ81	TACHOMETER
8DJ81LBE2	8DJ81	TACHOMETER
8DJ81LBF2	8DJ81	TACHOMETER
8DJ81LBH2	8DJ81	TACHOMETER
8DJ81LBK2	8DJ81	TACHOMETER
8DJ81LBL2	8DJ81	TACHOMETER
8DJ81LBS2	8DJ81	TACHOMETER
8DJ81LBT2	8DJ81	TACHOMETER
8DJ81LBX2	8DJ81	TACHOMETER
8DJ81LCB2	8DJ81	TACHOMETER
8DJ81LCD2	8DJ81	TACHOMETER
8DJ81LCF2	8DJ81	TACHOMETER
8DJ81LCK2	8DJ81	TACHOMETER
8DJ81LCP4	8DJ81	TACHOMETER
8DJ81LCP4-U	8DJ81	TACHOMETER
8DJ81LCR4	8DJ81	TACHOMETER
8DJ81LCR4-U	8DJ81	TACHOMETER
8DJ81LCT4	8DJ81	TACHOMETER
8DJ81LCT4-U	8DJ81	TACHOMETER
8DJ81LSC4	8DJ81	TACHOMETER
8DJ81LSC4-U	8DJ81	TACHOMETER
8DJ81LVA4	8DJ81	TACHOMETER
8DJ81LVA4-U	8DJ81	TACHOMETER
8DJ81LVB4	8DJ81	TACHOMETER
8DJ81LVB4-U	8DJ81	TACHOMETER
8DJ81LVF4	8DJ81	TACHOMETER
8DJ81LVF4-U	8DJ81	TACHOMETER
8DJ81LVG4	8DJ81	TACHOMETER
8DJ81LVG4-U	8DJ81	TACHOMETER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ81LVL4	8DJ81	TACHOMETER
8DJ81LVL4-U	8DJ81	TACHOMETER
8DJ81LWA1	8DJ81	TACHOMETER
8DJ81LWA2	8DJ81	TACHOMETER
8DJ81LWA4	8DJ81	TACHOMETER
8DJ81LWA4-U	8DJ81	TACHOMETER
8DJ81LWB2	8DJ81	TACHOMETER
8DJ81LWC2	8DJ81	TACHOMETER
8DJ81LWC4	8DJ81	TACHOMETER
8DJ81LWC4-U	8DJ81	TACHOMETER
8DJ81LWH2	8DJ81	TACHOMETER
8DJ81LWM2	8DJ81	TACHOMETER
8DJ81LWN2	8DJ81	TACHOMETER
8DJ81LWN2U	8DJ81	TACHOMETER
8DJ81LWR2	8DJ81	TACHOMETER
8DJ81LWR4	8DJ81	TACHOMETER
8DJ81LWR4-U	8DJ81	TACHOMETER
8DJ81LWS2	8DJ81	TACHOMETER
8DJ81LWS4	8DJ81	TACHOMETER
8DJ81LWS4-U	8DJ81	TACHOMETER
8DJ81LWT2	8DJ81	TACHOMETER
8DJ81LWT4	8DJ81	TACHOMETER
8DJ81LWT4-U	8DJ81	TACHOMETER
8DJ81LWV2	8DJ81	TACHOMETER
8DJ81LWY2	8DJ81	TACHOMETER
8DJ81LWY4	8DJ81	TACHOMETER
8DJ81LWY4-U	8DJ81	TACHOMETER
8DJ81LWZ2	8DJ81	TACHOMETER
8DJ81LWZ4	8DJ81	TACHOMETER
8DJ81LWZ4-4	8DJ81	TACHOMETER
8DJ81LXC2	8DJ81	TACHOMETER
8DJ81LXD2	8DJ81	TACHOMETER
8DJ81LXE2	8DJ81	TACHOMETER
8DJ81LXF2	8DJ81	TACHOMETER
8DJ81LXF4	8DJ81	TACHOMETER
8DJ81LXF4-U	8DJ81	TACHOMETER
8DJ81LXG2	8DJ81	TACHOMETER
8DJ81LXG4	8DJ81	TACHOMETER
8DJ81LXG4-U	8DJ81	TACHOMETER
8DJ81LXH2	8DJ81	TACHOMETER
8DJ81LXH2U	8DJ81	TACHOMETER
8DJ81LXH4	8DJ81	TACHOMETER
8DJ81LXH4-U	8DJ81	TACHOMETER
8DJ81LXK2	8DJ81	TACHOMETER
8DJ81LXK4	8DJ81	TACHOMETER
8DJ81LXK4-U	8DJ81	TACHOMETER
8DJ81LXL2	8DJ81	TACHOMETER
8DJ81LXM2	8DJ81	TACHOMETER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ81LXN2	8DJ81	TACHOMETER
8DJ81LXP2	8DJ81	TACHOMETER
8DJ81LXT2	8DJ81	TACHOMETER
8DJ81LXT4	8DJ81	TACHOMETER
8DJ81LXT4-U	8DJ81	TACHOMETER
8DJ81LXV2	8DJ81	TACHOMETER
8DJ81LXW2	8DJ81	TACHOMETER
8DJ81LXY2	8DJ81	TACHOMETER
8DJ81LXZ2	8DJ81	TACHOMETER
8DJ81LYA2	8DJ81	TACHOMETER
8DJ81LYB2	8DJ81	TACHOMETER
8DJ81LYC2	8DJ81	TACHOMETER
8DJ81LYP2	8DJ81	TACHOMETER
8DJ81LYP4	8DJ81	TACHOMETER
8DJ81LYP4-U	8DJ81	TACHOMETER
8DJ81LYT2	8DJ81	TACHOMETER
8DJ81LYT4	8DJ81	TACHOMETER
8DJ81LYT4-U	8DJ81	TACHOMETER
8DJ81LYV2	8DJ81	TACHOMETER
8DJ81LYV4	8DJ81	TACHOMETER
8DJ81LYV4-U	8DJ81	TACHOMETER
8DJ81LYW2	8DJ81	TACHOMETER
8DJ81LYX2	8DJ81	TACHOMETER
8DJ81LYX4	8DJ81	TACHOMETER
8DJ81LYX4-U	8DJ81	TACHOMETER
8DJ81LYZ2	8DJ81	TACHOMETER
8DJ81LZB2	8DJ81	TACHOMETER
8DJ81LZC2	8DJ81	TACHOMETER
8DJ81LZC4	8DJ81	TACHOMETER
8DJ81LZC4-U	8DJ81	TACHOMETER
8DJ81LZE2	8DJ81	TACHOMETER
8DJ81LZE4	8DJ81	TACHOMETER
8DJ81LZE4-U	8DJ81	TACHOMETER
8DJ81LZF2	8DJ81	TACHOMETER
8DJ81LZF4	8DJ81	TACHOMETER
8DJ81LZF4-U	8DJ81	TACHOMETER
8DJ81WAG2	8DJ81	TACHOMETER
8DJ81WAG4	8DJ81	TACHOMETER
8DJ81WAG4U	8DJ81	TACHOMETER
8DJ81WAG4-U	8DJ81	TACHOMETER
8DJ81WAL4	8DJ81	TACHOMETER
8DJ81WAL4-U	8DJ81	TACHOMETER
8DJ81WAP4	8DJ81	TACHOMETER
8DJ81WAP4-U	8DJ81	TACHOMETER
8DJ81WAY4	8DJ81	TACHOMETER
8DJ81WAY4-U	8DJ81	TACHOMETER
8DJ81WBA4	8DJ81	TACHOMETER
8DJ81WBA4-U	8DJ81	TACHOMETER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ81WBB4	8DJ81	TACHOMETER
8DJ81WBB4-U	8DJ81	TACHOMETER
8DJ81WBC4	8DJ81	TACHOMETER
8DJ81WBC4-U	8DJ81	TACHOMETER
8DJ81WBD4	8DJ81	TACHOMETER
8DJ81WBD4-U	8DJ81	TACHOMETER
8DJ81WBF4	8DJ81	TACHOMETER
8DJ81WBF4-U	8DJ81	TACHOMETER
8DJ81WBG4	8DJ81	TACHOMETER
8DJ81WBG4-U	8DJ81	TACHOMETER
8DJ81WBL4	8DJ81	TACHOMETER
8DJ81WBL4-U	8DJ81	TACHOMETER
8DJ81WBM4	8DJ81	TACHOMETER
8DJ81WBM4-U	8DJ81	TACHOMETER
8DJ81WBS4	8DJ81	TACHOMETER
8DJ81WBS4-U	8DJ81	TACHOMETER
8DJ81WBT4	8DJ81	TACHOMETER
8DJ81WBT4-U	8DJ81	TACHOMETER
8DJ81WCF4	8DJ81	TACHOMETER
8DJ81WCF4-U	8DJ81	TACHOMETER
8DJ81WCG4	8DJ81	TACHOMETER
8DJ81WCG4-U	8DJ81	TACHOMETER
8DJ81WCR4	8DJ81	TACHOMETER
8DJ81WCR4-U	8DJ81	TACHOMETER
8DJ81WCS4	8DJ81	TACHOMETER
8DJ81WCS4-U	8DJ81	TACHOMETER
8DJ81WCT4	8DJ81	TACHOMETER
8DJ81WCT4-U	8DJ81	TACHOMETER
8DJ81WCW4	8DJ81	TACHOMETER
8DJ81WCW4-U	8DJ81	TACHOMETER
8DJ81WCX4	8DJ81	TACHOMETER
8DJ81WCX4-U	8DJ81	TACHOMETER
8DJ81WDA4-U	8DJ81	TACHOMETER
8DJ81WDK4	8DJ81	TACHOMETER
8DJ81WDK4-U	8DJ81	TACHOMETER
8DJ81WDL4	8DJ81	TACHOMETER
8DJ81WDL4-U	8DJ81	TACHOMETER
8DJ82BAM1	DJ-82	TACHOMETER INDICATOR
8DJ82CAA1	DJ-82	TACHOMETER INDICATOR
8DJ82CAF1	DJ-82	TACHOMETER INDICATOR
8DJ82CAX1	DJ-82	TACHOMETER INDICATOR
8DJ82CBH1	DJ-82	TACHOMETER INDICATOR
8DJ82CBK1	DJ-82	TACHOMETER INDICATOR
8DJ82FAA1	DJ-82	TACHOMETER INDICATOR
8DJ82FAH1	DJ-82	TACHOMETER INDICATOR
8DJ82LAL1	DJ-82	TACHOMETER INDICATOR
8DJ88GAC1	8DJ88	FLOWMETER INDICATOR
8DJ88GAJ3	8DJ88	FLOWMETER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ88LAB1	8DJ88	FLOWMETER INDICATOR
8DJ88LAB2	8DJ88	FLOWMETER INDICATOR
8DJ88LAB3	8DJ88	FLOWMETER INDICATOR
8DJ88LWB1	8DJ88	FLOWMETER INDICATOR
8DJ88LWC2	8DJ88	FLOWMETER INDICATOR
8DJ88LWC3	8DJ88	FLOWMETER INDICATOR
8DJ88LWD2	8DJ88	FLOWMETER INDICATOR
8DJ88LWD3	8DJ88	FLOWMETER INDICATOR
8DJ88LWE3	8DJ88	FLOWMETER INDICATOR
8DJ88LWF2	8DJ88	FLOWMETER INDICATOR
8DJ88LWF3	8DJ88	FLOWMETER INDICATOR
8DJ88LWG3	8DJ88	FLOWMETER INDICATOR
8DJ88LWH3	8DJ88	FLOWMETER INDICATOR
8DJ88LWK3	8DJ88	FLOWMETER INDICATOR
8DJ88LWM3	8DJ88	FLOWMETER INDICATOR
8DJ88LWN3	8DJ88	FLOWMETER INDICATOR
8DJ88LWS3	8DJ88	FLOWMETER INDICATOR
8DJ88LWX3	8DJ88	FLOWMETER INDICATOR
8DJ88LWY3	8DJ88	FLOWMETER INDICATOR
8DJ88LXA3	8DJ88	FLOWMETER INDICATOR
8DJ88LXC3	8DJ88	FLOWMETER INDICATOR
8DJ88LYF3	8DJ88	FLOWMETER INDICATOR
8DJ89CAA1	DJ-89	TACHOMETER INDICATOR
8DJ89CAA2	DJ-89	TACHOMETER INDICATOR
8DJ89CAB1	DJ-89	TACHOMETER INDICATOR
8DJ89CAB2	DJ-89	TACHOMETER INDICATOR
8DJ89CAF1	DJ-89	TACHOMETER INDICATOR
8DJ89CAF2	DJ-89	TACHOMETER INDICATOR
8DJ89CAH1	DJ-89	TACHOMETER INDICATOR
8DJ89CAH2	DJ-89	TACHOMETER INDICATOR
8DJ89CAK1	DJ-89	TACHOMETER INDICATOR
8DJ89CAK2	DJ-89	TACHOMETER INDICATOR
8DJ89CAL1	DJ-89	TACHOMETER INDICATOR
8DJ89CAL2	DJ-89	TACHOMETER INDICATOR
8DJ89CAM1	DJ-89	TACHOMETER INDICATOR
8DJ89CAM2	DJ-89	TACHOMETER INDICATOR
8DJ89CAN1	DJ-89	TACHOMETER INDICATOR
8DJ89CAN2	DJ-89	TACHOMETER INDICATOR
8DJ89CAS1	DJ-89	TACHOMETER INDICATOR
8DJ89CAS2	DJ-89	TACHOMETER INDICATOR
8DJ89CAT1	DJ-89	TACHOMETER INDICATOR
8DJ89CAT2	DJ-89	TACHOMETER INDICATOR
8DJ89CAV1	DJ-89	TACHOMETER INDICATOR
8DJ89CAV2	DJ-89	TACHOMETER INDICATOR
8DJ89CAW1	DJ-89	TACHOMETER INDICATOR
8DJ89CAW2	DJ-89	TACHOMETER INDICATOR
8DJ89CAX1	DJ-89	TACHOMETER INDICATOR
8DJ89CAX2	DJ-89	TACHOMETER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8DJ89CAY1	DJ-89	TACHOMETER INDICATOR
8DJ89CAY2	DJ-89	TACHOMETER INDICATOR
8DJ89CAZ2	DJ-89	TACHOMETER INDICATOR
8DJ89CBA2	DJ-89	TACHOMETER INDICATOR
8DJ91BAB1	DJ-91	POSITION INDICATOR
8DJ91BABY2	DJ-91	POSITION INDICATOR
8DJ91BAC1	DJ-91	POSITION INDICATOR
8DJ91BAD1	DJ-91	POSITION INDICATOR
8DJ91LAA1	DJ-91	POSITION INDICATOR
8DJ91LAB1	DJ-91	POSITION INDICATOR
8DJ91LAD1	DJ-91	POSITION INDICATOR
8DJ91LAE1	DJ-91	POSITION INDICATOR
8DJ91LAF1	DJ-91	POSITION INDICATOR
8DJ91LAH1	DJ-91	POSITION INDICATOR
8DJ91LAK1	DJ-91	POSITION INDICATOR
8DJ91LWB1	DJ-91	POSITION INDICATOR
8DJ91LWD1	DJ-91	POSITION INDICATOR
8DJ97GAA1	DJ-97	FUEL-MASS FLOWMETER INDICATOR
8DJ97GAC1	DJ-97	FUEL-MASS FLOWMETER INDICATOR
8DJ97LAA1	DJ-97	FUEL-MASS FLOWMETER INDICATOR
8DL-OC6A		STANDBY ENGINE INDICATOR
8DW84A1AA1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84A2AA1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LAA210	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LAA215	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LAA216	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LAC1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LAC211	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LAT1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LAY60	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LVA1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LVA218	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LVA221	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LVD211	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LVH1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84LVZ1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84V1AA1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8DW84V3AA1	DW-84	DC AMMETERS AND VOLTMETERS INDICATOR
8ES003761-00		ENERGY BOX
8ES005236-03		POWER UNIT
8ES005236-13		POWER UNIT
8ES005237-03		POWER UNIT
8ES005237-13		POWER UNIT
8ES005238-03		POWER UNIT
8ES005238-13		POWER UNIT
8ES005304-00		ENERGY BOX
8ES005309-00		ENERGY BOX
8ES403701-02		REAR NAVIGATION LIGHT TRANSFORMER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8ES403703-02		REAR NAVIGATION LIGHT TRANSFORMER
8ES403703-02A		REAR NAVIGATION LIGHT TRANSFORMER
8ES405368-00		REAR NAVIGATION LIGHT TRANSFORMER
8ES455011-00		POWER SUPPLY UNIT
8ES455011-01		POWER SUPPLY UNIT
8ES455012-00		POWER SUPPLY UNIT
8ES455012-06		POWER SUPPLY UNIT
8ES455438-07		POWER SUPPLY UNIT
8ES455440-06		POWER SUPPLY UNIT
8GR1519	290D8042-503	OVER PRESSURE INDICATOR
8KE25GAC1	KE-25	FLOWMETER AMP
8KE25GAD1	KE-25	FLOWMETER AMP
8KE25GAE1	KE-25	FLOWMETER AMP
8KE25GAF1	KE-25	FLOWMETER AMP
8KE25GAN1	KE-25	FLOWMETER AMP
8KE91AAB1		ENGINE TORQUE ELECTRONIC UNIT
8KE91AAB2		ENGINE TORQUE ELECTRONIC UNIT
8TJ39AAA2		POSITION TRANSMITTER
8TJ39AAH1		POSITION TRANSMITTER
8TJ39AAH2		POSITION TRANSMITTER
8TJ39AAT1		POSITION TRANSMITTER
8TJ39AAV2		POSITION TRANSMITTER
8TJ39ABA2		POSITION TRANSMITTER
8TJ80GAA1		POWER SUPPLY
8TJ80GAA2		POWER SUPPLY
8TJ88GAC1		POWER SUPPLY
8TJ88GAD1		POWER SUPPLY
8TJ88GAD3		POWER SUPPLY
8TJ88GAE1		POWER SUPPLY
8TJ88GAF1		POWER SUPPLY
8TJ88GAH3		POWER SUPPLY
8TJ88GAN1		POWER SUPPLY
8TJ88GAN3		POWER SUPPLY
8TJ88GAN4		POWER SUPPLY
8TJ88GAP1		POWER SUPPLY
8TJ88GAP3		POWER SUPPLY
8TJ88GAR1		POWER SUPPLY
8TJ88GAR3		POWER SUPPLY
8TJ88GAT1		POWER SUPPLY
8TJ88GAV1		POWER SUPPLY
8TJ88GAV3		POWER SUPPLY
8TJ88GBC1		POWER SUPPLY
8TJ88GBD1		POWER SUPPLY
8TJ88GBD3		POWER SUPPLY
8TJ88GBE1		POWER SUPPLY
8TJ88GBF1		POWER SUPPLY
8TJ88GBN1		POWER SUPPLY
8TJ88GBN3		POWER SUPPLY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
8TJ88GBP1		POWER SUPPLY
8TJ92GAA2		LIQUID QUANTITY TRANSMITTER
8TJ92GAD2		LIQUID QUANTITY TRANSMITTER
8TJ95GAA1		FLOWMETER POWER SUPPLY
8TJ95GAA2		FLOWMETER POWER SUPPLY
8TJ95GAA3		FLOWMETER POWER SUPPLY
8TJ95GAAY2		FLOWMETER POWER SUPPLY
8TJ95GAB1		FLOWMETER POWER SUPPLY
8TJ95GAB2		FLOWMETER POWER SUPPLY
8TJ95GAB3		FLOWMETER POWER SUPPLY
8TJ95GAC3		FLOWMETER POWER SUPPLY
8TJ95GAD3		FLOWMETER POWER SUPPLY
8TJ95GBA2		FLOWMETER POWER SUPPLY
8TJ95GBAY3		FLOWMETER POWER SUPPLY
8TJ95GBB2		FLOWMETER POWER SUPPLY
9005-42		BATTERY POWER SUPPLY
9008-3-5A		BATTERY CARTRIDGE ASSY
9008D09-1		POWER RELAY
9008D09-2		POWER RELAY
9008D09-3		POWER RELAY
9010-1-1 MOD A	S231A130-1	ELECTRONIC CLOCK
9010-1-2	S231A130-2	ELECTRONIC CLOCK
9010-1-3	S231A130-1	ELECTRONIC CLOCK
9024-15704-03		SAFETY VALVE
9024-15704-03 AMDT A		SAFETY VALVE
9024-15704-2		SAFETY VALVE
9024-15704-2 AMDT A		SAFETY VALVE
9024-15704-2 AMDT AB		SAFETY VALVE
9024-15704-2 AMDT B		SAFETY VALVE
903BD	42-903	GYROSCOPIC HORIZON
90G183		PRESSURE SWITCH
90G236	10-60552-41	GAGE PRESSURE SWITCH
90G237	10-60552-5	GAGE PRESSURE SWITCH
90G37		PRESSURE SWITCH
9-102		FUEL USED INDICATOR
9-103		FUEL USED INDICATOR
9105A0001-01		TEMPERATURE SENSOR
9105A0005-01		TEMPERATURE SENSOR
9105A0005-02		TEMPERATURE SENSOR
9106A0005-01		FLOW SENSOR
9106A0005-02		FLOW SENSOR
915F213-3		BUS PROTECTION PANEL
915F213-4		BUS PROTECTION PANEL
919FLBR		DESYNN POSITION INDICATOR
929FL		DESYNN POSITION INDICATOR
93000-05601	10-61833-1	WINDOW HEAT CONTROL
9300-A152-1	A152-1	CONTROL UNIT
937FL		DESYNN POSITION INDICATOR





**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
93A055-00	A55	MICROPHONE MODULES
93A055-03	A55-3	MICROPHONE MODULES
93A055-10	A55B	MICROPHONE MODULES
93A055-20	A55B	MICROPHONE MODULES
93A055-30	A55B	MICROPHONE MODULES
93A055-40	A55B	MICROPHONE MODULES
93A055-45	A55B	MICROPHONE MODULES
93A055-50	A55B	MICROPHONE MODULES
93A055-55	A55B	MICROPHONE MODULES
93A055-60	A55B	MICROPHONE MODULES
93A055-65	A55B	MICROPHONE MODULES
93A055-66	A55B	MICROPHONE MODULES
93A055-67	A55B	MICROPHONE MODULES
93A055-95	A55B	MICROPHONE MODULES
93A100-10	A100	COCKPIT VOICE RECORDER
93A100-11	A100	COCKPIT VOICE RECORDER
93A100-30	A100	COCKPIT VOICE RECORDER
93A100-31	A100	COCKPIT VOICE RECORDER
93A100-32	A100	COCKPIT VOICE RECORDER
93A100-33	A100	COCKPIT VOICE RECORDER
93A100-80	A100A	COCKPIT VOICE RECORDER
93A100-81	A100A	COCKPIT VOICE RECORDER
93A100-82	A100A	COCKPIT VOICE RECORDER
93A100-83	A100A	COCKPIT VOICE RECORDER
93A100-84	A100A	COCKPIT VOICE RECORDER
93A100-85	A100A	COCKPIT VOICE RECORDER
93A150-20	A150	CONTROL UNIT
93A151-00	A151	CONTROL UNIT
93A151-01	A1511	CONTROL UNIT
93A151-20	A151B	CONTROL UNIT
93A151-30	A151B	CONTROL UNIT
93A151-40	A151B	CONTROL UNIT
93A151-50	A151B	CONTROL UNIT
93A152-00	A152	CONTROL UNIT
93A152-01	A1521	CONTROL UNIT
93A152-04	A1524	CONTROL UNIT
93A152-20	A152B	CONTROL UNIT
93A152-25	A152B	CONTROL UNIT
93A152-30	A152B	CONTROL UNIT
93A152-35	A152B	CONTROL UNIT
93A152-40	A152B	CONTROL UNIT
93A152-50	A152B	CONTROL UNIT
93A152-60	A152B	CONTROL UNIT
93A152-70	A152B	CONTROL UNIT
941D335-2		CIRCUIT BREAKER
941D335-4		CIRCUIT BREAKER
941D347-2		CIRCUIT BREAKER
9-441-01		FUEL TOTALIZER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
9-464-41		FUEL FLOW INDICATOR
948958-12	GTCP660-4	TURBINE ELECTRONIC CONTROL
948958-121	GTCP660-4	TURBINE ELECTRONICS CONTROL
948958-13	GTCP660-4	TURBINE ELECTRONIC CONTROL
948958-131	GTCP660-4	TURBINE ELECTRONICS CONTROL
948958-14	GTCP660-4	TURBINE ELECTRONIC CONTROL
948958-141	GTCP660-4	TURBINE ELECTRONICS CONTROL
948958-15	GTCP660-4	TURBINE ELECTRONIC CONTROL
948958-151	GTCP660-4	TURBINE ELECTRONICS CONTROL
948958-16	GTCP660-4	TURBINE ELECTRONIC CONTROL
948958-161	GTCP660-4	TURBINE ELECTRONICS CONTROL
948958-17	GTCP660-4	TURBINE ELECTRONIC CONTROL
948958-171	GTCP660-4	TURBINE ELECTRONICS CONTROL
948958-18	GTCP660-4	TURBINE ELECTRONIC CONTROL
948958-181	GTCP660-4	TURBINE ELECTRONICS CONTROL
94P32	10-60552-42	GAGE PRESSURE SWITCH
9601-02-04		FLAP HANDLE POSITION TRANSMITTER
9601-02-06		FLAP POSITION TRANSMITTER
9601-02-08		FLAP POSITION TRANSMITTER
9601-02-10		FLAP HANDLE POSITION TRANSMITTER
9601-02-11		FLAP HANDLE POSITION TRANSMITTER
9601-02-12		FLAP POSITION TRANSMITTER
9601-02-13		FLAP POSITION TRANSMITTER
9601-02-14		FLAP POSITION TRANSMITTER
963A0000-02		TRIM AIR VALVE
963A0000-02 AMDT A		TRIM AIR VALVE
963A0000-02 AMDT B		TRIM AIR VALVE
963B0000-01		TRIM AIR VALVE
965-0412-001		AIR DATA COMPUTER
965-0412-002		AIR DATA COMPUTER
966-0021-002		FLAP POSITION AND STALL WARNING TRANSMITTER
966-0022-001		FLAP POSITION AND STALL WARNING TRANSMITTER
978710-5		2 1/2" PNEUMATIC SHUTOFF VALVE
978710-6		2 1/2 " PNUEMATIC SHUTOFF VALVE
978734-1		FAN AIR VALVE
978734-3		FAN AIR VALVE
978734-4		FAN AIR VALVE
978734-5		FAN AIR VALVE
978842-1		FAN AIR VALVE
978842-2		FAN AIR VALVE
978842-3		FAN AIR VALVE
978852-2		2 1/2" SHUTOFF BUTTERFLY VALVE
978852-3		2 1/2 " SHUTOFF BUTTERFLY VALVE
979186-1		2 1/2" BUTTERFLY SHUTOFF VALVE
979188-1		2 1/2" SHUTOFF VALVE
979188-3		2 1/2" SHUTOFF VALVE
979826-1		PNUEMATIC SHUTOFF VALVE
979826-10		PNUEMATIC SHUTOFF VALVE



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
979826-11		PNUEMATIC SHUTOFF VALVE
979826-2		PNUEMATIC SHUTOFF VALVE
979826-3		PNUEMATIC SHUTOFF VALVE
979826-4		PNUEMATIC SHUTOFF VALVE
979826-5		PNUEMATIC SHUTOFF VALVE
979826-6		PNUEMATIC SHUTOFF VALVE
979826-7		PNUEMATIC SHUTOFF VALVE
979826-8		PNUEMATIC SHUTOFF VALVE
979826-9		PNUEMATIC SHUTOFF VALVE
979990-1		1.5" TEMPERATURE CONTROL VALVE
980-6005-074	AV-557C	COCKPIT VOICE RECORDER
980-6005-075	AV-557C	COCKPIT VOICE RECORDER
980-6005-076	AV-557C	COCKPIT VOICE RECORDER
980-6005-077	AV-557C	COCKPIT VOICE RECORDER
980-6005-078	AV-557C	COCKPIT VOICE RECORDER
980-6005-079	AV-557C	COCKPIT VOICE RECORDER
980-6100-001	103610-1	MICROPHONE MONITOR
980-6100-002	103610-2	MICROPHONE MONITOR
980-6100-003	103610-3	MICROPHONE MONITOR
980-6100-004	103610-4	MICROPHONE MONITOR
980-6100-010	103610	MICROPHONE MONITOR
9807-47		HYDRAULIC OIL QTY INDICATOR
9807-47-02		HYDRAULIC OIL QTY INDICATOR
9811-10		VALVE POSITION IND.
9813-25-05		DUAL TORQUE INDICATOR
9813-25-07		DUAL TORQUE INDICATOR
9813-25-12		DUAL TORQUE INDICATOR
9813-25-13		DUAL TORQUE INDICATOR
9813-25-15		DUAL TORQUE INDICATOR
9813-25-16		DUAL TORQUE INDICATOR
9813-25-17		DUAL TORQUE INDICATOR
9813-25-18		DUAL TORQUE INDICATOR
9813-25-19		DUAL TORQUE INDICATOR
9813-25-21		DUAL TORQUE INDICATOR
986F12-1		VALVE NON RETURN
98B302B	60B00257-5	HYDRAULIC FLUID TEMP DETECTOR
98B302C	60B00257-5	HYDRAULIC FLUID TEMP DETECTOR
98B302D	60B00257-7	HYDRAULIC FLUID TEMP DETECTOR
98B304A	60B00257-6	HYDRAULIC FLUID TEMP DETECTOR
98B304B	60B00257-6	HYDRAULIC FLUID TEMP DETECTOR
98B304C	60B00257-6	HYDRAULIC FLUID TEMP DETECTOR
98B304D	60B00257-8	HYDRAULIC FLUID TEMP DETECTOR
9A 375	EHU-15A/A	TEMPERATURE INDICATOR
9A 400	MS24569-1	TEMPERATURE INDICATOR
9A 550	MS24569-1	TEMPERATURE INDICATOR
9A1100		TORQUEMETER INDICATOR
9A2100	AEU-13/A	TORQUEMETER INDICATOR
9A375	EHU-15A/A	TEMPERATURE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
9A-375	EHU-15A/A	TEMPERATURE INDICATOR
9A400	MS24569-1	TEMPERATURE INDICATOR
9A550	MS24569-1	TEMPERATURE INDICATOR
9BG408324-00		HOUSING ASSEMBLY
9BG408324-80		DIMMER UNIT
A100		COCKPIT VOICE RECORDER
A14B1805C7		CIRCUIT BREAKER
A152		CVR CONTROL UNIT
A152-2		CONTROL UNIT
A17-1		AMPLIFIER
A35-MA-10L-1		ALTIMETER PRESSURE SENSITIVE
A35-MA-10L-2		ALTIMETER PRESSURE SENSITIVE
A80-AAU-7/A		PRESSURE ALTIMETER
A80-AAU-7A/A		PRESSURE ALTIMETER
A80-AAU-7A/A-101		PRESSURE ALTIMETER
A80-AAU-7A/A-20		PRESSURE ALTIMETER
A-80-AAU-8/A		PRESSURE ALTIMETER
A-80-AAU-8A/A		PRESSURE ALTIMETER
A80-AAU-8A/A		PRESSURE ALTIMETER
AA2585801	RG-1000	RATE GYROSCOPE ASSY
AB-1162-A		SYNCHRO
ABN7660-1		AUTO BRAKE PANEL ASSEMBLY
ABN7660-501		AUTO BRAKE PANEL ASSEMBLY
AC2A	S253T409-1	SERVO MOTOR GENERATOR
AC2-A	S253T409-1	SERVO MOTOR GENERATOR
AE1502U00		UNIVERSAL BRAKE COOLING FAN
AE1502U01		UNIVERSAL BRAKE COOLING FAN
AE1502U02		UNIVERSAL BRAKE COOLING FAN
AE1502U02AMDTA		UNIVERSAL BRAKE COOLING FAN
AE1502U02AMDTB		UNIVERSAL BRAKE COOLING FAN
AEU-13/A	10018-01	UNITIZED TORQUEMETER INDICATOR
AG1010AA02		ANTI-COLLISION BEACON ASSY.
AG1010AA03		ANTI-COLLISION BEACON ASSY.
AG1012AA03		RECOGNITION CONTROL ASSEMBLY
AG113B1		LIGHT ASSEMBLY
AG113C1		LIGHT ASSEMBLY
AH2467-02	1797M32P01	VALVE, SOLENOID SIGNAL, AIR
APE5100		ELECTRONIC CLOCK
APE5100-1		ELECTRONIC CLOCK
APE962		TIME DISPLAY UNITS
APE962-01		TIME DISPLAY UNITS
AR6460M1MOD1		ROTARY ACTUATOR
AR6460M1MOD2		ROTARY ACTUATOR
AR6460M2MOD1		ROTARY ACTUATOR
AR6460M2MOD2		ROTARY ACTUATOR
AR6460M2MOD3		ROTARY ACTUATOR
AR7077M1MOD1		ROTARY ACTUATOR
AR7077M1MOD2		ROTARY ACTUATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
AR7077M1MOD3		ROTARY ACTUATOR
AR7077M2MOD1		ROTARY ACTUATOR
AR7077M2MOD2		ROTARY ACTUATOR
AR7077M2MOD3		ROTARY ACTUATOR
AR7077M2MOD4		ROTARY ACTUATOR
AR7077M2MOD5		ROTARY ACTUATOR
AR7077M2MOD6		ROTARY ACTUATOR
AR7077M2MOD7		ROTARY ACTUATOR
AR7077M2MOD8		ROTARY ACTUATOR
AR7077M3		ROTARY ACTUATOR
AR7077M3MOD1		ROTARY ACTUATOR
AW2835AB01		CABIN ALTITUDE & DIFF PRESSURE INDICATOR
AW2835AB02		CABIN ALTITUDE & DIFF PRESSURE INDICATOR
AW2835AB04		CABIN ALTITUDE & DIFF PRESSURE INDICATOR
AW2835AB05		CABIN ALTITUDE & DIFF PRESSURE INDICATOR
AW2835AB06		CABIN ALTITUDE & DIFF PRESSURE INDICATOR
AW2835AB07		CABIN ALTITUDE & DIFF PRESSURE INDICATOR
AY-201S-15-B		TRANSMITTER SYNCHRO
AY-201S-1-B		TRANSMITTER SYNCHRO
AY-201S-96-B1		TRANSMITTER SYNCHRO
AY-202S-15-B		TRANSMITTER SYNCHRO
AY-203S-2-B	3563150-0428	TORQUE RECEIVER SYNCHRO
AY-203S-2-E	3563150-0350	TORQUE RECEIVER SYNCHRO
B0063-81101		COUNTER POINTER DRUM ALTIMETER
B0063-81106		COUNTER POINTER DRUM ALTEMETER
B0063-81107		ALTIMETER
B0063-81108		ALTIMETER
B0063-81114		ALTIMETER
B0063-82109		COUNTER POINTER DRUM ALTIMETER
B0200-81104		AIRSPEED INDICATOR
B0200-81108		AIRSPEED INDICATOR
B0200-81908		AIRSPEED INDICATOR
B0202 81904		MACH AIRSPEED INDICATOR
B0202 81905		MACH AIRSPEED INDICATOR
B0243-81113		AIRSPEEDATA
B0243-81911		MACH AIRSPEED INDICATOR
B0243-81921		AIRSPEEDATA
B0243-81923		AIRSPEEDATA
B0243-81925		AIRSPEEDATA
B0245 81104		MACH AIRSPEED IND.
B0245 81108		MACH AIRSPEED IND.
B0245 81110		MACH AIRSPEED IND.
B0247-81101		MACH AIRSPEED INDICATOR
B0247-81105		MACH AIRSPEED INDICATOR
B0247-81106		MACH AIRSPEED INDICATOR
B0247-81107		MACH AIRSPEED INDICATOR
B0650-71107-1		ALTITUDE ALERTING CONTROL
B0650-71107-2		ALTITUDE ALERTING CONTROL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
B0650-71109-1		ALTITUDE ALERTING CONTROL
B0650-71110		ALTITUDE ALERTING CONTROL
B0651-71102-1		ALTITUDE ALERTING CONTROL
B0651-71104-1		ALTITUDE ALERTING CONTROL
B0651-71106-1		ALTITUDE ALERTING CONTROL
B0651-71107-1		ALTITUDE ALERTING CONTROL
B0651-71110-1		ALTITUDE ALERTING CONTROL
B0651-72104-1		ALTITUDE ALERTING CONTROL
B0652-71104-1		ALTITUDE ALERTING CONTROL
B0652-71105-1		ALTITUDE ALERTING CONTROL
B0652-71108-1		ALTITUDE ALERTING CONTROL
B0652-71111-1		ALTITUDE ALERTING CONTROL
B0652-71113-1		ALTITUDE ALERTING CONTROL
B1178-3402		TRANSMITTER ASSEMBLY
B1178-3418		TRANSMITTER ASSEMBLY
B1178-3425		TRANSMITTER ASSEMBLY
B1178-3432		TRANSMITTER ASSEMBLY
B175-12		FUEL QUANTITY TOTALIZER IND.
B175-14		FUEL QUANTITY TOTALIZER IND.
B175-6		FUEL QUANTITY TOTALIZER IND.
B175-8		FUEL QUANTITY TOTALIZER IND.
B1800-81103		SERVOED ALTITUDE INDICATOR
B1800-81108		SERVOED ALTITUDE INDICATOR
B353-19		FUEL QTY INDICATOR
B701-1		POTABLE WATER QUANTITY INDICATOR
B706-1		POTABLE WATER QUANTITY INDICATOR
B706-2		POTABLE WATER QUANTITY INDICATOR
B706-3		POTABLE WATER QUANTITY INDICATOR
B712-6R		LIQUID QTY INDICATOR
B712-6W		LIQUID QTY INDICATOR
B712-7W		LIQUID QTY INDICATOR
B712-8W		LIQUID QTY INDICATOR
BC2065AE01		CONTROL BOX
BC2065B		CONTROL BOX
BC2065C		CONTROL BOX
BC2065D		CONTROL BOX
BH187B-4A		TOTAL AIR TEMPERATURE INDICATOR
BH187B-68		TOTAL AIR TEMPERATURE INDICATOR
BO202 81904		MACH AIRSPEED INDICATOR
BO202 81905		AIR SPEED DATA
BPS7-2	S283TO14-2	BATTERY POWER SUPPLY
BPS7-3	S283TO14-3	BATTERY POWER SUPPLY
BR9279-1		EXIT IDENTIFIER, FLOODLIGHT
BR9279-2		EXIT IDENTIFIER, FLOODLIGHT
BR9279-3		EXIT IDENTIFIER, FLOODLIGHT
BR9279-4		EXIT IDENTIFIER, FLOODLIGHT
BR9279-5		EXIT IDENTIFIER, FLOODLIGHT
BR9279-6		EXIT IDENTIFIER, FLOODLIGHT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
BR9279-7		EXIT IDENTIFIER, FLOODLIGHT
C12404AA01		ATC-TCAS CONTROL UNIT
C12404AB02		ATC-TCAS CONTROL UNIT
C12404BA02		ATC-TCAS CONTROL UNIT
C12404BB03		ATC-TCAS CONTROL UNIT
C12404EA01		ATC-TCAS CONTROL UNIT
C12404EA02		ATC-TCAS CONTROL UNIT
C20105000		TACHOMETER
C20105000-1		TACHOMETER
C20105000-2		TACHOMETER
C20105100		TACHOMETER
C20105100-1		TACHOMETER
CA-DP-10-ILB		DIFFERENTIAL PRESSURE INDICATOR
CG1234AC01		MODE SELECTOR UNIT
CG1234AC02		MODE SELECTOR UNIT
CG1237BD01		MODE SELECTOR UNIT
CG1244AC01		MODE SELECTOR UNIT
CG1244AD01		MODE SELECTOR UNIT
CG1244AD11		MODE SELECTOR UNIT
CGH-15-D-1/A004		TORQUE TRANSMITTER
CN-1314/A	9000C	VERTICAL DISPLACEMENT GYROSCOPE
CN-1314B/A		DISPLACEMENT GYROSCOPE
CN-998/ASN-43	ASN-43	DIRECTIONAL GYRO
CN-998A/ASN-43	ASN-43	DIRECTIONAL GYRO
CN-998B/ASN-43	ASN-43	DIRECTIONAL GYRO
D23119750		ELECTRICAL BOX
D23119750-1		ELECTRICAL BOX
D23119751		ELECTRICAL BOX
D23119760		ELECTRICAL BOX
D23119760-1		ELECTRICAL BOX
D23119761		ELECTRICAL BOX
D23119770		ELECTRICAL BOX
D23119770-1		ELECTRICAL BOX
D23119771		ELECTRICAL BOX
D434-56-001	10-62058-5	AUTOFLIGHT STATUS ANNUNCIATOR
DJG855A1		STATIC AIR TEMP INDICATOR/ TRUE AIRSPEED
DR-18E-1		RELAY
DR-18E-5		RELAY
DSN1967-3		ENGINE GAS GENERATOR RPM INDICATOR
DST-16		TEMPERATURE INDICATOR
DST-29-1		TEMPERATURE INDICATOR
DST-29-2		TEMPERATURE INDICATOR
DST-29-3		TEMPERATURE INDICATOR
DST-49		TEMPERATURE INDICATOR
DV3454A00		FAN SPEED CONTROLLER
DYLZ 3990		DUAL VALVE AND ACTUATOR ASSEMBLY
DYLZ 3990-1		DUAL VALVE AND ACTUATOR ASSEMBLY
DYLZ 3990-2		DUAL VALVE AND ACTUATOR ASSEMBLY



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
DYLZ 3990A		DUAL VALVE AND ACTUATOR ASSEMBLY
DYLZ 3991		DUAL VALVE AND ACTUATOR ASSEMBLY
DYLZ 3991-1		DUAL VALVE AND ACTUATOR ASSEMBLY
DYLZ 3991-2		DUAL VALVE AND ACTUATOR ASSEMBLY
DYLZ 3991-3		DUAL BUTTERFLY VALVE AND ACTUATOR ASSY
DYLZ 3991A		DUAL VALVE AND ACTUATOR ASSEMBLY
E21328002		ALTERNATE BRAKING CONTROL UNIT
E31832		TIME BASE, MAINTENANCE
E31832-P1		TIME BASE, ELECTRONIC MANUAL
EA100ANH-134H		HYDRAULIC OIL QUANTITY INDICATOR
EA100ANH-141H		HYDRAULIC OIL QUANTITY INDICATOR
EA100ANH-153H		HYDRAULIC OIL QUANTITY INDICATOR
EA100ANH-153H-1		HYDRAULIC OIL QUANTITY INDICATOR
EA102ANH-149H		HYDRAULIC OIL QUANTITY INDICATOR
EA401-6		LIQUID QUANTITY INDICATOR ASSEMBLY
EA401-7		LIQUID QUANTITY INDICATOR ASSEMBLY
EA401-8		LIQUID QUANTITY INDICATOR ASSEMBLY
EA401-8W		LIQUID QUANTITY INDICATOR ASSEMBLY
EA818-3406		TRANSMITTER ASSEMBLY
ED747201-1	EPRT100-1	ENGINE PRESSURE RATIO TRANSMITTER
ED747201-2	EPRT100-1	ENGINE PRESSURE RATIO TRANSMITTER
ED747202-1	EPRT100-1	ENGINE PRESSURE RATIO TRANSMITTER
ED747202-2	EPRT100-1	ENGINE PRESSURE RATIO TRANSMITTER
EHU-15A/A	9A 375	TEMPERATURE INDICATOR
EVT174-2E1		BRAKE COOLING FAN
EVT174-2E2		BRAKE COOLING FAN
EVT174-2E3		BRAKE COOLING FAN
EVT174-2E3 Amdt A		BRAKE COOLING FAN
EVT174-2E3 Amdt B		BRAKE COOLING FAN
EVT174-2E3 Amdt C		BRAKE COOLING FAN
EVT174-2E31		BRAKE COOLING FAN
EVT174-2E31 Amdt A		BRAKE COOLING FAN
EVT174-2E31 Amdt B		BRAKE COOLING FAN
EVT174-2E31 Amdt C		BRAKE COOLING FAN
EVT174-2E4		BRAKE COOLING FAN
EVT174-2E4 Amdt A		BRAKE COOLING FAN
EVT174-2E4 Amdt B		BRAKE COOLING FAN
EVT174-2E4 Amdt C		BRAKE COOLING FAN
EVT174-2E41		BRAKE COOLING FAN
EVT174-2E41 Amdt A		BRAKE COOLING FAN
EVT174-2E41 Amdt B		BRAKE COOLING FAN
EVT174-2E41 Amdt C		BRAKE COOLING FAN
EVT174-2E5		BRAKE COOLING FAN
EVT174-2E5 Amdt A		BRAKE COOLING FAN
EVT174-2E5 Amdt B		BRAKE COOLING FAN
EVT174-2E5 Amdt C		BRAKE COOLING FAN
EVT174-2E51		BRAKE COOLING FAN
EVT174-2E51 Amdt A		BRAKE COOLING FAN





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
EVT174-2E51 Amdt B		BRAKE COOLING FAN
EVT174-2E51 Amdt C		BRAKE COOLING FAN
EVT174-2E6		BRAKE COOLING FAN
EVT174-2E6 Amdt A		BRAKE COOLING FAN
EVT174-2E6 Amdt B		BRAKE COOLING FAN
EVT174-2E6 Amdt C		BRAKE COOLING FAN
EVT174-2E7		BRAKE COOLING FAN
EVT174-2E7 Amdt A		BRAKE COOLING FAN
EVT174-2E7 Amdt B		BRAKE COOLING FAN
EVT174-2E7 Amdt C		BRAKE COOLING FAN
EVT174-2E8		BRAKE COOLING FAN
EVT174-2E8 Amdt A		BRAKE COOLING FAN
EVT174-2E8 Amdt ABC		BRAKE COOLING FAN
EVT174-2E8 Amdt B		BRAKE COOLING FAN
EVT174-2E8 Amdt C		BRAKE COOLING FAN
EVT174-2E9		BRAKE COOLING FAN
EVT3454G		AVIONICS FAN
EVT3454H		AVIONICS FAN
EVT3454HC		AVIONICS FAN
EVT3454J		AVIONICS COOLING FAN
EVT3454J01		AVIONICS FAN
F1000240-01		LED LAVATORY CALL LIGHTS
F1000240-07		LED LAVATORY CALL LIGHTS
F1000240-15		LED LAVATORY CALL LIGHTS
F1000240-19		LED LAVATORY CALL LIGHTS
F1000240-21		LED LAVATORY CALL LIGHTS
F1000240-25		LED LAVATORY CALL LIGHTS
F1000250-01		LED AREA CALL PANEL
F1000250-05		LED AREA CALL PANEL
F1000270-00		LED LAVATORY LIGHT
F1000290-1		LED CABIN EMERGENCY LIGHT
F1000290-11		LED CABIN EMERGENCY LIGHT
F1000290-13		LED CABIN EMERGENCY LIGHT
F1000290-15		LED CABIN EMERGENCY LIGHT
F1000290-17		LED CABIN EMERGENCY LIGHT
F1000290-19		LED CABIN EMERGENCY LIGHT
F1000290-2		LED CABIN EMERGENCY LIGHT
F1000290-21		LED CABIN EMERGENCY LIGHT
F1000290-23		LED CABIN EMERGENCY LIGHT
F1000290-25		LED CABIN EMERGENCY LIGHT
F1000290-27		LED CABIN EMERGENCY LIGHT
F1000290-29		LED CABIN EMERGENCY LIGHT
F1000290-3		LED CABIN EMERGENCY LIGHT
F1000290-31		LED CABIN EMERGENCY LIGHT
F1000290-33		LED CABIN EMERGENCY LIGHT
F1000290-35		LED CABIN EMERGENCY LIGHT
F1000290-37		LED CABIN EMERGENCY LIGHT
F1000290-39		LED CABIN EMERGENCY LIGHT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
F1000290-4		LED CABIN EMERGENCY LIGHT
F1000290-41		LED CABIN EMERGENCY LIGHT
F1000290-43		LED CABIN EMERGENCY LIGHT
F1000290-45		LED CABIN EMERGENCY LIGHT
F1000290-47		LED CABIN EMERGENCY LIGHT
F1000290-49		LED CABIN EMERGENCY LIGHT
F1000290-5		LED CABIN EMERGENCY LIGHT
F1000290-7		LED CABIN EMERGENCY LIGHT
F1000290-9		LED CABIN EMERGENCY LIGHT
F1000955-01		LIGHT, SERVICE AREA
F1000956-00		LIGHT, SERVICE AREA
F1000956-10		LIGHT, SERVICE AREA
F1001019-00		RETURN TO SEAT SIGN
F1001940-00		LED LANDING AREA LIGHT
F1101316-01		LAVATORY LIGHT
F1101316-02		LAVATORY LIGHT
F1101316-02A		LAVATORY LIGHT
F212-1		FLAP POSITION INDICATOR
FL268FL		DESYNN POSITION INDICATOR
G5400-1		LANDING LIGHT
G5400-15		LANDING LIGHT
G5400-16		LANDING LIGHT
G5400-17		LANDING LIGHT
G5400-18		LANDING LIGHT
G5400-2		LANDING LIGHT
G5400-3		LANDING LIGHT
G5400-4		LANDING LIGHT
G5400-5		LANDING LIGHT
G5400-6		LANDING LIGHT
G6201		HF COMM CONTROL PANEL
G6773		VHF NAV/DME CONTROL PANEL
G6773-02		VHF NAV/DME CONTROL PANEL
G6773-03		VHF NAV/DME CONTROL PANEL
G6773-04		VHF NAV/DME CONTROL PANEL
G-6965-22		AIRCRAFT ROTATING WARNING NAVIGATIONAL LIGHT
G-6965-34		AIRCRAFT ROTATING WARNING NAVIGATIONAL LIGHT
G-6965-6		AIRCRAFT ROTATING WARNING NAVIGATIONAL LIGHT
G-6965-8		AIRCRAFT ROTATING WARNING NAVIGATIONAL LIGHT
G6981-01		AUDIO CONTROL PANEL
G6981-02		AUDIO CONTROL PANEL
G6981-03		AUDIO CONTROL PANEL
G6981-04		AUDIO CONTROL PANEL
G6990-01		MODE-S ATC/TCAS CONTROL PANEL
G6990-02		MODE-S ATC/TCAS CONTROL PANEL
G6990-05		MODE-S ATC/TCAS CONTROL PANEL
G6990-06		MODE-S ATC/TCAS CONTROL PANEL
G6990-07		MODE-S ATC/TCAS CONTROL PANEL
G6990-08		MODE-S ATC/TCAS CONTROL PANEL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
G6990-09		MODE-S ATC/TCAS CONTROL PANEL
G6990-12		MODE-S ATC/TCAS CONTROL PANEL
G6990-13		MODE-S ATC/TCAS CONTROL PANEL
G6990-15		MODE-S ATC/TCAS CONTROL PANEL
G6990-17		MODE-S ATC/TCAS CONTROL PANEL
G6990-19		MODE-S ATC/TCAS CONTROL PANEL
G6990-20		MODE-S ATC/TCAS CONTROL PANEL
G6990-21		MODE-S ATC/TCAS CONTROL PANEL
G6990-22		MODE-S ATC/TCAS CONTROL PANEL
G6990-24		MODE-S ATC/TCAS CONTROL PANEL
G6990-25		MODE-S ATC/TCAS CONTROL PANEL
G6990-26		MODE-S ATC/TCAS CONTROL PANEL
G6990-27		MODE-S ATC/TCAS CONTROL PANEL
G6990-28		MODE-S ATC/TCAS CONTROL PANEL
G6990-32		ATC/TCAS
G6990-33		MODE-S ATC/TCAS CONTROL PANEL
G6990-34		MODE-S ATC/TCAS CONTROL PANEL
G6990-35		MODE-S ATC/TCAS CONTROL PANEL
G6990-40		ATC/TCAS
G6990-53		PANEL
G6992-02		ATC/TCAS CONTROL PANEL
G6992-08		ATC/TCAS
G6992-12		PANEL
G6992-40		ATC/TCAS
G6992-42		PANEL
G7400-03		PANEL
G7400-12		VHF COMMUNICATION CONTROL PANEL
G7400-17		PANEL
G7400-27		PANEL
G7400-29		PANEL
G7400-30		VHF COMM
G7400-31		VHF COMMUNICATION CONTROL PANEL
G7401-03		HF COMM
G7401-06		HF COMM
G7402-01		ADF
G7402-04		ADF
G7402-05		ADF
G7403-01		ADF
G7404-121		RADIO TUNING
G7404-123		RADIO TUNING PANEL
G7404-124		RADIO TUNING PANEL
G7404-128		RADIO TUNING
G7404-21		RADIO TUNING
G7404-24		RADIO TUNING PANEL
G7404-28		RADIO TUNING
G7406-04		VHF COMM
G7406-12		VHF COMMUNICATION CONTROL PANEL
G7406-204		VHF COMM



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
G7422-22		VHF COMMUNICATION CONTROL PANEL
G7500-03		VHF NAV
G7501-01		MULTI MODE RECEIVER
G9140-2		RETRACTABLE LANDING LIGHT
G9140-3		RETRACTABLE LANDING LIGHT
G9140-4		RETRACTABLE LANDING LIGHT
G9140-5	10-3294-4	RETRACTABLE LANDING LIGHT
G9140-6		RETRACTABLE LANDING LIGHT
G9140-7		RETRACTABLE LANDING LIGHT
G9140-8		RETRACTABLE LANDING LIGHT
G9325A1		NAVIGATIONAL LIGHT
G9325A2		NAVIGATIONAL LIGHT
G9325A3		NAVIGATIONAL LIGHT
G9325A4		NAVIGATIONAL LIGHT
G9325A5		NAVIGATIONAL LIGHT
G9325A6		NAVIGATIONAL LIGHT
GG53A-1		DISPLACEMENT GYROSCOPE
GM7148-1	S315N401-1	DUAL LINEAR TRANSDUCER ASSEMBLY
GM7184-2	S315N401-2	DUAL LINEAR TRANSDUCER ASSEMBLY
GM7184-3	S315N401-3	DUAL LINEAR TRANSDUCER ASSEMBLY
GM7184-4	S315N401-4	DUAL LINEAR TRANSDUCER ASSEMBLY
GM7184-5	S315N401-5	DUAL LINEAR TRANSDUCER ASSEMBLY
GM7184-6	S315N401-6	DUAL LINEAR TRANSDUCER ASSEMBLY
GMT4200		ELECTRONIC CLOCK
H138JFM		GYROSCOPIC HORIZON
H150AKM1	S231T110-6	STANDBY ATTITUDE
H301ABM1		HORIZON GYRO
H301AFM		HORIZON GYRO
H301AGM1		HORIZON GYRO
H301AJM1		HORIZON GYRO
H301AKM1		HORIZON GYRO
H301APM1		HORIZON GYRO
H301ATM		HORIZON GYRO
H301AZM1		HORIZON GYRO
H301BAM		HORIZON GYRO
H301BCM1		HORIZON GYRO
H301BDM1		HORIZON GYRO
H321AAM1		HORIZON GYRO
H321ABM1		HORIZON GYRO
H321ACM1		HORIZON GYRO
H321AFM1		HORIZON GYRO
H321AGM1		HORIZON GYRO
H321AKM1		HORIZON GYRO
H321ALM1		HORIZON GYRO
H321AMM1		HORIZON GYRO
H321ANM1		HORIZON GYRO
H321AQM1		HORIZON GYRO
H321ASM1		HORIZON GYRO



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
H321AYM1		HORIZON GYRO
H321AZM1		HORIZON GYRO
H321BAM1		HORIZON GYRO
H321BDM1		HORIZON GYRO
H321BEM2		HORIZON GYRO
H321BFM2		HORIZON GYRO
H321BGM1		HORIZON GYRO
H321BHM1		HORIZON GYRO
H321BKM		HORIZON GYRO
H321BNM		HORIZON GYRO
H321BTM		HORIZON GYRO
H321BVM1		HORIZON GYRO
H321BW1		HORIZON GYRO
H321CBM		HORIZON GYRO
H321CCM		HORIZON GYRO
H321CEM		HORIZON GYRO
H321CJM		HORIZON GYRO
H321CMM		HORIZON GYRO
H321CZM		HORIZON GYRO
H321DAM		HORIZON GYRO
H321DBM		HORIZON GYRO
H321EEM		HORIZON GYRO
H341ANM		HORIZON GYRO
H341ANM1		HORIZON GYRO
H505B	S250N104-4	TRANSMITTER, CONTROL SURFACE POSITION
H509B	S250N104-6	CONTROL SURFACE POSITION TRANSMITTER
HC3100-20-01		SUPPORT BRACKET
HC3100-20-02		SUPPORT BRACKET
HC3100-20-03		SUPPORT BRACKET
HC3100-21-10		SUPPORT BRACKET
HC3100-22-10		SUPPORT BRACKET
HC3100-23-10		SUPPORT BRACKET
HC3100-25-10		SUPPORT BRACKET
HC3100-33-10		SUPPORT BRACKET
HG180A1		AIR DATA COMPUTER
HG180B1		AIR DATA COMPUTER
HG180B2		AIR DATA COMPUTER
HG180B3		AIR DATA COMPUTER
HG180R19		AIR DATA COMPUTER
HG180R20		AIR DATA COMPUTER
HG180R22		AIR DATA COMPUTER
HG180R23		AIR DATA COMPUTER
HG180R24		AIR DATA COMPUTER
HG180U1		AIR DATA COMPUTER
HG180U201		AIR DATA COMPUTER
HG180U202		AIR DATA COMPUTER
HG180U203		AIR DATA COMPUTER
HG180U204		AIR DATA COMPUTER



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
HG180U205		AIR DATA COMPUTER
HG180U206		AIR DATA COMPUTER
HG180U207		AIR DATA COMPUTER
HG180U208		AIR DATA COMPUTER
HG180U209		AIR DATA COMPUTER
HG180U210		AIR DATA COMPUTER
HG180U211		AIR DATA COMPUTER
HG180U212		AIR DATA COMPUTER
HG180U213		AIR DATA COMPUTER
HG180U215		AIR DATA COMPUTER
HG180U216		AIR DATA COMPUTER
HG180U217		AIR DATA COMPUTER
HG180U218		AIR DATA COMPUTER
HG180U219		AIR DATA COMPUTER
HG180U220		AIR DATA COMPUTER
HG180U221		AIR DATA COMPUTER
HG180U222		AIR DATA COMPUTER
HG180U223		AIR DATA COMPUTER
HG180U224		AIR DATA COMPUTER
HG180U227		AIR DATA COMPUTER
HG180U228		AIR DATA COMPUTER
HG180U229		AIR DATA COMPUTER
HG180U230		AIR DATA COMPUTER
HG180U231		AIR DATA COMPUTER
HG180U232		AIR DATA COMPUTER
HG180U233		AIR DATA COMPUTER
HG180U234		AIR DATA COMPUTER
HG180U235		AIR DATA COMPUTER
HG180U236		AIR DATA COMPUTER
HG180U237		AIR DATA COMPUTER
HG180U238		AIR DATA COMPUTER
HG180U239		AIR DATA COMPUTER
HG180U241		AIR DATA COMPUTER
HG180U243		AIR DATA COMPUTER
HG180U244		AIR DATA COMPUTER
HG180U245		AIR DATA COMPUTER
HG180U246		AIR DATA COMPUTER
HG180U247		AIR DATA COMPUTER
HG180U248		AIR DATA COMPUTER
HG180U249		AIR DATA COMPUTER
HG180U250		AIR DATA COMPUTER
HG180U251		AIR DATA COMPUTER
HG180U252		AIR DATA COMPUTER
HG180U253		AIR DATA COMPUTER
HG180U255		AIR DATA COMPUTER
HG180U256		AIR DATA COMPUTER
HG180U258		AIR DATA COMPUTER
HG180U259		AIR DATA COMPUTER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
HG180U260		AIR DATA COMPUTER
HG180U261		AIR DATA COMPUTER
HG180U262		AIR DATA COMPUTER
HG180U263		AIR DATA COMPUTER
HG180U264		AIR DATA COMPUTER
HG180U265		AIR DATA COMPUTER
HG180U266		AIR DATA COMPUTER
HG180U267		AIR DATA COMPUTER
HG180U268		AIR DATA COMPUTER
HG180U269		AIR DATA COMPUTER
HG180U270		AIR DATA COMPUTER
HG180U271		AIR DATA COMPUTER
HG180U272		AIR DATA COMPUTER
HG180U273		AIR DATA COMPUTER
HG180U274		AIR DATA COMPUTER
HG180U275		AIR DATA COMPUTER
HG180U276		AIR DATA COMPUTER
HG180U277		AIR DATA COMPUTER
HG180U278		AIR DATA COMPUTER
HG180U279		AIR DATA COMPUTER
HG180U280		AIR DATA COMPUTER
HG180U281		AIR DATA COMPUTER
HG180U282		AIR DATA COMPUTER
HG180U283		AIR DATA COMPUTER
HG180U284		AIR DATA COMPUTER
HG180U285		AIR DATA COMPUTER
HG180U286		AIR DATA COMPUTER
HG180U288		AIR DATA COMPUTER
HG180U289		AIR DATA COMPUTER
HG180U290		AIR DATA COMPUTER
HG180U291		AIR DATA COMPUTER
HG180U292		AIR DATA COMPUTER
HG180U293		AIR DATA COMPUTER
HG180U294		AIR DATA COMPUTER
HG180U295		AIR DATA COMPUTER
HG180U299		AIR DATA COMPUTER
HG180U303		AIR DATA COMPUTER
HG180U304		AIR DATA COMPUTER
HG180U309		AIR DATA COMPUTER
HG180U312		AIR DATA COMPUTER
HG180U313		AIR DATA COMPUTER
HG180U314		AIR DATA COMPUTER
HG180U315		AIR DATA COMPUTER
HG180U316		AIR DATA COMPUTER
HG180U317		AIR DATA COMPUTER
HG180U318		AIR DATA COMPUTER
HG180U319		AIR DATA COMPUTER
HG180U320		AIR DATA COMPUTER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
HG180U323		AIR DATA COMPUTER
HG180U326		AIR DATA COMPUTER
HG180U344		AIR DATA COMPUTER
HG180U345		AIR DATA COMPUTER
HG180U346		AIR DATA COMPUTER
HG180U403		AIR DATA COMPUTER
HG180U404		AIR DATA COMPUTER
HG180U51		AIR DATA COMPUTER
HG180U52		AIR DATA COMPUTER
HG180U53		AIR DATA COMPUTER
HG180U54		AIR DATA COMPUTER
HG180U55		AIR DATA COMPUTER
HG180U56		AIR DATA COMPUTER
HG180U57		AIR DATA COMPUTER
HG180U58		AIR DATA COMPUTER
HG180U59		AIR DATA COMPUTER
HG180U60		AIR DATA COMPUTER
HG180U61		AIR DATA COMPUTER
HG180U62		AIR DATA COMPUTER
HG180U63		AIR DATA COMPUTER
HG180U64		AIR DATA COMPUTER
HG180U65		AIR DATA COMPUTER
HG180U66		AIR DATA COMPUTER
HG180U67		AIR DATA COMPUTER
HG180U68		AIR DATA COMPUTER
HG180U69		AIR DATA COMPUTER
HG180U70		AIR DATA COMPUTER
HG180U701		AIR DATA COMPUTER
HG180U702		AIR DATA COMPUTER
HG180U703		AIR DATA COMPUTER
HG180U704		AIR DATA COMPUTER
HG180U705		AIR DATA COMPUTER
HG180U706		AIR DATA COMPUTER
HG180U707		AIR DATA COMPUTER
HG180U708		AIR DATA COMPUTER
HG180U709		AIR DATA COMPUTER
HG180U71		AIR DATA COMPUTER
HG180U710		AIR DATA COMPUTER
HG180U711		AIR DATA COMPUTER
HG180U712		AIR DATA COMPUTER
HG180U713		AIR DATA COMPUTER
HG180U714		AIR DATA COMPUTER
HG180U715		AIR DATA COMPUTER
HG180U716		AIR DATA COMPUTER
HG180U717		AIR DATA COMPUTER
HG180U718		AIR DATA COMPUTER
HG180U719		AIR DATA COMPUTER
HG180U720		AIR DATA COMPUTER





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
HG180U721		AIR DATA COMPUTER
HG180U722		AIR DATA COMPUTER
HG180U723		AIR DATA COMPUTER
HG180U724		AIR DATA COMPUTER
HG180U725		AIR DATA COMPUTER
HG180U726		AIR DATA COMPUTER
HG180U727		AIR DATA COMPUTER
HG180U729		AIR DATA COMPUTER
HG180U73		AIR DATA COMPUTER
HG180U732		AIR DATA COMPUTER
HG180U733		AIR DATA COMPUTER
HG180U737		AIR DATA COMPUTER
HG180U738		AIR DATA COMPUTER
HG180U739		AIR DATA COMPUTER
HG180U74		AIR DATA COMPUTER
HG180U742		AIR DATA COMPUTER
HG180U746		AIR DATA COMPUTER
HG180U747		AIR DATA COMPUTER
HG180U749		AIR DATA COMPUTER
HG180U75		AIR DATA COMPUTER
HG180U750		AIR DATA COMPUTER
HG180U751		AIR DATA COMPUTER
HG180U754		AIR DATA COMPUTER
HG180U756		AIR DATA COMPUTER
HG180U757		AIR DATA COMPUTER
HG180U759		AIR DATA COMPUTER
HG180U76		AIR DATA COMPUTER
HG180U77		AIR DATA COMPUTER
HG180U79		AIR DATA COMPUTER
HG180U80		AIR DATA COMPUTER
HG180U800		AIR DATA COMPUTER
HG180U801		AIR DATA COMPUTER
HG180U802		AIR DATA COMPUTER
HG180U803		AIR DATA COMPUTER
HG180U804		AIR DATA COMPUTER
HG180U805		AIR DATA COMPUTER
HG180U806		AIR DATA COMPUTER
HG180U807		AIR DATA COMPUTER
HG180U808		AIR DATA COMPUTER
HG180U809		AIR DATA COMPUTER
HG180U81		AIR DATA COMPUTER
HG180U810		AIR DATA COMPUTER
HG180U811		AIR DATA COMPUTER
HG180U812		AIR DATA COMPUTER
HG180U813		AIR DATA COMPUTER
HG180U814		AIR DATA COMPUTER
HG180U815		AIR DATA COMPUTER
HG180U816		AIR DATA COMPUTER



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
HG180U817		AIR DATA COMPUTER
HG180U82		AIR DATA COMPUTER
HG180U83		AIR DATA COMPUTER
HG180U84		AIR DATA COMPUTER
HG180U85		AIR DATA COMPUTER
HG180U850		AIR DATA COMPUTER
HG180U851		AIR DATA COMPUTER
HG180U86		AIR DATA COMPUTER
HG180U87		AIR DATA COMPUTER
HG180U88		AIR DATA COMPUTER
HG180U89		AIR DATA COMPUTER
HG180U90		AIR DATA COMPUTER
HG180U91		AIR DATA COMPUTER
HG180U92		AIR DATA COMPUTER
HG180U93		AIR DATA COMPUTER
HG180U94		AIR DATA COMPUTER
HG180U95		AIR DATA COMPUTER
HG180U96		AIR DATA COMPUTER
HG180U97		AIR DATA COMPUTER
HG180U98		AIR DATA COMPUTER
HG180U99		AIR DATA COMPUTER
HG180V1		AIR DATA COMPUTER
HG180V2		AIR DATA COMPUTER
HG180V3		AIR DATA COMPUTER
HG180V5		AIR DATA COMPUTER
HG180V8		AIR DATA COMPUTER
HG18OR11		AIR DATA COMPUTER
HG18OR12		AIR DATA COMPUTER
HG280D1		DIGITAL AIR DATA COMPUTER
HG280D2		DIGITAL AIR DATA COMPUTER
HG280D4		DIGITAL AIR DATA COMPUTER
HG280D5		DIGITAL AIR DATA COMPUTER
HG280D80		DIGITAL AIR DATA COMPUTER
HG480B1		DIGITAL AIR DATA COMPUTER
HG480B100		DIGITAL AIR DATA COMPUTER
HG480B13		DIGITAL AIR DATA COMPUTER
HG480B14		DIGITAL AIR DATA COMPUTER
HG480B2		DIGITAL AIR DATA COMPUTER
HG480B20		DIGITAL AIR DATA COMPUTER
HG480B3		DIGITAL AIR DATA COMPUTER
HG480B30		DIGITAL AIR DATA COMPUTER
HG480B40		DIGITAL AIR DATA COMPUTER
HG480B41		DIGITAL AIR DATA COMPUTER
HG480B42		DIGITAL AIR DATA COMPUTER
HG480B43		DIGITAL AIR DATA COMPUTER
HG480B5		DIGITAL AIR DATA COMPUTER
HG480B50		DIGITAL AIR DATA COMPUTER
HG480B60		DIGITAL AIR DATA COMPUTER



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
HG480C1		DIGITAL AIR DATA COMPUTER
HG480C2		DIGITAL AIR DATA COMPUTER
HG480E1	4061100-901	DIGITAL AIR DATA COMPUTER
HMEC 25-CAP	025-230-325	BOOMSET
HMEC 25-KAP	025-230-315	BOOMSET
HMEC 25-KAP-1	025-230-316	BOOMSET
J5BM1		RATE GYRO ASSY
J5BM2		RATE GYRO ASSY
JG1052AA01		ALTITUDE ALERT INDICATOR
JG1052AA02		ALTITUDE ALERT INDICATOR
JG1052AA03		ALTITUDE ALERT INDICATOR
JG1052AA04		ALTITUDE ALERT INDICATOR
JG1052AA05		ALTITUDE ALERT INDICATOR
JG1052AA06		ALTITUDE ALERT INDICATOR
JG1052AA07		ALTITUDE ALERT INDICATOR
JG1052AA08		ALTITUDE ALERT INDICATOR
JG1052AB01		ALTITUDE ALERT INDICATOR
JG1052AB02		ALTITUDE ALERT INDICATOR
JG1052AB03		ALTITUDE ALERT INDICATOR
JG1052AB04		ALTITUDE ALERT INDICATOR
JG1052AC01		ALTITUDE ALERT INDICATOR
JG1052AC02		ALTITUDE ALERT INDICATOR
JG1052AC03		ALTITUDE ALERT INDICATOR
JG1052AC04		ALTITUDE ALERT INDICATOR
JG1052AC09		ALTITUDE ALERT INDICATOR
JG1052AK01		ALTITUDE ALERT INDICATOR
JG1052AP01		ALTITUDE ALERT INDICATOR
JG1052BC01		ALTITUDE ALERT INDICATOR
JG1052BD01		ALTITUDE ALERT INDICATOR
JG1072AC10		REMOTE INDICATOR
JG1072AC13		REMOTE INDICATOR
JG116B4		TEMPERATURE INDICATOR
JG116B6		TEMPERATURE INDICATOR
JG116B7		TEMPERATURE INDICATOR
JG130A100		FUEL QUANTITY INDICATOR
JG130A62		FUEL QUANTITY INDICATOR
JG130A68		FUEL QUANTITY INDICATOR
JG130A76		FUEL QUANTITY INDICATOR
JG130A77		FUEL QUANTITY INDICATOR
JG130A94		FUEL QUANTITY INDICATOR
JG130A95		FUEL QUANTITY INDICATOR
JG130A97		FUEL QUANTITY INDICATOR
JG130A98		FUEL QUANTITY INDICATOR
JG130A99		FUEL QUANTITY INDICATOR
JG130C1		OIL QUANTITY INDICATOR
JG130C2		OIL QUANTITY INDICATOR
JG130C5		OIL QUANTITY INDICATOR
JG130C9		OIL QUANTITY INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
JG131A20		FUEL QUANTITY INDICATOR
JG131A35		FUEL QUANTITY INDICATOR
JG131A36		FUEL QUANTITY INDICATOR
JG131A37		FUEL QUANTITY INDICATOR
JG131A38		FUEL QUANTITY INDICATOR
JG131A40		FUEL QUANTITY INDICATOR
JG131A41		FUEL QUANTITY INDICATOR
JG131A42		FUEL QUANTITY INDICATOR
JG131A43		FUEL QUANTITY INDICATOR
JG131A45		FUEL QUANTITY INDICATOR
JG131A51		FUEL QUANTITY INDICATOR
JG131A53		FUEL QUANTITY INDICATOR
JG131A54		FUEL QUANTITY INDICATOR
JG131A55		FUEL QUANTITY INDICATOR
JG131A56		FUEL QUANTITY INDICATOR
JG131A57		FUEL QUANTITY INDICATOR
JG131A58		FUEL QUANTITY INDICATOR
JG131A59		FUEL QUANTITY INDICATOR
JG131A60		FUEL QUANTITY INDICATOR
JG131A61		FUEL QUANTITY INDICATOR
JG131A66		FUEL QUANTITY INDICATOR
JG131A67		FUEL QUANTITY INDICATOR
JG131A68		FUEL QUANTITY INDICATOR
JG131A69		FUEL QUANTITY INDICATOR
JG131A70		FUEL QUANTITY INDICATOR
JG131A71		FUEL QUANTITY INDICATOR
JG131A72		FUEL QUANTITY INDICATOR
JG131A73		FUEL QUANTITY INDICATOR
JG131A74		FUEL QUANTITY INDICATOR
JG131A75		FUEL QUANTITY INDICATOR
JG131A76		FUEL QUANTITY INDICATOR
JG131A77		FUEL QUANTITY INDICATOR
JG131A79		FUEL QUANTITY INDICATOR
JG131A80		FUEL QUANTITY INDICATOR
JG131A83		FUEL QUANTITY INDICATOR
JG140A20		FUEL QUANTITY INDICATOR
JG140A26		FUEL QUANTITY INDICATOR
JG141A11		FUEL QUANTITY INDICATOR
JG141A12		FUEL QUANTITY INDICATOR
JG141A13		FUEL QUANTITY INDICATOR
JG141A16		FUEL QUANTITY INDICATOR
JG141A17		FUEL QUANTITY INDICATOR
JG141A18		FUEL QUANTITY INDICATOR
JG141A20		FUEL QUANTITY INDICATOR
JG141A21		FUEL QUANTITY INDICATOR
JG141A22		FUEL QUANTITY INDICATOR
JG141A23		FUEL QUANTITY INDICATOR
JG141A3		FUEL QUANTITY INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
JG141A4		FUEL QUANTITY INDICATOR
JG141A9		FUEL QUANTITY INDICATOR
JG246A1		TEMPERATURE INDICATOR
JG246A2		TEMPERATURE INDICATOR
JG288A2	18-1545	PRESSURE RATIO INDICATOR
JG288A3	18-1540	PRESSURE RATIO INDICATOR
JG288A4	18-1541	PRESSURE RATIO INDICATOR
JG298A11		PRESSURE RATIO INDICATOR
JG298A3		PRESS.RATIO INDICATOR
JG298A4		PRESS.RATIO INDICATOR
JG298A5		PRESS.RATIO INDICATOR
JG298A6		PRESS.RATIO INDICATOR
JG298A7		PRESS.RATIO INDICATOR
JG298A8		PRESS.RATIO INDICATOR
JG298H1		PRESS.RATIO INDICATOR
JG298H2		PRESS.RATIO INDICATOR
JG402A12		FUEL QUANTITY INDICATOR
JG402A19		FUEL QUANTITY INDICATOR
JG402A2		FUEL QUANTITY INDICATOR
JG402A3		FUEL QUANTITY INDICATOR
JG402A32		FUEL QUANTITY INDICATOR
JG402A4		FUEL QUANTITY INDICATOR
JG402A41		FUEL QUANTITY INDICATOR
JG402A42		FUEL QUANTITY INDICATOR
JG402A43		FUEL QUANTITY INDICATOR
JG402A45		FUEL QUANTITY INDICATOR
JG402A52		FUEL QUANTITY INDICATOR
JG402A53		FUEL QUANTITY INDICATOR
JG402A54		FUEL QUANTITY INDICATOR
JG402A55		FUEL QUANTITY INDICATOR
JG403A30		FUEL QUANTITY INDICATOR
JG403B1	10-3065-265	FUEL QUANTITY INDICATOR
JG403B10	10-3065-277	FUEL QUANTITY INDICATOR
JG403B11		FUEL QUANTITY INDICATOR
JG403B12		FUEL QUANTITY INDICATOR
JG403B13		FUEL QUANTITY INDICATOR
JG403B14		FUEL QUANTITY INDICATOR
JG403B15	10-3065-277	FUEL QUANTITY INDICATOR
JG403B2		FUEL QUANTITY INDICATOR
JG403B3		FUEL QUANTITY INDICATOR
JG403B4		FUEL QUANTITY INDICATOR
JG403B5		FUEL QUANTITY INDICATOR
JG403B6		FUEL QUANTITY INDICATOR
JG403B7		FUEL QUANTITY INDICATOR
JG403B9		FUEL QUANTITY INDICATOR
JG403C1		FUEL QUANTITY INDICATOR
JG403C10		FUEL QUANTITY INDICATOR
JG403C11		FUEL QUANTITY INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
JG403C12		FUEL QUANTITY INDICATOR
JG403C13		FUEL QUANTITY INDICATOR
JG403C14		FUEL QUANTITY INDICATOR
JG403C15		FUEL QUANTITY INDICATOR
JG403C16		FUEL QUANTITY INDICATOR
JG403C17		FUEL QUANTITY INDICATOR
JG403C2		FUEL QUANTITY INDICATOR
JG403C3		FUEL QUANTITY INDICATOR
JG403C4		FUEL QUANTITY INDICATOR
JG403C5		FUEL QUANTITY INDICATOR
JG403C6		FUEL QUANTITY INDICATOR
JG403C8		FUEL QUANTITY INDICATOR
JG403C9		FUEL QUANTITY INDICATOR
JG412A1		FUEL QUANTITY INDICATOR
JG412A10		FUEL QUANTITY INDICATOR
JG412A11		FUEL QUANTITY INDICATOR
JG412A2		FUEL QUANTITY INDICATOR
JG412A3		FUEL QUANTITY INDICATOR
JG412A4		FUEL QUANTITY INDICATOR
JG412A52		FUEL QUANTITY INDICATOR
JG412A53		FUEL QUANTITY INDICATOR
JG412A54		FUEL QUANTITY INDICATOR
JG412A55		FUEL QUANTITY INDICATOR
JG412A56		FUEL QUANTITY INDICATOR
JG413B1		FUEL QUANTITY INDICATOR
JG413B2		FUEL QUANTITY INDICATOR
JG433A3		OIL QUANTITY INDICATOR
JG433A4		OIL QUANTITY INDICATOR
JG603C2		FUEL QUANTITY INDICATOR
JG603C3		FUEL QUANTITY INDICATOR
JG603C4		FUEL QUANTITY INDICATOR
JG603C42		FUEL QUANTITY INDICATOR
JG603C43		FUEL QUANTITY INDICATOR
JG603C44		FUEL QUANTITY INDICATOR
JG603C51		FUEL QUANTITY INDICATOR
JG603C52		FUEL QUANTITY INDICATOR
JG603C67		FUEL QUANTITY INDICATOR
JG603C70		FUEL QUANTITY INDICATOR
JG603C73		FUEL QUANTITY INDICATOR
JG603C78		FUEL QUANTITY INDICATOR
JG603C80		FUEL QUANTITY INDICATOR
JG603C81		FUEL QUANTITY INDICATOR
JG603D46		FUEL QUANTITY REPEATER INDICATOR
JG603D47		FUEL QUANTITY REPEATER INDICATOR
JG603D48		FUEL QUANTITY REPEATER INDICATOR
JG603D49		FUEL QUANTITY REPEATER INDICATOR
JG603D60		FUEL QUANTITY REPEATER INDICATOR
JG603D61		FUEL QUANTITY REPEATER INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
JG603D69		FUEL QUANTITY REPEATER INDICATOR
JG603D77		FUEL QUANTITY REPEATER INDICATOR
JG603D83		FUEL QUANTITY REPEATER INDICATOR
JG603D84		FUEL QUANTITY REPEATER INDICATOR
JG613C1		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C45		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C53		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C54		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C68		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C71		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C72		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C74		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C75		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C76		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C79		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG613C82		TOTAL AND GROSS WEIGHT FUEL QTY INDICATOR
JG865C1		ELECTRIC ALTIMETER INDICATOR
JG865C3		ELECTRIC ALTIMETER INDICATOR
JG866A1		PRESSURE RATIO INDICATOR
JG872A1		MASTER SAT INDICATOR
JG872A4		MASTER SAT INDICATOR
JG872A5		MASTER SAT INDICATOR
JG872B1		SERVO STATIC AIR TEMPERATURE INDICATOR
JG873A1	10-60768-21	MASTER TRUE AIRSPEED INDICATOR
JG873A4		MASTER TRUE AIRSPEED INDICATOR
JG873A5		MASTER TRUE AIRSPEED INDICATOR
JG873B1		SERVO TRUE AIRSPEED INDICATOR
JG908A1		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A10		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A11		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A12		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A13		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A14		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A15		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A16		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A17		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A18		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A19		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A21		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A25		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A27		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A28		RAM AIR TEMP/ ENGINE PRESSURE IND
JG908A29		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A3		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A30		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A33		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A4		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A41		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
JG908A5		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A55		RAM AIR TEMP./ ENGINE PRESSURE RATIO INDICATOR
JG908A57		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A58		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A6		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A7		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A8		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
JG908A9		RAM AIR TEMP./ ENGINE PRESS. RATIO IND.
L96H15-501		VALVE NON RETURN
LG80A2		PRESSURE RATIO TRANSMITTER
LG80E1		ENGINE PRESSURE RATIO COMPUTER
LKCB-18019	10-60757-26	2" ROUND WATT-VAR METER
LKCB-18041	40252	D.C. AMMETER
MGE23-400		MOTOT-GENERATOR
MGE23-400A		MOTOT-GENERATOR
MML-OC19AU		ENGINE GAGE TEMPERATURE INDICATOR
MS24569-1	9A 400	TEMPERATURE INDICATOR
MS28009-1		TEMPERATURE INDICATOR
MS28010-1		SYNCHRO STYLE MULTIPURPOSE PRESSURE
N40-1A10100-101		HANDSET WITH SUPPORT BRACKET
N40-1A10101-101		HANDSET WITH SUPPORT BRACKET
N40-1A10102-101		HANDSET WITH SUPPORT BRACKET
N40-1A10113-101		HANDSET WITH SUPPORT BRACKET
N40-1A10124-101		HANDSET WITH SUPPORT BRACKET
N40-1A10125-101		HANDSET WITH SUPPORT BRACKET
N40-1A10126-101		HANDSET WITH SUPPORT BRACKET
N40-1A10127-101		HANDSET WITH SUPPORT BRACKET
N40-1A10134-101		HANDSET WITH SUPPORT BRACKET
N40-1A10135-101		HANDSET WITH SUPPORT BRACKET
N40-1A10136-101		HANDSET WITH SUPPORT BRACKET
N40-1A10138-101		HANDSET WITH SUPPORT BRACKET
N40-1A10139-101		HANDSET WITH SUPPORT BRACKET
N40-1A10141-101		HANDSET WITH SUPPORT BRACKET
N40-1A10142-101		HANDSET WITH SUPPORT BRACKET
N40-1A10143-101		HANDSET WITH SUPPORT BRACKET
N40-1A10144-101		HANDSET WITH SUPPORT BRACKET
N40-1A10147-101		HANDSET WITH SUPPORT BRACKET
N40-1A10149-101		HANDSET WITH SUPPORT BRACKET
N40-1A10203-102		HANDSET WITH SUPPORT BRACKET
N40-1A10204-102		HANDSET WITH SUPPORT BRACKET
N40-1A10205-102		HANDSET WITH SUPPORT BRACKET
N40-1A20203-102		HANDSET WITH SUPPORT BRACKET
N40-1A20204-102		HANDSET WITH SUPPORT BRACKET
N40-1A20206-102		HANDSET WITH SUPPORT BRACKET
N40-1A20211-102		HANDSET WITH SUPPORT BRACKET
N40-1A20212-102		HANDSET WITH SUPPORT BRACKET
N40-1A20214-102		HANDSET WITH SUPPORT BRACKET
N40-1A20215-102		HANDSET WITH SUPPORT BRACKET





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
N40-1A20218-102		HANDSET WITH SUPPORT BRACKET
N40-1A20223-102		HANDSET WITH SUPPORT BRACKET
N40-1A20228-102		HANDSET WITH SUPPORT BRACKET
N40-1A20229-102		HANDSET WITH SUPPORT BRACKET
N40-1A20233-102		HANDSET WITH SUPPORT BRACKET
N40-1A20237-102		HANDSET WITH SUPPORT BRACKET
N40-1A20240-102		HANDSET WITH SUPPORT BRACKET
N40-1A20245-102		HANDSET WITH SUPPORT BRACKET
N40-1A20246-102		HANDSET WITH SUPPORT BRACKET
N40-1A30203-102		HANDSET WITH SUPPORT BRACKET
N40-1A40200-102		HANDSET WITH SUPPORT BRACKET
N40-1A40203-102		HANDSET WITH SUPPORT BRACKET
N40-1A40204-102		HANDSET WITH SUPPORT BRACKET
N40-1A40205-102		HANDSET WITH SUPPORT BRACKET
N40-1A40206-102		HANDSET WITH SUPPORT BRACKET
N40-1A40211-102		HANDSET WITH SUPPORT BRACKET
N40-1A40212-102		HANDSET WITH SUPPORT BRACKET
N40-1A40214-102		HANDSET WITH SUPPORT BRACKET
N40-1A40215-102		HANDSET WITH SUPPORT BRACKET
N40-1A40217-102		HANDSET WITH SUPPORT BRACKET
N40-1A40218-102		HANDSET WITH SUPPORT BRACKET
N40-1A40220-102		HANDSET WITH SUPPORT BRACKET
N40-1A40221-102		HANDSET WITH SUPPORT BRACKET
N40-1A40222-102		HANDSET WITH SUPPORT BRACKET
N40-1A40223-102		HANDSET WITH SUPPORT BRACKET
N40-1A40228-102		HANDSET WITH SUPPORT BRACKET
N40-1A40229-102		HANDSET WITH SUPPORT BRACKET
N40-1A40230-102		HANDSET WITH SUPPORT BRACKET
N40-1A40231-102		HANDSET WITH SUPPORT BRACKET
N40-1A40233-102		HANDSET WITH SUPPORT BRACKET
N40-1A40246-102		HANDSET WITH SUPPORT BRACKET
N40-1A40248-102		HANDSET WITH SUPPORT BRACKET
N40-1AB0218-102		HANDSET WITH SUPPORT BRACKET
N40-1B10100-101		HANDSET WITH SUPPORT BRACKET
N40-1B10101-101		HANDSET WITH SUPPORT BRACKET
N40-1B10102-101		HANDSET WITH SUPPORT BRACKET
N40-1B10113-101		HANDSET WITH SUPPORT BRACKET
N40-1B10124-101		HANDSET WITH SUPPORT BRACKET
N40-1B10125-101		HANDSET WITH SUPPORT BRACKET
N40-1B10126-101		HANDSET WITH SUPPORT BRACKET
N40-1B10127-101		HANDSET WITH SUPPORT BRACKET
N40-1B10134-101		HANDSET WITH SUPPORT BRACKET
N40-1B10135-101		HANDSET WITH SUPPORT BRACKET
N40-1B10136-101		HANDSET WITH SUPPORT BRACKET
N40-1B10138-101		HANDSET WITH SUPPORT BRACKET
N40-1B10139-101		HANDSET WITH SUPPORT BRACKET
N40-1B10141-101		HANDSET WITH SUPPORT BRACKET
N40-1B10142-101		HANDSET WITH SUPPORT BRACKET



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
N40-1B10143-101		HANDSET WITH SUPPORT BRACKET
N40-1B10144-101		HANDSET WITH SUPPORT BRACKET
N40-1B10147-101		HANDSET WITH SUPPORT BRACKET
N40-1B10149-101		HANDSET WITH SUPPORT BRACKET
N40-1B10203-102		HANDSET WITH SUPPORT BRACKET
N40-1B10204-102		HANDSET WITH SUPPORT BRACKET
N40-1B10205-102		HANDSET WITH SUPPORT BRACKET
N40-1B20203-102		HANDSET WITH SUPPORT BRACKET
N40-1B20204-102		HANDSET WITH SUPPORT BRACKET
N40-1B20206-102		HANDSET WITH SUPPORT BRACKET
N40-1B20211-102		HANDSET WITH SUPPORT BRACKET
N40-1B20212-102		HANDSET WITH SUPPORT BRACKET
N40-1B20214-102		HANDSET WITH SUPPORT BRACKET
N40-1B20215-102		HANDSET WITH SUPPORT BRACKET
N40-1B20218-102		HANDSET WITH SUPPORT BRACKET
N40-1B20223-102		HANDSET WITH SUPPORT BRACKET
N40-1B20228-102		HANDSET WITH SUPPORT BRACKET
N40-1B20229-102		HANDSET WITH SUPPORT BRACKET
N40-1B20233-102		HANDSET WITH SUPPORT BRACKET
N40-1B20237-102		HANDSET WITH SUPPORT BRACKET
N40-1B20240-102		HANDSET WITH SUPPORT BRACKET
N40-1B20245-102		HANDSET WITH SUPPORT BRACKET
N40-1B20246-102		HANDSET WITH SUPPORT BRACKET
N40-1B30203-102		HANDSET WITH SUPPORT BRACKET
N40-1B40200-102		HANDSET WITH SUPPORT BRACKET
N40-1B40203-102		HANDSET WITH SUPPORT BRACKET
N40-1B40204-102		HANDSET WITH SUPPORT BRACKET
N40-1B40205-102		HANDSET WITH SUPPORT BRACKET
N40-1B40206-102		HANDSET WITH SUPPORT BRACKET
N40-1B40211-102		HANDSET WITH SUPPORT BRACKET
N40-1B40212-102		HANDSET WITH SUPPORT BRACKET
N40-1B40214-102		HANDSET WITH SUPPORT BRACKET
N40-1B40215-102		HANDSET WITH SUPPORT BRACKET
N40-1B40217-102		HANDSET WITH SUPPORT BRACKET
N40-1B40220-102		HANDSET WITH SUPPORT BRACKET
N40-1B40221-102		HANDSET WITH SUPPORT BRACKET
N40-1B40222-102		HANDSET WITH SUPPORT BRACKET
N40-1B40223-102		HANDSET WITH SUPPORT BRACKET
N40-1B40228-102		HANDSET WITH SUPPORT BRACKET
N40-1B40229-102		HANDSET WITH SUPPORT BRACKET
N40-1B40230-102		HANDSET WITH SUPPORT BRACKET
N40-1B40231-102		HANDSET WITH SUPPORT BRACKET
N40-1B40233-102		HANDSET WITH SUPPORT BRACKET
N40-1B40246-102		HANDSET WITH SUPPORT BRACKET
N40-1B40248-102		HANDSET WITH SUPPORT BRACKET
P35-1		WING FLAP POSITION TRANSMITTER
PW259PG1		DIRECT READING PRESSURE GAUGE
PW409PGM2		DIRECT READING PRESSURE GAUGE



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
R1053M18		LIMIT MECHANISM ASSEMBLY
R1053M18-1		LIMIT MECHANISM ASSEMBLY
R1053M18-2		LIMIT MECHANISM ASSEMBLY
RC-20-ILB	10-60755-2	RATE OF CLIMB INDICATOR
RD-AM8303		COCKPIT SPEAKER
RD-AM8303-01		COCKPIT SPEAKER
RD-AM8304		COCKPIT SPEAKER
RG1007AA03		FLASHER TIMING UNIT
RL/801AM/MS/3		ALTIMETER
RL/801AM/MS/5		ALTIMETER
RL/801AM/MS/7		ALTIMETER
RL/820AM/MS/3		ALTIMETER
RL1101AMMS10		SERVO ALTIMETER
RL202EED5		TEMPERATURE INDICATOR
RL504CUFFA10		ALERTING ALTITUDE UNIT
RP198-00	301-794-601-0	T12 TEMPERATURE SENSOR
RP198-01	301-794-602-0	T12 TEMPERATURE SENSOR
RPS1-B	100865	BATTERY POWER SUPPLY
RRB41057-53		FORWARD ATTENDANT'S PANEL ASSY
S.149		RATIOMETER INDICATOR
S.458		RATIOMETER INDICATOR
S.483		RATIOMETER INDICATOR
S.483.1.17		RATIOMETER INDICATOR
S100-0080-00	A100S	SOLID-STATE COCKPIT VOICE RECORDER
S100-0080-01	A100S	SOLID-STATE COCKPIT VOICE RECORDER
S210T120-103	S210T120-103	PRESSURE REGULATING AND SHUTOFF VALVE
S210T120-113	S210T120-103	PRESSURE REGULATING AND SHUTOFF VALVE
S210T120-133	S210T120-103	PRESSURE REGULATING AND SHUTOFF VALVE
S210T120-143	S210T120-103	PRESSURE REGULATING AND SHUTOFF VALVE
S210T120-153	S210T120-103	PRESSURE REGULATING AND SHUTOFF VALVE
S210T130-72	1150406-1	AUXILIARY ZONE TEMPERATURE CONTROLLER
S210T170-20	420035-1	MOTOR ACTUATED FLAPPER SELECTOR VALVE
S210T170-30	420035-2	MOTOR ACTUATED FLAPPER SELECTOR VALVE
S210T170-40	420035-3	MOTOR ACTUATED FLAPPER SELECTOR VALVE
S212N101-29	107494-3	REVERSE FLOW CHECK CONTROL VALVE
S212N101-45	107494-4	REVERSE FLOW CHECK CONTROL VALVE
S231A130-1		ELECTRONIC CLOCK
S231A130-2	9010-1-2	ELECTRONIC CLOCK
S231N001-11	402EED2-1	STANDBY ENGINE INDICATOR
S231N001-14	402EED3-2	STANDBY ENGINE INDICATOR
S231N001-15	402EED1-3	STANDBY ENGINE INDICATOR
S231N001-6	402EED1-1	STANDBY ENGINE INDICATOR
S231T110-6	S231T110-6	STANDBY ATTITUDE
S231T120-1	2600-06-1	DIGITAL ELECTRONIC CLOCK
S231T245-2	SEDLOC9A	DUAL DUCT PRESSURE IND
S231T245-3	SEDLOC9B	DUAL DUCT PRESSURE IND
S231T245-4	SEDLOC9C	DUAL DUCT PRESSURE IND
S242A600-1001	2584A	CONTROL DISPLAY UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
S242A600-1002	2584A3	CONTROL DISPLAY UNIT
S242A600-1003	2584A6	CONTROL DISPLAY UNIT
S242A600-2001	2584A1	CONTROL DISPLAY UNIT
S242A600-2002	2584A4	CONTROL DISPLAY UNIT
S242A600-2003	2584A7	CONTROL DISPLAY UNIT
S242A600-3001	2584A2	CONTROL DISPLAY UNIT
S242A600-3002	2584A5	CONTROL DISPLAY UNIT
S242A600-3003	2584A8	CONTROL DISPLAY UNIT
S242N701-205	DSP-701A	DISPLAY SELECT PANEL
S242N701-206	DSP-701A	DISPLAY SELECT PANEL
S242T403-204	RMI-733	RADIO MAGNETIC INDICATOR
S242T403-205	RMI-733	RADIO MAGNETIC INDICATOR
S242T403-206	RMI-733	RADIO MAGNETIC INDICATOR
S242T403-207	RMI-733	RADIO MAGNETIC INDICATOR
S242T404-304	622-5048-104	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-310	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-311	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-312	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-330	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-331	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-332	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-350	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-351	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-352	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-353	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S242T404-370	EFIC-701D	ELECTRONIC FLIGHT INSTRUMENT CONTROL
S250N104-4	H505B	TRANSMITTER, CONTROL SURFACE POSITION
S250N104-6	H509B	TRANSMITTER, CONTROL SURFACE POSITION
S253T409-1	AC2-A	SERVO MOTOR GENERATOR
S256T007-10	18-1958-10	FLAP POSITION TRASMITTER
S256T007-12	18-1958-12	FLAP POSITION TRASMITTER
S256T007-14	18-1958-14	FLAP POSITION TRASMITTER
S256T007-15	18-1958-15	FLAP POSITION TRASMITTER
S256T007-17	18-1958-17	FLAP POSITION TRASMITTER
S256T007-21	18-1958-21	FLAP POSITION TRASMITTER
S283N702-10	05939-10	FLUORESCENT LAMP BALLAST
S283N702-103	05939-103	FLUORESCENT LAMP BALLAST
S283N702-104	05939-104	FLUORESCENT LAMP BALLAST
S283N702-105	05939-105	FLUORESCENT LAMP BALLAST
S283N702-107	05939-107	FLUORESCENT LAMP BALLAST
S283N702-108	05939-108	FLUORESCENT LAMP BALLAST
S283N702-109	05939-109	FLUORESCENT LAMP BALLAST
S283N702-110	05939-110	FLUORESCENT LAMP BALLAST
S283N702-113	05939-113	FLUORESCENT LAMP BALLAST
S283N702-114	05939-114	FLUORESCENT LAMP BALLAST
S283N702-115	05939-115	FLUORESCENT LAMP BALLAST
S283N702-116	05939-116	FLUORESCENT LAMP BALLAST
S283N702-13	05939-13	FLUORESCENT LAMP BALLAST



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
S283N702-14	05939-14	FLUORESCENT LAMP BALLAST
S283N702-15	05939-15	FLUORESCENT LAMP BALLAST
S283N702-16	05939-16	FLUORESCENT LAMP BALLAST
S283N702-3	05939-3	FLUORESCENT LAMP BALLAST
S283N702-4	05939-4	FLUORESCENT LAMP BALLAST
S283N702-5	05939-5	FLUORESCENT LAMP BALLAST
S283N702-7	05939-7	FLUORESCENT LAMP BALLAST
S283N702-8	05939-8	FLUORESCENT LAMP BALLAST
S283N702-9	05939-9	FLUORESCENT LAMP BALLAST
S283T013-15		AIRCRAFT NAVIGATIONAL LIGHT
S283T013-16		AIRCRAFT NAVIGATIONAL LIGHT
S283T014-2	BPS7-2	BATTERY POWER SUPPLY
S283T014-3	BPS7-3	BATTERY POWER SUPPLY
S283U008-16	8184-1	ELECTRONIC BALLAST
S283U008-16 MOD A	8184-1 MOD A	ELECTRONIC BALLAST
S315N401-1	GM7184-1	DUAL LINEAR TRANSDUCER ASSEMBLY
S315N401-2	GM7184-2	DUAL LINEAR TRANSDUCER ASSEMBLY
S315N401-3	GM7184-3	DUAL LINEAR TRANSDUCER ASSEMBLY
S315N401-4	GM7184-4	DUAL LINEAR TRANSDUCER ASSEMBLY
S315N401-5	GM7184-5	DUAL LINEAR TRANSDUCER ASSEMBLY
S315N401-6	GM7184-6	DUAL LINEAR TRANSDUCER ASSEMBLY
S332T004-37	8D1496	SWITCH, GAGE PRESSURE
S347T001-11	WL203EED6	FUEL FLOW/USED INDICATOR
S347T001-13	WL203EED7	FUEL FLOW/USED INDICATOR
S347T001-14	WL203EED8	FUEL FLOW/USED INDICATOR
S347T001-15	WL203EED9	FUEL FLOW/USED INDICATOR
S347T001-16	WL203EED10	FUEL FLOW/USED INDICATOR
S347T001-24	WL203EED11	FUEL FLOW/USED INDICATOR
S347T001-25	WL203EED12	FUEL FLOW/USED INDICATOR
S347T001-26	WL203EED13	FUEL FLOW/USED INDICATOR
S347T001-7	WL203EED3	FUEL FLOW/USED INDICATOR
S347T001-8	WL203EED4	FUEL FLOW/USED INDICATOR
S417N512-10	11-5833-9	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-11	11-5833-11	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-12	11-5833-13	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-13	11-5833-15	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-23	11-5833-21	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-24	11-5833-23	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-26	11-5833-25	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-27	11-5833-17	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-28	11-5833-19	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-4	11-5833-1	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-6	11-5833-3	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-7	11-5833-5	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S417N512-8	11-5833-7	INTERIOR ILLUMINATED SIGN LIGHT SUBASSEMBLY
S451T201-10	181RA71R206	CARGO SYSTEM POWER DRIVE UNIT
S451T201-11	181RA71R206A	CARGO SYSTEM POWER DRIVE UNIT
S451T201-12	181RA71R206B	CARGO SYSTEM POWER DRIVE UNIT



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
S451T201-13	181RA71R206C	CARGO SYSTEM POWER DRIVE UNIT
S451T201-15	2022538-101	CARGO POWERED DRIVE UNIT
S451T201-3		CARGO POWERED DRIVE UNIT
S451T201-4	2022538-4	CARGO POWERED DRIVE UNIT
S451T201-5	2022538-5	CARGO POWERED DRIVE UNIT
S451T201-7		CARGO POWERED DRIVE UNIT
SEDL-OC29J	120-IN-0067	NH/NL% RPM INDICATOR
SEDL-OC2R	120-IN-0068	TORQUE INDICATOR
SEDLOC3A		DUAL FUEL PRESSURE INDICATOR
SEDLOC4A		DUAL OIL PRESSURE INDICATOR
SEDLOC4K		DUAL OIL PRESSURE INDICATOR
SEDL-OC7P		HYDRAULIC BRAKE PRESSURE INDICATOR
SEDLOC9A		DUAL DUCT PRESSURE IND.
SEDLOC9B		DUAL DUCT PRESSURE IND.
SEDLOC9C		DUAL DUCT PRESSURE IND.
SEL-O19BC	206-075-680-103	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19BD	206-075-680-105	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19BU	206-075-680-107	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19BW	206-075-680-101	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-OC19AG		EXHAUST GAS TEMPERATURE INDICATOR
SEL-OC19AM		TURBINE TEMPERATURE INDICATOR
SEL-OC19AP		TURBINE TEMPERATURE INDICATOR
SEL-OC19D		EXHAUST GAS TEMPERATURE INDICATOR
SEL-OC19E		EXHAUST GAS TEMPERATURE INDICATOR
SEL-OC19F		EXHAUST GAS TEMPERATURE INDICATOR
SEL-OC19G		EXHAUST GAS TEMPERATURE INDICATOR
SEL-OC19N		EXHAUST GAS TEMPERATURE INDICATOR
SEL-OC29DA		NH % RPM INDICATOR
SEL-OC29DF		PROP RPM INDICATOR
SEL-OC29DH	120-IN-0047	PROP RPM INDICATOR
SEL-OC29DJ		NL %RPM INDICATOR
SEL-OC29DK		NH %RPM INDICATOR
SEL-OC29F		GAS GENERATOR TACHOMETER INDICATOR
SEL-OC3F		FUEL PRESSURE INDICATOR
SEL-OC3G		FUEL PRESSURE INDICATOR
SEL-OC3H		FUEL PRESSURE INDICATOR
SEL-OC3J		FUEL PRESSURE INDICATOR
SEL-OC4G		OIL PRESSURE INDICATOR
SEL-OC4H		OIL PRESSURE INDICATOR
SEL-OC4J		OIL PRESSURE INDICATOR
SEL-OC4K		OIL PRESSURE INDICATOR
SETL-OC329A		TRIPLE TACHOMETER ENGINE ROTOR INDICATOR
SK-30-MC-IL-3		AIRSPD INDICATOR
SP2983		DOME LIGHT
SR-015F		PRESSURE RATIO INDICATOR
SR-027A		OXY PRESSURE INDICATOR
SR-04E		OIL PRESSURE INDICATOR
SR-18B		DOOR POSITION INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
SR-18C		DOOR POSITION INDICATOR
SR-3J		FUEL PRESS INDICATOR
SR-4J		OIL COOLER FLAP POSITION INDICATOR
SR-4K		OIL PRESSURE INDICATOR
SR-4M		GEAR OIL PRESSURE INDICATOR
SR-4U		FLAP POSITION INDICATOR
SR-5E		MANIFOLD PRESSURE INDICATOR
SR-5F		FREON PRESSURE INDICATOR
SR-5G		PRESSURE INDICATOR
SRD-27A		SYNCHRO INDICATOR
SRDL-0C7E	10-3223-43	DUAL HYD PRESSURE INDICATOR
SRDL-12B		DUAL FLAP POSITION INDICATOR
SRDL-4A		DUAL OIL PRESSURE INDICATOR
SRDL-6D		INDICATOR DUAL PRESSURE
SRDL-7A		IND HYD PRESS
SRDL-7B		DUAL BRAKE PRESSURE INDICATOR
SRDL-7G		DUAL HYD BRAKE PRESSURE INDICATOR
SRDL-7H		IND. DUAL HYD SYSTEM PRESSURE
SRDL-7J		DUAL AIR-HYD BRAKE PRESS INDICATOR
SRL-04A		OIL PRESSURE INDICATOR
SRL-04G		OIL PRESSURE INDICATOR
SRL-07AM		PNEUMATIC BRAKE INDICATOR
SRL-07AP		HYDRAULIC BRAKE PRESSURE INDICATOR
SRL-07B		AIR BRAKE INDICATOR
SRL-07BH		RUDDER HYD PRESSURE INDICATOR
SRL-07C		HYDRAULIC BRAKE PRESSURE INDICATOR
SRL-07CA		IND, BRK PRESS
SRL-07CR		REVERSER HYD INDICATOR
SRL-07S		SPOILER HYDRAULIC PRESSURE INDICATOR
SRL-0C7EM		HYDRAULIC BRAKE PRESSURE INDICATOR
SRL-12H		HYDRAULIC FLUID QUANTITY INDICATOR
SRL-12J		HYDRAULIC FLUID QUANTITY INDICATOR
SRL-7D		HYDRAULIC PRESSURE INDICATOR
SRL-7K		HYD. PRESS.INDICATOR
SRL-92D		PNEUMATIC PRESSURE INDICATOR
SRL-92E		SUPPLY AIR PRESSURE INDICATOR
SRL-92F		PNEUMATIC PRESSURE INDICATOR
SRL-92G		TEMP. CONTROL VALVE POSITION IND.
SRL-92H		PNEUMATIC PRESSURE INDICATOR
SRL-92P		PNEUMATIC PRESSURE INDICATOR
SRLD-3A		INDICATOR FUEL PRESSURE
SRL-O4H		OIL PRESS INDICATOR
SRL-O4L		OIL PRESS. INDICATOR
SRL-O7AG		PRESS INDICATOR
SRL-O7AM		PNEUMATIC BRAKE INDICATOR
SRL-O7AZ		HYD BRK PRESS INDICATOR
SRL-O7B		AIR BRAKE INDICATOR
SRL-O7BZ		HYDRAULIC PRESSURE INDICATOR



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
SRL-O7CL		AIR BRAKE INDICATOR
SRL-O7CM		HYD SYS PRESS INDICATOR
SRL-O7CN		HYD BRK. INDICATOR
SRL-O7CR		HYDRAULIC REVERSER PRESSURE INDICATOR
SRL-O7F		HYD PRESS IND.
SRL-O7N		AIR BRAKE PRESSURE INDICATOR
SRL-O7N-M1		AIR BRAKE PRESSUE INDICATOR
SRL-O7S		PRESS INDICATOR
SRL-OC4N		OIL PRESS. INDICATOR
SRL-OC7EM	10-3223-44	HYD. BRAKE PRESSURE INDICATOR
SR-O9D		AIR SUPPLY DUCT PRESSURE INDICATOR
SRT-314A		TORQUEMETER INDICATOR
ST3100-20-01		HANDSET
ST3100-20-02		HANDSET
ST3100-21-10		HANDSET
ST3100-21-11		HANDSET
ST3100-21-12		HANDSET
ST3100-21-13		HANDSET
ST3100-21-14		HANDSET
ST3100-21-15		HANDSET
ST3100-21-16		HANDSET
ST3100-21-17		HANDSET
ST3100-21-18		HANDSET
ST3100-21-21		HANDSET
ST3100-21-22		HANDSET
ST3100-21-25		HANDSET
ST3100-21-28		HANDSET
ST3100-21-30		HANDSET
ST3100-21-31		HANDSET
ST3100-21-32		HANDSET
ST3100-22-10		HANDSET
ST3100-22-12		HANDSET
ST3100-22-14		HANDSET
ST3100-22-18		HANDSET
ST3100-22-21		HANDSET
ST3100-22-22		HANDSET
ST3100-22-24		HANDSET
ST3100-22-26		HANDSET
ST3100-22-28		HANDSET
ST3100-22-30		HANDSET
ST3100-22-31		HANDSET
ST3100-22-32		HANDSET
ST3100-23-10		HANDSET
ST3100-23-12		HANDSET
ST3100-23-14		HANDSET
ST3100-23-15		HANDSET
ST3100-23-16		HANDSET
ST3100-23-17		HANDSET





**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
ST3100-23-18		HANDSET
ST3100-23-19		HANDSET
ST3100-23-20		HANDSET
ST3100-23-21		HANDSET
ST3100-23-22		HANDSET
ST3100-23-23		HANDSET
ST3100-23-24		HANDSET
ST3100-23-25		HANDSET
ST3100-23-26		HANDSET
ST3100-23-27		HANDSET
ST3100-23-28		HANDSET
ST3100-23-29		HANDSET
ST3100-23-30		HANDSET
ST3100-23-31		HANDSET
ST3100-23-32		HANDSET
ST3100-24-15		HANDSET
ST3100-24-16		HANDSET
ST3100-24-17		HANDSET
ST3100-24-20		HANDSET
ST3100-24-21		HANDSET
ST3100-25-32		HANDSET
ST3100-26-18		HANDSET
ST3100-26-32		HANDSET
ST3100-26-33		HANDSET
ST3100-27-12		HANDSET
ST3100-27-32		HANDSET
ST3100-27-37		HANDSET
ST3100-28-34		HANDSET
ST3100-28-35		HANDSET
ST3100-28-36		HANDSET
ST3100-28-38		HANDSET
ST3100-30-01		HANDSET
ST3100-33-10		HANDSET
SYLG-51153		CARGO COMPARTMENT LINEAR ACTUATOR
T521		BUS PROTECTION PANEL
TD1514-1002	60B50058-3	TOILET TIMER SWITCH
TD1535-1002	60B50058-4	TOILET TIMER SWITCH
TD1702-1002	60B50058-6	TOILET TIMER SWITCH
TD1715-1002	60B50058-5	TOILET TIMER SWITCH
TGH-11-RE-4/A004		TORQUE TRANSMITTER
V2T152B		BUTTERFLY AIR VALVE
V2T152D		BUTTERFLY AIR VALVE
V2T512BAMDTA		BUTTERFLY AIR VALVE
VD3810		MIXED FLOW FAN
VD3900-02		RECIRCULATION FAN
VD3900-03		RECIRCULATION FAN
VD3901-00		RECIRCULATION FAN
VD3920		EXTRACTION FAN



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
VIL-OC4A		OIL PRESSURE INDICATOR
VIL-OC4E		OIL PRESSURE INDICATOR
VIL-OC7D		HYDRAULIC PRESSURE INDICATOR
VSDL-OC204A		OIL PRESSURE INDICATOR
VSDL-OC204C		OIL PRESSURE INDICATOR
VSDL-OC219A		OIL TEMPERATURE INDICATOR
VSDL-OC219C		OIL TEMPERATURE INDICATOR
VSDL-OC410R		DIGITAL FAN SPEED INDICATOR
VSDL-OC410S		DIGITAL FAN SPEED INDICATOR
VSDL-OC410T		DIGITAL FAN SPEED INDICATOR
VT477-2		QUANTITY INDICATOR
VT477-3		QUANTITY INDICATOR
WL/113AMA/JA/1		MACH-AIRSPEED INDICATOR
WL/113AMA/JA/2		MACH-AIRSPEED INDICATOR
WL/113AMA/JA/4		MACH-AIRSPEED INDICATOR
WL/113AMA/JA/5		MACH-AIRSPEED INDICATOR
WL/118AMA/JA/1		MACH-AIRSPEED INDICATOR
WL/118AMA/JA/4		MACH-AIRSPEED INDICATOR
WL/120AMA/JA/1		MACH-AIRSPEED INDICATOR
WL/120AMA/JA/3	10-60768-35	MACH-AIRSPEED INDICATOR
WL/120AMA/JA/4		MACH-AIRSPEED INDICATOR
WL/120AMA/JA/5		MACH-AIRSPEED INDICATOR
WL/801AM/CP/1		ALTIMETER
WL/801AM/MS/3		ALTIMETER
WL/801AM/MS/6		ALTIMETER
WL/802AM/CP/1		ALTIMETER
WL/804AM/CP/1		ALTIMETER
WL/806AM/CP/1		ALTIMETER
WL/807AM/CP/1		ALTIMETER
WL/808AM/EA/1		ALTIMETER
WL/808AM/EA/2		ALTIMETER
WL/809AM/MS/2		ALTIMETER
WL/810AM/MS/1		ALTIMETER
WL/820AM/MS/1		ALTIMETER
WL/820AM/MS/2		ALTIMETER
WL/820AM/MS/4		ALTIMETER
WL/820AM/MS/5		ALTIMETER
WL/820AM/MS/6		ALTIMETER
WL/820AM/MS/7		ALTIMETER
WL/820AM/MS/8		ALTIMETER
WL/841AM/MS/1		ALTIMETER
WL/841AM/MS/2		ALTIMETER
WL/841AM/MS/3		ALTIMETER
WL/841AM/MS/4		ALTIMETER
WL/842AM/MS/1		ALTIMETER
WL/842AM/MS/2		ALTIMETER
WL/852AM/MS/1		ALTIMETER
WL/852AM/MS/2		ALTIMETER



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
WL/855AM/MS/1		ALTIMETER
WL/855AM/MS/2		ALTIMETER
WL/856AM/MS/1		ALTIMETER
WL/862AM/MS/1		ALTIMETER
WL/862AM/MS/2		ALTIMETER
WL/862AM/MS/3		ALTIMETER
WL/862AM/MS/4		ALTIMETER
WL/862AM/MS/5		ALTIMETER
WL/862AM/MS/7		ALTIMETER
WL101AMS1		ALTIMETER/AIRSPEED INDICATOR
WL101AMS2		ALTIMETER/AIRSPEED INDICATOR
WL101AMS5		ALTIMETER/AIRSPEED INDICATOR
WL101AMS6		ALTIMETER/AIRSPEED INDICATOR
WL101EED2	10-62028-2	N1 PERCENTAGE RPM INDICATOR
WL101EED3	10-62028-3	N1 PERCENTAGE RPM INDICATOR
WL102AMS1		ALTIMETER/AIRSPEED INDICATOR
WL102AMS2		ALTIMETER/AIRSPEED INDICATOR
WL102AMS3		ALTIMETER/AIRSPEED INDICATOR
WL102AMS4		ALTIMETER/AIRSPEED INDICATOR
WL102AMS5		ALTIMETER/AIRSPEED INDICATOR
WL102AMS6		ALTIMETER/AIRSPEED INDICATOR
WL104AMAJA1		MACH-AIRSPEED INDICATOR
WL104AMAJA10		MACH-AIRSPEED INDICATOR
WL104AMAJA11		MACH-AIRSPEED INDICATOR
WL104AMAJA2		MACH-AIRSPEED INDICATOR
WL104AMAJA5		MACH-AIRSPEED INDICATOR
WL104AMAJA6		MACH-AIRSPEED INDICATOR
WL104AMAJA8		MACH-AIRSPEED INDICATOR
WL104AMAJA9		MACH-AIRSPEED INDICATOR
WL1101AMMS1		SERVO ALTIMETER
WL1101AMMS10		SERVO ALTIMETER
WL1101AMMS2		SERVO ALTIMETER
WL1101AMMS3		SERVO ALTIMETER
WL1101AMMS4		SERVO ALTIMETER
WL1101AMMS7		SERVO ALTIMETER
WL1101AMMS8		SERVO ALTIMETER
WL1103AMMS1		SERVO ALTIMETER
WL1103AMMS10		SERVO ALTIMETER
WL1103AMMS13		SERVO ALTIMETER
WL1103AMMS19		SERVO ALTIMETER
WL1103AMMS2		SERVO ALTIMETER
WL1103AMMS3		SERVO ALTIMETER
WL1103AMMS4		SERVO ALTIMETER
WL1105AMMS2		SERVO ALTIMETER
WL1107AMMS1		SERVO ALTIMETER
WL1107AMMS3		SERVO ALTIMETER
WL111AMA-JA1		MACH-AIRSPEED INDICATOR
WL111AMA-JA10		MACH-AIRSPEED INDICATOR



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
WL111AMA-JA2		MACH-AIRSPEED INDICATOR
WL1150AMMS1		SERVO ALTIMETER
WL1150AMMS2		SERVO ALTIMETER
WL1150AMMS4		SERVO ALTIMETER
WL115AMA-JA1		MACH-AIRSPEED INDICATOR
WL115AMA-JA3		MACH-AIRSPEED INDICATOR
WL115AMA-JA4		MACH-AIRSPEED INDICATOR
WL120AMA-JA6		MACH-AIRSPEED INDICATOR
WL1350AMMS1		ALTIMETER
WL1350AMMS2		ALTIMETER
WL1350AMMS3		ALTIMETER
WL1350AMMS4		ALTIMETER
WL1350AMMS5		ALTIMETER
WL1350AMMS6		ALTIMETER
WL1381AMMS1		ALTIMETER
WL1381AMMS2		ALTIMETER
WL1381AMMS3		ALTIMETER
WL1381AMMS4		ALTIMETER
WL201EED2	10-62031-1	N2 % RPM INDICATOR
WL202EED3	10-62032-2	TEMPERATURE INDICATOR
WL202EED4	10-62032-3	TEMPERATURE INDICATOR
WL202EED6	10-62032-5	TEMPERATURE INDICATOR
WL203EED10	S347T001-16	FUEL FLOW/USED INDICATOR
WL203EED11	S347T001-24	FUEL FLOW/USED INDICATOR
WL203EED12	S347T001-25	FUEL FLOW/USED INDICATOR
WL203EED13	S347T001-26	FUEL FLOW/USED INDICATOR
WL203EED3	S347T001-7	FUEL FLOW/USED INDICATOR
WL203EED4	S347T001-8	FUEL FLOW/USED INDICATOR
WL203EED6	S347T001-11	FUEL FLOW/USED INDICATOR
WL203EED7	S347T001-13	FUEL FLOW/USED INDICATOR
WL203EED8	S347T001-14	FUEL FLOW/USED INDICATOR
WL203EED9	S347T001-15	FUEL FLOW/USED INDICATOR
WL501RC1		CABIN RATE OF CLIMB INDICATOR
WL502RC1		CABIN RATE OF CLIMB INDICATOR
WL503RC1		CABIN RATE OF CLIMB INDICATOR
WL504CUFEA1		ALERTING ALTITUDE UNIT
WL504CUFEA12		ALERTING ALTITUDE UNIT
WL504CUFEA2		ALERTING ALTITUDE UNIT
WL504CUFEA3		ALERTING ALTITUDE UNIT
WL504CUFEA7		ALERTING ALTITUDE UNIT
WL504CUFEA8		ALERTING ALTITUDE UNIT
WL504CUFEA9		ALERTING ALTITUDE UNIT
WL508CUFEA1		ALERTING ALTITUDE UNIT
WL508CUFEA2		ALERTING ALTITUDE UNIT
WL508CUFEA3		ALERTING ALTITUDE UNIT
WL508CUFEA4		ALERTING ALTITUDE UNIT
WL509CUFEA1		ALERTING ALTITUDE UNIT
WL510CUFEA1		ALERTING ALTITUDE UNIT



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
WL510CUFEA2		ALERTING ALTITUDE UNIT
WL510CUFEA3		ALERTING ALTITUDE UNIT
WL511CUFEA2		ALERTING ALTITUDE UNIT
WL511CUFEA3		ALERTING ALTITUDE UNIT
WL512CUFEA1		ALERTING ALTITUDE UNIT
WL513CUFEA1		ALERTING ALTITUDE UNIT
WL513CUFEA2		ALERTING ALTITUDE UNIT
WL513CUFEA3		ALERTING ALTITUDE UNIT
WL513CUFEA4		ALERTING ALTITUDE UNIT
XW20548-M1	2311M69-1	WINDSHIELD WIPER MOTOR ASSEMBLY
XW20548-M1A	2311M69-2	WINDSHIELD WIPER MOTOR ASSEMBLY
XW20548-M1A-1	2311M69-3	WINDSHIELD WIPER MOTOR ASSEMBLY
XW20548-M1A-2	2311M69-4	WINDSHIELD WIPER MOTOR ASSEMBLY
XW20548-M1A-3	2311M69-5	WINDSHIELD WIPER MOTOR ASSEMBLY
XW20548-M1A-4	2311M69-6	WINDSHIELD WIPER MOTOR ASSEMBLY
Z020H0000110		PROGRAMMING AND TEST PANEL
Z020H0001110		PROGRAMMING AND TEST PANEL
Z020H0001112		PROGRAMMING AND TEST PANEL
Z050HAABBCCD		PROGRAMMING AND TEST PANEL
Z111H0000110	Z111H	ATTENDANT INDICATION PANEL
Z111H0000111	Z111H	ATTENDANT INDICATION PANEL
Z111H0000112	Z111H	ATTENDANT INDICATION PANEL
Z111H0000113	Z111H	ATTENDANT INDICATION PANEL
Z111H0000114	Z111H	ATTENDANT INDICATION PANEL
Z111H0001110	Z111H	ATTENDANT INDICATION PANEL
Z111H0001112	Z111H	ATTENDANT INDICATION PANEL
Z111H0002110	Z111H	ATTENDANT INDICATION PANEL
Z111H0002112	Z111H	ATTENDANT INDICATION PANEL
Z111H0020110	Z111H	ATTENDANT INDICATION PANEL
Z111H0020111	Z111H	ATTENDANT INDICATION PANEL
Z111H0020112	Z111H	ATTENDANT INDICATION PANEL
Z111H0020113	Z111H	ATTENDANT INDICATION PANEL
Z111H0020114	Z111H	ATTENDANT INDICATION PANEL
Z111H0020150	Z111H	ATTENDANT INDICATION PANEL
Z111H0020151	Z111H	ATTENDANT INDICATION PANEL
Z111H0021110	Z111H	ATTENDANT INDICATION PANEL
Z111H0021112	Z111H	ATTENDANT INDICATION PANEL
Z111H0021150	Z111H	ATTENDANT INDICATION PANEL
Z111H0021151	Z111H	ATTENDANT INDICATION PANEL
Z111H0022110	Z111H	ATTENDANT INDICATION PANEL
Z111H0022112	Z111H	ATTENDANT INDICATION PANEL
Z111H0022150	Z111H	ATTENDANT INDICATION PANEL
Z111H0022151	Z111H	ATTENDANT INDICATION PANEL
Z111H0023112	Z111H	ATTENDANT INDICATION PANEL
Z111H0023130	Z111H	ATTENDANT INDICATION PANEL
Z111H0023150	Z111H	ATTENDANT INDICATION PANEL
Z111H0023151	Z111H	ATTENDANT INDICATION PANEL
Z111H0024130	Z111H	ATTENDANT INDICATION PANEL



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
Z111H0025150	Z111H	ATTENDANT INDICATION PANEL
Z111H0025151	Z111H	ATTENDANT INDICATION PANEL
Z111H0030113	Z111H	ATTENDANT INDICATION PANEL
Z111H0030151	Z111H	ATTENDANT INDICATION PANEL
Z111H0031151	Z111H	ATTENDANT INDICATION PANEL
Z111H0032114	Z111H	ATTENDANT INDICATION PANEL
Z111H0032151	Z111H	ATTENDANT INDICATION PANEL
Z111H0033130	Z111H	ATTENDANT INDICATION PANEL
Z111H0033131	Z111H	ATTENDANT INDICATION PANEL
Z111H0033151	Z111H	ATTENDANT INDICATION PANEL
Z111H0034130	Z111H	ATTENDANT INDICATION PANEL
Z111H0034131	Z111H	ATTENDANT INDICATION PANEL
Z111H0035151	Z111H	ATTENDANT INDICATION PANEL
Z111H0036151	Z111H	ATTENDANT INDICATION PANEL
Z111H0037130	Z111H	ATTENDANT INDICATION PANEL
Z111H0037131	Z111H	ATTENDANT INDICATION PANEL
Z111H0037151	Z111H	ATTENDANT INDICATION PANEL
Z111H0038131	Z111H	ATTENDANT INDICATION PANEL
Z111H0039131	Z111H	ATTENDANT INDICATION PANEL
Z111H0100131	Z111H	ATTENDANT INDICATION PANEL
Z120H0002110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0003110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0004110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0005110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0006110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0008110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0009110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0010110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0011110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0012110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0014110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0015110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0016110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0022110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0023110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0024110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0025110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0026110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0028110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0029110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0030110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0031110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0032110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0033110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0034110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0035110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0036110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0037110	Z120H	ADDITIONAL ATTENDANT PANEL



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
Z120H0038110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0039110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0040110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0042110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0043110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0044110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0045110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0046110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0047110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0048110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0049110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0050110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0051110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0052110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0053110	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0054111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0055111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0056111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0057111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0059111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0060111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0061111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0062111	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0063112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0064112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0065112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0066112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0067112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0068112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0070112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0071112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0072112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0073112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0074112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0075112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0076112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0077112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0078112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H0079112	Z120H	ADDITIONAL ATTENDANT PANEL
Z120H050530B		ADDITIONAL ATTENDANT PANEL
Z120H050730B		ADDITIONAL ATTENDANT PANEL
Z120H050830B		ADDITIONAL ATTENDANT PANEL
Z120H050930B		ADDITIONAL ATTENDANT PANEL
Z120H051030B		ADDITIONAL ATTENDANT PANEL
Z120H051130B		ADDITIONAL ATTENDANT PANEL
Z120H051230B		ADDITIONAL ATTENDANT PANEL
Z120H051430B		ADDITIONAL ATTENDANT PANEL
Z120H051630B		ADDITIONAL ATTENDANT PANEL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
Z120H052330B		ADDITIONAL ATTENDANT PANEL
Z120H052530B		ADDITIONAL ATTENDANT PANEL
Z120H052730B		ADDITIONAL ATTENDANT PANEL
Z120H052830B		ADDITIONAL ATTENDANT PANEL
Z120H052930B		ADDITIONAL ATTENDANT PANEL
Z120H053330B		ADDITIONAL ATTENDANT PANEL
Z120H054130B		ADDITIONAL ATTENDANT PANEL
Z120H054430B		ADDITIONAL ATTENDANT PANEL
Z120H054530B		ADDITIONAL ATTENDANT PANEL
Z120H054630B		ADDITIONAL ATTENDANT PANEL
Z120H054730B		ADDITIONAL ATTENDANT PANEL
Z120H054830B		ADDITIONAL ATTENDANT PANEL
Z120H054930B		ADDITIONAL ATTENDANT PANEL
Z120H055030B		ADDITIONAL ATTENDANT PANEL
Z120H055330B		ADDITIONAL ATTENDANT PANEL
Z120H055430B		ADDITIONAL ATTENDANT PANEL
Z120H055530B		ADDITIONAL ATTENDANT PANEL
Z120H055730B		ADDITIONAL ATTENDANT PANEL
Z120H055830B		ADDITIONAL ATTENDANT PANEL
Z120H055930B		ADDITIONAL ATTENDANT PANEL
Z120H056030B		ADDITIONAL ATTENDANT PANEL
Z120H056130B		ADDITIONAL ATTENDANT PANEL
Z120H056230B		ADDITIONAL ATTENDANT PANEL
Z120H056330B		ADDITIONAL ATTENDANT PANEL
Z120H056630B		ADDITIONAL ATTENDANT PANEL
Z120H056730B		ADDITIONAL ATTENDANT PANEL
Z120H056830B		ADDITIONAL ATTENDANT PANEL
Z120H056930B		ADDITIONAL ATTENDANT PANEL
Z120H057030B		ADDITIONAL ATTENDANT PANEL
Z120H057230B		ADDITIONAL ATTENDANT PANEL
Z120H057330B		ADDITIONAL ATTENDANT PANEL
Z120H057430B		ADDITIONAL ATTENDANT PANEL
Z130H0005110	Z130H	FORWARD ATTENDANT PANEL
Z130H0006110	Z130H	FORWARD ATTENDANT PANEL
Z130H0008110	Z130H	FORWARD ATTENDANT PANEL
Z130H0009110	Z130H	FORWARD ATTENDANT PANEL
Z130H0010110	Z130H	FORWARD ATTENDANT PANEL
Z130H0011110	Z130H	FORWARD ATTENDANT PANEL
Z130H0012110	Z130H	FORWARD ATTENDANT PANEL
Z130H0017110	Z130H	FORWARD ATTENDANT PANEL
Z130H0018110	Z130H	FORWARD ATTENDANT PANEL
Z130H0019110	Z130H	FORWARD ATTENDANT PANEL
Z130H0022110	Z130H	FORWARD ATTENDANT PANEL
Z130H0023110	Z130H	FORWARD ATTENDANT PANEL
Z130H0024110	Z130H	FORWARD ATTENDANT PANEL
Z130H0025110	Z130H	FORWARD ATTENDANT PANEL
Z130H0026110	Z130H	FORWARD ATTENDANT PANEL
Z130H0028110	Z130H	FORWARD ATTENDANT PANEL





**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
Z130H0029110	Z130H	FORWARD ATTENDANT PANEL
Z130H0030110	Z130H	FORWARD ATTENDANT PANEL
Z130H0031110	Z130H	FORWARD ATTENDANT PANEL
Z130H0032110	Z130H	FORWARD ATTENDANT PANEL
Z130H0033110	Z130H	FORWARD ATTENDANT PANEL
Z130H0034110	Z130H	FORWARD ATTENDANT PANEL
Z130H0035110	Z130H	FORWARD ATTENDANT PANEL
Z130H0036110	Z130H	FORWARD ATTENDANT PANEL
Z130H0037110	Z130H	FORWARD ATTENDANT PANEL
Z130H0038110	Z130H	FORWARD ATTENDANT PANEL
Z130H0039110	Z130H	FORWARD ATTENDANT PANEL
Z130H0040110	Z130H	FORWARD ATTENDANT PANEL
Z130H0041110	Z130H	FORWARD ATTENDANT PANEL
Z130H0042110	Z130H	FORWARD ATTENDANT PANEL
Z130H0043110	Z130H	FORWARD ATTENDANT PANEL
Z130H0044110	Z130H	FORWARD ATTENDANT PANEL
Z130H0045110	Z130H	FORWARD ATTENDANT PANEL
Z130H0046110	Z130H	FORWARD ATTENDANT PANEL
Z130H0047110	Z130H	FORWARD ATTENDANT PANEL
Z130H0048110	Z130H	FORWARD ATTENDANT PANEL
Z130H0049110	Z130H	FORWARD ATTENDANT PANEL
Z130H0052110	Z130H	FORWARD ATTENDANT PANEL
Z130H0053110	Z130H	FORWARD ATTENDANT PANEL
Z130H0054110	Z130H	FORWARD ATTENDANT PANEL
Z130H0055110	Z130H	FORWARD ATTENDANT PANEL
Z130H0056110	Z130H	FORWARD ATTENDANT PANEL
Z130H0058110	Z130H	FORWARD ATTENDANT PANEL
Z130H0059110	Z130H	FORWARD ATTENDANT PANEL
Z130H0060110	Z130H	FORWARD ATTENDANT PANEL
Z130H0061110	Z130H	FORWARD ATTENDANT PANEL
Z130H0062110	Z130H	FORWARD ATTENDANT PANEL
Z130H0063110	Z130H	FORWARD ATTENDANT PANEL
Z130H0064110	Z130H	FORWARD ATTENDANT PANEL
Z130H0065110	Z130H	FORWARD ATTENDANT PANEL
Z130H0066110	Z130H	FORWARD ATTENDANT PANEL
Z130H0067110	Z130H	FORWARD ATTENDANT PANEL
Z130H0068110	Z130H	FORWARD ATTENDANT PANEL
Z130H0069110	Z130H	FORWARD ATTENDANT PANEL
Z130H0070110	Z130H	FORWARD ATTENDANT PANEL
Z130H0071110	Z130H	FORWARD ATTENDANT PANEL
Z130H0072110	Z130H	FORWARD ATTENDANT PANEL
Z130H0073110	Z130H	FORWARD ATTENDANT PANEL
Z130H0074110	Z130H	FORWARD ATTENDANT PANEL
Z130H0075110	Z130H	FORWARD ATTENDANT PANEL
Z130H0076110	Z130H	FORWARD ATTENDANT PANEL
Z130H0077110	Z130H	FORWARD ATTENDANT PANEL
Z130H0079110	Z130H	FORWARD ATTENDANT PANEL
Z130H0080110	Z130H	FORWARD ATTENDANT PANEL



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
Z130H0081110	Z130H	FORWARD ATTENDANT PANEL
Z130H0082110	Z130H	FORWARD ATTENDANT PANEL
Z130H0083110	Z130H	FORWARD ATTENDANT PANEL
Z130H0084110	Z130H	FORWARD ATTENDANT PANEL
Z130H0085110	Z130H	FORWARD ATTENDANT PANEL
Z130H0086110	Z130H	FORWARD ATTENDANT PANEL
Z130H0087110	Z130H	FORWARD ATTENDANT PANEL
Z130H0088110	Z130H	FORWARD ATTENDANT PANEL
Z130H0089110	Z130H	FORWARD ATTENDANT PANEL
Z130H0090110	Z130H	FORWARD ATTENDANT PANEL
Z130H0091110	Z130H	FORWARD ATTENDANT PANEL
Z130H0092110	Z130H	FORWARD ATTENDANT PANEL
Z130H0093110	Z130H	FORWARD ATTENDANT PANEL
Z130H0094110	Z130H	FORWARD ATTENDANT PANEL
Z130H0095110	Z130H	FORWARD ATTENDANT PANEL
Z130H0096110	Z130H	FORWARD ATTENDANT PANEL
Z130H0098110	Z130H	FORWARD ATTENDANT PANEL
Z130H0099110	Z130H	FORWARD ATTENDANT PANEL
Z130H0101110	Z130H	FORWARD ATTENDANT PANEL
Z130H0102110	Z130H	FORWARD ATTENDANT PANEL
Z130H0103110	Z130H	FORWARD ATTENDANT PANEL
Z130H0104110	Z130H	FORWARD ATTENDANT PANEL
Z130H0105110	Z130H	FORWARD ATTENDANT PANEL
Z130H0106110	Z130H	FORWARD ATTENDANT PANEL
Z130H0107110	Z130H	FORWARD ATTENDANT PANEL
Z130H0108110	Z130H	FORWARD ATTENDANT PANEL
Z130H0109110	Z130H	FORWARD ATTENDANT PANEL
Z130H0110110	Z130H	FORWARD ATTENDANT PANEL
Z130H0111110	Z130H	FORWARD ATTENDANT PANEL
Z130H0114110	Z130H	FORWARD ATTENDANT PANEL
Z130H0115110	Z130H	FORWARD ATTENDANT PANEL
Z130H0116110	Z130H	FORWARD ATTENDANT PANEL
Z130H0117110	Z130H	FORWARD ATTENDANT PANEL
Z130H0118110	Z130H	FORWARD ATTENDANT PANEL
Z130H0119110	Z130H	FORWARD ATTENDANT PANEL
Z130H0120110	Z130H	FORWARD ATTENDANT PANEL
Z130H0121110	Z130H	FORWARD ATTENDANT PANEL
Z130H0122110	Z130H	FORWARD ATTENDANT PANEL
Z130H0123110	Z130H	FORWARD ATTENDANT PANEL
Z130H0124110	Z130H	FORWARD ATTENDANT PANEL
Z130H0125110	Z130H	FORWARD ATTENDANT PANEL
Z130H0126110	Z130H	FORWARD ATTENDANT PANEL
Z130H0127110	Z130H	FORWARD ATTENDANT PANEL
Z130H0128110	Z130H	FORWARD ATTENDANT PANEL
Z130H0129110	Z130H	FORWARD ATTENDANT PANEL
Z130H0130110	Z130H	FORWARD ATTENDANT PANEL
Z130H0131110	Z130H	FORWARD ATTENDANT PANEL
Z130H0132110	Z130H	FORWARD ATTENDANT PANEL



**WINGS AEROSPACE, LLC**  
**COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
Z130H0133110	Z130H	FORWARD ATTENDANT PANEL
Z130H0134110	Z130H	FORWARD ATTENDANT PANEL
Z130H0135110	Z130H	FORWARD ATTENDANT PANEL
Z130H0136110	Z130H	FORWARD ATTENDANT PANEL
Z130H0137110	Z130H	FORWARD ATTENDANT PANEL
Z130H0138110	Z130H	FORWARD ATTENDANT PANEL
Z130H0139110	Z130H	FORWARD ATTENDANT PANEL
Z130H0140110	Z130H	FORWARD ATTENDANT PANEL
Z130H0141110	Z130H	FORWARD ATTENDANT PANEL
Z130H0142110	Z130H	FORWARD ATTENDANT PANEL
Z130H0143110	Z130H	FORWARD ATTENDANT PANEL
Z130H0144110	Z130H	FORWARD ATTENDANT PANEL
Z130H0145110	Z130H	FORWARD ATTENDANT PANEL
Z130H0146110	Z130H	FORWARD ATTENDANT PANEL
Z130H0147110	Z130H	FORWARD ATTENDANT PANEL
Z130H0148110	Z130H	FORWARD ATTENDANT PANEL
Z130H0149110	Z130H	FORWARD ATTENDANT PANEL
Z130H0150110	Z130H	FORWARD ATTENDANT PANEL
Z130H0151110	Z130H	FORWARD ATTENDANT PANEL
Z130H0152110	Z130H	FORWARD ATTENDANT PANEL
Z130H0153110	Z130H	FORWARD ATTENDANT PANEL
Z130H0154110	Z130H	FORWARD ATTENDANT PANEL
Z130H0155110	Z130H	FORWARD ATTENDANT PANEL
Z130H0156110	Z130H	FORWARD ATTENDANT PANEL
Z130H0158110	Z130H	FORWARD ATTENDANT PANEL
Z130H0159110	Z130H	FORWARD ATTENDANT PANEL
Z130H0160110	Z130H	FORWARD ATTENDANT PANEL
Z130H0161110	Z130H	FORWARD ATTENDANT PANEL
Z130H0162110	Z130H	FORWARD ATTENDANT PANEL
Z130H0163110	Z130H	FORWARD ATTENDANT PANEL
Z130H0164110	Z130H	FORWARD ATTENDANT PANEL
Z130H0165110	Z130H	FORWARD ATTENDANT PANEL
Z130H0166110	Z130H	FORWARD ATTENDANT PANEL
Z130H0167110	Z130H	FORWARD ATTENDANT PANEL
Z130H0168110	Z130H	FORWARD ATTENDANT PANEL
Z130H0169110	Z130H	FORWARD ATTENDANT PANEL
Z130H0170110	Z130H	FORWARD ATTENDANT PANEL
Z130H0171110	Z130H	FORWARD ATTENDANT PANEL
Z130H0172110	Z130H	FORWARD ATTENDANT PANEL
Z130H0173110	Z130H	FORWARD ATTENDANT PANEL
Z130H0174110	Z130H	FORWARD ATTENDANT PANEL
Z130H0175110	Z130H	FORWARD ATTENDANT PANEL
Z130H0176110	Z130H	FORWARD ATTENDANT PANEL
Z130H0177110	Z130H	FORWARD ATTENDANT PANEL
Z130H0178110	Z130H	FORWARD ATTENDANT PANEL
Z130H0179110	Z130H	FORWARD ATTENDANT PANEL
Z130H0180110	Z130H	FORWARD ATTENDANT PANEL
Z130H0181110	Z130H	FORWARD ATTENDANT PANEL



**WINGS AEROSPACE, LLC  
COMMERCIAL AIRCRAFT CAPABILITIES LIST**

<b>PARTNO</b>	<b>MODEL</b>	<b>DESCRIPTION</b>
Z130H0182110	Z130H	FORWARD ATTENDANT PANEL
Z130H0183110	Z130H	FORWARD ATTENDANT PANEL
Z130H0184110	Z130H	FORWARD ATTENDANT PANEL
Z130H0185110	Z130H	FORWARD ATTENDANT PANEL
Z130H0186110	Z130H	FORWARD ATTENDANT PANEL
Z130H0187110	Z130H	FORWARD ATTENDANT PANEL
Z130H0188110	Z130H	FORWARD ATTENDANT PANEL
Z130H0189110	Z130H	FORWARD ATTENDANT PANEL
Z130H0190110	Z130H	FORWARD ATTENDANT PANEL
Z130H0191110	Z130H	FORWARD ATTENDANT PANEL
Z130H0192110	Z130H	FORWARD ATTENDANT PANEL
Z130H0193110	Z130H	FORWARD ATTENDANT PANEL
Z130H0194110	Z130H	FORWARD ATTENDANT PANEL
Z130H0195110	Z130H	FORWARD ATTENDANT PANEL
Z130H0196110	Z130H	FORWARD ATTENDANT PANEL
Z130H0197110	Z130H	FORWARD ATTENDANT PANEL
Z130H0198110	Z130H	FORWARD ATTENDANT PANEL
Z130H0215110	Z130H	FORWARD ATTENDANT PANEL
Z130H0217110	Z130H	FORWARD ATTENDANT PANEL
Z130H0218110	Z130H	FORWARD ATTENDANT PANEL
Z130H0219110	Z130H	FORWARD ATTENDANT PANEL
Z130H0231110	Z130H	FORWARD ATTENDANT PANEL
Z130H0241110	Z130H	FORWARD ATTENDANT PANEL
Z130H0244110	Z130H	FORWARD ATTENDANT PANEL
Z130H0245110	Z130H	FORWARD ATTENDANT PANEL
Z250H2101110		READING LIGHT POWER UNIT
Z250H2102110		READING LIGHT POWER UNIT
Z250H2103110		READING LIGHT POWER UNIT
Z250H2111110		READING LIGHT POWER UNIT
Z250H2112110		READING LIGHT POWER UNIT
Z250H2113110		READING LIGHT POWER UNIT
Z260H0000110		SEAT ROW INDICATOR
Z260H0000110 Amd. A		SEAT ROW INDICATOR
Z260H0000110 Amd. B		SEAT ROW INDICATOR
Z260H0000110 Amd. C		SEAT ROW INDICATOR
Z260H0002110		SEAT ROW INDICATOR
Z260H0002110 Amd. A		SEAT ROW INDICATOR
Z260H0002110 Amd. B		SEAT ROW INDICATOR