

Brand	Model Number	Part Number	Date Code	Original Remote	Compatible Remote(s)	Alternate Remote(s)	Type
<b>Automate</b>							
Automate	Auto-key	703M	6G - 6I	499T (NLA)	None		learn
Automate	1	705A	4A - 6D	None/uses fac remote	Factory OEM Remote		N/A
Automate	1	700A	6D - up	None/uses fac remote	Factory OEM Remote		N/A
Automate	2	420A	2K - 4H	493T	None		scratch
Automate	2	710A	5J - 6F	493C	493T		learn
Automate	2	710A	6G - 7D	493C	493T,484T		learn
Automate	2 HF	710A	7E - up	491T (NLA)	485M, 491C (NLA)		learn
Automate	2	2102A	7G - current	474A	473A, 471C		learn
Automate	3	430A	Up to 2B	465T	None		scratch
Automate	3	430A	2C - 6C	493T	None		scratch
Automate	3+	432A	5L - 7E	493C	493T,484T		learn
Automate	3+ HF	432A	7F - 8E	491T (NLA)	485M, 491C (NLA)		learn
Automate	4	440A	Up to 2J	465T	None		scratch
Automate	4	440A	3D - 4L	493T	None		scratch
Automate	5	435A	2E - 4F	493T	None		scratch
Automate	5+	437A	3L - 5K	493C	493T, 484T		learn
Automate	5+	437A	5L - 7E	493C	493T,484T		learn
Automate	5+ HF	437A	7F - up	491T (NLA)	485M, 491C (NLA)		learn
Automate	5 HF	438A	4D - 7C	491T (NLA)	485M, 491C (NLA)		learn
Automate	6	445A	Up to 3B	465T	None		scratch
Automate	6	445A	3E - 5A	493T	None		scratch
Automate	6 HF	448A	4I - 6H	491T (NLA)	485M, 491C (NLA)		learn
Automate	6 HF	448A	7C - 7G	485T (NLA)	485M, 491C (NLA)		learn
Automate	7	280A	All	465T	None		learn
Automate	7 HF	553A	6B - 6K	491T (NLA)	485M, 491C (NLA)		learn
Automate	7 HF	553A	7C - 8E	485T (NLA)	485M, 491C (NLA)		learn
Automate	8	281T	All	465T	None		learn
Automate	410	410A	All	471T	474A, 473A, 471C		learn
Automate	415	415A	All	None/uses fac remote	Factory OEM Remote		N/A
Automate	417	417A	All	None/uses fac remote	Factory OEM Remote		N/A
Automate	425	425A	8I - up	475Q (NLA)	474A, 473A, 471C		learn
Automate	435	435A	8I - up	475Q (NLA)	474A, 473A, 471C		learn
Automate	552	552A	All	476A (NLA)	474A, 473A, 471C		learn
Automate	553	553A	6B - 8L	485T (NLA)	485M, 491C (NLA)		learn
Automate	553	553A	9B - up	476A (NLA)	474A, 473A, 471C		learn
Automate	AM1	427A	3L - up	None/uses fac remote	474A, 473A, 471C *		learn
Automate	AM1	3001A	all	None/uses fac remote	474A, 473A, 471C *		N/A
Automate	AM2	416A	All	474A	473A, 471C		learn
Automate	AM2	2102A	7G - current	474A	473A, 471C		learn
Automate	AM5	436A	3L - up	474A	473A, 471C		learn
Automate	AM5	3101A	8E - current	474A	473A, 471C		learn
Automate	AM6	562A	All	474A	473A, 471C		learn
Automate	AM6	4103A	All	474A	7111A		learn
Automate	AM6.2	4101A	7H - current	7111A	7111A		learn
Automate	AM6.2	4113A	All	7111A	7111A	474A	learn
Automate	AM7	563A	3H - up	474A	473A, 471C		learn
Automate	AM7	5103A	All	474A	474A		learn
Automate	AM9	564A	All	477A (LCD 2wy), 474A	473A, 471C		learn
Automate	AM9	5303A	All	477A (LCD 2wy), 474A	477A (2wy), 474A		learn
Automate	AM14	4301A	All	7301A (TRX722A) (LCD 2wy) (NLA)	7301A (TRX722A) (LCD 2wy)		learn
Automate	AM15	4311A	All	7301A (TRX722A) (LCD 2wy) (NLA)	7301A (TRX722A) (LCD 2wy)		learn
Automate	3901T	3901T	All	None/uses fac remote	Factory OEM Remote		N/A
Automate	3902T	3902T	All	None/uses fac remote	Factory OEM Remote		N/A
Automate	3903T	3903T	All	None/uses fac remote	Factory OEM Remote		N/A
Automate	SSKR (All)		All	Not included in kit	471A, 471C		learn

\*Need to add an external receiver to use aftermarket remotes

Automate Select							
Automate (Select)	1.5	3808A	All	None/uses fac remote	7643A, 7645A (Dealer Master Remote)		learn
Automate (Select)	3203	3203A	All	7243A (LE 2wy), 7143A	7351A (LC 2wy), 7243A (LE 2wy), 7143A	7142A, 7242A (LE 2wy)	learn
Automate (Select)	3303	3303A	All	7351A (LC 2wy), 7143A	7351A (LC 2wy), 7243A (LE 2wy), 7143A	7142A, 7242A (LE 2wy)	learn
Automate (Select)	3807A	3807A	All	None/uses fac remote	7643A		learn
Automate (Select)	4104	4104A	All	7142A	7142A	7113A	learn
Automate (Select)	4114	4114A	All	7113A	7113A	7142A	learn
Automate (Select)	4204	4204A	All	7242A (LE 2wy), 7142A	7351A (LC 2wy), 7243A (LE 2wy), 7143A, 7142A	7213A (LED 2wy)	learn
Automate (Select)	4214	4214A	All	7213A (LED 2wy), 7113A	7213A (LE 2wy), 7142A	7113A, 7213A (LED 2wy)	learn
Automate (Select)	4304	4304A	All	7351A (LC 2wy), 7142A	7351A (LC 2wy), 7243A (LE 2wy), 7143A, 7142A	7113A, 7213A (LED 2wy)	learn
Automate (Select)	5104	5104A	All	7142A	7142A	7113A	learn
Automate (Select)	5204	5204A	All	7242A (LE 2wy), 7142A	7351A (LC 2wy), 7243A (LE 2wy), 7143A, 7142A	7113A, 7213A (LED 2wy)	learn
Automate (Select)	5304	5304A	All	7351A (LC 2wy), 7142A	7351A (LC 2wy), 7243A (LE 2wy), 7143A, 7142A	7113A, 7213A (LED 2wy)	learn
Automate RSR/RXT Kits							
Automate	4108A	4108A	All	7142A			learn
Automate	4218A	4218A	All	7213A (LED 2wy), 7113A			learn
Automate	4208A	4208A	All	7242A (LE 2wy), 7142A			learn
Automate	4118A	4118A	All	7113A			learn
Automate	4108AL	4108A	All	474A			learn
Automate	4118AL	4118A	All	7111A			learn
Boa							
Boa	105B	105B	All	474B	None		learn
Boa	165B	165B	All	474B	None		learn
Boa	175B	175B	All	475B	None		learn
Boa	265B	265B	All	474B	None		learn
Boa	275B	275B	All	475B	None		learn
Boa	500	500B	All	473B	None		learn
Directed							
Directed	2102T	2102T	All	PKETR1	None		learn
Equalizer							
Equalizer	1	723E	6E	493T	None		scratch
Equalizer	1	725B	All	491T (NLA)	485M, 491C (NLA)		learn
Equalizer	2	432E	6A	493C	493T, 484T		learn
Equalizer	3	437E	5H	493C	493T, 484T		learn
Equalizer	3	703T	6G - 6I	499T (NLA)	None		learn
Hornet							
Hornet	121T	121T	4C - 6J	493T	None		scratch
Hornet	553T	553T	7H - 8B	491T (NLA)	485M, 491C (NLA)		learn
Hornet	553T	555T	9B - up	475Q (NLA)	474T, 473T, 471C		learn
Hornet	554T	554T	All	477T (LCD 2wy), 474T	473T, 471C		learn
Hornet	560T	560T	All	479H	479H		learn
Hornet	563T	563T	All	474T	473T, 471C		learn
Hornet	564T	564T	All	477T (LCD 2wy), 474T	473T, 471C		learn
Hornet	569T	569T	All	471H	471H, 471C		learn
Hornet	570T	570T	All	471T	471C		learn
Hornet	700J	700J	All	None/uses fac remote	Factory OEM Remote		N/A
Hornet	700T	700T	6A - up	None/uses fac remote	Factory OEM remote		N/A
Hornet	705T	705T	4G - 6A	None/uses fac remote	Factory OEM remote		N/A
Hornet	706T	706T	4A	No remote/ NOT RF	N/A		N/A
Hornet	707T	707T	2F - 4A	No remote/ NOT RF	N/A		N/A
Hornet	710T	710T	Up to 7J	465T	None		scratch

Directed TX Cross Reference

Hornet	710T	415T	8A - up	471T	474T, 473T, 471C	learn
Hornet	715T	715T	All	465T	None	scratch
Hornet	717T	717T	2G - 3D	465T	None	scratch
Hornet	718T	718T	2E - 4A	NLA	None	N/A
Hornet	718T	718T	4F - 6D	493T	None	learn
Hornet	718T	718T	6G - 7B	493C	493T	learn
Hornet	719T	719T	2C - 3B	NLA	None	N/A
Hornet	719T	719T	3D - 6D	493T	None	scratch
Hornet	719T	719T	6F - 7C	492T	493T	learn
Hornet	719T	719T	7D - 7J	491T (NLA)	485M, 491C (NLA)	learn
Hornet	720T	720T	2C - 3C	NLA	None	N/A
Hornet	720T	720T	3E - 6A	493T	None	scratch
Hornet	720T	720T	7J - up	491T (NLA)	485M, 491C (NLA)	learn
Hornet	721T	721T	2J - 2L	No Longer Available	493T	scratch
Hornet	721T	721T	2J - 5E	493T	None	scratch
Hornet	722T	722T	2H - 4G	493T	None	scratch
Hornet	723T	723T	5G - 7E	493T	None	scratch
Hornet	725T	725T	7G - up	491T (NLA)	485M, 491C (NLA)	learn
Hornet	727T	727T	All	No remote/ NOT RF	474T, 473T, 471C *	N/A
Hornet	730T	730T	2E - 3K	465T	None	scratch
Hornet	730T	730T	3K-1 - 7A	493T	None	scratch
Hornet	730T	730T	7G - up	491T (NLA)	485M, 491C (NLA)	learn
Hornet	732T	732T	6C - 7E	493C	484T	learn
Hornet	732T	732T	7J - 8E	491T (NLA)	485M, 491C (NLA)	learn
Hornet	735T	735T	4C - 4G	493T	None	scratch
Hornet	737T	737T	4I - 5J	493C	493T, 484T	learn
Hornet	740T	281T	All	465T	None	learn
Hornet	740T	740T	4K - up	473T	474T, 471C	learn
Hornet	742T	742T	All	474T	473T, 471C	learn
Hornet	745T	745T	All	477T (LCD 2wy), 474T	473T, 471C	learn
Hornet	748T	748T	8L - 9A	491T (NLA)	485M, 491C (NLA)	learn
Hornet	755T	755T	2B - 4G	465T	None	scratch
Hornet	851T	851T	All	471T	471T	

\*Need to add an external receiver to use aftermarket remotes

**Merlin**

Merlin	2000	122T	All	470T	471C	learn
Merlin	3000	225T	All	482T,473B	None	learn

**Python**

Python	Python Responder One	4203P	All	7211P (LED 2wy)	7211P (2wy)	learn
Python	55	723B	6J - 7E	493T	None	scratch
Python	60	261P	2K - 4H	493T	None	scratch
Python	60	430P	4I - 6H	493T	None	scratch
Python	70	271P	2L - 5C	484T	493C, 493T	learn
Python	80	281P	2L - 5C	484T	493C, 493T	learn
Python	90	291P	2K - 4L	484T	None	learn
Python	323	3203P	All	7251P (LE 2wy), 7153P	7251P (LE 2wy), 7153P	7351P (LC 2wy), 7254P (LE 2wy)
Python	333	3303P	All	7351P (LC 2wy), 7153P	7351P (LC 2wy), 7153P	7251P (LE 2wy), 7254P (LE 2wy)
Python	400 HF	410P	8G - up	471T	474P, 473P, 471C	7141P, 7142P
Python	411	4111P	All	7111P	7111P	7141P, 7141P, 7142P
Python	413	4103P	All	474P	474P	7141P, 7142P, 7111P
Python	414	4104P	ALL	7153P	7153P	7152P, 7251P* (LE 2wy), 7254P* (LE 2wy), 7351P* (LC 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)
Python	424	4204P	All	7251P (LE 2wy), 7152P	7153P	7154P, 7254P (LE 2wy), 7351P (LC 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)
Python	440 HP	416P	All	474P	473P, 471C	7141P, 7142P

Directed TX Cross Reference

Python	441	4411P	All	7111P	7111P	474P, 7141P, 7142P	learn
Python	443 (MRI unit)	4403P	All	7142P		474P, 7141P, 7111P	learn
Python	450 HF	552P	7H - 8L	491T (NLA)	485M, 491C (NLA)		learn
Python	450 ESP	552P	9B - 0I	471T	474P, 473P, 471C	7141P, 7142P	learn
Python	450 ESP	552P	0J - up	476P (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	460 HP	426P	All	473P	474P, 471C	7141P, 7142P	learn
Python	Responder 460	3305P	All	7341P (LCD 2wy), 7142P	7341P (LCD 2wy), 7142P	474P, 7141P, 488T (LED 2wy)	learn
Python	460 Max	3105P	All	7142P	7142P	474P, 7141P	learn
Python	500	3101P	All	474P	473P, 471C	7142P	learn
Python	502	3102P	All	7141P	474P, 473P, 471C	7142P	learn
Python	513	5103P	All	474P	474T	7142P, 7141P	learn
Python	514	5104P	All	7153P	7152P	7152P, 7251P* (LE 2wy), 7351P* (LC 2wy), 7652P*, 7752P* (LC3 2wy), 7941P* (HD 2wy)	learn
Python	524	5204P	All	7251P (LE 2wy), 7152P	7153P	7154P, 7254P (LE 2wy), 7351P (LC 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	533	5303P	All	477P (LCD 2wy), 474P	477T (LCD 2wy)	7142P, 7141P	learn
Python	543	5403P	All	7142P			learn
Python	571XP	572P	4G - 4K	487P (LED 2wy) (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	571XP	572P	5J - 6K	488P (LED 2wy)	487P (LED 2wy), 488P (LED 2wy), 474P, 473P, 471C	7141P, 7142P, 488T (LED 2wy)	learn
Python	574	5704P	All	7752P (LC3 2wy), 7652P	7752P (LC3 2wy), 7652P	7654P, 7754P (LC3 2wy), 7652P, 7752P (LC3 2wy), 7941P (HD 2wy)	learn
Python	580	4202P	up to 9K	7251P (LE 2wy), 7152P	7153P	7153P, 7152P, 7154P, 7254P (LE 2wy), 7251P (LE 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	580	4202P	9J	7251P (LE 2wy), 7152P	7153P	7153P, 7152P, 7154P, 7254P (LE 2wy), 7251P (LE 2wy), 7351P (LC 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	581XP	542P	All	479P (LCD 2wy)	472P (NLA)		learn
Python	592	5902P	All	7941P (HD 2wy), 7652P	7941P (HD 2wy), 7652P	7654P, 7752P (LC3 2wy), 7754P (LC3 2wy)	learn
Python	594	5904P	All	7941P (HD 2wy), 7652P	7941P (HD 2wy), 7652P	7654P, 7752P (LC3 2wy), 7754P (LC3 2wy)	learn
Python	PC 650 HF(ESP)	429T	9A - up	471T	474P, 473P, 471C	7141P, 7142P	learn
Python	625 HF	430P	8D - up	471T	474P, 473P, 471C	7141P, 7142P	learn
Python	650	432P	5L - 7E	493C	493T, 484T		learn
Python	650 HF	432P	7F - 8B	491T (NLA)	485M, 491C (NLA)		learn
Python	650 HF	432P	8B - up	471T	474P, 473P, 471C	7141P, 7142P	learn
Python	660 HP	436P	All	474P	473P, 471C	7141P, 7142P	learn
Python	660XP	436P	All	474P	473P, 471C	7141P, 4742P	learn
Python	671 XP	437P	All	487P (LED 2wy) (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	680 XP	434P	All	479P (LCD 2wy)	472P (NLA)		learn
Python	700	3201P	All	488P (LED 2wy), 474P	473P, 471C	7341P, 7141P, 7142P, 488T (LED 2wy)	learn
Python	702	3202P	All	488P (LED 2wy), 7141P	474P, 473P, 471C	7341P, 7142P, 488T (LED 2wy)	learn
Python	750	437P	5B - 5K	493C	493T, 484T		learn
Python	750	437P	5L - 7C	493C	493T, 484T		learn
Python	871 XP	567P	4E - 4I	487P (LED 2wy) (NLA)	487P (LED 2wy), 474P, 473P, 471C	7141P, 7142P	learn
Python	871 XP	567P	5E - 6I	488P (LED 2wy)	487P (LED 2wy), 488P (LED 2wy), 474P, 473P, 471C	7141P, 7142P, 488T (LED 2wy)	learn
Python	872	5202P	up to 9K	7251P (LE 2wy), 7152P	7153P	7153P, 7254P (LE 2wy), 7652P*, 7654P*, 7752P* (LC3 2wy), 7754P* (LC3 2wy), 7941P* (HD 2wy)	learn
Python	872	5202P	10A - up	7251P (LE 2wy), 7152P	7153P	7153P, 7154P, 7351P (LC 2wy), 7652P*, 7752P* (LC3 2wy), 7941P* (HD 2wy)	learn
Python	880XP	554P	All	478P (LCD 2wy) (NLA)	479P (LCD 2wy), 472P (NLA)		learn
Python	881XP	564P	All	479P (LCD 2wy)	472P (NLA)		learn
Python	900	3301P	All	489P (LCD 2wy), 474P	487P (LED 2wy), 473P, 471C	7341P, 7141P, 7142P, 488T	learn

Directed TX Cross Reference

Python	902	3302P	All	489P (LCD 2wy), 7141P	474P, 473P, 471C	7341P, 7142P, 488T	learn
Python	950	4301P	All	7701P (LCD 2wy)	7701P (LCD 2wy), 7642P		learn
Python	951	4702P	All	7752P (LC3 2wy), 7652P	7752P (LC3 2wy), 7652P		learn
Python	990	5301P	All	7701P (LCD 2wy)	7701P (LCD 2wy), 7642P		learn
Python	991	5702P	All	7752P, 7652P	7752P (LC3 2wy), 7652P	7654P, 7754P, 7652P, 7941P (HD 2wy)	learn
Python	1000 HF	268P	4F-4H	491T (NLA)	485M, 491C (NLA)		learn
Python	1000 HF	438P	4G - 8B (a)	491T (NLA)	485M, 491C (NLA)		learn
Python	1000 HF	438P	8B - up	471T	474P, 473P, 471C	7141P, 7142P	learn
Python	PC 1000 HF(ESP)	439P	7J - up	475T (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	1090	5501P	All	7541P (OLED 2wy) (NLA)	7141P, 474P, 473P, 471C	7142P	learn
Python	1200 HP	561P	All	473P	473P, 471C (limited operation)		learn
Python	1400XP	562P	All	474P	473P, 471C	7141P, 7142P	learn
Python	1400 XPL	562PL	All	7641P (NLA)	7641P		learn
Python	1401	4102P	up to 9K	7153P	7153P	7152P, 7251P* (LE 2wy), 7254P* (LE 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	1401	4102P	9J - up	7153P	7153P	7152P, 7251P* (LE 2wy), 7254P* (LE 2wy), 7351P* (LC 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	1500 HF	553P	5J - 7C	491T (NLA)	485M, 491C (NLA)		learn
Python	1500 HF	553P	7C - 7L	485T (NLA)	485M, 491C (NLA)		learn
Python	1500 HF	553P	8D - 8I	475T (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	1500 HF(ESP)	553P	9B - up	475Q (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	1600 XP	563P	All	474P	473P, 471C	7141P, 7142P	learn
Python	1601	5102P	up to 9K	7153P	7152P	7152P, 7251P* (LE 2wy), 7652P*, 7752P* (LC3 2wy), 7941P* (HD 2wy)	learn
Python	1601	5102P	9J - up	7153P	7152P	7152P, 7251P* (LE 2wy), 7254P* (LE 2wy), 7351P* (LC 2wy), 7652P*, 7654P*, 7752P* (LC3 2wy), 7754P* (LC3 2wy), 7941P* (HD 2wy)	learn
Python	2000 HF	371P	6A - 6F	485T (NLA)	485M, 491C (NLA)		learn
Python	3000 HF	381P	5H - 6H	485T (NLA)	485M, 491C (NLA)		learn
Python	3000 HF	381P	6I - 7E	485T (NLA)	485M, 491C (NLA)		learn
Python	3000 HF	381P	7F - 7L	485T (NLA)	485M, 491C (NLA)		learn
Python	PC 3000 HF	381P	8B - 8G	475T (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	PC 3000 HF(ESP)	381P	9A - up	475Q (NLA)	474P, 473P, 471C	7141P, 7142P	learn
Python	PS3000	PS3000	All	No remote	No remote	can add 9474T	learn
Python	PS5000	PS5000	All	474P	474P	7142P, 7141P	learn
Python	4106P	4106P	All	7154P	7154P	7153P, 7152P, 7251P* (LE 2wy), 7254P* (LE 2wy), 7351P* (LC 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	4206P	4206P	All	7254P (LE 2wy), 7154P	7254P (LE 2wy), 7154P	7153P, 7152P, 7251P (LED 2wy), 7351P (LCD 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	4706P	4706P	All	7754P (LC3 2wy), 7654P	7754P (LC3 2wy), 7654P	7652P, 7752P, 7941P (HD 2wy)	learn
Python	5106P	5106P	All	7154P	7154P	7153P, 7152P, 7251P* (LE 2wy), 7254P* (LE 2wy), 7351P* (LCD 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC2 2wy)	learn
Python	5206P	5206P	All	7254P (LE 2wy), 7154P	7254P (LE 2wy), 7154P	7153P, 7152P, 7251P (LE 2wy), 7351P (LC 2wy), 7652P*, 7654P*, 7941P* (HD 2wy), 7752P* (LC3 2wy), 7754P* (LC3 2wy)	learn
Python	5706P	5706P	All	7754P (LC3 2wy), 7654P	7754P (LC3 2wy), 7654P	7652P, 7752P, 7941P (HD 2wy)	learn
Python	5906P	5906P	All	7941P (HD 2wy), 7654P	7941P (HD 2wy), 7654P	7652P, 7754P (LC3 2wy)	learn

\* With upgraded IVU

**Python RSR/RXT Kits**

Python	4108P	4108P	All	7153P			learn
Python	4218P	4218P	All	7211P			learn

Directed TX Cross Reference

Python	4208P	4208P	All	7251P (LE 2wy), 7153P			learn
Python	4708P	4708P	All	7752P (LC3 2wy), 7654P			learn
Python	9211PL	9211PL	All	7211P			learn
Python	9153PL	9153PL	All	7153P	7152P	7152P	learn
Python	9251PL	9251PL	All	7251P (LE 2wy)	7152P, 7153P	7152P, 7153P	learn
Python	9752PL	9752PL	All	7752P (LC3 2wy)	7652P	7652P	learn

**Pro Guard**

Pro Guard	2300	723G	6D - 6F	493T	None		scratch
Pro Guard	2500	725G	ALL	491T (NLA)	485M, 491C (NLA)		learn
Pro Guard	4700	437B	5B - 5G	493C	493T, 484T		learn
Pro Guard	4800	438B	5B - 5H	493C	493T, 484T		learn
Pro Guard	7100	271B	2L - 5A	493C	493T, 484T		learn

**Rattler**

Rattler	100	411R	All	471T	473T, 471C	474T*	learn
Rattler	110D	312R	All	473R	473T, 471C		learn
Rattler	200	421R	All	471T	473T, 471C	474T*	learn
Rattler	210D	322R	All	473R	473T, 471C		learn
Rattler	250	425R	All	471T	473T, 471C		learn
Rattler	259D	259R	All	471T	473T, 471C		learn
Rattler	300	431R	All	471T	473T, 471C		learn
Rattler	310D	332R	All	473R	473T, 471C		learn
Rattler	359D	359R	All	471T	473T, 471C		learn
Rattler	369D	369R	All	473R	473T, 471C		learn

\* Auto learn feature not available with 4 button remote and 1 button on the remote will have no function.

**Ready Remote (Non-DIY)**

Ready Remote	4103R	4103R	All	7143R	7111R		learn
Ready Remote	4113R	4113R	All	7111R	7143R		learn
Ready Remote	5103R	5103R	All	7143R			learn

**Sidewinder**

Sidewinder	1000	718B	3K	No Longer Available	None		N/A
Sidewinder	2000	719B	3K	493T	None		scratch
Sidewinder	2200	721B	3K - 5F	493T	None		scratch
Sidewinder	3000	720B	3K - 4H	493T	None		scratch
Sidewinder	3000 HF	410S	8G - up	471T	474T, 473T, 471C		learn
Sidewinder	3200	722B	3K	493T	None		scratch
Sidewinder	3200 HS	416S	All	474S (NLA)	474T, 473T, 471C		learn
Sidewinder	3300 HS	426S	All	473S (NLA)	474T, 473T, 471C		learn
Sidewinder	3500	552S	7H - 8L	491T (NLA)	485M		learn
Sidewinder	3500 ESP	552S	9B - 0H	471T	474T, 473T, 471C		learn
Sidewinder	3500 ESP	552S	0I - up	476S	474T, 473T, 471C		learn
Sidewinder	4200	420B	2K - 5F	493T	None		scratch
Sidewinder	4200	420S	5B - 5F	493T	None		scratch
Sidewinder	4500 HF	430S	8D - up	471T	474T, 473T, 471C		learn
Sidewinder	5000	432S	5L - 7E	493C	493T, 484T		learn
Sidewinder	5000 HF	432S	7F - 8B	491T (NLA)	485M, 491C (NLA)		learn
Sidewinder	5000 HF	432S	8B - up	471T	474T, 473T, 471C		learn
Sidewinder	5000 HF(ESP)	429S	9A - up	471T	474T, 473T, 471C		learn
Sidewinder	5200	430S	2H - 4E	493T	None		scratch
Sidewinder	5200 XS	436S	All	474S (NLA)	474T, 473T, 471C		learn
Sidewinder	6000	435B	2L - 4F	493T	None		scratch
Sidewinder	6000	437S	4J - 6H	493C	493T, 484T		learn
Sidewinder	6000	437S	6I - 7E	493C	493T, 484T		learn
Sidewinder	6000 HF(2 btn)	437S	7F - 7I	491T (NLA)	485M, 491C (NLA)		learn
Sidewinder	6000 HF	438S	4J - 8B (a)	491T (NLA)	485M, 491C (NLA)		learn
Sidewinder	6000 HF	438S	8D - up	471T	474T, 473T, 471C		learn
Sidewinder	PC 6000 HF	439S	8B - up	475T (NLA)	474T, 473T, 471C		learn

Directed TX Cross Reference

Sidewinder	6100	440B	2L - 3D	493T	None	scratch
Sidewinder	6200	445B	2L - 4H	493T	None	scratch
Sidewinder	6500 HF	553S	5K - 6H	491T (NLA)	485M, 491C (NLA)	learn
Sidewinder	6500 HF	553S	7A - 8B	485T (NLA)	485M, 491C (NLA)	learn
Sidewinder	6500 HF	553S	8D - 8I	475T (NLA)	474T, 473T, 471C	learn
Sidewinder	6500 HF(ESP)	553S	9B - up	475Q (NLA)	474T, 473T, 471C	learn
Sidewinder	7000 HF	381S	5H - 6H	485T (NLA)	485M, 491C (NLA)	learn
Sidewinder	7000 HF	381S	6I - 7C	485T (NLA)	485M, 491C (NLA)	learn
Sidewinder	7000 HF	381S	7D - 7H	485T (NLA)	485M, 491C (NLA)	learn
Sidewinder	PC 7000 SHF	381S	TBA	475Q (NLA)	474T, 473T, 471C	learn
Sidewinder	7100	271B	2L - 5A	484T	493C, 493T	learn
Sidewinder	7200	281B	All	484T	493C, 493T	learn

**Steal Stopper**

Steal Stopper	50	220S	All	465T	None	scratch
Steal Stopper	50/S	221S	All	465T	None	scratch
Steal Stopper	60	225S	Up to 2E	465T	None	scratch
Steal Stopper	60	261S	2E - 2I	493T	None	scratch
Steal Stopper	60/S	226S	All	465T	None	scratch
Steal Stopper	70	271S	Up to 2E	465T	None	learn
Steal Stopper	70	271S	2F - 2J	493T	484T	learn
Steal Stopper	80	281S	EZS4CXDEI235	465T	None	learn
Steal Stopper	80	281S	EZSDEI280	493T	484T	learn
Steal Stopper	90	291S	2E - 2J	484T	None	learn
Steal Stopper	1000	SS1000	All	465T	None	scratch
Steal Stopper	2000	SS2000	All	No remote/NOT RF	None	N/A
Steal Stopper	PRO 3000	SS3000	All	No remote/NOT RF	None	N/A
Steal Stopper	PRO 4000	SS4000	All	No remote/NOT RF	None	N/A
Steal Stopper	PRO 5000	SS5000	All	465T (optional)	None	scratch
Steal Stopper	6001	SS6001	All	No remote/NOT RF	None	N/A

**Stinger**

Stinger	W/515R	438K	8K	471T	474S, 473S, 471C	learn
Stinger	Keyless entry	711K	8K	471T	474S, 473S, 471C	learn
Stinger	W/514T	438J	8K	471T	474S, 473S, 471C	learn

**Wasp**

Wasp	718W	718W	3F - 3H	NLA	None	N/A
Wasp	718W	718W	4/95 - 5/95	NLA	None	N/A
Wasp	718W	718W	6/95 - 10/95	465T	None	learn
Wasp	718W	718W	6F - 7C	493C	None	learn
Wasp	718W	718W	7D - up	491T (NLA)	485M, 491C (NLA)	learn

**Valet**

Valet	450T	450T	6D - up	No remote/ NOT RF	N/A	N/A
Valet	450R	450R	6D - 6I	485T (NLA)	485M	learn
Valet	450R	450R	8C - 8E	475T (NLA)	474T, 473T, 485M	learn
Valet	519T	519T	2J - 5J	465T / 493C	493T, 484T	learn
Valet	519T	519T	6A - up	493C	493T, 484T	learn
Valet	519H	519H	5A - 8H	491T (NLA)	485M, 491C (NLA)	learn
Valet	519H	519H	8K - up	471T	474T, 473T, 471C	learn
Valet	519H2	519H2	All	see install guide for TX & RX application	see install guide for TX & RX application	learn
Valet	550T	550T	All	No remote/ NOT RF	N/A	N/A
Valet	551R	551R	7G - 9A	491T (NLA)	485M, 491C (NLA)	learn
Valet	551R	551R	9B - up	471T	471C, 473T	learn
Valet	551T	551T	All	No remote/ NOT RF	N/A	N/A
Valet	552T	552T	4I - 7C	491T (NLA)	485M, 491C (NLA)	learn
Valet	552T	552T	7G - 8J	490T (NLA)	485M, 491C (NLA)	learn
Valet	552T	552T	9A - up	471T	471C, 473T, 474T	learn
Valet	554R	554R	All	477T (LCD 2wy), 474T	473T, 471C	learn

Directed TX Cross Reference

Valet	561T	561T	All	No remote/ NOT RF	473T *		learn
Valet	561R	561R	All	473T	473T, 471C (limited operation)		learn
Valet	562T	562T	All	474T	473T, 471C		learn
Valet	563T	563T	All	474T	473T, 471C		learn
Valet	710T	710A	5J - 6F	493C	493T, 484T		learn
Valet	710T	710T	6G - 7D	492C	493T, 484T		learn
Valet	710T	710T	7E - up	491T (NLA)	485M, 491C (NLA)		learn
Valet	711T	711T	2C - 5K	465T	None		scratch
Valet	711T	711T	7E - up	491T (NLA)	485M, 491C (NLA)		learn
Valet	712T	712T	2J - 7D	465T	None		scratch
Valet	712T	712T	4K - up	474T	473T, 471C		learn
Valet	716T	716T	All	474T	473T, 471C		learn

\*Need to add an external receiver to use aftermarket remotes

**Viper**

Viper	Viper ResponderOne	4203V	All	7211V (LED 2wy)	7211V (LED 2wy)		learn
Viper	50	405V	All	No remote/NOT RF	None		N/A
Viper	100	410V	All	465T	None		scratch
Viper	100 HF (ESP)	410V	8G - up	471T	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	130 XV	561V	All	473V	473V, 471C (limited operation)		learn
Viper	150	715V	All	465T	None		scratch
Viper	150 HF	552V	7H - 8L	491T (NLA)	485M, 491C (NLA)		learn
Viper	150 ESP	552V	9C - 0H	471T	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	150 ESP	552V	0I - up	476V	474V, 473V, 471C	7145, 7141V, 7142V	learn
Viper	160 XV	562V	All	474V	473V, 471C	7145V, 7141V, 7142V	learn
Viper	160 XVL	562VL	All	7641V (NLA)	7641V		learn
Viper	200	420V	Up to 2B	465T	None		scratch
Viper	200	420V	2C - 5J	493T	None		scratch
Viper	200	122V	0D - up	470T	471C		learn
Viper	201	201V	All	465T	None		scratch
Viper	210 HV	416V	All	474V	473V, 471C	7145V, 7141V, 7142V	learn
Viper	211HV	412V	All	474V	473V, 471C	7145V, 7141V, 7142V	learn
Viper	C 30	430C	2D - 5B	493T	None		scratch
Viper	300	430V	Up to 2B	465T	None		scratch
Viper	300	430V	2C - 7E	493T	None		scratch
Viper	300 HF	430V	7G - 8B (a)	491T (NLA)	485M, 491C		learn
Viper	300 HF	430V	8B - 9A	471T	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	PC 300 HF (ESP)	429V	All	471T	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	300+	432V	5L - 7E	493C	493T,484T		learn
Viper	300+	432V	7F - 8B (a)	491T (NLA)	485M, 491C (NLA)		learn
Viper	300+ HF	432V	8B - 9B	471T	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	330V	427V	All	No remote/NOT RF	474V, 473V, 471C *	7145V, 7141V, 7142V, 474T	N/A
Viper	350 Classic	330V	Up to 2A	465T	None		scratch
Viper	350 Classic	330V	2B - 4E	493T	None		scratch
Viper	350 HV	426V	All	473V	474V, 471C	7145V, 7141V, 7142V, 474T	learn
Viper	Responder 350	3305V	All	7341V (LCD 2wy), 7142V	7341V (LCD 2wy), 7142V	7345V (LCD 2wy), 7145V, 474T, 7141V, 488V (LED 2wy), 488T (LED 2wy)	learn
Viper	350+	3105V	All	7142V	7142V	7145V, 474T, 7141V	learn
Viper	400	440V	Up to 2C	465T	None		scratch
Viper	400	440V	2D - 4L	493T	None		scratch
Viper	450 Classic	340V	Up to 2G	465T	None		scratch
Viper	450 Classic	340V	2H - 4B	493T	None		scratch
Viper	500	435V	Up to 2D	465T	None		scratch
Viper	500	435V	2E - 4C	493T	None		scratch
Viper	C 50	437C	4C - 5K	493C	493T, 484T		learn
Viper	C 50	437C	5L - 6C	493C	493T,484T		learn
Viper	500+	437V	3L - 5K	493C	493T, 484T		learn
Viper	500+	437V	5L - 7E	493C	493T,484T		learn



Directed TX Cross Reference

Viper	500 HF(Code Plus)	438V	4D - 7L	491T (NLA)	485M, 491C (NLA)		learn
Viper	500 HF	438V	8B - up	471T	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	PC 500 HF (ESP)	439V	7J - up	475T	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	500 NX	436V	5G	492T	None		learn
Viper	550 Classic	335V	Up to 2C	465T	None		scratch
Viper	550 Classic	335V	2D - 4B	493T	None		scratch
Viper	550 HF	553V	5I - 6J	491T (NLA)	485M, 491C (NLA)		learn
Viper	550 HF	553V	7D - 8B	485T (NLA)	485M, 491C (NLA)		learn
Viper	550 HF	553V	8D - 9A	475T (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	550 HF (ESP)	553V	9B - up	475Q (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	560 XV	563V	All	474V	473V, 471C	7145V, 7141V, 7142V	learn
Viper	571 XV	572V	4G - 5G	487V (LED 2wy) (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	571 XV	572V	6K - up	488V (LED 2wy)	487V (LED 2wy), 488V (LED 2wy), 474V, 473V, 471C	7345V, 7145V, 7141V, 7142V, 488T (LED 2wy)	learn
Viper	591 XV	542V	All	479V (LCD 2wy)	472V (NLA)		learn
Viper	C 60	445C	2D - 4L	493T	None		scratch
Viper	600	445V	Up to 2B	465T	None		scratch
Viper	600	445V	2C - 5E	493T	None		scratch
Viper	600 Classic	345V	Up to 2A	465T	None		scratch
Viper	600 Classic	345V	2C - 4B	493T	None		scratch
Viper	600 HF (Code Plus)	448V	4L - 6L	491T (NLA)	485M, 491C (NLA)		learn
Viper	600 HF (Code Plus)	448V	7A - 8B (a)	485T (NLA)	485M, 491C (NLA)		learn
Viper	600 HF	448V	8B - 8L	475T (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	PC 600HF (ESP)	449V	9A - up	475Q (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	650 XV	436V	All	474V	473V, 471C	7145V, 7141V, 7142V	learn
Viper	671 XV	437V	All	487V (LED 2wy) (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	690 XV	434V	All	479V (LCD 2wy)	479V (LCD 2wy), 472V (NLA)		learn
Viper	C 70 HF	448C	5E - 6D	491T (NLA)	485M, 491C (NLA)		learn
Viper	Ultra 700	370V	Up to 2H	493T	493C, 484T		learn
Viper	Ultra 700	370V	2I - 5C	484T	493C, 493T		learn
Viper	700 HF	371V	6A - 6F	485T (NLA)	485M, 491C (NLA)		learn
Viper	700 ESP	379V	All	476V	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	771 XV	567V	4E - 4L	487V (LED 2wy) (NLA)	487V (LED 2wy), 474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	771 XV	567V	5A - 7J	488V (LED 2wy)	487V (LED 2wy), 488V (LED 2wy), 474V, 473V, 471C	7345V, 7145V, 7141V, 7142V, 488T (LED 2wy)	learn
Viper	790 XV	554V	All	478V (LCD 2wy) (NLA)	479V (LCD 2wy), 472V (NLA)		learn
Viper	791 XV	564V	All	479V (LCD 2wy)	472V (NLA)		learn
Viper	Ultra 800	380V	Up to 2D	493T	493C, 484T		learn
Viper	Ultra 800	380V	2D - 5A	484T	493C, 493T		learn
Viper	800 HF	381V	5H - 6H	485T (NLA)	485M, 491C (NLA)		learn
Viper	800 HF	381V	6I - 7B	485T (NLA)	485M, 491C (NLA)		learn
Viper	800 HF	381V	7C - 7L	485T (NLA)	485M, 491C (NLA)		learn
Viper	PC 800 SHF	381V	8B - 8F	475T (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	800 SHF ESP	381V	8G - UP	475T (NLA)	474V, 473V, 471C	7145V, 7141V, 7142V	learn
Viper	850XV	446V	All	474V	473V, 471C	7145V, 7141V, 7142V	learn
Viper	Ultra 900	390V	Up to 4L	484T	None		learn
Viper	1000	3101V	All	474V	473V, 471C	7145V, 7141V, 7142V	learn
Viper	1002	3102V	All	7141V	474V, 473V, 471C	7145V, 7142V	learn
Viper	3105V	3105V	12L - Up	7145V		474T, 473V	learn
Viper	3000	3201V	All	488V (LED 2wy), 474V	473V, 471C	7341V (LCD 2wy), 7345V (LCD 2wy), 7145V, 7141V, 7142V, 488T (LED 2wy)	learn
Viper	3002	3202V	All	488V (LED 2wy), 7141V	474V, 473V, 471C	7341V (LCD 2wy), 7345V (LCD 2wy), 7145V, 7142V, 488T (LED 2wy)	learn
Viper	3203	3203V	All	7251V (LE 2wy), 7153V	7251V (LE 2wy), 7153V	7152V, 7153V, 7254V (LE 2wy), 7351V (LC 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn
Viper	3203	3203V	12I - Up	7254V (LE 2wy), 7153V	7254V (LE 2wy), 7153V	7152V, 7251V (LE 2wy), 7351V (LC 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn

Directed TX Cross Reference

Viper	3303	3303V	All	7351V (LC 2wy), 7153V	7351V (LC 2wy), 7153V	7152V, 7251V (LE 2wy), 7254V (LE 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn
Viper	3305	3305V	12L - Up	7345V (LCD 2wy), 7145V		474T, 7141V, 488V (LED 2wy), 488T (LED 2wy)	learn
Viper	3606V	3606V	All	7656V (new RF)	7856V (LED 2wy)	7856V (LED 2wy), 7756V (LCD 2wy)	learn
Viper	3706V	3706V	All	7756V (LCD 2wy), 7656V (new RF)	7856V (LED 2wy)		learn
Viper	3806V	3806V	All	7856V (LED 2wy), 7656V (new RF)	7756V (LCD 2wy)		learn
Viper	3305V	3305V	All	7345V (LCD 2wy), 7145V		474T, 473V	learn
Viper	3901V	3901V	All	None/uses fac remote	Factory OEM Remote		N/A
Viper	3902V	3902V	All	None/uses fac remote	Factory OEM Remote		N/A
Viper	3903V	3903V	All	None/uses fac remote	Factory OEM Remote		N/A
Viper	4103XV	4103V	All	7142V	7142V	7145V, 474T, 7141V	learn
Viper	4104	4104V	All	7153V	7152V	7152V, 7254V* (LE 2wy), 7153V*, 7251V*, 7351V* (LC 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), G4317941V* (HD 2wy), 7944V* (HD 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn
Viper	4105V	4105V	All	7145V		7111V	learn
Viper	4115V	4115V	All	7111V		7145V	learn
Viper	4204	4204V	All	7251V (LE 2wy), 7152V	7153V	7153V, 7254V (2wy), 7351V (LC 2wy), 7652V*, 7654V*, 7752V* (2wy), 7941V* (HD 2wy), 7944V* (HD 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn
Viper	4204	4204V	12J - Up	7254V (LE 2wy), 7153V	7153V	7152V, 7251V (LE 2wy), 7351V (LC 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn
Viper	4205V	4205V	All	7211V (LED 2wy)	7211V (LED 2wy)		learn
Viper	4606V	4606V	All	7656V (new RF)	7756V (LCD 2wy), 7856V (LED 2wy)		learn
Viper	4704	4704V	All	7752V (LC3 2wy), 7652V	7752V (LC3 2wy), 7652V	7654V, 7941V (HD 2wy), 7944V (HD 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn
Viper	4704	4704V	12J - Up	7752V (LC3 2wy), 7654V	7752V (LC3 2wy), 7654V	7652V, 7941V (HD 2wy), 7944V (HD 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn
Viper	4706V	4706V	All	7756V, (LCD 2wy), 7656V (new RF)	7856V (LED 2wy)		learn
Viper	4806V	4806V	All	7856V (LED 2wy), 7656V (new RF)	7756V (LCD 2wy)		learn
Viper	5000	3301V	All	489V (LCD 2wy), 474V	473V, 471C	7341V, 488V (LED 2wy), 7145V, 7141V, 7142V, 488T (LED 2wy), 7354V (LCD 2wy), 7145V	learn
Viper	5002	3302V	All	489V (LCD 2wy), 7141V	474V, 473V, 471C	7341V, 488V (2wy), 7145V, 7142V, 488T (2wy), 7345V (2wy), 7145V	learn
Viper	5101	4102V	All	7153V	7152V	7152V, 7251V* (LE 2wy), 7254V (LE 2wy), 7652V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy)	learn
Viper	5101	4102V	9J - up	7153V	7152V	7152V, 7251V* (LE 2wy), 7254V (LE 2wy), 7351V* (LC 2wy), 7652V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy)	learn
Viper	5104	5104V	All	7153V	7152V	7152V, 7251V* (LE 2wy), 7254V* (LE 2wy), 7351V* (LC 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V** (HD 2wy) -- 7656V**, 7856V (LED 2wy)**, 7756V (LCD 2wy)**	learn

Directed TX Cross Reference

Viper	5204	5204V	All	7251V (LE 2wy), 7152V	7153V	7153V, 7254V (LE 2wy), 7351V (LC 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5204	5204V	12J - Up	7254V (LE 2wy), 7153V	7153V	7152V, 7251V (LE 2wy), 7351V (LC 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5301	4202V	Up to 9H	7251V (LE 2wy), 7152V	7153V	7153V, 7254V (LE 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy)	learn
Viper	5301	4202V	9I - Up	7251V (LE 2wy), 7152V	7153V	7153V, 7254V (LE 2wy), 7351V (LC 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy)	learn
Viper	5500	4301V	All	7701V (LCD 2wy)	7701V (LCD 2wy), 7642V (NLA)		learn
Viper	5501	4702V	All	7752V (LC3 2wy), 7652V	7752V (LC3 2wy), 7652V	7654V, 7652V, 7941V (HD 2wy), 7944V (HD 2wy)	learn
Viper	5601	5102V	Up to 9K	7153V	7152V	7152V, 7251V* (LE 2wy), 7254V* (LE 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5601	5102V	9L - up	7153V	7152V	7152V, 7251V* (LE 2wy), 7254V* (LE 2wy), 7351V*, 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy)	learn
Viper	5606V	5606V	All	7656V (new RF)	7856V (LED 2wy), 7756V (LCD 2wy)		learn
Viper	5701	5202V	Up to 9J	7251V (LE 2wy), 7152V	7153V	7153V, 7254V (LE 2wy), 7652V*, 7654V*, 7752V* (LC3 2wy), 7941V* (HD 2wy), 7944V* (HD 2wy)	learn
Viper	5701	5202V	9K - Up	7251V (LE 2wy), 7152V	7153V	7153V, 7254V (2wy), 7351V (LCD 2wy), 7652V*, 7654V*, 7752V* (2wy), 7941V* (HD 2wy), 7944V* (HD 2wy)	learn
Viper	5704	5704V	All	7752V (LC3 2wy), 7652V	7752V (LC3 2wy), 7652V	7654V, 7941V (HD 2wy), 7944V (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5704	5704V	12K - Up	7752V (LC3 2wy), 7654V	7752V (LC3 2wy), 7654V	7654V, 7652V, 7941V (HD 2wy), 7944V (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5706V	5706V	All	7756V, (LCD 2wy), 7656V (new RF)	7856V (LED 2wy), 7756V (LCD 2wy)		learn
Viper	5806V	5806V	All	7856V (LED 2wy), 7656V (new RF)	7756V (LCD 2wy)		learn
Viper	5900	5301V	All	7701V (LCD 2wy)	7701V (LCD 2wy), 7642V		learn
Viper	5901	5702V	All	7752V (LC3 2wy), 7652V	7752V (LC3 2wy), 7652V	7654V, 7652V, 7941V (HD 2wy), 7944V (HD 2wy)	learn
Viper	5902	5902V	All	7941V (HD 2wy), 7652V	7941V (HD 2wy), 7652V	7752V (LC3 2wy), 7944V (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5904	5904V	All	7941V (HD 2wy), 7652V	7941V (HD 2wy), 7652V	7654V, 7752V (LC3 2wy), 7944V (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5904	5904V	12I - Up	7941V (HD 2wy), 7654V	7941V (HD 2wy), 7654V	7652V, 7752V (LC3 2wy), 7944V (HD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	5906V	5906V	All	7944V (HD 2wy), 7654V		7941V (HD 2wy), 7652V, 7752V (LCD 2wy) -- 7656V**, 7856V (LED 2wy)***, 7756V (LCD 2wy)**	learn
Viper	7900	5501V	All	7541V (OLED 2wy) (NLA)	7141V, 474V, 473V, 471C	7145V, 7142V	learn
Viper	Vss3000	Vss3000	All	No remote		can add 9474T	learn
Viper	Vss4000	Vss4000	All	7153V	7153V		learn
Viper	Vss5000	Vss5000	All	474V	474V	7145V, 7142V, 7141V	learn

\* With upgraded IVU \*\* With upgraded IVU and cable (new RF)

Viper RSR/RXT Kits

Viper	4108V	4108V	All	7153V			learn
Viper	4218V	4218V	All	7211V (LED 2wy)			learn

Directed TX Cross Reference

Viper	4208V	4208V	All	7251V (LE 2wy), 7153V		7254V (LE 2wy)	learn
Viper	4708V	4708V	All	7752V (LC3 2wy), 7654V			learn
Viper	9211VL	9211VL	All	7211V (LED 2wy)			learn
Viper	9153VL	9153VL	All	7153V	7152V	7152V	learn
Viper	9251VL	9251VL	All	7251V (LE 2wy)	7152V, 7153V	7254V (LE 2wy), 7152V, 7153V	learn
Viper	9752VL	9752VL	All	7752V (LC3 2wy)	7652V	7654V, 7652V	learn

**RF Kits (New RF)**

Viper	9656V	9656V	All	7656V (new RF)		7756V (LCD 2wy), 7856V (LED 2wy)	
Viper	9756V	9756V	All	7756V (LCD 2wy), 7656V (new RF)		7856V (LED 2w)	
Viper	9856V	9856V	All	7856V (LED 2wy), 7656V (new RF)		7756V (LCD 2wy)	

**Designtech**

Designtech	20095	564A		477T (LCD 2wy), 474T	23361		
Designtech	20930			20069			
Designtech	23739			26671			
Designtech	23926			26662			
Designtech	23927			26671			
Designtech	24921			23161			
Designtech	24923			23161			
Designtech	24926			26161			
Designtech	24927			26171			
Designtech	25622			no remote			
Designtech	28622			no remote			
Designtech	28623			28861			
Designtech	28624			28871			
Designtech	40026			24461			
Designtech	40027			24471			
Designtech	41026			24161			
Designtech	41027			24171			

**Autostart**

Autostart USA	AS-3472TW-FM			ASRF5603BC	ASRF5603BC, ASRF1501BK (1way)		
Autostart USA	AS-3372TW-FM			ASRF3503BK	ASRF3503BK, ASRF1501BK(1way)		
Autostart USA	AS-2775			ASRA2503BK	ASRA2503BK		
Autostart USA	AS-2272			ASRA2202BK	ASRA2202BK		
Autostart USA	AS-6850vTW-FM				ASRF-6601BK LCD, ASTR-2545		
Autostart USA	AS-6450vTW-FM				ASTR-5500 LED, ASTR-2545FM		
Autostart USA	AS-6250V				ASRA-2501G		
Autostart USA	AS-2450vTW-FM				ASRF-5602G LCD, ASTR-2545FM		
Autostart USA	AS-2350vTW-FM				ASRF-3501G LED, ASTR-2545FM		
Autostart USA	AS-1755v				ASRA-2501G		
Autostart USA	AS-1452v				ASRA-2402BK		
Autostart USA	ASL-550TW-FM				ASRF-6601BK LCD, ASTR-2545		
Autostart USA	ASL-350				ASRA-2402BK		
Autostart Canada	AS-6850TW-FM				ASRF-6601BK LCD, ASTR-2545FM		
Autostart Canada	AS-6450TW-FM				ASTR-5500 LED, ASTR-2545FM		
Autostart Canada	AS-6270				n/a		
Autostart Canada	AS-6250				ASRA-2501G		
Autostart Canada	AS-2451TW-FM				ASRF-5602G LCD		
Autostart Canada	AS-2450TW-FM				ASRF-5501G LCD		
Autostart Canada	AS-2400TW-FM				ASRF-5501G LCD		
Autostart Canada	AS-2350TW-FM				ASRF-3501G LED		
Autostart Canada	AS-2310TW-FM				ASRF-3501G LED		
Autostart Canada	AS-1855				ASTR-2545 FM		
Autostart Canada	AS-1835				ASTR-2545 FM		
Autostart Canada	AS-1775				n/a		
Autostart Canada	AS-1757				ASTR-5147 AM		

Directed TX Cross Reference

Autostart Canada	AS-1727	ASTR-5147 AM
Autostart Canada	AS-1755	ASRA-2501G
Autostart Canada	AS-1735	ASRA-2501G
Autostart Canada	AS-1454	ASRA-2402BK
Autostart Canada	AS-1455	ASRA-2402BK
Autostart Canada	AS-1451iHF	ASTR-B274
Autostart Canada	AS-1452iHF	ASTR-B274
Autostart Canada	AS-1414iHF	ASTR-B274
Autostart Canada	AS-1424iHF	ASTR-B274
Autostart Canada	AS-1271	n/a
Autostart Canada	AS-1272	n/a
Autostart Canada	AS-1251	ASRA-2201G
Autostart Canada	AS-1252	ASRA-2201G
Autostart Canada	AS-1221	ASRA-2201G
Autostart Canada	ASL-550TW-FM	ASRF-6601BK LCD, ASTR-2545
Autostart Canada	ASL-350	ASRA-2402BK