



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1010	6615-01-248-0835	GYROSCOPE RATE
2100	6635-01-127-4653	TESTER, ULTRASONIC
2145	6610-01-160-6585	INDICATOR, VERTICAL VELOCITY
6504	6695-01-097-0441	TESTER, OXYGEN MASK
8465	6685-01-311-5141	PRESSURE TRANSMITTER
10700	6610-00-181-2539	ACCELEROMETER
11700	6615-01-059-7909	RATE GYRO
13930	4810-00-717-5076	VALVE, LINEAR
38704	6615-01-078-4943	RATE SENSOR UNIT
44143		PUMP FUEL METERING AND DISTRIBUT
47418	2925-01-206-5230	DUAL IGNITER EXCITER LH, RH
55113	4320-00-062-0511	HYDRAULIC PUMP
55331	4320-00-062-0511	HYD PUMP
56020		AUXILIARY AC MOTOR
57420	1650-00-866-8193	VALVE ASSEMBLY
57520	4820-01-053-7753	VALVE ASSEMBLY
57640	1620-01-054-0042	STEERING UNIT, A/C NOSE WHEEL
60814	2995-01-060-8514	VALVE
60957	2915-01-041-4481	FUEL FLOW PROPORTION
65029	4320-00-451-5511	HYDRAULIC PUMP
65054	4320-00-162-3917	HYDRAULIC PUMP
101597	6625-01-124-0226	MICROWAVE FREQUENCY MULTIPLIER
122000	6685-01-052-5353	SENSOR DIFFERENTIAL
122100	4820-00-393-6186	VALVE ASSY
126460	6605-01-058-0975	IND HORIZONTAL SITUATION
126461		INDICATOR, HORIZONTAL
135070	6610-01-132-1898	INDICATOR, ATTITUDE
150620	5895-00-539-1911	APX 101 IFF RECEIVER TRANSMITTER
154000	5895-01-112-6380	RECEIVER-TRANSMITTER, RADIO
163300	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
163350	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
164750	5895-01-294-1053	INTERROGATOR-TRANSPONDER SET
168940		POWER SUPPLY ASSEMBLY
168960	6150-12-198-3190	TRANSMITTER ASSEMBLY
229235	4810-01-035-2340	VALVE, REGULATING, FL
234755	4810-01-456-0377	VALVE, BUTTERFLY
320135	4810-01-363-1952	VALVE, REGULATIN
321154	1660-00-969-9483	VALVE, AIR
323135	2995-01-227-0751	VALVE ASSEMBLY ANTI-ICING JET ENG.
327065	2995-01-364-7906	ANTI-ICE VALVE ASSY
329945	2995-01-467-1617	ANTI-ICE VALVE ASSY
400240	6645-00-076-3050	CLOCK, MECH
424047	1650-01-056-8914	MOTOR-PUMP HYDRAULIC
441083	3040-01-071-8325	ACTUATOR MECHANICAL
441085	3040-01-071-5952	ACTUATOR MECHANICAL



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
441476	2995-01-206-0648	S-F229-CONTROL-EXHAUST NOZZLE CNVRG
441533	3040-01-277-4737	ACTUATOR
441614	3040-01-324-9089	ACTUATOR
441991	2995-01-620-5459	S-F229-CONTROL-EXHAUST NOZZLE CNVRG
442115	3040-01-478-8903	ACTUATOR
472740	6680-01-060-4248	INDICATOR LIQUID QUANTITY
472887	6680-01-060-4249	FUEL QTY IND (D)
503600	4810-01-050-5843	VALVE, SHUTOFF
556563	4820-00-887-3298	DEFOG TEMP CONTROL VLV
570480	5821-00-970-6115	RADIO SET CONTROL
575210	5821-01-062-0986	VHF CONTROL PANEL
727429	1650-01-085-2887	DRIVE,CONSTANT SPEED,HYDRAULIC
734556	1650-01-145-0046	DRIVE,CONSTANT SPEE
737060	1650-01-167-8738	DRIVE,CONSTANT SPEED,HYDRAULIC
759057	2915-01-206-0686	PUMP
910094	6620-01-310-4916	LIGHT OFF DETECTOR
1112358	6105-00-838-5227	ROTOR, REWIND
2113245	6130-01-084-8523	POWER SUPPLY
2585726	6605-00-833-5087	TRANSMITTER REMOTE COMPASS
4028894	4320-00-286-0780	SCAVENGE PUMP ASSY
4046015	2935-01-007-8381	COOLER, LUBRICATING
4062403	2840-01-205-7696	DUCT, FAN, OUTER REAR
4065899	2840-01-243-2471	DUCT, FAN, OUTER FRONT
4075527	6150-01-347-9288	CABLE ASSY
4076007	2840-01-386-8242	DUCT, FAN, OUTER FRONT
4080687	2925-01-408-1480	DUAL IGNITER EXCITER LH, RH
4080993	2840-01-387-2657	DUCT, FAN, OUTER REAR
4086982	6150-01-490-4096	CABLE ASSEMBLY
4504554	2835-01-308-3769	STARTER, JET FUEL
5007076	2835-01-140-1623	GEARBOX, ENGINE STARTING
5902453	4810-01-086-5757	SERVO VALVE, PRESSURE
5902924		JET FUEL STARTER
5914011	2835-01-308-3769	STARTER, JET FUEL
7649675	1660-01-046-0943	HEAT EXCHANGER
12607535	1280-01-126-0079	RADAR SET SUBASSEMBLY
12609185	1280-01-126-0079	RADAR SET SUBASSEMBLY
12609799	6625-01-0097WF	FREQ. SYNTHESIZER
26130010	4810-00-987-3948	VALVE, SHUTOFF
7461402002	5998-01-256-3428	CIRCUIT CARD ASSEMBLY
01-01375-002	5985-01-294-9788	ANTENNA 1 ELECTRONICS ASSEMBLY
01-01375-002A	5985-01-294-9788	ANTENNA 1 ELECTRONICS ASSEMBLY
01-01375-003	5985-01-352-9699	ELECTRONIC UNIT, GLOBAL
0103190-07	1680-01-053-0071	REEL SHOULDER
02-1300	1610-01-052-0823	ACTUATOR,HYD, A/R
0411079-001	1650-01-198-2107	HYDRAULIC SERVOVALVE



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
10-0020-0013		OXYGEN CONVERTER
10-01126-07	6130-01-914-2914	POWER SUPPLY- DED
10-01128-07		DISPLAY HEAD ASSY AND/OR DATA DISPLAY
1003001G-21	5895-01-443-9174	TRANSPONDER SET
101-00169		BARFIELD PITOT STATIC TEST
102108-16-1	1660-00-492-7990	REGULATOR,AIR PRESS
102108-18		CABIN AIR PRESS REG VLV
102108-18-1	1660-01-052-6752	Regulator, Air Pressure
102108-19-1	1660-01-039-7911	REGULATOR,AIR PRESS
102200-236		CHECK VALVE
102200-237		VALVE, CHECK
102200-3802		VALVE, BUTTERFLY
102200-3803		VALVE, BUTTERFLY
102200-3804		VALVE MOTOR OPERATED
102200-4060		VALVE ASSY
102200-4070		VALVE, SOLENOID
102200-5091		VALVE CHECK
102200-5121		VALVE, BLEED AIR VARIABLE
102200-597		CHECK VALVE
102200-598		VALVE, REGULATOR
103146-7-1	1660-01-060-2834	VALVE ASSEMBLY,ENVI
103146-7-2	1660-01-134-4414	VALVE ASSEMBLY,ENVI
10-621125-1		IGNITION LEAD
10C-0020-6	1660-00-327-7048	LIQUID OXYGEN CONVERTER
10C-0020-9	6130-00-327-7048	CONVERTER LOX
11144-4		MONITOR FREQUENCYS
11200-10	4810-01-178-0432	VALVE
11214-1	4810-01-135-1673	MODULATING VALVE
11216-1	4810-01-122-2572	VALVE ASSEMBLY
11217-1	1660-01-134-3020	SENSOR /CONTROLLER
11217-2	1660-01-196-5999	SENSOR /CONTROLLER
11221-4		EFCS
11224-4	6130-01-140-2238	POWER SUPPLY
1211176-001	1650-01-046-5759	CYLINDER ASSEMBLY,A
1211176-002	1650-01-129-5004	CYLINDER ASSY,ACT
1211176-003	1650-01-417-6406	CYLINDER ASSEMBLY,A
1211178-005	1650-01-042-3259	ACT SPD BRK LH
1211178-006	1650-01-040-8468	ACTUATOR
1211178-007	1650-01-042-3259	ACTUATOR, SPEED BRAKE LH
1211178-008	1650-01-040-8468	ACTUATOR, SPEED BRAKE RH
1211179-001	1650-01-058-8553	CYLINDER ASSEMBLY,A
1211179-002	1650-01-129-7553	CYLINDER ASSEMBLY,A
1211179-003	1650-01-417-8525	ACTUATORS HYD.NOSE GEAR DOOR
1211180-001		ACTUATOR, NLG GEAR
1211180-002	1620-01-058-6153	NLG RET/EXT ACTUATOR



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1211180-003	1620-01-125-1559	CYLINDER AND PIS
1211180-004	1650-01-417-9655	CYLINDER ASSEMBLY ACTUATING LINE
1211262-003	1650-01-278-5720	CYLINDER ASSEMBLY,A
1211262-004	1650-01-300-4351	CYLINDER ASSEMBLY,A
1211262-005		ACTUATOR MLG-RH DOOR UPLOCK
1211262-006	1650-01-417-8523	ACTUATOR MLG-LH DOOR UPLOCK
12117-000	2935-01-085-2864	HEAT EXCHANGE FUEL
1218-73-3	6685-01-231-2404	EPU INDICATOR
12604334-1	6625-01-124-0226	MULTIPLIER ELECTRICAL
1281B2	6685-01-042-7835	PNEUMATIC SENSOR ASSY
1325-1	6130-01-342-7708	POWER SUPPLY
135070-5	6610-01-550-7794	ATTITUDE INDICATOR
1356-583324M1	1650-01-056-7136	FLT CTL ACCUMULATOR
13C13602E01	4810-01-340-6457	SHUTOFF VALVE
1437-2		GAGE PRESSURE SWITCH
14-43260-501	1650-01-003-0724	CYLINDER PITCH ACTUATOR
14-51100-1	1680-00-139-8020	GEARBOX ASSEMBLY, AIRCRAFT
1463-55F-B55-1		AIRSPEED INDICATOR
1463-55F-B55-4		MACH METER
14950-40	1660-00-169-1888	OXY.REGULATER
150-022-002	6620-01-247-7655	TRANSMITTER FUEL FLOW
150620á	5895-00-539-1911	RECEIVER-TRANSMITTER,RADIO IDENTIFICATION
160001-1100	2835-01-154-3533	JET FUEL STARTER ASSEMBLY
160001-1100A	2835-01-308-3769	ENGINE, GAS TURBINE, NONAIRCRAFT
160001-300		STARTER, JET FUEL
160001-401/1101		STARTER, JET FUEL
160001-924-03	2835-01-308-3769	JET FUEL STARTER
160034-300	2910-01-072-2709	FUEL CONTROL UNIT
160034-400		FUEL CONTROL UNIT, JFS
160333-10-01		SIG. ACQU. UNIT
16202-801		MLG BRAKE CONTROL VALVE
162B202A	6685-00-553-4726	INDICATOR
163295-0002		RECEIVER ASSEMBLY
163295-0003		RECEIVER ASSEMBLY
164-1	6680-00-753-8932	LOX QUN. IND
1646130-5	2915-01-060-6851	FUEL TRANSFER PUMP TURBINE DRIVEN
1646130-7	2915-01-235-5188	FUEL TRANSFER PUMP TURBINE DRIVEN
1646-1-7		LIGHT BALLAST
164750-0002	5895-01-436-7592	AIFF APX-109
164750-0003	5895-01-476-8255	AIFF APX-109
1647T100-13	1680-01-148-4167	ACTUATOR CANOPY
1680-4U-A2	6610-01-074-2883	RATE OF CLIMB INDICATOR
1680-4U-A3		RATE OF CLIMB INDICATOR
1685T100-3	1680-01-055-9510	ACTUATOR,ELECTRO-ME
1685T100-5	1680-01-085-4423	ACTUATOR ELECTRO-MECHANICAL LINE



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
16C0605-825	6615-01-127-3160	CONTROLLER ENGAGING AUTOMETIC
16C0650-801	6615-01-129-7445	PANEL, MANUAL TRIM
16C0705-3	6615-01-042-7834	GYROSCOPE
16C0715-1	6680-01-039-7817	ACCELEROMETOR
16C0715-3	6610-01-039-7817	ACCELEROMETER
16C0851-837	5998-01-123-0046	ELECTRONIC COMP.
16C1072-801	1680-01-133-6874	GRIP ASSY, CONTROL
16C1072-805	1680-01-251-4634	GRIP ASSY
16C1072-809	1680-01-302-1387	GRIP ASSY
16C1090-1	1680-01-263-0648	AIRCRAFT CONTROL STICK GRIP ASSEMBLY
16E10105-807	1280-01-214-0033	INTERCONNECTING
16E1039-689	6130-01-217-6548	BATTERY CONTROL ASSY
16E1073-817	1680-01-104-2514	PANEL
16E1080-807	6110-01-137-4061	PANEL ASSY
16E1081-801	6110-01-055-3507	PANEL, POWER DISTRIBUTION
16E1082-3	6220-01-051-0952	CONTROL ELECTRIC LIGHT
16E1082-5	6220-01-049-8835	PANEL INDICATING LIGHT
16E1082-801	6220-01-051-0952	CONTROL,ELECTRIC LIGHT
16E1082-803		PANEL
16E1083-803	1680-01-051-3052	PANEL POWER
16E1085-801		PANEL
16E1085-811	1680-01-317-8385	PANEAL, CONTROL ELECTRICAL
16E1132-813		LANDING GEAR CONTROL PANEL
16E1132-821		LANDING GEAR CONTROL PANEL
16E1132-823	1680-01-088-9022	LANDING GEAR CONTROL PANEL
16E1132-825		LANDING GEAR CONTROL PANEL
16E1132-827		LANDING GEAR CONTROL PANEL
16E1132-831		LANDING GEAR CONTROL PANEL
16E1132-833		LANDING GEAR CONTROL PANEL
16E1132-835		LANDING GEAR CONTROL PANEL
16E1132-837	1680-01-135-4597	LANDING GEAR PNL (FWD)
16E1156-85	6110-01-201-4072	PANEL POW DISTR
16E1163-853	1680-01-135-5211	LANDING GEAR PNL (AFT)
16E130-25	5985-01-308-1819	ANTENNA
16E1373-825	5945-01-228-3923	RELAY ASSEMBLY
16E2507-837	6110-01-292-8699	PANEL POW DISTR
16E2543-833	5945-01-181-9848	MATRIX ASSEMBLY
16E3131-11	6130-01-209-9062	POWER SUPPLY
16F8469-801	1680-01-308-7090	PANEL ASSEMBLY
16H1904-5		JFS HYDRAULIC MANIFOLD
16H1904-801	1650-01-136-3407	MANIFOLD ASSY
16H1904-803	4730-01-340-3446	JFS HYDRAULIC MANIFOLD
16L202-21	1630-01-045-4508	BRAKE CONT VALVE
16L202-3	1630-01-038-8992	MANIFOLD,FLUID,AIRC
16L202-5	1630-01-075-0563	MANIFOLD, FLUID



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
16L202-801	1630-01-084-8399	VALVE ASSEMBLY BRAKE
16M002-3	1650-01-041-0477	DRIVE UNIT HYD
16M002-5	1650-01-322-6311	DRIVE UNIT, HYDRAULIC
16M002-801	1650-01-159-0277	LEADING EDGE PDU ASSY
16M002-807	1650-01-283-4054	LEADING EDGE PDU ASSY
16M002-811	1650-01-322-6311	DRIVE UNIT, HYDRAULIC
16M002-815	1650-01-306-1268	DRIVE UNIT, HYDRAULIC
16M002-817	1650-01-564-1844	LEADING EDGE PDU ASSY
16M002-819	1650-01-368-8214	DRIVE UNIT, HYDRAULIC
16M002-821	1650-01-340-6328	DRIVE UNIT, HYDRAULIC
16P1873-813	1680-01-114-6248	GRIP ASSY
16P1873-815	1680-01-114-6249	GRIP ASSEMBLY
16P1873-833	1680-01-289-3013	GRIP ASSY
16P1873-863	1680-01-505-5328	GRIP ASSY
16P3141-805		SWITCH
16VC001001-4	6685-01-042-7835	TRANSMITTER PRESSURE (PSA)
16VC002-3	6610-01-222-6439	TRANSMITTER ANGLE OF ATTACK
16VE001001-2	6130-01-052-8225	POWER SUPPLY
16VE001001-3	6220-01-061-5713	LIGHT NAVIGATION
16VE002001-1	6680-01-060-4248	INDICATOR LIQUID QUANTITY
16VE002001-3	6680-01-060-4249	INDICATOR LIQUID QUANTITY
16VE002003-3	6680-01-074-9369	TRANSMITTER
16VE002004-2	6680-01-075-4853	TRANSMITTER LIQUID QUANTITY
16VE002006	6680-01-043-9409	TRANSMITTER,
16VE002010-3	6680-01-173-5315	TRANSMITTER LIQUID QUANTITY
16VE002010-5	6680-01-261-5242	TRANSMITTER, LIQUID
16VE002010-6	6680-01-265-2897	TRANSMITTER,
16VE003001-3	6680-01-072-2799	TRANSMITTER LIQUID QUANTITY
16VE027001	1650-01-222-3790	DRIVE, CONSTANT SPEED, HYDRAULIC
16VE027001-3	1650-01-132-2147	DRIVE, CONSTANT SPEED, HYDRAULIC
16VE027001-6	1650-01-157-1591	DRIVE, CONSTANT SPEED, HYDRAULIC
16VE038001-4	6220-01-071-8437	LIGHT ASSEMBLY INDICATOR
16VE038002	6220-01-188-9891	WARNING LIGHT
16VE038008-3	6220-01-257-4734	LIGHT ASSEMBLY INDICATOR
16VE038009-14	6220-01-477-9591	LIGHT ASSEMBLY INDICATOR
16VE228-1	1650-01-145-0046	DRIVE, CONSTANT SPEED, HYDRAULIC
16VE228-2	1650-01-228-9276	DRIVE, CONSTANT SPEED, HYDRAULIC
16VE237-21	6130-01-165-2055	POWER SUPPLY
16VE237-22	6130-01-209-9062	POWER SUPPLY
16VF001-2	6610-01-044-1860	INDICATOR ATTITUDE
16VF002-1	6610-01-114-6817	INDICATOR ANGLE
16VF003-2	6620-01-129-7247	INDICATOR ELECTRICAL
16VF005-1	6620-01-051-2045	POSITION IND.
16VH001-102	1650-01-059-6392	CYLINDER ASS
16VH001-104	1650-01-106-1594	CYLINDER ASS



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
16VH001-2	1650-01-042-3257	CYLINDER ASS
16VH001-202	1650-01-060-1272	SERVOACTUATOR ASSY
16VH001-204	1650-01-105-7111	SERVOACTUATOR ASSY
16VH001-206	1650-01-165-7203	SERVOACTUATOR ASSY
16VH001-3	1650-01-042-3258	CYLINDER ASS
16VH003001-10	2835-01-116-0006	POWER UNIT GAS TURB.
16VH003001-11	2835-01-263-9440	POWER UNIT GAS TURB.
16VH020-1	4820-01-056-9712	VALVE,THERMAL RELIEF
16VH028-1	1650-01-056-8914	MOTOR-PUMP,HYDRAULIC
16VH036-1	4320-01-162-6456	PUMP, HYDRAULIC
16VH201-2	1650-01-129-5004	MLG DOOR ACTUATOR
16VH201-7		ACTUATOR, MLG DOOR
16VH202-1	1650-01-058-8553	NLG DOOR ACTUATOR
16VH202-2	1650-01-129-7553	NLG DOOR ACTUATOR
16VH202-3	1650-01-417-8525	ACTUATOR, NLG DOOR
16VH203-3	1650-01-125-1559	NLG RET/EXT ACTUATOR
16VH203-4	1650-01-417-9655	ACTUATOR, NLG GEAR
16VH207-1	1650-01-096-4404	ACTUATOR,HYD
16VH301-1	4810-01-041-5328	VALVE, LANDING GEAR SELECTOR
16VH301-2	4810-01-041-5328	VALVE, LANDING GEAR SELECTOR
16VH301-4	4810-01-137-2476	SOLENOID VALVE
16VH302-2	4810-01-050-3369	SOLENOID VALVE
16VH302-4	4810-01-050-3369	SOLENOID VALVE
16VH307-1	1650-00-404-0445	VALVE,LINEAR,DIRECTIONAL CONTROL
16VH308-4	4810-01-073-4200	LINEAR DIRECT VALVE
16VK013001-5	1680-01-249-2355	ACTUATOR ELECTRO CANOPY
16VK013001-6	1680-01-101-4436	ACTUATOR ELECTRO CANOPY
16VK013001-7	1680-01-137-9978	ACTUATOR,ELE
16VK013001-8	1680-01-148-4167	ACTUATOR ELECTRO-MECHANICAL ROTARY
16VK013001-9	1680-01-249-2355	ACTUATOR,ELE
16VK013002-1	1680-01-055-9510	ACTUATOR,ELE
16VK013002-2	1680-01-085-4423	ACTUATOR ELECTRO
16VK013002-4	1680-01-142-8095	ACTUATOR ELECTRO-MECH
16VK062-2	1660-01-473-2858	OXYGEN SYSTEM
16VK064-2	1660-01-473-3547	CONCENTRATOR,OXYGEN,AIRCRAFT
16VL013004-1	1620-01-054-0042	NLG STEERING VALVE
16VL014002-3	1630-01-217-3142	CONTROL UNIT ANTISKID
16VM003001-4	1650-01-261-8078	ACTUATOR, HYDRO-MECHANICAL
16VM003001-5	1650-01-308-0839	ACTUATOR, HYDRO-MECHANICAL
16VM003002-1	1680-01-048-8977	ACTUATOR ELECTRO-MECHANICAL
16VM003002-5	1680-01-230-1279	ACTUATOR
16VM003002-6	1680-01-276-8711	ACTUATOR,ELECTRO-ME
16VM003005-1	1650-01-045-1019	SERVOCYLINDER
16VM003005-2	1650-01-150-8939	CYLINDER ASSY
16VM003006-4	1680-01-168-9396	ACT. ELETRO MECHANICAL LINE



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
16VM004-1	1650-01-042-3259	ACTUATOR, SPEED BRAKE LH
16VM004-5	1650-01-042-3259	ACTUATOR, SPEED BRAKE LH
16VM0046	1680-01-040-8468	CYLINDER ASSEMBLY ACTUATING LINE
16VM004-6	1650-01-040-8468	ACTUATOR, SPEED BRAKE RH
16VP005-4	2915-01-083-0431	FILTER FLUID
16VP006-3	2915-01-041-4481	PROPORTIONER FUEL PUMP
16VP009-2	4810-01-058-8666	VENT VALVE
16VP009-3	4810-01-123-7254	VENT VALVE
16VP012-3	4810-01-320-5294	BUTTERFLY VALVE
16VP100-119	2925-01-456-6010	CONTROLLER START
16VP100-58	2835-01-235-5249	ACCESSORY DRIVEGEARBOX
16VP100-76	2925-01-115-0306	CONTROLLER, JET FUEL
16VP106-2	2835-01-069-2883	TURBINE SHAFT
16VP123-2	2835-01-115-6111	SHAFT TURBINE
16VY001-4	1660-01-107-2459	COOLING TURBINE
16VY002-5	1660-01-046-0943	HEAT EXCHANGER
16VY004-4	4810-01-052-5358	VALVE,BUTTERFLY
16VY004-5	4810-01-052-5358	VALVE
16VY004-6	4810-01-142-6616	VALVE,REGULATING & SHUT-OFF
16VY004-7	4810-01-345-1092	VALVE,REGULATING & SHUT-OFF
16VY007001-4	4810-01-073-3221	VALVE, REGULATING
16VY007001-5	4810-01-075-4402	VALVE, REGULATING
16VY007001-6	4810-01-127-4626	VALVE, REGULATING
16VY007001-7	4810-01-127-4627	VALVE, REGULATING
16VY007001-8	4810-01-155-4943	VALVE ASSY
16VY007001-9	4810-01-154-3200	VALVE ASSY
16VY007002-4	4810-01-153-0975	REGULATING VALVE
16VY010003-1	4810-01-122-2572	VALVE ASSEMBLY
16VY017-4	1660-01-217-6558	REGULATOR,AIR PRESSURE,AIRCRAFT CABIN
16VY100-10	4810-01-130-7379	VALVE,REGULATING,FLUID PRESSURE
16VY102001-2	1660-01-052-5355	VALVE ASSEMBLY ENVIRONMENTAL
16VY107-1	1660-01-042-8009	SEPARATOR WATER AIR
16VY109-2	4810-01-050-5843	VALVE
16Z1450-1	1680-01-115-8047	PANEL ASSEMBLY AVTR "TCI"
18-1704		HYDRAULIC PRESSURE TRANSMITTER
18-1935	6620-00-290-6505	PRESSURE TRANSMITTER
18-1937		POSITION TRANSMITTER
18-1969-18	6695-01-525-1761	FLAP POSITION TRANSMITTER
1825-4LW		COMP & DUCT TEMP INDICATOR
182900-3	1680-01-254-0471	ACTUATOR, ELECTROMECHANICAL
19E235-2A	2835-01-115-6111	SHAFT TURBINE
200027176-10	1650-01-155-6849	NLG STEERING CYLINDER
200-069-002	6620-01-060-3086	TACH INDICATOR
200-069-003	6620-01-178-7838	TACH INDICATOR
2006003-105	1620-01-071-4803	LANDING GEAR TENSION STRUT



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
2006003-107	1620-01-441-6911	LANDING GEAR TENSION STRUT
2006016-103	1650-01-158-1285	ACTUATOR, MLG RETRACT
2006100-105	1620-01-202-3255	MLG SHOCK STRUT
2006100-107	1620-01-195-1141	LANDING GEAR RETRACTABLE
2006100-111	1620-01-296-3911	SHOCK STRUT
2006100-123	1620-01-442-0946	LANDING GEAR RETRACTABLE
200610-107	1620-01-195-1141	MLG STRUT
2006106-105	1620-01-200-7131	PISTON, LANDING GEAR STRUT
2006106-109	1620-01-442-0167	PISTON LANDING GEAR STRUT
2006322-105	1620-01-071-4841	DRAG BRACE LANDING GEAR
2006500-111	1620-01-162-7542	DRAG BRACE LANDING GEAR
2006500-117	1620-01-240-4805	DRAG BRACE LANDING GEAR
2006600-127		NLG SHOCK STRUT
2006600-129		NLG SHOCK STRUT
2006600-131		NLG SHOCK STRUT
2006600-135		NLG SHOCK STRUT
2006600-139		NLG SHOCK STRUT
2006600-143	1620-01-225-5457	NLG SHOCK STRUT
2006600-147		NLG SHOCK/STRUT ASSY.
2006600-151		NLG SHOCK STRUT
2006600-155	1620-01-162-7518	LG RETRACTABLE
2006600-161	1620-01-225-5457	NLG SHOCK STRUT
2006629-105	1620-01-071-5592	APM. ASSY TORQUE
2006629-111	1620-01-124-9137	ARM. ASSY TORQUE L/G
2006907-103	1650-01-056-9655	NLG STEERING ACTUATOR
2006907-105	1650-01-056-9655	CYLINDER ASSEMBLY ACTUATING LINE
2007003-103	1620-01-252-1049	TENSION, STRUT ASSEMBLY
20140-1000-0201		LIQUID QUANTITY INDICATOR
20220-0101	6680-01-580-2565	HYD OIL QTY TRANSMITTER
2022032-1-1	1680-01-045-1019	PDU SERVO ACTUATOR
2022032-2-1	1650-01-150-8939	ACTUATOR
2022052-1-1	1680-01-045-1018	GEARBOX ASSEMBLY
2022056-1-1	1680-01-048-8977	ACTUATOR, ELECTRO-ME
2022058-1-1	1680-01-042-3261	ACTUATOR, MECHANICAL
2022058-1-2	1680-01-225-7319	ACTUATOR, MECHANICAL
2022070-1-1	1650-01-041-0478	DRIVE UNIT, HYDRAULI
2022070-2-1	1650-01-143-0394	DRIVE UNIT, HYD
2022070-3-1	1650-01-149-4738	DRIVE UNIT, HYDRAULI
2022072-4-1	1680-01-168-9396	ACTUATOR BRAKE
2045996-2	1650-01-072-3678	MOTOR, HYDRAULIC
2048342-1-4	1680-01-230-1280	ACTUATOR, ELECTRO-ME
2048342-2-1	1680-01-276-8711	ACTUATOR, ELECTRO-ME
2048344-1-4	1680-01-230-1279	ACTUATOR, MECHANICAL
2048666-2-1	1650-01-308-0839	DRIVE UNIT, HYDRAULI
208-013-002		FAN TIT INDICATOR



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
208-013-003		FAN TIT INDICATOR
208013-004		INDICATOR TEMPERATURE
208-013-004	6620-01-178-7651	FTIT INDICATOR
208-013-005	6620-01-276-9825	INDICATOR, TEMPERATURE
2094-6	6610-01-049-8747	ACCELEROMETER
2100756-3-1	6610-01-047-6627	COMPUTER AIR DATA
2101272-2-1		EPU CONTROLLER
2101272-4-2	1680-01-258-5608	POWER SUPPLY
2101382-3-1	6685-01-149-6398	TRANSMITTER PRESSURE (PSA)
21092A		CABIN PRESSURE ALTIMETER
2109-5	6685-01-112-9094	CABIN PRESS IND.
216-42463-1	4320-00-162-3917	HYDRAULIC PUMP
217-003-112M		MASTER INDICATOR
21SN41-84		PRESSURE SWITCH
2204330-3-2	1660-01-155-9146	TURBINE,AIRCRAFT CO
2204330-4-1	1660-01-363-2742	TURBINE,AIRCRAFT CO
229185-3	4810-01-057-1731	VALVE,REGULATING,FL
229185-4	4810-01-225-7171	VALVE, REGULATOR
229255-3	4810-01-071-4753	VALVE,REGULATING,FL
229255-4	4810-01-130-7379	VALVE,REGULATING,FL
2472T100-1	4810-01-264-9668	ACTUATOR,ELECTRO-MECHANICAL,
2491-1	2915-01-235-5188	FUEL TRANSFER PUMP TURBINE DRIVEN
2497T100-1	4810-01-257-9316	BUTTERFLY VALVE
2497T100-5	4810-01-320-5294	BUTTERFLY VALVE
25730032-04	4810-00-730-2852	VALVE,SOLENOID
2616638-1	6130-01-272-8813	POWER SUPPLY
2616638-2	6130-01-272-8813	POWER SUPPLY
2660017M1	4810-00-104-5672	VALVE, SOLENOID
2750023-101	1660-01-052-5359	CONTROL,AIRCRAFT
2750024-101	1660-01-052-5354	CONTROL BOX ELECTRICAL/ELECTRONIC
2750038-101	4810-01-054-9843	VALVE,REGULATING,FL
2750514-5	1650-01-039-4983	RESEVOIR
2750514-6	1650-01-039-4984	ACCUMULATOR, HYDRAULIC
2750514-7	1650-01-039-4983	HYDRAULIC ACCUMILATOR
2750514-8	1650-01-039-4984	HYDRAULIC ACCUMILATOR
2750534M1	1650-01-064-0020	ACCUMULATOR HYD
2750534M3	1650-01-263-1604	ACCUMULATOR HYDRAULIC
28YBL100A-1	6130-00-314-0050	POWER SUPPLY
29270-10A-A1	1660-00-243-0393	OXYGEN DEMAND REGULATOR
29270-10A-B1	1660-00-243-0393	OXYGEN REGULATOR
30006-0000-03	6680-01-261-5242	TRANSMITTER LIQUID QUANTITY
31216-001		5KVA GENERATOR
3129307-1	6130-01-388-0266	POWER SUPPLY
3129307-4	6130-01-388-0266	POWER SUPPLY
3129308-1	6130-01-388-6637	POWER SUPPLY



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
3129308-4	6130-01-388-6637	POWER SUPPLY
315E100-3	1680-01-101-4436	ACTUATOR,ELECTRO-ME
3213722-5-1	4810-01-157-2583	VALVE, SHUTOFF
3213790-4-1	4810-01-052-5358	VALVE,REGULATING & SHUT-OFF
3213790-5-1	4810-01-052-5358	VALVE,BUTTERFLY
3213790-5-1	4810-01-052-5358	VALVE,REGULATING & SHUT-OFF
3213790-5-2	4810-01-252-9429	VALVE,REGULATING & SHUT-OFF
3213790-6-1	4810-01-142-6616	VALVE,REGULATING & SHUT-OFF
3213790-6-2	4810-01-256-1982	VALVE,REGULATING & SHUT-OFF
3213790-7-1	4810-01-345-1092	VALVE,REGULATING,FL
3213790-7-1	4810-01-345-1092	VALVE,REGULATING & SHUT-OFF
3214482-1-1	1660-01-155-6854	VALVE
3214806-1-1	1660-01-217-6555	REGULATOR,AIR PRESS
3214806-2-1	1660-01-217-6558	REGULATOR,AIR PRESS
3214806-3-1	1660-01-345-2115	REGULATOR,AIR PRESS
3214806-4-1	1660-01-445-9556	REGULATOR AIR PRESSURE
321502-4-1	4810-00-796-1672	VALVE, BUTTERFLY
321825-1	2995-01-199-0612	VALVE ANTI ICE
323155-3	2995-01-199-0612	VALVE ASSEMBLY,ANTI
323155-5		ANTI-ICING VALVE
323155-7	2995-01-313-0343	VALVE ASSEMBLY,ANTI
3252001-0101	6610-00-086-3840	ALTIMETER SERVO CONTROL
3252022-0101	6610-01-035-0673	ALTIMETER,SERVO CONTROLLED,AUTOM
3260011-0101	1660-01-005-6318	OXYGEN REGULATOR
3260011-0701	1660P3260011-0701	REGULATOR, OXYGEN
3260060-0108	1660-01-383-6734	OXYGEN REGULATOR
3261130-0102	1660-01-473-2858	EMER OXY SYS
329PG		PRESSURE GAUGES
3300223-6001	4920-01-321-1839	TEST STAND DEMAND
3300223-6003	4920-01-521-3685	TEST STAND
330025G01	4320-01-162-6456	PUMP,HYDRAULIC
330025G01	4320-01-162-6456	PUMP, HYDRAULIC
3567762-3002	6620-00-290-6505	TRANSMITTER,PRESSURE
362-014-001	6610-01-040-4430	INDICATOR, ANGLE
36380-8	4820-01-056-9712	VALVE,THERMAL RELIEF
363J100-1	1680-01-142-8095	ACTUATOR, ELECTRO-MECHANICAL
365000-3	2915-00-438-5854	PUMP FUEL METERING AND DISTRIBUT
371688-101	2910-00-907-7481	PUMP FUEL
37516-3	1560-01-054-2800	F1 BLADDER TANK
383296-1-1		STARTER
3833000-20	1650-01-060-1272	CYLINDER ASSEMBLY,A
3833000-21	1650-01-105-7111	CYLINDER ASSEMBLY,A
3833000-22	1650-01-165-7203	CYLINDER ASSEMBLY ACTUATING LINEAR
3833000-5	1650-01-042-3258	CYLINDER ASSEMBLY,A
383370-8-1		STARTER



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
3834000-20	1650-01-059-6392	CYLINDER ASSEMBLY,A
3834000-21	1650-01-106-1594	CYLINDER ASSEMBLY ACTUATING LINE
3834000-3	1650-01-042-3257	ACTUATOR
390000-1	2915-01-041-8639	DUAL FUEL PUMP
3930015-101	1650-01-376-1218	FLT CTL ACCUMULATOR
393084-11426	6680-00-078-3756	INDICATOR LIQUID QUANTITY
396-00	4810-00-791-1157	CABIN AIR SAFETY VALVE
396-00-1	4810-00-895-5652	CABIN AIR SAFETY VALVE
396308-1-1	4810-01-040-2372	VALVE, FLOW CONTROL
4001T94G06	4820-00-905-1137	CHECK VALVE
4001T94G08	4820-00-191-3810	CHECK VALVE
4004T40G01		CHECK VALVE
4025116-907	6610-01-308-1859	COMPUTER AIR DATA
40283D	4810-01-349-0405	ACTUATOR ELECTRO-MECHANICAL
4059194F	6620-00-290-6505	PRESSURE TRANSMITTER
4100020-1	1650-01-104-6188	MOTOR,HYDRAULIC
4100050-2	1650-01-058-6259	MOTOR,HYDRAULIC
4111016-1	1650-01-302-3404	MOTOR-PUMP,HYDRAULI
441294-3	2915-01-206-0654	CONTROLLER, FUEL PUMP
441991-11	2995-01-450-2816	CONTROL,EXHAUST NOZZLE,TURBINE E
45731-1291		COOLER, LUBRICATING
45731-1411	2935-01-394-8316	COOLER, LUBRICATING
460700-14-01	6615-01-356-6851	COMPUTER FLIGHT CONTROL
472741-3	6680-01-074-9369	TRANSMITTER LIQUID QUANTITY
472741-3	6680-01-074-9369	TRANSMITTER
472742-1		TRANSMITTER
472854-2		TRANSMITTER
4800-000-00	1740-01-381-2919	TRAILER, GROUND HANDLING
4810-001-2		VALVE, RAM AIR SHUT-OFF
5003599B	1650-010872863	MOTOR HYDRAULIC
5003599B	1650-01-087-2863	HYDRAULIC START MOTOR
5003599D	1650-01-087-2863	HYDRAULIC START MOTOR
5003599D	1650-01-087-2863	HYDRAULIC START MOTOR
5003599E	1650-01-087-2863	MOTOR,HYDRAULIC
5003599E	1650-01-087-2863	HYDRAULIC START MOTOR
5003600E	1650-01-087-2863	HYDRAULIC MOTOR
5004314C	2925-01-115-0306	CONTROLLER, JET FUEL STARTER
5004451H	2835-01-235-5249	Gearbox, Accessory Drive
500702-5211		FAN ASSY
5007076A	2835-01-140-1623	GEARBOX, ENGINE STARTING
5007076B	2835-01-208-0169	GEARBOX, ENGINE STARTING
501-1027-01	6615-00-877-9343	GYROSCOPE RATE
501-1131-01	6610-00-200-8832	ATTITUDE INDICATOR
501-1131-02	6610-00-200-8742	ATTITUDE IND, STBY
503600-1		VALVE, RAM AIR SHUT-OFF



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
5076-300	6620-01-321-6819	TACHOMETER
51516-001	6110-01-383-7195	CONTROL,GENERATOR (GCU)
5173100-002	6340-01-235-3351	ALARM SET, PILOT WARNING
5207-00-1	4810-01-154-3200	VALVE, REGULATING
55107-02		PUMP
55113-02	4320-01-152-8301	HYDRAULIC PUMP
55113A	4320-01-376-3868	PUMP HYDRAULIC RAM HAND DRIVEN
56830-2	4810-01-050-3369	HYDRAULIC SOLENIOD
56830-3	4810-01-292-5417	HYDRAULIC SOLENIOD
56830-6	4810-01-050-3369	HYDRAULIC SOLENIOD
56870-1	4810-01-041-5328	SOLENOID VALVE
56870-1	4810-01-041-5328	VALVE, LANDING GEAR SELECTOR
56870-2	4810-01-041-5328	LG HYD SOLENOID SELECTOR VALVE
56870-2	4810-01-041-5328	VALVE, LANDING GEAR SELECTOR
56870-4	4810-01-137-2476	VALVE SOLENOID
56870-4	4810-01-137-2476	VALVE, LANDING GEAR SELECTOR
571545-6-1	1660-00-123-9594	COOLING TURBINE
571545-7-1	1660-01-063-1213	COOLING TURBINE
571545-8-1	1660-01-394-2481	COOLING TURBINE
57240-11	4810-01-073-4200	VALVE
57730-5	1620-01-136-5173	ELEC COMP
581670-2-2	4810-01-099-6392	VALVE PACKAGE AND/OR VALVE, SOLENIOD
581750-10-1	2835-01-116-0006	POWER GAS TURBINE
581750-11-1	2835-01-263-9440	POWER UNIT,GAS TURB
581760-2-1	4810-01-116-3360	VALVE,FLOW CONTROL
58500-3	4810-01-324-3564	VALVE,LINEAR,DIRECTIONAL CONTROL: F16
58500-6	4810-01-324-3564	VALVE LINEAR DIRECTIONAL CONTROL:F16C/D
585-AVU-8C/A		AIRSPD AND DIRECTION INDICATION
585R944H02	6130-01-361-0655	POWER SUPPLY
5901030B	2910-01-072-2709	FUEL CONTROL ASSEMBLY
5901030C	2910-01-135-5681	FUEL CONTROL ASSEMBLY
5901091B		JET FUEL STARTER
5901091B		STARTER, JET FUEL
5902924A	2835-01-154-3533	JET FUEL STARTER
6002052-1		WHEEL SPEED SENSOR
6002052-2	1630-01-071-2277	SENSOR, WHEEL SPEED
6002052-3	1630-01-217-3141	SENSOR,ANTI-LOCK BRAKE,AIRCRAFT
601-4176-001	5998-01-086-8829	POWER CIRCUIT CARD ASSEMBLY
60-2805-3	6130-01-149-8915	POWER SUPPLY
60794-4	2915-01-179-3834	FILTER, FLUID
60813-2	4820-01-110-7775	VALVE, LINEAR
60946-5	1650-01-516-5108	HYD ACCUMULATOR
622-0507-001	5826-01-012-1938	RCVR, XMTR TAC
622-2510-003		TACAN CONTROLLER
622-4038-001	5821-01-062-1019	R/T 1300 ARC186



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
622-4039-001	5821-01-062-0986	VHF CONTROL PANEL
622-4956-103	5821-01-258-7579	ARC 190 R/T 1341(V)3
622-8084-001	5985-01-228-9402	AMPLIFIER-CONVERTER
627076-2-1	1660-01-057-5182	SENSOR CONTROLLER
627076-3-1	1660-01-140-8406	CONTROL BOX ELECTRICAL/ELECTRONIC
638-9090-001	5821-01-077-4298	RECEIVER ASSY
65054A		HYDRAULIC PUMP
67810-1	4810-01-259-0464	VALVE SOLENOID
691R748G01	5841-01-132-6867	NOISE REGULATOR ASSEMBLY
695568-5	1650-01-155-6849	NLG STEERING CYLINDER
705365-7	6110-01-108-2690	INVERTER CONTROL
705365-8	6110-01-108-2690	INVERTER, CONTROL
705465-2	6220-01-070-0244	WARNING LIGHT BANK
705565-2	6130-01-051-7518	CHARGER,BATTERY
705580-1	6130-01-051-3918	CONVERTER 500VA
705906-804	5821-00-601-5131	RECIEVER, TRANSMITTER
706057-801	5821-00-509-2435	MOUNTING BASE
708500-2	2915-01-448-8506	MAIN FUEL GEAR PUMP
709290-1	6130-01-165-2055	POWER SUPPLY
709290-2	6130-01-209-9062	CONVERTER REGULATOR
7125-9415	6615-01-178-0583	GYROSCOPE RATE
718372B	4810-01-058-3551	VALVE, REGULATING
727429A	1650-01-132-2147	DRIVE,CONSTANT SPEE
727429B	1650-01-153-1225	DRIVE SPEED CONSTANT
727429C	1650-01-157-1591	DRIVE,CONSTANT SPEE
727429D	1650-01-220-3774	DRIVE,CONSTANT SPEED,HYDRAULIC
727429E	1650-01-222-3790	DRIVE CONSTANT SPEED HYDRAULIC
734556A	1650-01-228-9276	DRIVE,CONSTANT SPEED,HYDRAULIC
7506-00097	6130-99-735-6318	POWER SUPPLY
7506-00098	6130-99-741-9556WF	PSU LV
7506-00104	6130-99-776-6884WF	PSU LV
7-511C10035-1	6615-00-137-6038	GYROSCOPE RATE
751864-2	1660-01-019-8663	HEAT EXCHANGER
75500000-1		INDICATOR,HORIZ
7609-37M5-2	6685-00-526-7864	PRESSURE TRANSMITTER
763615-3	4810-01-052-3770	VALVE,REGULATING,FL
763615-4	4810-01-153-0975	VALVE,REGULATING,FL
764828-4	1660-01-107-2459	Turbine Aircraft Cooling
764828-4	1660-01-107-2459	COOLING TURBINE
764828-4-1	1660-01-588-4637	COOLING TURBINE
764962-2	1660-01-050-5847	HEAT EXCHANGER,AIR
764967-5	1660-01-046-0943	HEAT EXCHANGER
764967-7	1660-01-331-0068	HEAT EXCHANGER
765592-11	4810-01-163-4392	VALVE ASSY
765592-12	4810-01-155-4943	VALVE, REGULATING, FLUID PRESSURE



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
765592-13	4810-01-154-3200	VALVE REGULATING FLUID PRESSURE
765592-4	4810-01-073-3221	VALVE
765592-5		VALVE,REGULATING,FLUID PRESSURE
765592-8		VALVE,REGULATING,FLUID PRESSURE
765592-9		VALVE,REGULATING,FLUID PRESSURE
767600-1	4810-01-282-7884	VALVE, REGULATOR
77600000-3	6610-01-044-1860	INDICATOR, ATTITUDE
77600000-4	6610-010929846	INDICATOR ATTITUDE
78010-11175	6680-01-048-2998	INDICATOR LIQUID QU *TCI*
780110-11157	6680-01-048-2998	INDICATOR LIQUID QUANTITY
78600000-01	6620-01-051-2045	NOZZLE POSITION IND
78700000-01	6610-01-114-6817	IND, ANGLE
791130H05D09	6620-01-449-3101	DIAGNOSTIC UNIT,AIRCRAFT ENGINE (EDU)
791130H05D10	6620-01-449-3101	DIAGNOSTIC UNIT AIR
801000653-2	5841-01-221-8638	RECEIVER TRANSMITTER UNIT
822-0204-002	5826-01-387-0975	RECEIVER RADIO NAVIGATION
822-0204-022	5826-01-387-0975	RECEIVER RADIO
822500-6	1680-01-110-4407	HALON RESERVOIR
8517713-922	5998-01-436-0165	CIRCUIT CARD ASSEMBLY
8526000-920	1280-01-481-5723	GENERATOR DISPLAY COLOR
85900000-02	5895-01-230-1284	CONVERTER, SIGNAL DATA
86400-3162	6645-01-122-2318	Clock
880T100	1680-00-073-8204	ACTUATOR, LINEAR
880T100-3	1680-01-329-7411	ACTUATOR, LINEAR
8-8421-030-2	1650-01-043-7540	ACUM ASSEMBLY
88700000-05		VERTICAL VELOCITY INDICATOR
8DJ113LWN1	6620-00-802-7164	RATE OF FLOW INDICATOR
8DJ179DBD3		FAN TURB. TEMP. IND.
8DJ179DBE1	6620-01-256-4307	INDICATOR TEMPERATURE
8DJ215WBA1	6620-01-129-7247	INDICATOR ELECTRICAL TACHOMETER
8DJ215WBR1	6620-01-270-7772	INDICATOR ELECTRICAL
8TJ62GBZ3	6620-01-020-1722	TRANSMITTER
900101-807		RECEIVER-TRANSMITTER,RADIO
9043185-1		IGNITION LEAD
914691-823	5998-01-481-3710	MODULE
9246250-10	1630-01-417-1493	CONTROL UNIT, ANTISK
946F506-3	6115-01-058-1595	PM STATOR
946F932-1	6115-01-058-1521	ROTOR ASSY
946F932-2	6115-01-058-1521	ROTOR ASSY
947F310-1	6110-01-038-5065	CONTROL GENERATOR
947F485-1	6115-01-058-1455	MAIN STATOR
948D723-1		MAIN STATOR
948F458-5		GENERATOR CONTROL UNIT
948F463-4	6115-01-148-0483	10 KVA GENERATOR
948F463-5	6115-01-246-5622	ALTERNATOR, GENERATOR



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
948F463-6	6115-01-246-5622	12 KVA GENERATOR
975138-9	1650-01-084-1570	SERVOVALVE, HYDRAULIC
976J976-4		STATOR, REWIND
977J008-2	6115-01-149-7588	AC GENERATOR
977J024	6115-01-095-5500	AC GENERATOR
977J024-1	6115-01-044-7144	AC GENERATOR
977J024-2	6115-01-095-5500	GENERATOR, ALTERNATI
977J024-3	6115-01-141-5801	GENERATOR, ALTERNATI
977J024-4	6115-01-141-5801	GENERATOR
977J033-2		GENERATOR
977J033-3	6115-01-061-7982	GENERATOR, ALTERNATI
977J033-5	6115-01-028-4374	AC GENERATOR
977J033-8	6115-01-104-8632	AC GENERATOR
977J036-1	6115-00-576-0018	AC GENERATOR
977J036-2	6115-01-077-1299	AC GENERATOR
977J330-2	6115-01-236-8434	GEN, ALTERNATING
977J330-3		GENERATOR 60KVA
979196-2-1	1660-01-052-5355	VALVE ASSEMBLY, ENVI
979198-11	1660-01-052-5356	ALVE CONTROL CABIN
979290-4-1	4810-01-073-3810	VALVE, REGULATING, FL
A2850-1	6615-00-857-0828	RATE GYROSCOPE
A2850-5	6615-00-869-0825	GYROSCOPE RATE
A4132210003	6610-00-179-5086	ALTIMETER
A4132210015	6610-01-016-1583	ALTIMETER SERVO CONTROLLED AUT
A536A379-02	6605-01-075-4770	SERVO & ELEC
A81-6	5895-00-623-2912	AMPLIFIER
AAU18A	6610-00-078-5694	INDICATOR VERTICAL VELOCITY
AAU19A	6610-00-179-5086	ALTIMETER SERVO
AAU19AA	6610-00-086-3840	ALTIMETER SERVO
AAU-34/A	6610-01-035-0673	ALTIMETER, SERVO
AAU-3A/A	6685-00-226-5700	CABIN PRESSURE ALTIMETER
AAU3AA	6685-00-725-9117	CABIN PRESS IND.
ABU-4A/A	6610-01-049-8747	ACCELEROMETER
ADTS405-1-8398-MO	4920-01-432-3906	TEST SET FLIGHT
ARU-42/A-1	6610-00-200-8832	ATTITUDE INDICATOR
ARU42A1	6610-00-200-8773	ATTITUDE INDICATOR
ARU-50/A		FLIGHT ATTITUDE INDICATOR
AV18A1117	4820-01-058-3205	VALVE BUTTERFLY
AV19E1003	4810-01-058-8666	VALVE
AV19E1003-1	4810-01-123-7254	VALVE PRESSURE VENT
AV1B1660	4810-01-054-6013	VALVE, SOLENOID
AVU-8B/A		AIRSPEED INDICATOR
AVU-8C/A		AIRSPEED INDICATOR
B2888-01	6615-00-857-0828	RATE GYRO TRANSMITTER
B2888-02	6615-00-869-0825	RATE GYROSCOPE



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
B405501	1660-01-407-8855	REGULATOR, OXYGEN
C2893410007		MB-1A ALTIMETER
C3435210005	6610-01-060-6760	AIRSPEED INDICATOR; AVU-8C/A
C3435210006	6610-01-046-4844	INDICATOR AIR SPEED MACH NO
C7901-1	1650-01-056-7136	ACCUMULATOR
C7902-2	1650-01-043-7540	ACCUMULATOR
CB2125-5	6605-00-815-1903	STANDBY COMPASS
CB-2125-5	6605-00-815-1903	COMPASS
CB2125T5	6605-00-815-1903	COMPASS MAGNETIC
CP-1-AAU-3/A-12	6685-00-226-5700	ALTIMETER
CP1AAU3A12	6685-00-226-5700	CABIN PRESS IND.
DM001-302	5895-01-426-5318	MODEM COMMUNICATIONS:F/F-16 ACFT
DSL-647	6680-00-139-0002	INDICATOR LIQUID QUANTITY
DSL647-2	6680-01-310-3235	INDICATOR LIQUID QUANTITY
EFU-22A/A-7	6620-01-060-6418	INDICATOR RATE OF FLOW
EHU-49/A	6620-01-180-5183	INDICATOR TEMPERATURE
ERU-6/A	6620-00-684-1952	INDICATOR, ELEC
GD4937		IFF CONTROLLER C-6280A
GG2479AA01	6615-00-169-1564	GYROSCOPE RATE
GG2479AB01	6615-00-137-6038	XMTR, RATE GYRO
GMU37A	6680-00-753-8932	INDICATOR LIQUID QUANTITY
GMU-37A	6680-00-976-3923	LIQUID OXYGEN IND
H330025G01	4320-01-162-6456	PUMP, HYDRAULIC
HP1141100-3	1650-00-404-0445	VALVE LINEAR DIRECTIONAL CONTROL
J115103-517	1680-01-055-3451	ACTUATOR ELECTRO-MECHANICAL LINE
J115140-505	1680-01-004-5337	CONTROL ASSEMBLY PITCH STAB
M3500-5		MD-1B TURN & SLIP IND
M727429-7	1650-01-222-3790	DRIVE,CONSTANT SPEED,HYDRAULIC
MF-3913-2	1650-00-540-0162	MOTOR
MF-3913-5	1650-00-540-0162	MOTOR
MIL-C-19328	1660-010414494	CONVERTER LIQUID OXYGEN
MS23009-1	6610-00-910-4284	ACCELEROMETER
MS23009-2		ACCELEROMETER
MS28005-8	6685-00-526-7864	TRANSMITTER,PRESSURE 0-4000 PSI
MS28500-8T		TRANSMITTER PRESSURE
MS28889-2	4820-00-535-6483	VALVE,PNEUMATIC TANK
MS3370-1	6130-00-314-0050	CONVERTER
PV3-075-15	1650-01-056-8914	MOTOR-PUMP,HYDRAULI
PV3-075-4	4320-00-404-1977	ENGINE HYD PUMP
PV3-075-4; -4A; -16	4320-00-404-1977	HYDRAULIC PUMP
PV3-075-4A	4320-00-404-1977	HYDRAULIC PUMP
PWA57495	4920-01-361-0044	HEATER, AIRCRAFT ENGINE
R-2514A/U	5826-01-387-0975	RADIO NAVIGATION RECEIVER
RC-60-AAU/18/A	6610-00-781-5787	INDICATOR VERTICAL VELOCITY
RC-60-AAU-18/A	6610-00-781-5787	IND, VERTICAL VELOCITY



WINGS AEROSPACE, LLC
F-16 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
RCS-60-AAU-18/A		INDICATOR, VERTICAL VELOCITY AAU-18A
RR54660D	2915-01-192-0847	PUMP,FUEL,METERING
S85-AVI-8C/A		AIRSPED & DIRECTION INDICATOR
S85-AVU-8C/A		INDICATOR,AIRSPED AND DIRECTION
S-85-AVU-8C/A	6610-01-263-2409	IND MACHMETER
SLZ7317-1		TRANSMITTER AOA
SLZ9695-2	6610-01-052-5584	TRANSMITTER, ANGLE OF ATTACK
SLZ9695-3	6610-01-222-6439	TRANSMITTER, ANGLE
ST207A		SYNCHRO STYLE HYD PRESS TX
TRU-2A/A	6615-00-857-0828	GYROSCOPE RATE
TRU63/A3	6620-01-167-0874	TRANSMITTER RATE OF FLOW
UA539800-1	2935-01-214-7360	FUEL OIL COOLER ASSY