



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1605		TURN & SLIP INDICATOR
2145	6610-01-160-6585	VERTICAL VELOCITY INDICATOR
8465	6685-00-526-7864	TRANSMITTER PRESSURE
10900	6610-00-183-0371	ACCELEROMETER
18492	1660-00-401-1096	CONVERTER, LIQUID OXYGEN
20100	6615-00-973-2657	GYRO, RATE
20110		RATE GYRO ASSEMBLY
51325	4810-00-078-4729	VALVE, LINEAR DIRECT
101280	6620-00-993-3403	FUEL FLOW INDICATOR
109090	6610-00-131-8817	INDICATOR, ATTITUDE
126460	6605-01-058-0975	INDICATOR, HORIZONTAL SITUATION
131100	4820-00-003-1821	VALVE CANOPY
196716	5826-00-952-3709a	INDICATOR BEARING DISTANCE
552115	1660-00-798-3210	TURBINE, AIRCRAFT COOLING
570642	1660-00-888-6350	CONTROL ANTI-ICE
573901	1660-00-977-4182	REGULATOR AIR PRESSURE
575427	6130-00-056-6718	INVERTER, POWER
633093	5998-01-021-3029	INTEGRATOR ASSEMBLY CIRCUIT CARD ASSEMBLY
700592	6130-01-070-8783	POWER SUPPLY
703306	5998-01-346-3220	POWER SUPPLY MODULE
703308		DUAL PRF MASTER TIMING
703309	5998-01-285-7908	ASSEMBLY
703317	5998-01-285-9787	ASSEMBLY
836525	6615-01-045-7350	STABILITY AUGMENTATION
3571281	6620-00-022-8056	TACHOMETER
22253340		SERVO VALVE
22253350		HYD SERVO V/V
10000165-1	6610-01-075-1488	TRANSMITTER, ANGLE OF ATTACK
102108-16-1	1660-00-492-7990	CABIN PRESSURE REGULATOR
102108-19-1	1660-01-039-7911	CABIN AIR PRESS REGULATOR
102150-0-14		CABIN AIR PRESS VALVE
103D100	1680-00-500-6064	ACTUATOR
10-516300-1	2925-01-034-9215	VIBRATION IGNITION
10-516300-2	2925-01-323-9835	EXCITER IGNITION
10C-0001-26	1660-00-122-8101	LOX CONVERTER
10C0020-0013		SPHERE ASSY
10C-0020-6	1660-00-327-7048	LIQUID OXYGEN CONVERTER
10C-0021-0001		TANK, LIQUID OXYGEN CONVERTER:
10C0021-5	1660-00-148-9239	CONVERTER, LIQUID OXYGEN
10C-0021-5	1660-00-148-9239	CONVERTER, LIQUID OXYGEN
11177-1		SWITCHING ASSY
11177-3	1680-01-135-7847	SWITCHING
123335-3	4810-00-866-8132	VALVE ANTI-ICING
124623-01-09a	6615-00-852-1611	GYRO DISPLACEMENT
14-40605-9	1620-00-007-1781	OLEO MLG
14-41600-503	1620-01-046-2783	RETRACTABLE NLG



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
14-42516-1		UPLOCK ASSY ARRESTING HOOK
14-43140-501	1650-00-327-7008	CYLINDER ASSEMBLY
14-43260-501	1650-01-003-0724	CYLINDER
14-43270-1	1650-00-471-2558	CYLINDER ASSEMBLY,ACTUATOR
14-50901-5	1680-00-500-6064	ACTUATOR ROTARY (AUX)
14-50907	4810-01-065-3457	VALVE BUTTERFLY
14-50907-3	4810-00-007-3433	VALVE,BUTTERFLY
14-51100-1	1680-00-139-8020	GEARBOX ASSEMBLY, AIRCRAFT
14-51100-501	1680-01-440-5106	GEARBOX ASSEMBLY,AIRCRAFT
14-62909-5	5895-01-443-9174	TRANSPONDER SET
1463-55KB55-1	6610-01-008-1653	INDICATOR, MACH AND TRUE AIR SPEED
1463-55K-B55-2	6610-01-109-4841	MAX ALLOW AIRSPEED
14-64900-1	6680-00-138-6701	INDICATOR,LIQUID QUANTITY
14-64900-9	6680-00-333-6757	FUEL QUANTITY
14-64912-1	6610-00-471-2745	ANGLE OF ATTACK INDICATOR
14-64912-3	6610-00-390-4495	ANGLE OF ATTACK INDICATOR
14-64912-7	6610-01-021-4265	AOA INDICATOR
14950-34M	1660-01-010-4949	OXYGEN REGULATOR
14950-40	1660-00-169-1888	REGULATOR,OXYGEN,DILUTER DEMAND
15482-1A1	5996-00-855-9045	AMPLIFIER, ELECT
15482-1A1A	5996-00-102-9656	AMPLIFIER
156578-01-01	6610-00-148-7180	ATTITUDE IND
156880-1-1		OIL COOLER
164-1	6680-00-753-8932	LIQUID OXY QTY IND
17223-1A	6615-00-581-5792	CONTROL DIRECTIONAL
18-1718-3A		TRANSMITTER
181RA38R176	1680-00-232-2235	ACTUATOR, ELECTRO-MECHANICAL, ROTARY
182-029-12	6685-00-842-4980	TEMPERATURE INDICATOR
182-029-16	6685-00-842-4980	INDICATOR TEMPERATURE
182-032-2	6685-00-842-4988	INDICATOR, TEMPERATURE, SYNCHRO
18-54903-3	1660-01-049-3423	PRESS, REG., VALVE
18-54925-3	1660-01-019-8577	AIR CONDITIONING EQUIPMENT*DSP
18-61104-3	5985-00-139-1505	ANTENNA
19005-2C	6615-00-451-3834	Gyro Direction
19315/19005-2C	6615-00-451-3834	GYROSCOPE DISPLAY
19E83-5BCL100	1680-01-037-6734	DRIVE ASSY
200-000D	1730-00-114-0304	KIT, LOX PURGING
203-003-002	6680-00-333-6757	QUANTITY INDICATOR
2094-6	6610-01-049-8747	ACCELEROMETER
2100756-3-1	6610-01-047-6627	COMPUTER AIR DATA
21043-3	1660-00-445-9384	CONVERTER,LIQUID OXYGEN
226855-3		BUTTERFLY SHUTOFF VALVE
2-43160-502	1650-00-780-0386	SERVOCYLINDER
2-43160-508	1650-00-998-1287	AILERON SERVO CYLINDER
2-43330-508	1650-00-065-7694	SERVOCYLINDER HYDRAULIC
2-43330-510	1650-00-065-7694	SERVOCYLINDER HYDRAULIC



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
2-43330-511		RUDDER ACTUATOR
2-43330-512	1650-00-065-7694	RUDDER ACTUATOR
250A160	1630-01-055-5056	WHEEL, MAIN
250A160C	1630-01-055-5056	WHEEL, LANDING GEAR
250-A-160C	1630-01-055-5056	WHEEL, MAIN LANDING GEAR
2562A13	6610-00-961-1971	AOA TRANSMITTER
2562A-13		AOA TRANSMITTER
2562A13M	6610-00-359-2226	TRANSMITTER, ANGLE OF ATTACK
2562A-13M	6610-00-359-2226	TRANSMITTER, ANGLE OF ATTACK
2-60910-1	6220-00-061-4140	CONTROL, LIGHT, AIRCRAFT
2-60910-501	6220-00-061-4140	CONTROL, LIGHT, AIRCRAFT
2-73914-3	6615-00-479-9523	GYROSCOPE, RATE
28B94-111-A	6115-01-036-7763	GENERATOR
29255-10AA2	1660-00-061-6335	REGULATOR OXYGEN
29270-10AA1	1660-00-243-0393	REGULATOR OXYGEN DEMAND
29270-10A-A1	1660-00-243-0393	OXYGEN REGULATOR
29270-10AB1	1660-00-243-0393	REGULATOR, OXYGEN
29270-10A-B1	1660-00-243-0393	REGULATOR, OXYGEN, DEMAND
297270-10AA1	1660-00-169-1888	OXYGEN REGULATOR
2CM11BAA5	6620-00-785-2251	GENERATOR, TACHOMETER
3001T03G03	2915-00-483-4282	FUEL DRAIN VALVE
3006T88G01	2915-00-909-2305	VALVE, FUEL PRESSU
3006T88G05	2915-00-143-6107	VALVE, FUEL PRESS
30G1	6610-00-390-4495	INDICATOR, ANGLE OF ATTACK
30G3	6610-01-021-4265	IND, ALTITUDE
30G-3	6610-01-021-4265	ATTITUDE INDICATOR
3252001-0101	6610-00-086-3840	ALTI. SERVO CONTROL
3252022-0101	6610-01-035-0673	ALTIMETER, SERVO CONTROLLED, AUTOM
3260010-0201	1660-00-132-3454	REGULATOR, OXYGEN, DI
3260011-0101	1660-01-005-6318	REGULATOR, OXYGEN, DILUTER DEMAND
3260011-0701	1660P3260011-0701	REGULATOR OXYGEN
3265-1	1270-00-394-6741	RADAR TARGET DATA PROCESSOR
34100C1D-6-1C1	6620-00-684-1952	INDICATOR, ELECT
3-43905-1	4810-00-735-8305	VALVE, GEAR ACT HYD
34E94-11A	4320-00-003-5641	PUMPING UNIT, HYDRAULIC, POWER DR
34E94-11B	4320-00-123-3730	PUMPING UNIT, HYDRAULIC, POWER DR
34E94-11G	4320-01-228-3396	PUMPING UNIT HYDRAULIC POWER DRIVEN
3-51100-1	1680-00-739-8339	GEARBOX ASSEMBLY, AIRCRAFT
3-54917-503	1680-00-148-3900	ACTUATOR, ELECTRO-MECHANICAL, ROTA
3-54917-505	1680-01-020-0308	ACTUATOR, ELECTRO MECHANICAL
35-589F00	5998-01-063-2804	CIRCUIT CARD ASSE
3571112-6003	6610-00-242-2764	TRIM POSITION ACTUATOR
3571211-1001	6685-00-580-4732	INDICATOR TEMPERATURE
3571222-2002	6620-00-163-8793	INDICATOR PRESSUR
3571250-8001	6685-00-181-2416	TEMPERATURE INDICATOR
3571261-4001	6620-00-684-1952	INDICATOR, ELECT



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
3571261-6001		ELECTRICAL TACH IND.
3571261-7001	6620-00-182-7569	GAS PRODUCER TACH INDICATOR
3571281-6001	6620-00-022-8056	ELECTRICAL TACH IND.
3-60913-507		POWER SUPPLY
3-70418-2	1680-01-203-7363	ARM ANTITORQUE RH.
372697-18	2925-01-013-9867	STARTER, ENGINE ELECTRIC
37D401750P104		SPRAYBAR ASSY, MAIN
3809219-1	6685-01-109-2948	CABIN PRESSURE INDICATOR
3809219-2	6685-01-109-2948	INDICATOR, PRESSURE
4016T79P01	2915-00-167-9145	T5 MOTOR & CAM
4025T65P01	4810-00-163-3017	VALVE, REGU
4035T26P02	2995-00-088-4182	CYLINDER ASSEMBLY (VEN ACTUAT)
43550-2	6615-00-181-2719	DISPLACEMENT GYRO
4-43200-508	1650-00-463-7773	ACTUATOR HORIZONTAL
4-43200-509		HORIZONTAL STAB ACTUATOR
4-43200-510		HORIZONTAL STAB ACTUATOR
45-0024-1	6220-00-051-3811	LIGHT LANDING
49290-1	2925-01-323-9835	COIL, IGNITION
499-00-3	1680-00-138-6310	ACTUATOR,ELECTRO-MECHANICAL,RO
5000T66P10	2915-00-006-6805	GOVERNOR,OVERSPEED
5007T85P03	2915-00-725-7139	MAIL FUEL NOZZLE
5007T85P06	2915-01-105-5635	NOZZLE FUEL INLET
501-1096-01	6610-00-719-8446	ATTITUDE INDICATOR
501-1098-01		VERTICAL GYROSCOPE
501-1131-01	6610-00-200-8832	ATTITUDE INDICATOR
501-1131-02	6610-00-200-8742	ATTITUDE INDICATOR
5014T67P03	2915-00-556-0588	PILOT SPRAYBAR,AFTERBURNER
5014T67P04	2915-01-082-9772	PILOT SPRAY BAR AFTERB
5015T24P11	2915-00-001-2627	PUMP,FUEL,JET ENG.*TCI*
5015T24P12	2915-01-017-2366	PUMP,FUEL,JET ENG.*TCI*
5017T57P04	4320-00-763-5908	FUEL PUMP AFTER BURNER
5018T98P01	6105-00-766-5191	MOTOR-TACHOMETER GENERATOR
5020T89G03		MOTOR TACHOMETER
50230-1	4810-00-007-3433	VALVE, BUTTERFLY
50230-7		Bleed Valve
5039T90P02		IGNITION, EXCITER
5039T90P03	2925-01-034-9215	VIBRATION IGNITER
5039T90P04	2925-01-323-9835	IGNITION EXCITER
5039T90P05		IGNITION, EXCITER
5040T18P01	2915-01-037-6724	SPRAY BAR MAIN
5040T19P01	2915-01-040-7201	SPRAY BAR MAIN
5045T16P04	2915-01-178-9124	SPRAY BAR, PILOT
522-3826-000		AMPLIFIER RELAY ASSY
541838-104	1270-00-139-1508	RADAR TARGET DATA PROCESSOR
5418383-104	5895-01-128-0074	AMPLIFIER
5561F4A	4820-00-404-5866	VALVE REGULATING, FLUID PRESSURE



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
6001T79G01	2915-00-999-1646	MAIN FUEL CONTROL
6005T64P24	2840-00-784-9697	FLAME HOLDER
6006T18G05	2915-00-151-6295	FUEL CONT. USE 2915011668385
6006T18G07	2915-00-302-1051	FUEL CONT. USE 2915011668385
6006T18G08	2915-00-518-6461	FUEL CONTROL, AFTERBURNER
6006T18G10	2915-01-034-7125	CONTROL,AFTERBURNER
6006T18G11	2915-01-166-8385	MAIN FUEL CONTROL AFTERBURNER
6006T18G12	2915-01-111-4880	FUEL CONTROL,AFTERB
6006T18G13	2915-01-166-8385	FUEL CONTROL A/B
6006T18G14	2915-01-166-8385	FUEL CONTROL,AFTERB
6007T17G03	2840-00-160-1713	VEN HOUSING
6008T97P05	4320-00-123-3730	POWER UNIT
6008T97P05M	4320-00-123-3730	PUMPING UNIT, HYDRAULIC, POWER
6008T97P13	4320-01-228-3396	PUMPING UNIT, HYDRAULIC
6009T69P02	4320-01-042-3943	PUMP ROTARY
6011T600G11	2915-00-122-8900	FUEL CONTROL MAIN TURBINE ENG.
6011T60G06	2915-01-311-6434	FUEL CONTROL,MAIN,TURBINE ENGINE
6011T60G11	2915-00-122-8900	FUEL CONTROL,MAIN,TURBINE ENGINE
6011T60G16	2915-01-012-5839	FUEL CONTROL,MAIN,TURBINE ENGINE
6011T60G17	2915-01-159-5375	FUEL CONTROL MAIN TURBINE
6011T60G18	2915-01-199-7449	FUEL CONTROL,MAIN,TURBINE ENGINE
6011T60G19	2915-01-246-4060	FUEL CONTROL,MAIN,TURBINE ENGINE
618-5710-001	6220-00-152-6729	EDGE LIGHT PANEL ASSEMBLY
622-0582-001		DF ANTENNA
633056-403	5998-00-152-6366	WRITE GUN BIAS SUPPLY
633062-307	5998-00-152-6366	WRITE GUN BIAS SUPPLY
633074-311	5826-01-061-1870	MARKER BEACON ASSEMBLY
633074-353	5998-01-076-8407	POWER SUPPLY REGULATOR CIRCUIT CARD ASSEMBLY
633076-351	5998-01-049-7692	SEARCH PROGRAMMER CIRCUIT CARD ASSEMBLY
633079-1	5998-01-006-1672	CARD ASSEMBLY
633079-351	5998-01-067-2841	CARD ASSEMBLY
633080-311	5999-01-061-0540	TRACK GATE ERROR DETECTOR
633080-353	6130-00-165-9891	POWER SUPPLY MODULE
633091-1	6130-01-081-8156	POWER SUPPLY MODULE ASSEMBLY
633093-303	5998-01-076-8408	INTEGRATOR CIRCUIT CARD ASSEMBLY
633096-1	6220-00-152-6729	EDGE LIGHT PANEL ASSEMBLY
633096-303	1270-00-205-8707	DVST, YOKE AND SHIELD ASSEMBLY
633098-301	1270-00-205-8707	DVST, YOKE AND SHIELD ASSEMBLY
633107-305	5998-00-152-6335	DEFLECTION AMPLIFIER
633157-301	5998-00-152-6335	DEFLECTION AMPLIFIER
633157-305	5998-00-152-6366	WRITE GUN BIAS SUPPLY
633157-307	5998-01-012-0491	ERASE PULSE GENERATOR CIRCUIT CARD ASSEMBLY
633180-1	1285-00-165-9897	RECEIVER-TRANSMITTER SUBASSEMBLY
633180-303	1285-00-165-9897	RECEIVER-TRANSMITTER SUBASSEMBLY
633180-305	1285-00-165-9897	RECEIVER-TRANSMITTER SUBASSEMBLY
633180-351	1270-00-165-9922	DVST, YOKE AND SHIELD ASSEMBLY



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
633200-309	1270-00-165-9922	DVST, YOKE AND SHIELD ASSEMBLY
633200-351	1270-00-165-9922	DVST, YOKE AND SHIELD ASSEMBLY
633200-353	1270-01-084-0231	DVST, YOKE AND SHIELD ASSEMBLY
633300-313	1270-00-139-1507	RADAR SET INDICATOR
633353-403	5841-01-121-5928	FRONT RADAR INDICATOR
633353-413		RANGE INDICATOR
633353-427	1270-00-146-3788	RADAR TRANSMITTER
633353-429	1290-00-025-5458	ASSEMBLY
633353-431	1290-00-025-5458	ASSEMBLY
633353-433	1270-01-009-9328	HIGH VOLTAGE MODULE
633353-455	5998-01-043-6552	RADAR MODULATOR NO. 2 CIRCUIT CARD ASSEMBLY
633353-457	1270-01-048-1549	HIGH VOLTAGE MODULE
633356-309	5998-01-083-4328	FILAMENT SWITCHING MODULE
633368-1	5998-01-083-4329	DUAL PRF MASTER TIMING CIRCUIT CARD ASSEMBLY
633368-351	5998-01-070-1455	MODULATOR CIRCUIT CARD ASSEMBLY
633369-1	5996-01-016-1472	INTERMEDIATE FREQUENCY PREAMPLIFIER
633400-305	6130-00-166-0031	POWER SUPPLY HEAT SINK MODULE
633500-307	1270-01-050-5380	POWER SUPPLY HEAT SINK MODULE
633500-315	5996-00-166-0037	SERVO AMPLIFIER MODULE
633500-319	5985-00-139-1505	ANTENNA
633525-301	1270-00-139-1508	RADAR TARGET DATA PROCESSOR
633553-1	1270-00-139-1508	RADAR TARGET DATA PROCESSOR
633553-301	1270-00-394-6741	RADAR TARGET DATA PROCESSOR
633600-351	5998-00-152-6366	WRITE GUN BIAS SUPPLY
633608-1	6220-00-152-6729	EDGE LIGHT PANEL ASSEMBLY
633745-1	6220-00-152-6729	EDGE LIGHT PANEL ASSEMBLY
633800-351	6130-01-121-5929	POWER SUPPLY COUPLER ASSEMBLY
633804-1	5998-01-021-3022	DEFLECTION DRIVER CIRCUIT CARD ASSEMBLY
633878-C	1270-01-042-8436	SLOTTED ARRAY ANTENNA
633922-303	5841-01-121-5930	REAR RADAR INDICATOR
633980-307	5996-01-021-7089	POWER SUPPLY ASSEMBLY
634002-401		GIMBAL WAVEGUIDE
634016-305	5998-01-066-1175	AFC FREQUENCY AGILITY CIRCUIT CARD ASSEMBLY
634100-301	5895-01-079-7114	POST AMPLIFIER/AFC MODULE ASSEMBLY
634101-1	5998-01-076-8409	CURSOR DEFLECT CIRCUIT CARD ASSEMBLY
634104-1	5998-01-076-8410	BIT CIRCUIT CARD ASSEMBLY
634106-1	1270-01-021-2963	RADAR TARGET DATA PROCESSOR
634110-1	5998-01-083-8513	VIDEO AMPLIFIER ("A6") CIRCUIT CARD ASSEMBLY
634200-301	5998-01-135-8072	REGULATOR & SWITCHING CIRCUIT CARD ASSEMBLY
634300-305	1270-01-077-4724	RECEIVER TRANSMITTER
634300-305	1270-01-139-2964	VIDEO AMPLIFIER CIRCUIT CARD ASSEMBLY
634400-303	1270-01-063-7873	ANTENNA LRU
634400-303	5998-01-135-8071	TRANSFER CONTROL CIRCUIT CARD ASSEMBLY
634400-305	1270-01-071-8909	RADAR SET CONTROL
634500-303	1270-01-071-7473	Radar Processor
634500-303	1270-01-077-4724	RECEIVER/TRANSMITTER, RADAR



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
634500-501	1270-01-063-7873	ANTENNA ASSEMBLY
634504-303	5985-01-280-4835	ANTENNA ASSEMBLY
634506-1	1270-01-071-7473	RADAR PROCESSOR
634508-1		RADAR PROCESSOR CHASSIS
634510-301	5998-01-076-8411	MODE CONTROL COMPARISON CIRCUIT CARD ASSEMBLY
634512-1	5998-01-076-8412	ASSEMBLY
634569-301	5998-01-076-8413	ASSEMBLY
634614-1	5999-01-066-1177	SEARCH PROGRAMMER CIRCUIT CARD ASSEMBLY
634684-401	5998-01-076-7899	MULTIPLEXER, RANGE LOGIC CIRCUIT CARD ASSEMBLY
634700-303	1270-01-076-6978	DIGITAL SCAN
634700-303	5996-01-121-5949	ELECTRONIC (SERVO) AMPLIFIER
634734-305	5998-01-076-8414	ANGLE TRACKER CIRCUIT CARD ASSEMBLY
634744-301	5999-01-071-7510	CONTROL LOGIC CIRCUIT CARD ASSEMBLY
634800-305	1270-01-076-6978	DIGITAL SCAN CONVERTER
6-43430-503	1650-00-900-5438	CYLINDER ASSEMBLY
6-43902-507	1650-00-123-8068	CYLINDER ASSEMBLY,ACTUATING,LINE
6-43902-509	1620-01-139-6672	STEERING UNIT,ACFT.NOSE WHEEL
6-43908-1	1650-00-764-6302	VALVE,LINEAR,DIRECT
645504-303	5998-01-076-8417	CIRCUIT CARD ASSEMBLY
64585-303	6615-00-479-9523	GYROSCOPE RATE
6608267-2		BLOWER ASSY-COCKPIT
6-60906-1	6220-00-051-3811	LIGHT,LANDING,AIRCRAFT
6650-5230-5023	2915-01-192-7449	FUEL CONTROL MAIN TURBINE
66WAZ300-5	4320-00-086-7167	PUMP, HYDRAULIC
66WAZ300-6	4320-00-493-1291	HYDRAULIC PUMP
671CPX4-037D	6610-00-526-6083	ALTIMETER,PRESSURE
684400-1	6605-00-292-9214	GYRO G 1200 - 684400-1
6D210		VALVE SELECTOR, FUEL
6U6034	4810-00-487-7721	VALVE
700599-1	5841-01-073-3507	VIDEO INDICATOR
700600-6	5998-01-076-8411	MODE CONTROL COMPARATOR ASSEMBLY
700604-7	4720-00-195-5753	POWER SUPPLY - FILAMENT SWITCHING MODULE
700620-1	1290-00-025-5458	ASSEMBLY
700620-2	1270-01-009-9328	HIGH VOLTAGE MODULE
700630-1	5998-01-086-1364	HIGH VOLTAGE MODULE RESISTOR BOARD ASSEMBLY
700685-4	5998-01-135-5844	ASSEMBLY
7006M51G02	2915-00-480-8112	T5 AMPLIFIER
7006M51G2	5996-00-480-8112	AMPLIFIER, ELECTRONIC
703110-1	5998-01-135-5844	ASSEMBLY
703200-1	1290-00-025-5458	ASSEMBLY
703200-301	5998-01-043-6552	RADAR MODULATOR NO. 2 CIRCUIT CARD ASSEMBLY
703220-1		VIDEO AMPL AND REDESTAL CCT
703241-1	5841-01-311-0200	RECEIVER-TRANSMITTER RADAR
703242-1	5841-01-311-0200	RECEIVER-TRANSMITTER RADAR
703243-1	5996-01-289-8535	POST AMPLIFIER/AFC MODULE
703244-1		HIGH VOLTAGE POWER SUPPLY



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
703306-1	5998-01-346-3221	AUXILIARY MODULE ASSEMBLY
703308-1	5998-01-285-6396	ANGLE TRACKER CCT, CIRCUIT CARD ASSEMBLY
7033089-1	5998-01-285-6396	ANGLE TRACKER CCT, CIRCUIT CARD ASSEMBLY
703315-1	5998-01-285-7908	ASSEMBLY
703317-301	5998-01-285-9787	ASSEMBLY
705533-801	5821-00-493-1364	RECEIVER-TRANSMITTER,RAD
708461-1	6130-00-783-5157á	POWER SUPPLY
708986-801	5821-00-719-6134á	RECEIVER TRANSMITTER
709220-1	5998-01-286-1427	POWER SUPPLY
748871-2	1660-00-399-2368	REFRIGERATION UNIT,AIR CYCLE,AIR
748890-2	1660-01-019-8575	CONTROL DEFOG
749064-6	1660-00-588-3462	COOLING TURBINE
751872-3	1660-01-019-8577	AIR CONDITIONING EQUIPMENT
751872-4		AIR CONDITIONING EQUIPMENT
755-00000-1	6605-01-018-2184	INDICATOR, HORIZONTAL
7829194-30	1620-01-343-2478	LANDING GEAR,RETRACTABLE
836525-3	6615-00-264-0974	COMPONENT ASSEMBLY,STABILITY AUG
836525-5	6615-01-045-7350	STAB. AUG. ASSY
836525-7	6615-01-047-7646	STAB. AUG. ASSY
837976-7	6220-00-361-5150	LIGHT ASSEMBLY,INDICATOR
8-43440-501	1650-00-139-8660	DAMPER FLUTTER
890500-203	6605-01-389-0775	LN-93 INU
8DJ100WBA5	6685-00-469-9323	INDICATOR, TEMPERATURE, THERMOCOUPLE
8DJ135LWB1		RATE OF FLOW IND
8DJ142LXF4	6620-00-003-9771	FUEL FLOW IND
8DJ179WBA1	6685-00-022-7983	INDICATOR, TEMPERATURE
8DJ179WBH1	6685-00-111-4172	INDICATOR TEMPERATURE
8DJ179WBK1	6685-00-138-1564	INDICATOR TEMPERATURE
8DJ81CAA2	6620-00-969-3972	INDICATOR, TACHOMETER
8DJ81LWA2	6620-00-994-9159	TACH IND
8DJ81LWA4	6620-00-684-1952	TACH IND
8DJ81LZA4	6620-00-311-0549	TACHOMETER IND
8DJ96LWA1	6620-00-800-5579	FUEL FLOW IND
8TJ120GAA1	6130-01-060-7619	DUAL POWER SUPPLY
8TJ61GBL3	6620-00-421-2223	FUEL FLOW TRANSMITTER
8TJ85GHX3	6620-01-035-7300	FUEL FLOW TRANSMITTER
906D075-7	6110-00-815-3052	PANEL, PROTECTION
946F769-1	6115-01-044-0507	STATOR,GENERATOR
947F310-1	6110-01-038-5065	CONTROL GENERATOR
976J898-2	6115-00-138-0852	GENERATOR,ALTERNATING CURRENT
976J902-6	6110-01-034-6090	CONTROL GENERATOR
9A1043	6680-01-050-7282	SET INDICATOR,LIQUID QTY
9A1043/9A1044	6680-01-050-7282	INDICATOR SET, LIQUID
A4132210003	6610-00-179-5086	ALTIMETER
A4132210015	6610-01-016-1583	ALTI SERVO CONTROL
A5464220075	2915-00-167-9145	T5 MOTOR & CAM



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
AA318196	1630-00-227-2000	BRAKE, MULTIPLE DISK
AAU-18/A	6610-00-781-5787	INDICATOR, VERTICAL VELOCITY
AAU18A	6610-00-078-5694	INDICATOR VERTICAL
AAU-19A/A	6610-00-086-3840	ALTIMETER, SERVO CONTROL
AAU-34/A	6610-01-115-0131	ALTIMETER, SERVO, CONTROLLED AUT
AAU3AA	6685-00-078-0098	ALTIMETER PRESSURIZED
ABP113-5E	4320-00-763-5908	FUEL PUMP
AL1020M4	1680-00-008-0040	ACTUATOR
AL1020M4-1	1680-01-040-4332	PITCH, TRIM ACTUATOR
AL1020M5	1680-00-999-2269	ACTUATOR, ELECTRO MECHANICAL
ANARN67	1660-00-883-5773	CONVERTER, LIQUID OXYGEN
ARU-20/A	6610-00-148-7180	REMOTE ATTITUDE IND
ARU-42/A-1	6610-00-200-8832	INDICATOR, ATTITUDE
ARU42A1	6610-00-200-8773	INDICATOR, ATTITUDE
AV14K1148	4810-00-295-7133	VALVE, LINEAR, DIRECT
AV16E1171B	2915-00-908-1768	VALVE, FUEL, SHUTOFF
B118-161	6680-00-878-6133	INDICATOR LIQUID QTY
B40550-1	1660-01-407-8855	REGULATOR, OXYGE
C3435210005	6610-01-060-6760	IND., MACH AND TRUE AIR SPEED
CB2125-5	6605-00-815-1903	COMPASS, MAGNE.MI
DSL-647	6680-00-139-0002	INDICATOR, LIQUID QUANTITY
DSL647-2	6680-01-310-3235	INDICATOR
EFU-12A/A	6620-00-897-7759	FUEL FLOW INDICATOR*CRIT*
EHU11AA	6685-00-580-4732	E.G.T. INDICATOR
EHU9A		INDICATOR TEMP
ERU-6A/A	6620-00-022-8056	TACHOMETER IND
ERU6AA	6620-00-043-6082	TACHOMETER INDICATOR
GMU-37/A	6680-00-753-8932	LIQUID OXY QTY IND
GMU37A	6680-00-976-3923	INDICATOR, LIQUID QUANTITY
H1278CP31	5996-01-285-6389	AMPLIFIER
H60G0398	4810-00-735-8305	VALVE, GEAR
M83178-1	1660-00-243-0393	REGULATOR, OXYGEN, DEMAND
MC4358-2	1630-00-112-2603	CYLINDER ASSY
MC7545	6645-00-076-3050	CLOCK AIRCRAFT MECHANICAL
MIL-A-83419	6610-01-035-0673	ALTIMETER SERVO
MIL-C-25973	1660-00-062-2722	CONVERTER, LIQUID OXYGEN
MILI27192	6685-00-226-6612	INDICATOR TEMPERATURE
MIL-I-83026	6620-00-003-9771	INDICATOR, RATE OF FLOW
MIL-R-83178	1660-00-132-3453	REGULATOR, OXYGEN, DI
MS23009-2		ACCELEROMETER
MS24378-2	6610-00-758-3486	TRANSMITTER, ANGLE OF ATTACK
MS27599-1	1660-00-195-2729	REGULATOR OXYGEN DILUTER DEMAND
MS28005-8	6685-00-526-7864	TRANSMITTER PRESSURE
MS28041-1	6610-00-531-5387	INDICATOR TURN AND SLIP
MS28075-1B	6610-00-473-5046	INDICATOR
MS3470L16-8S	5935-01-092-2928	CONNECTOR



WINGS AEROSPACE, LLC

F5 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
OMP3863-5	1650-00-123-8068	ACTUATOR
OMP-3863-5	1650-00-123-8068	CYLINDER ASSEMBLY, ACTUATING
RC-60-AAU/18/A	6610-00-781-5787	INDICATOR VERTICAL VELOCITY
RCS-60-AAU-18/A		VERT VELOCITY IND
RR16500A32		LUBE PUMP
RR52780A	2915-00-382-9088	PUMP,BOOST
S85AVU8A	6610-00-267-9944	INDICATOR AIR SPEED
S85-AVU-8B/A	6610-00-182-7652	MACH/MAX AIRSPEED
S85AVU8BA	6610-00-182-7652	INDICATOR MACH AND TRUE AIR SPEED
S85-AVU-8-B-A		MACH AIRSPEED INDICATOR
SBK16A24G42	6615-00-451-3834	GYROS DISPLAY
V14500-113		VALVE SOLENOID
	5996-01-285-6389	AMPLIFIER
		POST AMP ASSEMBLY
	1270-00-205-8707	DVST, YOKE AND SHIELD ASSEMBLY