

Instructions for Draining Water from Arms

1. Open awning with remote or with crestron about one foot
2. Go inside control box and find the slide switch for motor only.
3. Hold slide switch down for “motor only” until awning stops unrolling
4. Loosen the four screws on the end of the arm to break the seal between the black square bearing and the arm (**NOTE: DO NOT REMOVE SCREWS, ONLY LOOSEN THEM ENOUGH TO BREAK THE SEAL**)
5. Let all the water drip out of the end of the arms.
6. Re-tighten the four screws on the end of the black square bearing.
7. Slide the “motor only switch” up to close the awning until it stops rolling up.
8. Slide the bottom power switch off then on again to reset the PLC.
9. Make sure the X5 and X6 lights are lit up and your awning should be ready to open