



WINGS AEROSPACE, LLC C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
124.013		DUAL TEMP PRESSURE INDICATOR
124.04		AC/DC VOLTMETER
124.115		DUAL TEMP PRESSURE INDICATOR
124.933		TEMP IND
1000		OVEN HEATER
4100		RELAY ASSEMBLY
6204	4810-00-800-0079	VALVE, PRESS
7046	1650-00-071-6388	CYLINDER ASSEMBLY ACTUATING LINE
8118	1680-01-107-2666	ACTUATOR ASSY TRIM TAB
8347	1680-00-373-8044	GEAR BOX ASSEMBLY AL
8446	1680-00-615-1335	ACTUATOR, MECHANICAL
8521	1680-01-257-2445	GEAR BOX ASSEMBLY
8526		ACTUATOR,ELECTRO-MECHANICAL,LINE
8545	1680-01-217-5837	BALLSCREW ASSY
8546	1680-01-222-2551	BALLSCREW ASSEMBLY
13210	4810-00-564-7793	VALVE, LINEAR
13930	4810-00-717-5076	VALVE, FLAP SELECTOR
16000	5996-00-501-2379	N1 AMPLIFIER
21021	4810-00-738-6358	VALVE SOLENOID
22281		Dual Tachometer
27100		SUCTION PUMP
39606	2935-01-244-1475	COOLER LUBRICATING
44910	6230-00-887-2308	LANTERN ELECTRIC
47560	4810-00-208-9693	VALVE LINEAR DIRECT
47610	4810-00-208-9709	VALVE, LINEAR
47680	4810-00-761-6225	VALVE SOLENOID
49740	4810-00-612-2696	VALVE RAMP CONTROL
50320		DAMPENER , FLUID PRESSURE
52760		VALVE, SELECTOR EMERG
53230	1680-01-102-4577	SHUT-OFF VALVE
54055	4320-00-717-1138	PUMP UNIT,CENTRIFUGAL
66039	4320-00-616-3812	PUMP, AXIAL PISTONS
70262	1650-00-803-2221	VALVE BYPASS
89000	6620-00-901-7848	TRANSMITTER, PRESSURE
102402	5895-00-593-0509	EXCITER ASSEMBLY
102981	1650-00-873-6241	TURBINE DRIVES
103432		SHUT OFF VALVE
104156		VALVE
104901	1650-00-872-7516	DRIVE UNIT,AIR TURBINE
106388	4810-00-513-4471	VALVE, BUTTERFLY
108420		STARTER CONTROL VALVE
108605	4810-00-541-6805	VALVE BUTTERFLY
115715	4320-00-6314859	PUMP, CENTRIFUGAL -1/12/2011 - 30/11/2012
121010	4810-01-232-2676	VALVE SOLENOID
121355	4810-00-555-1418	VALVE BUTTERFLY
152297	2995-00-775-9213	ACTUATOR, MOTOR ASSY



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
154485		CURRENT TRANSFORMER
179307	2915-00-616-5726	ACTUATOR ELECTRO ME
190772	2915-00-626-3123	VALVE ASSY PARALLEL
202921	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
203430	1660-00-793-1564	TURBINE, AIRCRAFT CO
301701	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
345384		DOOR ACCESS AIRCRAFT
400201	6645-00-950-8599	CLOCK AIRCRAFT
400202		CLOCK, AIRCRAFT MECHANICAL
400240	6645-00-076-3050	CLOCK
411600		VALVE RELIEF TANK
428066		PUMP ASSEMBLY VARIABLE DISPLACEMENT
519661	1610-00-651-3887	INDICATOR ASSY OIL
520430		VALVE DISCHARGE
537874	6105-00-628-7433	MOTOR 200VAC
538278		AUTOMATIC F. SWITCH
546488	1610-00-179-6130	Valve Housing Cover
554654	1610-00-876-1812	SPINNER FRONT PROPELLOR
554665	1610-00-873-6251	SPINNER, PROP, A/I, REAR
560501	1610-00-873-6424	AFTERBODY HALF BODY
572865	1610-00-862-5524	BRUSH BLOCK, PROPELLER
575427	6130-00-056-6718	STATIC INVERTER
582855	1610-00-009-6832	VALVE HOUSING
615058	6625-00-794-8188	PRE-AMPLIFIER ASSEMBLY
669780		RELAY BOX
692525	5930-00-732-2509	SWITCH PRESS OIL
692993		VALVE SHUT-OFF
695037	1650-00-092-4252	CYLINDER,RAMP UPLOCK
695197	4810-00-529-3253	VALVE LINEAR DIRECTIONAL CONTROL
759057		PUMP
765000	1680-00-073-0841	SUPPRESSOR, SURGE
800530		EXTINGUISHER BOTTLE
1105123	1680-01-208-0174	ACTUATOR,ELECTRO-MECHANICAL,LINEAR
1505380	5841-00-845-4243	GENERATOR,STABILIZATION DATA
1887850	5841-01-051-6339	RADAR AND BEACON CI
1889519		SYNCHRONIZER
1889520		ANTENNA
1889523	5841-01-053-7872	Indicator, Az Range APN-59
5231975	2915-00-897-3164	NOZZLE FUEL SPRAYING
5232105	2915-00-655-1933	FUEL NOZZLE
6404486	2915-00-464-6946	SPEED SENSING CONTROL
6781978	4810-00-540-2106	VALVE SOLENOID
6792265	4320-00-674-0932	PUMP,ROTARY
6794215	2915-00-777-9017	CONTROL ASSEMBLY, CO
6794320		NOZZLE,FUEL SPRAY
6809618	2915-00-655-1933	NOZZLE ASSY FUEL



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
6809636		RELAY BOX
6809639	5945-00-854-4392	RELAY ASSY
6815622	2995-00-877-3666	VALVE ASSY ANTI-ICEING
6821491	2915-01-107-2763	FILTER, FLUID
6821701	6150-00-859-6815	WIRING HARNESS BRANCHED
6824286	4810-00-749-8896	VALVE SOLENOID
6827239	2915-00-706-2719	VALVE ASSY TEMP
6829274	6620-00-856-8263	FUEL FLOW INDICATOR
6846567	4320-00-012-7080	PUMP ASSY OIL SCAVENGE EXTERNAL
6847347		VANE SEGMENT,COMPRESSOR,AIRCRAFT
6852620		SEAL METALLIC AIRCRAFT
6859424	2840-00-127-5730	HOUSING MECHANICAL P&A
6870095	2915-00-458-2767	AMPLIFIER TEMPERATURE
6870215		PUMP & FILTER ASSY
6871248		SEAL METALLIC AIRCRAFT
6873465	2915-00-464-6946	CONTROL ASSY SPEED SEN'R
6894068	2840-01-049-1153	LINER COMBUSTION
8427707	2935-01-202-5339	COOLER ASSY OIL AIRCRAFT
8575600	2915-00-622-4036	CONTROL ASSEMBLY,SP
9550616	1630-00-809-0394	MAIN WHEEL
9560685		BRAKE ASSY
23004669		SEAL ASSY
23031741		VANE SEGMENT 2ND STAGE
23031745	2840-01-255-7498	VANE
23031746	2840-01-247-0263	VANE
23031747	2840-01-247-0266	VANE
23031748	2840-01-247-0264	VANE
23052609	5996-01-274-7553	AMPLIFIER TEMPERATUR
23059687	5996-01-406-4035	AMPLIFIER. ELECTRONIC CONTROL
23064874	2915-01-444-7667	FUEL CONTROL ASSY
26020066	5930-00-860-4159	THERMOSTAT ANTI ICING
26130010	4810-00-987-3948	VALVE,SOLENOID (SHUTOFF VALVE)
27241301	4820-00-006-5087	CHECK VALVE
27431471	1660-01-015-5017	REGULATOR, EJECTOR
76123002		SYNCHROPHASER
1384740101	6615-00-061-3131	GYROSCOPE, RATE SWITCHING MC-1
3.6E+85		STARTER
1.855E+99	1650-00-626-5729	DISC,BRAKE
HEAT		
00000C522	5835-01-128-7757	CKPIT VOICE RECDR (A 100A) W/UNDERWATR LOC BEACON
0019000-01	6625-01-006-1584	TEST SET TACAN
015-870145-3-8	1680-01-437-0394	REEL HARNESS
022489-054-03	4320-00-654-3617	PUMP FUEL ROTARY
066-01127-1601		Mode S Transponder
066-01149-0048		RECEIVER
066-01171-3706	6610-01-433-2219	INDICATOR VERTICAL



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
066-03084-0032		INDICATOR, RADAR TARGET
066-04031-1122		GPS RECEIVER
066-04031-2121		GPS RECEIVER
066-1071-00		TRANSPONDER
066-1077-00		DIG ADF REC
066-3031-01		RADIO ALT IND
066-3046-07		HSI IND
066-3084-32		IND RADAR
066-50000-2220	5841-01-514-7274	(TCAS) PROCESSOR,RADAR DATA
066-50000-2930		TCAS PROCESSOR
0666-5000-2220		T.C.A.S PROCESSOR
071-01480-0001		TCAS CONTROL PANEL
071-01480-001		TCAS CONTROLLER OF TCAS PROCESSOR TPA-81A
071-01515-1301		TCAS CONTROL PANEL
071-01519-0101		RT/ VERTICAL12" ANT
088422-010	1650-00-640-8491	ACCUMULATOR HYDRAULIC
092-000-001	6340-00-304-5556	DETECTOR ICE
10018-01		INDICATOR TORQUEMETER
10040-1000-0101	6680-01-220-4090	FUEL QTY DIGITAL INDICATOR
10040-3000-0101		FUEL QTY IND.
10040-5000-0101	6680-01-224-7271	INDICATOR, LIQUID
1005910-4		HYD. PRESSURE REDUCER VALVE
1005910-5	4829-99-983-3598	VALVE REGULATING
100-601702-051		MCDU CMA-2014
100-601900-402		FMU CMA-900
10073-0101	6680-01-350-8049	INDICATOR, LIQUID
10074-0101		FUEL QUANTITY INDICATOR
1009350-2	2915-00-616-5726	ACTUATOR ELECTRO ME
10095-0101	6620-01-394-4018	INDICATOR
10-111160-3	2925-00-706-2720	EXCITER IGNITION
10-111160-6		VIBRATOR, IGNITION COIL
1012200-4	4810-00-014-1772	VALVE, LINEAR, DIRECT
101450-31243	6610-01-176-9314	ALTIMETER ENDCODER
1018-1-200		CONTROL DISPLAY UNIT
102076-3	1660-00-784-7463	AIR PRESS CONTROLLER
102076-5	1660-00-857-0742	CONTROLLER
102076-745-3	1660-00-784-7463	CABIN PRESS CONTROL
102150-0	1660-00-343-4692	REGULATOR,AIR PRESSURE,AIRCRAFT
102150-0-12		VALVE
102150-0-13		CABIN AIR PRESS VALVE
102150-0-14		CABIN AIR PRESS VALVE
102538-2-1	1660-00-062-0301	CONTROLLER,AIR PRESSURE,AIRCRAFT
102842ED	1680-00-675-8017	ACTUATOR, ELECTRO-MECH
102842FM		ACTUATOR
102842FN	2915-00-775-6674	ACTUATOR,ELECTRO-MECHANICAL,ROTA
103036-3	1660-00-783-6159	REG AIR FLOW



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
103036-5	1660-01-483-3094	REGULATOR, AIR FLOW
103036-724	1660-00-735-3655	REGULATOR,AIR PRESSURE,AIRCRAFT
103432-1		VALVE SHUT OFF
104156-1-7	4810-00-529-3584	VALVE BUTTERFLY
10450-31105	6610-00-160-3226	PRESSURE ALTIMETER
1051R274		GEAR BOX, LANDING GEAR
1051R300	1620-00-406-5828	GEAR BOX LANDING GEAR
106040-1-1		FLOW CONTROL AND SHUT OFF
106040-3	1660-00-625-6195	REGULATOR AIR PRESSURE
106040-4-1	1660-00-084-6707	REGULATOR AIR PRESSURE
10-61068-1	4410-00-689-1609	HEATER WATER ELECT
106388-1-2	4810-00-513-4471	VALVE BUTTERFLY
106616-1-1	1660-00-084-6708	FLOW CONTROL AND SHUT OFF VALVE (FLT DECK)
107996-1-1		PNEUMATIC THERMOSTAT
107996-66	6685-00-934-8208	THERMOSTAT,FLOW CONTROL
108032-0-39		REGULATOR DIFERENCIAL PRESSURE
109016-7	4810-00-797-3261	VALVE LOAD CONTROL
109382-13	4810-00-494-5727	VALVE BUTTERFLY
109486-6-1		VALVE, BLEEDER
109710-2-1		APU BUTTERFLY VALVE
109710-6-1		BLEED VALVE
109710-9-1	4810-01-393-3991	CONVERT LVC
109710-9-1	4810-01-393-3991	VALVE, BUTTERFLY
10C-0001-0026	1660-00-122-8101	CONVERTER LIQUID OXY
10C-0001-26	1660-00-122-8101	CONVERTER,LIQUID OXYGEN
10C-0001-26	1660-00-122-8101	CONVERTER,LIQUID OXYGEN
10-C0001-26	1660-00-768-5256	CONVERTER,LIQUID OXYGEN
1105123-1	1680-01-254-6893	ACTUATOR,ELECTRO-MECHANICAL,LINE
1105123-1	1680-01-254-6893	ACTUATOR,ELECTRO-MECHANICAL,LINE
11060-7	1630-00-859-3997	VALVE, POWER BRAKE
1111-5	1650-00-650-7610	CYLINDER ASSY, ACTUATING
111302-5	6605-01-245-7660	INDICATOR, HORIZONTAL SITUATION
114672-0		PUMP AND CONTROL ASSEMBLY,FUEL
114PS205-2	3010-00-420-5226	ACTUATOR, ELECTRO-MECHANICAL, ROTARY
115-230	6685-01-329-0849	INDICATOR TEMPERATURE
1184R125	1680-00-733-3491	WINCH AIRCRAFT MOUNTED
1184R125	1680-00-733-3491	WINCH, AIRCRAFT
1192-30-111101		NAVIGATION COMPUTER UNIT
1192-30-111101		NAVIGATION COMPUTER UNIT
12085-1		MOTOR ASSY PYLON
12-10001-01	6680-01-419-1995	TRANSMITTER,LIQUID QUANTITY
1214BX-8-05	6610-00-526-7947	INDICATOR AIR SPEED
1214DX8-05	6610-00-530-0026	INDICATOR AIR SPEED
121535-1	4810-00-706-0266	SHUTOFF VALVE ASSY
121535-1	4810-00-706-0266	VALVE AIR BLEED
121535-1	4810-00-706-0266	VALVE BUTTERFLY



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
121672-01-17	6615-00-900-5959	VERTICAL DISPLACEMENT GYRO
123488-010-01	4320-00-631-4859	FUEL PUMP
123488-010-01	4320-00-631-4859	CENTRIFUGAL FUEL PUMP
123510-014-01	2915-01-185-1847	PUMP
124.115-3		DUAL TEMP PRESSURE INDICATOR
124-1006-1	6620-01-328-0926	INDICATOR ENG OIL TE
124-1007-1	6620-01-308-2520	INDICATOR PRESSURE
124-1207	6685-01-328-7139	INDICATOR TEMPERATURE
124623-01-14		MD1 Gyro
124-934		DUAL AC/DC VOLT
124-934A		DUAL AC/DC VOLT
126-179	6620-01-308-2604	INDICATOR, ITT
132555-1		VALVE OIL SHUT OFF
1333-613233		ENGINE BLEED SHUT OFF
1333-613233M1	4810-00-065-9471	VALVE BUTTERFLY
1356-542897	1650-00-987-8389	Accumulator Assembly, Double Shell
1356-542899	1650-00-721-6416	ACCUMULATOR, HYDRAULIC
1371-598820	4810-00-737-3349	VALVE SOLENOID
1372-3		SERVO VALVE HYDRAULIC
140180-01-01	6615-00-738-6204	RATE GYRO
140260-01-03	6615-00-928-0072	GYROSCOPE
14080-1	4810-00-610-9390	VALVE LINEAR DIRECT
14080-1	4810-00-610-9390	VALVE LINEAR DIRECT
147601-2	2915-00-072-6226	HEATER AND STRAINER
147B31A3	6685-00-005-9025	INDICATOR TEMPERATURE
14950-17	1660-00-856-0550	REGULATOR OXYGEN
14950-34		OXYGEN REGULATOR
14950-34M	1660-01-010-4949	OXYGEN REGULATOR
14950-40	1660-00-169-1888	OXYGEN REGULATOR
14950-45	1660-00-169-1888	REGULATOR,OXYGEN,DILUTER DEMAND
149D6050-1	1680-01-021-8032	DROGUE STOWAGE ASSEMBLY
152050-4		OIL COOLER
15482-1A1	5996-00-855-9045	AMPLIFIER, ELECT
1580997-2	6115-00-327-4068	ROTOR GENERATOR
158410-3		OIL COOLER
159245-3		ALTIMETER, INDICATOR
162B2	6685-00-553-4726	INDICATOR, TEMPERATURE
162B202A	6685-00-553-4726	INDICATOR LAMP
162B2D	6685-00-097-6263	INDICATOR,TEMPERATURE,ELECTRICAL RESISTANCE
162B2G	6685-00-005-9024	INDICATOR TEMP
164-1	6680-00-753-8932	LIQUID OXY QTY IND
1650E412	1620-00-677-6681	BALLSCREW MAIN GEAR
1650R319	1680-00-627-9857	GEAR BOX ASSY, MAIN
1701DX10-04	6610-01-067-0228	INDICATOR AIRSPEED
1701DX4-04	6610-00-585-4931	INDICATOR AIRSPEED
1701DX8-04	6610-00-179-9033	INDICATOR AIR SPEED



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1701DX-8-04	6610-00-179-9033	INDICATOR AIR SPEED
179250-0003	5865-01-451-2868	COUNTERMEASURES DISPENSER SWITCH
17960-0102-002		GNS-XLS FMS
179684-1	5996-00-605-8496	AMPLIFIER ASSY
179822-1		TD amplifier
17M700-274		FLIGHT RECORDER
18000-2	5826-01-459-5969	INDICATOR BEARING
18-1105	6685-00-557-0215	FUEL PRESSURE IND.
18-1278		OIL PRESS IND
18-54903-3	1660-01-049-3423	PRESSURE REG. VALVE SHUT OFF
188440-2-1		HEAT EXCH
18900-160	4820-00-880-4744	VALVE REGULATING TE
190772-2	2915-00-626-3123	VALVE ASSY PARALLEL
191006-1-2	1660-01-044-0091	WATER SEPARATOR, AIR CON
191390-2-2	1660-01-150-9084	HEAT EXCHANGER
19-20-5	6610-00-580-9363	INDICATOR, POSITION
1A20454H01	4440-01-324-1783	COMPRESSOR DEHYDRATOR
1A23446H01	5895-01-316-1232	INTERROGATOR SET
1D17431G01	6130-01-182-3032	POWER SUPPLY
1D17431G02	6130-01-318-3166	POWER SUPPLY
1D17627G01	5840-01-182-6432	EXCITER RADIO
1D17627G01	5840-01-182-6432	EXCITER RADIO
1D18517G01		CIRCUIT CARD ASSEMBLY
1D18517G01		CIRCUIT CARD ASSEMBLY
1D18517G02	5998-01-316-0046	CIRCUIT CARD ASSEMBLY
1D20464G01	6130-01-221-6862	INVERT POWER MODULE
1D20801G01	6130-01-215-8501	POWER SUPPLY
1D22877G01		ANTENNA PEDESTAL
1D23052G01	6130-01-262-8351	POWER SUPPLY
1D23551G01	5840-01-350-9085	DISPLAY UNIT RADAR
1D27054G01		CIRCUIT CARD ASSY
1D27545G02	5998-01-300-2228	CIRCUIT BOARD
1D27545G02	5998-01-300-2228	CIRCUIT BOARD
1D27749G02	5998-01-299-9945	CIRCUIT BOARD
1D27749G02	5998-01-299-9945	CIRCUIT BOARD
1D5745G2	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
1D5745G3	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
200-1000-01	6130-01-360-4061	POWER SUPPLY
200-1001-01	6220-01-360-5434	CONTROL ELEC. LIGHT
201-004-001	6620-01-038-5801	TORQUE INDICATOR
20140-0351	6610-00-006-5783	AIRSPD INDICATOR
20-224-01	6680-01-290-5920	INDICATOR, LIQUID QUANTITY
202919-306	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
202921-303	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
203-003-002	6680-00-333-6757	QUANTITY INDICATOR
203720-1	1660-00-897-4306	TURBINE, AIRCRAFT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
203720-3		TURBINE COOLER
2038091-0502		RX-AFC MOD
2041232-1104	6210-00-140-8738	RADAR PILOTO INDICATOR
2041232-3110		RADAR INDICATOR
2052002-521	5826-00-543-0759	RECEIVER
206-075-190-1		TEMP. INDICATOR
2067157-0162		RADAR TRANSCEIVER
2068599-0705	5985-01-495-3531	WAVE GUIDE SWITCH
2070409-0101		RADAR ANTENNA
2070409-0101		RADAR ANTENNA, WEATHER
2070410-0101	5821-01-408-7392	TRANSCEIVER
2070410-0101	5821-01-408-7392	WEATHER RADAR RECEIVER TRANSMITTER
2070552-0103		RADAR CONTROL UNIT
2070963-0103		WEATHER RADAR RT
2070963-0104		RECEIVER TRANSMITTER RADAR
2070963-0105	5841-01-314-9947	TRANSCEIVER RADAR
2070964-0107	5841-01-314-9991	SCOPE RADAR
2070965-0105		CONTROL SET RADAR
207410-0101		RNTX UNIT RADAR IF
209-070-262-101	5895-01-252-5691	TEMP INDICATOR
209-070-262-3		INDICATOR TEMP
209-070-262-9		INDICATOR,TEMP PRESS
209-070-263-1	6625-00-248-6971	DUAL AC/DC VOLT
209-070-263-3		DUAL INDICATOR
209-070-264-1	6625-00-248-6976	AMP METER
209-070-264-3		DUAL AMP METER
209-070-275-1	6620-15-160-0834	INDICATOR FUEL 0-50 PSI
20B95-4	6110-01-109-5099	REGULATOR VOLTAGE
20B95-4A	6110-01-109-5099	REGULATOR,VOLTAGE
210-2360	4730-00-626-9199	SWIVEL JOINT
21086-1	1660-00-730-0150	CONVERTER,LIQUID OXYGEN
2118-363		ACCELEROMETER
2119-001	6610-00-585-5929	ACCELEROMETER
2119-001-2	6610-00-585-1355	ACCELEROMETER
2119-500	6610-00-007-1030	ACCELEROMETER, MECHANICAL
212-070-108-7	6680-01-492-3356	TRIPLE TACH IND.
212-070-116-9	6620-01-492-3358	PRESSURE INDICATOR
212-070-160-005		DUAL TORQUE IND.
212-070-160-101		DUAL TORQUE IND.
212-070-160-15		DUAL TORQUE IND.
212-070-160-17		DUAL TORQUE IND.
212-070-160-5	6680-01-478-4288	DUAL TORQUE IND.
212-070-160-7	6680-01-492-3357	DUAL TORQUE IND
212-070-238-3		ALTIMETER
212-070-238-7		ALTIMETER
212-070-239-001	6610-00-617-6056	VERTICAL SPEED INDICATOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
212-075-036-101	6625-01-252-7616	INDICATOR,TEMPERATURE
212-075-037-101		GAS PRODUCER TACH
212-075-067-105		ITT INDICATOR
212-075-420-3		ITT INDICATOR
212-075-562-1		ITT INDICATOR
212-075-562-3	6685-01-492-2612	INDICATOR I.T.T.
219A967	1630-00-914-1329	WHEEL LANDING GEAR
219A967-1		NOSE WHEEL
21B17-10-B	6110-01-044-4331	REGULATOR VOLTAGE
2200440-6-1		REFRIGERATOR UNIT
22A703		TACH GENERATOR
2301420-1	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
23052609A	5996-01-274-7553	AMPLIFIER TEMPERATURE
23079-1020		ARMATURE
23410-3	1630-00-998-7897	VALVE, BRAKE CONTROL
235550-4	5821-01-245-9095	RECEIVER, TRANSMITTER
239-004		FREQUENCY METER
2488136G001	5865-01-178-0408	DOWN CONVERTER MIXER
25100-004		ALERTER
25122A37B-1-A1		HYD PRESSURE IND.
2527T100-1	1680-00-070-9980	WINCH
25430135-06		CONTROL BOX TEM
25430135-07	1660-00-387-4319	BOX CONTROL TEMP
25530562-01		THERMOSTAT
25730032-04		AIR CONTROL VALVE
25730043-03		VALVE,SOLENOID
2586257-1	6605-00-447-9654	COMPENSATOR, REMOTE
2586261-1	6605-00-447-9665	DIGITAL CONTROLLER
2586333-1		DIRECTIONAL GYRO
2586333-2	6615-00-180-0895	DIRECTIONAL GYRO
2586333-3	6615-01-065-7226	GYROSCOPE DISPLACEMENT
2587193-43	6615-01-020-7531	GYRO DIRECTIONAL
2588302-3		GYROSCOPE DISPLACEMENT
2589226-1		AMP POWER SUPPLY
26130010-01	4810-00-987-3948	VALVE SOLENOID
2690346-1	6615-01-260-8214	RATE INTEGRATING GYRO, LC22
270-2196-020	6615-01-068-8713	AIRSPEED SENSOR
27231317-01	1660-01-014-4509	CONTROLLER TEMPERATURE
275540-003	5826P275540-003	RMI
27620-1	1650-01-217-7899	BRAKE HYDRO-MECANICAL
28B135-145A		AC GENERATOR
28B58-93	6115-01-224-5848	GEN ALTERNATING
28B58-9B	6115-01-224-5848	GENERATOR ALTERNATOR BEN
28B58-9-B	6115-01-224-5848	GENERATOR, BENDIX
28VS200C1	6130-00-081-7844	POWER SUPPLY
28VS200C-1	6130-00-081-7844	POWER SUPPLY



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
2905-001	6105-01-216-4182	MOTOR,DIRECT CURRENT
29270-10A-A1	1660-00-243-0393	OXYGEN REGULATOR
29270-10A-B1	1660-00-243-0393	OXYGEN REGULATOR
2CM11BAA5	6620-00-785-2251	ALTERNATOR
2CM353C1	6115-00-946-8441	Generator Alt
2CM5ADR	6680-00-487-4289	Tach Generator
2CM63E1A	2925-00-178-0940	GENERATOR
2CM9ADE8	6680-00-008-4544	TACHOMETER GENERATOR
3006T88G05	2915-00-143-6107	VALVE, FUEL PRESS
30-231	6340-01-087-2792	SMOKE DETECTOR TYPE II
30678-17	1680-00-797-4478	ACTUATOR ELECTRO MECH
31008-1066		ROTOR,GENERATOR
31-032599-04	5985-01-154-9125	AMPLIFIER DETECTOR
31220-004	6115-00-678-6319	GENERATOR AC
31416000-1	6130-01-387-7271	POWER SUPPLY
318357-000	5998-01-236-3735	BACKPLANE ASSEMBLY
318427-001	5998-01-407-6121	CIRCUIT CARD ASSEMBLY
318476-901	5998-01-269-6978	VIDEO PROCESSOR NO. 1 CIRCUIT CARD ASSEMBLY
318557-000	5998-01-236-3735	BACKPLANE ASSEMBLY
32005-007	6680-00-585-1503	TACHOMETER GENERATOR
320362-3-1		VALVE , SOLENOIDE
32-054528-02	5865-01-165-9375	RF ASSEMBLY (A5)
32-054542-01	5865-01-059-4560	IF FILTER
32-054576-01	6130-01-059-1470	POWER SUPPLY
3213722-2-1	4810-01-004-5634	VALVE REGULATING
3213722-3-1	4820-01-093-9141	BLEED VALVE ASSY
3213722-5-1	4810-01-157-2583	VALVE REGULATING FLUID
321502-4-1	4810-00-796-1672	VALVE BUTERFLY
32220-1	1680-01-387-6739	WINCH, AIRCRAFT
325996-003	5998-01-459-5226	CIRCUIT CARD ASSEMBLY
3260011-0101	1660-01-005-6318	REG OXYG DILUTER
3290290-1-1	4810-01-482-4911	VALVE, BUTTERFLY
3290290-2-3	4810-01-417-7022	VALVE, BUTTERFLY
330332-4	2915-00-706-2719	TD VALVE
330332-5	2915-01-318-8927	VALVE, TEMPERATURE D
3303583-5	1620-00-572-2605	COLLAR, ACTUATOR ATT
3303591-1	1620-00-085-2624	NLG STRUT ASSY
3303591-3	1620-00-505-1184	LANDING GEAR,RETRACTABLE (NLG STRUT ASSY)
330625-101	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
330625-211	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
3308-950	6605-00-020-3886	SERVO MECHASISM
3316498-1		MLG SHOCK STRUT ASSY
3318488-1	1660-01-130-4645	CONTROL BOX WINDSHIELD
3-34D15	6130-01-170-7850	MC-1, POWER SUPPLY
338329-26		LEADING EDGE, OUTER
3400770-7	1620-00-410-0874	NLG CYLINDER



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
3401835-3		PARTS KIT PROPELLER
3402292-1	6110-01-109-5100	PANEL CONTROL
3403172-1	4920-01-236-7670	TEST SET, INDICATOR
34102C1C4-1C1	6620-00-959-6614	INDICATOR, TACHOMETER
341417-3		MANIFOLD ELEVATOR
343D902G01		INDICATOR HEIGHT
34538-4	1680-00-845-0699	ACTUATOR SPOILER DOOR
3505228-1-1	2995-00-337-5145	STARTER,ENGINE,AIR TURBINE
3505230-1-1	2995-00-337-5116	STARTER ENGINE
35-055	4810-00-528-3666	VALVE, SOLENOID
3505786-1	2995-01-493-4166	STARTER,ENGINE,AIR TURBINE
3505786-1-1		STARTER
352-1	7025-01-211-6011	PRINTER AUTOMATIC
352863-9		SCOOP ASSEMBLY ENGINE
353D226G01	5840-01-066-9001	INTERFERENCE BLANKER SET
353D582G01	5985-01-027-0225	COUPLER ROTARY RADIO
3567609-3703	6685-01-146-8649	AUTOSYN PRESSURE TRANSMITTER
3571281-8102	6620-01-159-4330	TACHOMTER
359900-27		CONTROL COLUMN
3603100-1		FUEL CONTROL
3603100-1-1	2910-01-013-2741	FUEL CONTROL
360414-1L	1560-00-613-6501	DOOR ACCESS AIRCRAFT
3604174-1	5930-01-019-5594	SWITCH SLIDE
3604174-1-1	5930-01-019-5594	SWITCH SLIDE
360614-1	1560-00-624-9338	DOOR,AIRCRAFT
3609150-3-1		FUEL CONTROL UNIT
3609150-8	2910-01-329-3239	FUEL CONTROL
3614657-0102	5841-01-314-9993	MODE SELECTOR
362511-95	1560-00-886-9037	Tank Oil
363001-1		DOOR PASSENGER AIRCRAFT
363498-1	1650-00-652-9673	ELEVATOR HYD BOOSTER
364D540G01		FREQUENCY MULTIPLIER
365D019G01	5840-01-158-0146	PULSE FREQUENCY MODULE
36A225543G01	6115-00-412-0340	STATOR,GENERATOR
36A84		STARTER
36E165-2C		AIR STARTER
36E165-2QC	2995-01-329-6341	STARTER,ENGINE,AIR TURBINE
36E84-18		STARTER
36E84-18F	2995-01-060-4443	STARTER, AIR TURBINE
36E84-18QC	2995-01-060-4443	STARTER, ENGINE, AIR TUR
36E84-18QD	2995-01-130-9394	STARTER ENGINE AIR TURBINE
36E84-18QF	2995-01-194-8153	STARTER,ENGINE,AIR TURBINE
370012-1		LEADING EDGE, VERTICAL
370018-5	1560-00-928-3106	ELEVATOR AIRCRAFT
370018-6	1560-00-928-3105	ELEVATOR AIRCRAFT
370510-29	1560-00-716-2869	LEADING EDGE AIRCRAFT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
370749-1	1650-00-620-7514	CYLINDER ASSEMBLY
370750-1	1650-00-788-8799	CYL ASS RAMP
371688-101	2910-00-907-7481	FUEL PUMP & CONTROL ASSY
371688-39	2915-01-171-3486	PUMP & CONTROL UNIT FUEL
372021-11	1650-01-132-3641	SERVO MECHANISM, HYDRAULIC/PNEUMATIC, AIRCR
372021-11X119	1650-01-132-3641	BOOSTER ASSY RUDDER
372021-5	1650-00-651-4180	RUDDER CONTROL BOOSTER
372021-7		SERVOMECHANISM, HYDRAULIC/PNEUMAT
372522-80	1560-00-084-3747	DOOR LANDING GEAR
372697-18	2920-01-013-9867	STARTER, ENGINE, ELECTRICAL
372697-18-1	2920-01-359-9819	STARTER
372697-24-1	2925-01-217-5889	STARTER, ENGINE, ELECTRICAL
373531-5	1620-00-953-5572	NLG STEERING VALVE
373531-7	1620-00-953-5572	VALVE, STEERING
374455-2	1650-00-784-9692	AILERON BOOSTER ASSY
374455-3	1650-00-784-9692	SERVOMECHANISM HYDRAULIC
374455-7	1650-01-134-4415	SERVOMECHANISM HYDRAULIC
374461-5	1650-00-784-9693	ELEVATOR CONTROL BOOSTER ASSY
375322-10		STARTER, ENGINE, ELE
375322-9	2920-00-060-0057	STARTER ASSY
375456-7	1560-00-912-1806	FLAP INBOARD LH
376730-0-024	2835-00-007-7955	GTC
376730-0-24	2835-00-007-7955	GAS TURBINE COMPRESSOR
37D401750P104		SPRAYBAR ASSY, MAIN
38106-001	6130-01-217-5880	POWER SUPPLY, REMOTE
381116-1	2835-01-056-6467	AUXILIARY TURBINE (APU)
381116-1-7		APU
381116-1-8	2835-01-437-1578	ENGINE, GAS TURBINE, NONAIRCRAFT
381252-1-1	2835P381252-1-1	APU ASSY GTC P85-185L
38140-7	1680-00-677-6238	ROTARY ACTUATOR
38140-9-1		ROTARY ACTUATOR
382052-1	1560-00-716-2869	LEADING EDGE ASSY
383198-1-1	2995-00-985-1355	STARTER ENGINE AIR TURBINE
383534-2-1	2995-00-007-7957	STARTER ASSY
383534-2-2		STARTER
388028-19	1620-01-423-3708	PISTON, LANDING GEAR
388059-11	1620-00-862-4057	PISTON AY SHOCK STRUT
388064-3	1620-00-805-8495	DRAG BRACE, LANDING GEAR, MLG
388071-3	1620-00-085-2624	LANDING GEAR, RETRAC
389154-1	1560-00-888-2231	RADOME ASSY
38E73-4A	2925-01-038-5770	VALVE CONTROL
38E73-7A	4810-01-060-5087	VALVE ASSY, STARTER CONTR
39-075	1630-00-908-9999	VALVE, DUAL CONTROL
39-075A	1630-00-998-7896	VALVE, SKID CONTROL
392122-1-1	4810-00-897-7308	VALVE, STARTER CONTROL
396308-1-1	4810-01-040-2372	VALVE CONTROL FLOW



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
396308-2-1	4810-01-040-2372	VALVE CONTROL FLOW
396308-2-2	4810-01-040-2372	VALVE CONTROL FLOW
398648-1-1		VALVE, BUTTERFLY
398648-1-2	4810-00-575-7781	VALVE BUTTERFLY
398650-1-1	4810-00-575-7789	VALVE,BUTTERFLY
398654-1-1	4810-00-601-3194	TEMP CONTROL VALVE
398654-1-2	4810-01-039-0459	SHUTOFF VALVE
3D58770G01	5985-01-387-4414	COUPLER ROTARY RADIO
3S2060DC102D1	6110-00-944-3046	CONTROL GENERATOR
3S2060DR113C2	6110-01-206-9877	REGULATOR VOLTAGE
4000504-0301		Antenna, Radar
4000504-0303		RADAR ANT
4000831-0105		RADAR RT
4001670-2511		INDICATOR RADAR TARGET
4020936-903	6615-01-280-4702	SYNCHRONIZER, ELECTR
4024400-7		FLIGHT RECORDER
403-6BX		RELAY VOLTAGE AC
40-621	6695-00-719-7103	TRANSDUCER
4088T42P01	6620-01-328-6973	INDICATOR ELEC TACH
41 10004		SUCTION PUMP
411000-2	4320-00-050-8205	PUMP HYDRAULIC
411000-4	4320-00-152-1488	Pump, Suction Boost Hydraulic
41-2036-004		VALVE, SOLENOID
41750-3-41BG		CARGO WINCH
41C220-53	1660-00-822-3344	VALVE AIR
42-109	1630-00-085-2625	BOX CONTROL ANT-SKI
42-109-1A	1630-00-133-8183	CONTROL UNIT ANTISKID
42-109A	1630-01-104-1015	ANTI-SKID BOX
430391A		REGULATOR,VOLTAGE
4344D1-3	1680-01-181-9873	ACTUATOR INBOARD WING FLAP JACKSCREW
4344D1-4	1680-01-181-9874	ACTUATOR INBOARD WING FLAP JACKSCREW
4344D2-1		SCREW AND YOKE, OUTBOARD
4344D2-3		SCREW AND YOKE, OUTBOARD
4344EA-2	1680-01-004-2086	SCREW ASSEMBLY INBOARD
4344EA3	3040-01-414-2019	ACTUATOR,MECHANICAL,LINEAR
4344EA-3	3040-01-414-2019	ACTUATOR JACK SCREW
4344EA-4		SCREW ASSEMBLY, INBOARD
43932-052	6610-01-074-2819	ALTIMETER
440970-1		FUEL CONTROL UNIT
440970-2	2915-01-113-8557	CONTROL, MAIN
440978-1	2915-01-008-7398	FUEL CONTROL UNIT
44344EA-4		ACTUATOR ASSY
45-0024-1	6220-00-051-3811	LIGHT LANDING
451200-02-03		MODE SELECTOR UNIT LTN-92
452080-05-04	6605-01-107-5585	INERTIAL NAV UNIT LTN-72
452080-05-85-15		INU/GPS



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
452090-02	6605-01-053-5554	CONTROL DISPLAY UNIT
452100-02		LTN-72 MODE SELECTOR
452100-02-03	6605-01-290-5720	MODE SELECT UNIT LTN-51
452574-01	6605-01-048-2000	COMPUTER NAVIGATION LTN-51
454620-01-28-04		INERTIAL NAV UNIT LTN-72
457EA1		ACTUATOR MECHANICAL
457EA2	1680-00-777-0135	ACTUATOR O/B FLAP JAKSSC
457EA3		BALLSCREW ASSEMBLY
457EA-3	1680-00-777-0136	ACTUATOR
457EA4	1680-00-773-2904	GEARBOX WING FLAP
458900-06-01	7025-01-290-5721	CONTROL DISPLAY UNIT
458900-08-01		CONTROL CDU UNIT LTN-92
463001-04-05	6605-01-294-6975	INERTIAL NAV UNIT LTN-92
463001-6000-0413		INERTIAL NAVIGATION UNIT
463001-7000-0506	6605-01-425-2022	CONTROL UNIT,NAVIGATION SET (LTN-92)
468100-0-1		RELAY DE-ICING TIMER
482-0061-030	6655-01-283-0303	RADIO MAGNETIC INDICATOR
4A037-1	4810-00-908-2931	VALVE LINEAR
500012-01	6130-01-412-3096	INS (BATTERY)
500702-3021	4140-00-051-2620	FAN, VANEAXIAL
5008-3001		SERVO TEMP INDICATOR TOT
50150-20	4810-00-728-3396	VALVE,LINEAR,DIRECTIONAL CONTROL
5021-3001		TURBINE OUTLET TEMPERATURE INDICATOR
502BL10	6685-00-061-6255	INDICATOR TEMP
502BL10A	6685-00-937-4039	INDICATOR TEMPERATURE
510414-3-2	6610-00-759-7170	COMPUTER, TRUE AIR
51107-003	6110-00-649-8835	REGULATOR VOLTAGE
51509-002R	6110-00-165-3755	VOLT REG & PROT PANEL
51509-009D		GENERATOR CONTROL UNIT
518-28007-204	6610-01-259-0251	ALTIMETER, ENCODING
518-28007-208	6630-01-071-1654	ENCODING ALT
52.0261.650.00	5865-01-059-4560	IF FILTER
522-1230-00		RECEIVER TRANSMITTER
522-1501-00		HF TRANSCEIVER
522-1658-000		MOUNTING BASE ELECTRIC
522-2213-000	5821-00-838-7051	Control Radio Set
522-2424-004	5821-00-846-6037	OSCILATOR RADIO FR
522-2447-252		CONTROL NAVIGATION
522-2447-556		CONTROL RADIO SET
522-2494-100	5826-00-346-7298	INSTRUMENTATION
522-2702-014		D.M.E.
522-2702-061		D.M.E.
522-2900-057	6615-01-038-7294	CONTROL, SERVO, AUTOMATIC PILOT
522-2996-011	5826-00-114-4063	RECEIVER RADIO NAVIG
522-3195-00	5895-01-106-3765	RECEIVER RADIO
522-3197-00	5826-00-141-3785	INSTRUMENTATION



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
522-3552-005	5955-00-768-7694	OSCILLATOR
522-3698-003	5826-00-758-4546	ALTIMETER RADIO SET
522-3985-001		VERTICAL GYRO
522-4114-003	5841-00-758-4547	INDICATOR RADIO ALTIM'TR
522-4114-010	5841-00-134-5975	INDICATOR RADIO ALTIMETER
5232105N		FUEL NOZZLE
523EA-8		FLAP DRIVING MOTOR
528-0113-005	5821-00-868-7528	TRANSLATOR, SIGNAL DATA
528-0598-004		POWER SUPPLY
53150-1	4810-01-066-0321	VALVE LINEAR DIRECTION CONTROL
53230-1	2995-01-228-8008	VALVE
532-38105-202	6610-01-263-1400	INDICATOR AIRSPEED & DIRECT
532-38105-304		INDICATOR AIRSPEED
53C3794	1660-00-787-3961	PORTABLE OXYGEN BOTTLE
540200-2	1680-00-080-2959	ACTUATOR ELECTRO-MECHAN
540200-3	1680-00-060-2959	ACTUATOR
540538-2-1		ACTUATOR
540906-2-6	4810-00-999-5275	ACTUATOR ELECTRO MECH
540906-3-5	4810-01-083-3603	ACTUATOR ELECTRO MECHANICAL
541214-1-2	1660-00-777-0154	ACTUATOR ELECTRO-MECHAN
544-9291-00	6130-00-019-8398	Power Supply
544-9293-00	5896-00-845-8367	RECEIVER TRANSMITTER SUBASSY
546-7273-004	5821-00-818-3738	AMPLIFIER SUBASSEMBLY
549-1680-004	5821-00-019-6291	BOARD ASSY
54H60-117	1610-01-096-7677	Hub & Blade
54H60-91	1610-00-846-8332	PROPELLER,AIRCRAFT
54H60-91/-117		PROPELLERS
5502636-2	5996-01-096-4648	AMPLIFIER,ELECTRONIC CONTROL
5502636-4	2915-01-221-6837	AMPLIFIER,TEMPERATU
551R291G01	6130-01-310-4939	POWER SUPPLY
551R291G02	6130-01-310-4939	POWER SUPPLY
562A5M5	6615-01-040-0126	COMPUTER,FLIGHT CONTROL
562C-8A	6625-01-038-7297	YAW COMPUTER
57023932-012		ALTIMETER
570-23932-012	6610-01-074-2819	ALTIMETER BAROMETRIC
571925-3-1	1660-01-036-5903	TURBINE ACFT COOLING
57-761-04	4820-00-876-9872	VALVE,REGULATING,FLUID PRESSURE
581R481H01	5996-01-036-5639	SOLID STATE AMPLIFIER
581R481H04	5996-01-224-7914	AMPLIFIER ASSEMBLY
583R181H03	5865-01-082-0338	SIGNAL PROCESSOR
583R181H08	5865-01-224-2714	PROCESSOR, COUNTERMEASURES SIGNAL
585R195H03	5996-01-224-8905	RADIO FREQUENCY AMPLIFIER
585R944H01	6130-01-192-6999	POWER SUPPLY
585R944H02	6130-01-361-0655	POWER SUPPLY
590A3J	6615-01-038-7296	CONTROL, AIR DATA
590A3J1	6615-01-477-9209	CONTROL AIR DATA



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
590A-3J1	6615-01-091-0363	AIR DATA CONTROL
5A527-000	2935-00-966-3321	COOLER AND VALVE
5A835	2935-00-999-5673	COOLER & VALVE ASSY
5A844	4820-00-072-5573	VALVE, REGULATING, TEMPERATURE
5A844-000		VALVE, REGULATING
5C16-42-35K05-1D		INDICATOR AIRSPEED
5C16-42-35K05-1DA		INDICATOR AIRSPEED
5C5786		SWIVEL,JOINT HIDRAULIC
5C5787-3	1650-00-009-6833	VALVE ASSEMBLY HYDR
5C5787-7	1650-00-208-3344	SERVO VALVE HYDRAULIC
5C5788-3	1650-00-007-1027	VALVE ASSY
5C5791	1650-00-257-7934	CYLINDER ASSY ACTUATING LINE
5C5792-1	1650-01-069-2337	CYLINDER ASSY,ACTUATING
6014-1		THERMOSTAT OIL TEMP CONTROL
601-4203-003		CIRCUIT CARD ASSY.
601-4204-003		CIRCUIT CARD ASSY.
601-4205-001		CIRCUIT CARD A-5
601-4209-001		CIRCUIT CARD
601-4209-003		CIRCUIT CARD
601-4301-001		CIRCUIT CARD ASSY.
601-5764-001	5998-01-270-1079	CIRCUIT CARD ASSY
601-5779-004		CIRCUIT CARD ASSEMBLY
601-5780-002	5998-01-121-7033	CIRCUIT CARD ASSEMBLY
601-5801-004	5998-01-134-1079	CIRCUIT CARD ASSEMBLY
60-369A	2915-00-971-9130	PUMP FUEL TANK
60-371B	2915-00-971-9131	PUMP SUBMERGED ACFT
60-371D	2915-01-160-8283	PUMP SUBMERGED AIRCRAFT
60-551	4320-00-631-4859	PUMP UNIT ROTARY
608-6615-001	5999-01-115-1898	CIRCUIT CARD ASSY
609-8479-001		CIRCUIT CARD ASSY
609-8479-013	5998-01-074-3255	CIRCUIT CARD ASSEMBLY
611J781G10	5840-01-182-1110	MATRIX COMBINER
611J870G01	5840-01-182-1107	MATRIX ASSY
617-8408-001	6130-01-086-8130	POWER SUPPLY
617-9113-004	5998-01-086-2023	CIRCUIT CARD ASSEMBLY
618-3896-004	5999-01-115-1899	CIRCUIT CARD ASSEMBLY
618-4349-001		SENSOR SUB ASSY
61B3-1A	6115-00-351-5766	DISCONNECT ASSY, GEN. PROP.
61B3-1-A	6115-01-459-1272	DISCONNECT ASSEMBLY
62-052748-01	5985-01-062-8035	RF SWITCH
621-0453-003	6625-01-092-5457	SYNTHESIZER ELECTRIC
62201239-001		RECEIVER, VOR/LOC/GS/MB
622-0458-001		COUPLER ANTENNA
622-0507-001	5826-01-012-1938	RECEIVER-TRANSMITTER, RADIO
622-0944-003		MODE SEL
622-0945-007	6615-01-038-7295	MODE SELECTOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
622-1001-001		CONTROL AIR DATA
622-1001-002	6615-01-038-7296	CONTROL AIR DATA
622-1001-022	6615-01-038-7296	CONTROL AIR DATA
622-1239-001		VOR RECEIVER VIR-31
622-1396-002		VHF COM TRANSCEIVER
622-1396-102	5821-01-316-3554	RADIO SET
622-1678-001	5826-01-012-4864	ADAPTER MX 9577A
622-2224-002		ATC TRANSPONDER
622-2224-003		ATC TRANSPONDER
622-2360-001	5826-01-012-7084	CONTROL C-10057A-ARN 118
622-2362-001	5826-01-125-1023	RECEIVER,RADIO
622-2921-002	5826-01-126-6339	DME TRANSCEIVER
622-3016-001	6615-01-168-4952	SERVO PRIMARY
622-3257-001		RECEIVER VOR/ILS
622-3371-001	5820-01-312-2024	TRANSCEIVER (628T-2A)
622-3372-001		RECEIVER - TRANSMITTER
622-3374-002	6610-01-101-1927	INDICATOR ATTITUDE
622-3380-001	5895-01-122-3456	AMPLIFIER RADIO SET
622-3700-001	5821-01-081-0367	RECEIVER TRANSMITTER
622-3702-001		BEARING DIST IND
622-3742-001		RECEIVER TRANSMITTER
622-3890-003	5841-01-220-1390	ALTIMETER SET, ELECT
622-3915-001		INDICATOR,RANGE
622-4298-001		HORIZONTAL SITUATION IND
622-4393-002	6615-01-092-0363	CONTROL BOX
622-4394-013		COMPUTER AIR DATA
622-4565-001	6615-01-328-1062	VERTICAL REFERENCE GYRO
622-4956-004	5821-01-286-6543	RECEIVER
622-4956-103	5821-01-258-7579	RECEIVER-TRANSMITTER, RADIO
622-5132-401	5841-01-432-3798	RECEIVER TRANS
622-5146-001		TACAN RT
622-5377-001	5895-01-254-2749	RECEIVER TRANSMITTER
622-5486-001	5826-01-188-4493	SELECTOR, MODE
622-5486-001N		MODE SELECTOR
622-5796-399		AP COMP
622-5846-011		MODE SELECTOR
622-6129-001	5985-01-151-5848	COUPLER,ANTENNA
622-6136-002		GYRO
622-6190-204	5895-01-289-5799	COMPUTER
622-6324-002	5821-01-215-3451	V/UHF CONTROL PANEL
622-6376-004		RECEIVER, RADIO
622-6521-015	5895-01-493-3013	NAV CONTROLLER
622-6521-016	5821-01-249-6476	CONTROL INDICATOR
622-6728-213	6610-01-450-2713	INDICATOR AIR SPEED
622-8051-003	6605-01-450-7993	COMPUTER, AIR DATA
622881-09		SERVO AMPLIFIER,MOD 1&2



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
622-9210-004		TRANSPONDER
622-9722-233	6610-01-450-2710	ALTIT, PRE, AUP, LRU1
622G607	5840-01-088-9011	BALL TRACKER
6-256-251	2915-00-822-3059	VALVE, FLOAT VENT
630-34960-235	6610-01-312-1580	COMPUTER AIR SPEED
630-37070-235	6610-01-101-1905	COMPUTER AIR SPEED
6350-A33-CC-C	1660-00-250-0681	CYLINDER VALVE ASSY
64141-351-1		ALTIMETER
642-4203-001		CIRCUIT CARD RMI DRIVER
642-4204-001	5998-01-370-9424	CIRCUIT CARD
642-4208-001	5961P*-4208-001	CIRCUIT CARD
642-4214-001		INTERCONNECT BOARD
6-458-101-1	2915-00-566-0334	FUELING VALVE
645A570A01	5895-01-182-1104	RECEIVER SUB ASSY
645A589A07		AMPLIFIER RADIO FREQUENCY
648R028G02	5995-01-057-0538	CABLE ASSEMBLY
648R195G01	5995-01-056-8526	CABLE ASSEMBLY, W7
656751-2	6986-00-137-0488	DRIVE ANTENNA
657501-1	5895-00-411-3480	NOISE SOURCE, AVALANCHE, SOLID STATE (RCVR - XMITTER)
657565-1	5998-00-411-1682	CORRECTION CIRCUIT CARD ASSEMBLY
657670-2		RECEIVER RADAR
657793-1	5841-00-411-3461	MODULATOR RECEIVER
657828-1	5895-00-411-3464	AMPLIFIER, INTERMEDIATE
658020-1	5841-00-411-3473	OSCILLATOR SOLID STATE
65A27D1	5841-00-900-8081	WARNING SET
66039-01	4320-01-171-0452	HYDRAULIC PUMP
662841-14	5985-00-252-3494	SEQUENCER, MOD 1
662845-06		CIRCUIT CARD ASSY.
662845-07	5999-00-153-4123	CIRCUIT CARD ASSEMBLY
662849-01		SYNCHRO REPEATER
662849-06		SYNCHRO REPEATER LTN 51
662849-12		SYNCHRO REPEATER
662853-03	5998-00-153-4126	CIRCUIT CARD ASSEMBLY
662853-6	5998-00-153-4126	CIRCUIT CARD ASSY. LTN-51
662857-12	5975-01-240-3259	MOUNTING BASE ELEC LTN-51
662857-13	5975-01-240-3258	MOUNTING BASE ELEC LTN51
662869-05		INPUT CONVERTER
662873-06		CCA D/A CONVERTER
662881-01	5998-01-319-3886	CIRCUIT CARD ASSEMBLY
662881-01-04		SERVO AMPLIFIER, MOD3
662881-04		SERVO AMPLIFIER UNMODIFY
662881-05		SERVO AMPLIFIER UNMODIFY
662881-06		SERVO AMPLIFIER
662881-17		SERVO AMPLIFIER, MOD 3
662881-18	5975-01-240-3258	SERVO AMPLIFIER MOD3
662889-04		CIRCUIT CARD AMB LTN-51



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
662889-05		CIRCUIT CARD ASSY
662897-02		CIRCUIT CARD ASSY LTN-51
662897-05		QUANTIZER INERTIAL
662897-06		QUANTIZER
662897-10		CCA QUANTIZER
662897-12	5998-01-240-3681	CIRCUIT CARD ASSY LTN-51
663450-08		51 INU
663454-01	6515-01-313-9905	GIMBAL ASSY LTN-51
663454-03		GIMBAL
663550-04-01	6605-00-124-9447	CDU LTN-51
663604-03	6605-00-152-7238	TRANSFORMER RECTIFIER
663604-04	6605-00-152-7238	TRANSFORMER RECTIFIER
667500-01	6625-01-096-8663	GYROSCOPE
667500-02		GYROSCOPE
66WBD300-1	4320-00-955-3126	PUMP AXL
66WU300-4	4320-00-955-3125	Pump
67-2790-001		VALVE, BUTTERFLY
67-2790-002	4810-00-003-4369	Valve Butterfly
673443-01		CIRCUIT CARD, DATA
673718-01		POWER SUPPLY LTN-51
673718-03		POWER SUPPLY INU
6782647-J		RELAY IGNITION
6794320(K)		NOZZLE,FUEL SPRAY
6798233L	4920-00-891-3616	TEST SET ELECTRONIC SYSTEMS
6809618-L		FUEL NOZZLE
6809639MX		RELAY BOX
683R592G01	6130-01-090-0628	POWER SUPPLY
686R068G01	5865-01-107-0151	POWER SUPPLY SUBASSEMBLY
686R750G01	5998-01-192-2738	BAND 4/5 A10 BOARD ASSEMBLY
6904-2720-1	6625-00-424-4197	TEST SET SUBASSEMBLY
692751-1	5985-00-252-3494	ANTENNA - LINE 20
692756-1	5841-00-252-3497	RECEIVER TRANSMITTER
692757-1	5841-00-252-3498	CONTROL RADAR
692760-1	5841-00-252-3500	INDICATOR,AZIMUTH-RANGE
692762-1		INDICATOR,RADAR TARGET
692762-3	5841-01-089-1753	INDICATOR RADAR TARGET
692762-4	5841-01-088-8142	INDICATOR, RADAR TARGET
695043-1	1650-00-994-8631	CYLINDER ASSEMBLY,ACTUATING,LINEAR
695422-10	1650-00-626-5728	BRAKE FLAP LH
695422-11	1650-00-626-5729	DISC,BRAKE
695495-3	4810-00-866-8212	VALVE, LINEAR DIRECT
695539-3	6620-00-573-7870	THERMOSTAT FLOW CONTROL
695539-4		UNDER FLOOR HEAT THERMOSTAT
695568-1	1650-00-570-8688	CYLINDER ASSEMBLY,ACTUATING,LINE
695568-3		CYLINDER ASSY. NOSE LANDING GEAR
695568-5	1650-01-155-6849	CYLINDER NLG HYD



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
695594-4	1650-00-513-5415	SERVOVALVE, HYDRAULIC
695676-11	1680-01-004-2086	ACTUATOR ASSEMBLY
695683-1		SWITCH SIGNAL
695683-3	5930-00-629-6660	SWITCH, PRESSURE
695698-3	2915-00-574-3227	VALVE OUTBOARD VENT
695700-3		ELEVATOR TRIM TAB ACTUATOR
695746-1	2915-00-632-7932	VALVE FUEL SYSTEM
695762-3	4810-00-566-7114	VALVE LINEAR
695769-3	2915-00-083-9373	PUMP SUBMERGED AIRCRAFT
695775-2	1680-00-981-7652	ACTUATOR, ELECTRO-MECHANICAL, LINE
695797-1	6680-00-580-1247	INDICATOR LIQUID QUANTITY
695805-1	4810-00-987-3948	VALVE, ANTI-ICING
695807-1	1680-01-208-0174	ACTUATOR ELECTRO-MECHANICAL
695807-3	1680-01-254-6893	ACT ELEC MACH LINE
695810-3	2915-00-789-1102	HEATER ASSEMBLY, FUEL
695812-2C		SHUT-OFF VALVE
697232-1	1650-00-204-1703	MOTOR HYDRAULIC
697395-1	1630-00-998-7897	VALVE, BRAKE CONTROL
697396-1	6695-00-719-7103	TRANSMITTER
697749-1	6680-01-220-4090	FUEL QTY DIGITAL INDICATOR
697749-15	6680-01-350-8049	INDICATOR, LIQUID
697749-9		INDICATOR LIQUID QTY
698611-1		TORQUEMETER IND
700647-1	5998-00-422-3252	CIRCUIT CARD
7006M51G02	2915-00-480-8112	T5 AMPLIFIER
703873-2	5985-00-252-3493	PITCH ACTUATOR ASSEMBLY
703874-2	5985-00-252-3492	ANTENNA DRIVE
704175-1	1610-00-895-8588	SPINNER, PROPELLER, AIRCRAFT
704175-2	1610-01-372-0536	SPINNER PROPELLER
705079-1	1610-00-941-4353	BRACKET ASSY
714325-3	1610-01-038-5779	VALVE HOUSING PROPELLER
714325-5	1610-01-016-2196	VALVE HOUSING
714325-7	1610-01-318-4870	HOUSING ASSEMBLY, VA
714819-1	5895-00-252-3492	ROLL ACTUATOR SUBASSEMBLY
714820-1	5985-00-252-3493	PITCH ACTUATOR ASSEMBLY
722-2032-001		AUDIO ASSY
722-5140-002		SENSOR RATE OF TURN
731300-3	2915-00-357-2496	VALVE, FLOAT, AIRCRAFT
733872-2	1610-00-005-8685	HOUSING ASSY PUMP
733872-5	1610-01-350-7769	PUMP HOUSING
733872-6	1610-01-220-6052	PUMP HOUSING
736639-1	5996-00-421-8429	AMPLIFIER ASSEMBLY
736639-2	5895-01-103-5399	AMPLIFIER ASSEMBLY
751872-3	1660-01-019-8577	AIR CONDITION
757R501	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY
757R501G02	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
759R379G01	6130-01-211-8075	POWER SUPPLY CONTROL
759R379G02	6130-01-211-8075	POWER SUPPLY CONTROL
7609-17B5-1	6620-00-526-7917	SSUFDR
761230-2		SYNCHROPHASER
766840-1	1610-01-097-8728	SYCHROPHASER
766840-2	1610-01-155-9337	SYNCHRO PHASER
766R023G01	5998-01-246-1704	ANTENNA BOARD ASSEMBLY
7-716835	2915-00-739-3047	VALVE, FLOAT AIRCRAFT
772-5140-001		RATE SENSOR
772-5140-002	6615-01-134-3127	GYROSCOPE FLIGHT
772-5370-003	5826-01-065-9189	HORIZONTAL SIT.IND.
774474-1	1610-01-112-3771	STOP ASSEMBLY PROPELLER
774800-1	1610-01-128-7400	Synchrophaser
776840-2	1610-01-155-9337	SYNCHRO PHASER
777-1225-001		CONTROL,RADIO SET
777-1493-006		ADF CONTROL
77D0069-1	6130-01-058-5927	POWER SUPPLY
784755-1	5977-01-209-4979	HOLDER ELECTRICAL
792-6140-001	5985-01-089-3064	MOD. COUPLER
792-6216-004		ADF RECEIVER
792-6221-003		REMOTE SELECTOR
792-6255-005		MODE CPLR
792-6275-002	5826-01-065-1759	CONTROL GAIN ADF
792-6348-005	6615-01-038-7299	CONTROLLER AUTOPILOT
792-6348-005N		AUTO PILOT CONTROLLER
792-6357-002		ATTITUDE DIR IND
792-6657-001		VHF COMM TRANS
792-6694-001	6615-00-348-3874	VERTICAL REFERENCE
792-6703-003	6615-01-040-0126	COMPUTER,FLIGHT CONTROL
792-6781-003	6615-01-037-7780	SERVO UNIT
792-6785-002	6615-01-065-9448	MOUNT, SERVO
797-2445-013	5998-01-074-0568	CIRCUIT CARD ASSY
797-3639-013	5998-01-074-5119	ELECTRONIC COMPONENTS ASSEMBLY
798C528G01	6115-01-014-5457	ROTOR
798C635G01		Stator Generator
800500-19	4120-01-010-5171	CONTAINER ASSY FIRE
800530-1	4210-01-300-5266	EXTINGUISHER
8037M2	1680-01-013-9501	ELE TRIM ACTUATOR
8067-1A	1680-01-009-8293	ELEVATOR SCREW JACK
8067-2A	1680-01-009-8294	SCREW-JACK, ELEVATOR
8067-3A	1680-01-131-0901	SCREW-JACK
8067-4A	1680-01-131-0902	SCREW-JACK
8118A	1680-01-107-2667	ACTUATOR ASSY, DUAL OUTP
81D0240-1	6130-01-192-6999	POWER SUPPLY
82-052759-01	5996-01-060-6746	LOG VIDEO AMPLIFIER
82-052760-01	5865-01-059-4571	IF DISCRIMINATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
82-052795-01	6130-01-058-5927	POWER SUPPLY
822-0761-001	5826-35-787-5499	RECEIVER TRANSMITTER
822-1046-001	5820-01-474-0840	RECEIVER , 618M-5A
822-1114-001	5821-01-467-8793	VHF COMM TRANS
822-1944-001	6610-01-519-0844	INDICATOR AIRSPEED & DIRECTION
8318-0610	5930-01-216-3233	SELECTOR SWITCH
8318-0610-1	5930-01-216-3233	SELECTOR SWITCH
8348M1	1620-00-617-9123	LANDING GEARBOX
83832-1	1660-00-870-9373	HEAT EXCHANGER
83832-1-2	1660-00-870-9373	HEAT EXCHANGER AIR
839966-1		AMPLIFIER TEMPERATURE
83D0439-1	6130-01-192-6999	POWER SUPPLY
8430M3		BALL SCREW
8430M4	1620-01-263-6733	BALLSCREW ASSEMBLY
8445M1	1680-01-324-8157	INBD FLAP ACTUATOR
8446M1	1680-01-324-8158	FLAP ACTUATOR
85027-1	1660-01-468-3917	HEAT EXCHANGER AIR
8545M1		BALLSCREW ASSEMBLY
8546M1	1680-01-222-2551	BALLSCREW ASSEMBLY
8575600G		CONTROL SPEED SENSITIVE
86250-2		OIL COOLER ASSY W/ REGULATOR
8656M2	1680-01-497-7142	ACTUATOR,ELECTRO-MECHANICAL,LINE
880057-1	5895-01-206-7147	ITERROGATOR SET
880T100		ACTUATOR
880T100-3	1680-01-329-7411	ACTUATOR, ELECTRO-ME
89000-1	6620-00-901-7848	PRESSURE TRANSMITTER
89000-1 / TRU81/A		TRANSMITTER PRESSURE
892541-100	6350-00-015-8049	FIRE CONTROL UNIT
898028-1-1	4820-00-007-7956	STARTER VALVE
89D0834-1	6130-01-361-0655	POWER SUPPLY
8DJ100WAA2	6685-00-897-8400	INDICATOR TEMPERATURE
8DJ135LWB1	6680-01-061-3996	RATE OF FLOW IND
8DJ179WAD1	6685-01-096-6867	TEMP INDICATOR
8DJ179WBK1	6685-00-138-1564	INDICATOR TEMPERATURE
8DJ43AAM	6620-00-515-4541	INDICATOR ELECTRICAL TACHOMETER
8DJ43AAM13	6680-00-663-4207	TACHOMETER INDICATOR
8DJ43AAM14	6680-00-663-4271	TACHOMETER INDICATOR
8DJ43BAD		Electric Thermometer
8DJ64GBC1	6620-01-098-2960	INDICATOR FUEL
8DJ64GBH1	6620-01-038-5769	FUEL FLOW IND
8DJ67FCA		Tachometer Indicator
8DJ71GAB	6620-00-551-2631	INDICATOR RATE OF FLOW
8DJ71GAB1	6620-00-551-2631	INDICATOR RATE OF FUEL FLOW
8DJ81CAA1	6620-00-621-0143	TACHOMETER INDICATOR
8DJ81CAA2	6620-00-969-3972	TACHOMETER INDICATOR
8DJ81CAA4	6620-01-063-9636	TACH IND



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
8DJ81CBD4	6620-01-157-9266	INDICATOR TACHOMETER
8T51GAA5	6130-00-772-8567	POWER SUPPLY ACH
8TJ50(4A5-5)		FUEL FLOW METER
8TJ50GA		FUEL FLOW METER
8TJ50GAA5	6620-00-720-3223	F/F TRANSMITTER
8TJ50GAS5	6620-00-720-3223	F/F TRANSMITTER
8TJ51-GAA		POWER SUPPLY FLOW METER
8TJ51GAA4		FUEL MASS FLOWMETER
8TJ51GAA5		POWER SUPPLY
8TJ64GBW2		TRANSMITER FLOW METER
8TJ64GBW-2		TRANSMITTER FUEL FLOW
8TJ95GAA4		POWER SUPPLY
907-74	6625-00-199-1879	METER, ELECTRICAL
908-164	6625-00-199-1879	METER ELECTRICAL
914858-851		RECEIVER TRANSMITTER
915-38106-001	6130-01-217-5880	POWER SUPPLY REMOTE
918476-000	5998-01-269-6978	CIRCUIT CARD ASSEMBLY
918819-801	5998-00-570-4262	CIRCUIT CARD ASSEMBLY
9205-4584		RELAY
93-100-90	5835-01-128-7757	RECORDER
93A100-90	5835-01-128-7757	VOICE RECORDER
93-A100-90	5835-01-128-7757	CVR (COCK-PIT RECORDER)
93-A152-16		CONTROL UNIT VOICE RECORDER
9-464-40 / -62		INDICATOR, FUEL FLOW
9-464-40MOD-B	6680-01-484-0254	INDICATOR, FUEL FLOW
948894-4-1		CONTROL OVERTEMP.
9550616-1LC	1630-01-038-5126	WHEEL LANDING GEAR
9560685-1		BRAKE ASSY
965-0412-002	6610-01-101-1913	COMPUTER, AIR DATA
965-0476-088	6340-01-101-1888	COMPUTER WARNING GPWS
976J215-1	6110-00-689-8602	CONTROL GENERATOR
976J215-2	6110-00-689-9842	PANEL PROTECTION
976J480-2	6115-00-997-6517	GENERATOR AC
979470-2-1		SHUTOFF VALVE
980-4120-RXUS		SSUFD
9819-08	6610-00-058-9527	ATTITUDE IND
98G41-1	5930-00-463-7442	SWITCH,PRESSURE
9900-39		REGULATOR
9A022-1	4810-00-013-7091	VALVE PRESSURE
9A100	6620-01-206-5748	INDICATOR
9A1100	6620-01-206-5748	TORQUEMETER IND
9A2090	6620-01-437-3144	TORQUEMETER INDICATOR
9A2100	6620-01-264-8685	TORQUEMETER IND
9A360HEA	6680-00-937-0429	INDICATOR LIQUID QUANTITY
9A375	5585-00-148-8247	TEMPERATURE INDICATOR
9A-375	6685-00-148-8247	TEMPERATURE INDICATOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
A100		VOICE RECORDER UNIT
A13A	6645-00-403-4947	CLOCK 8 DAY
A13A-2	6645-01-235-9465	CLOCK,PANEL
A40A1750	6110-00-500-0391	VOLT.REG.
A40A1750-2	6110-00-483-9247	REGULATOR VOLTAGE
A451M9A	1680-01-077-3439	LANDING GEAR CONTROL
A487-3	1680-00-705-9996	ACTUATOR MECHANICAL
A487-4	1680-00-777-0135	ACTUATOR MECHANICAL
A489-3		ACTUATOR ELECTROMICHAICAL ROTARY
A489-3/A489-4	1680-00-672-8931	ACTUATOR ELECTRO-MECH
A489-4		ACTUATOR ELECTRO-MECH
A489-5	1680-01-013-3229	ACTUATOR ELECTRIC
A555-1A	1680-00-822-0170	ACTUATOR,ELECTRO-MECHANICAL,LINEAR
A555-2A	1680-00-822-0171	ACTUATOR ELECTRO-MECHAN
A700AQ4		RELAY CURRENT CUT-OUT
A7111D-2	1610-00-482-7947	Blades
A800530	1680-00-677-6319	EXTINGUISHER SUB ASSY
A800530-1	1680-01-300-5266	EXTINGUISHER FIRE AIRCRAFT
A80-AAU-8/A	6610-00-774-5656	ALTIMETER PRESSURE
A80AAU8A	6610-00-774-5656	ALTIMETER
A846-6	5945-00-628-6484	RELAY HYBRID
AAU-21A	6610-00-168-0797	ENCODER/ALTIMETER
AAU-32A	6610-00-134-5625	ALTIMETER
AAU8A	6610-00-722-0967	ALTIMETER PRESSURE
AC310064		GYROSCOPE VERTICAL
AC410037	6610-01-311-5872	INDICATOR
AC60742		AXLE MAXARET
AEU-13/A	6620-01-172-6946	TORQUEMETER IND.
AI-803CR	6610-01-461-5251	INDICATOR, ATTITUDE
AL 232AS-PC		AIR SPEED INDICATOR
AM-6639/ALR	5985-01-154-9125	AMPLIFIER DETECTOR
AN6012-1A	4820-00-528-3264	VALVE
AN6281-8-10		FUSE HYD.
ANUPM33A	6625-00-539-8587	TEST SET RADAR
AP4V-16-01		E.D.P.
AT740A	5985-00-673-5831	MODE 'S' ANTENNA
AV 16B1470C		VALVE MOTOR OPERATED FUEL SHUT OFF
AV16B1464C	4810-00-627-5271	GATE VALVE
AV16B1467D	2915-00-632-7932	VALVE 1 INCH MOTOR OPERATED FUEL SHUTOFF
AV16B1470C	4810-00-653-7572	GATE VALVE
AV16B1867D	2915-00-632-7932	VALVE FUEL SYSTEM
AV19E1003-1	4810-01-123-7254	VALVE PRESSURE VENT
AVR743D8	5945-00-729-1244	RELAY UNDER VOLTAGE DC
AVR-743D-8	5945-00-729-1244	RELAY UNDER VOLTAGE DC
AVR869E		PHASE SEQUENCE RELAY
B123J	5945-00-675-7413	CONTACTOR, ELECTRIC



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
B123JA	5945-01-250-9675	RELAY,ELECTROMAGNETIC
B15-945-42-05-11N		CLOCK, AIRCRAFT
B4515210003	6610-01-038-2081	ALTIMETER, PILOT
B45152-10-013	6610-01-477-4148	ALTIMETER
B45152-10-02	6610-01-134-5625	ENCODING ALTIMETER
B4515210103	6610-01-038-2122	ALTIMETER
B-459	5945-01-250-9675	RELAY,ELETROMAGNETIC
B52C22	4810-00-672-1085	VALVE ASSY, WING DUCT P&A
BH187R111	6685-00-573-7407	INDICATOR,TEMPERATURE,SYNCHRO
BTI600-202M	6685-01-356-7401	INDICATOR TEMP
BYLB51044	4810-01-218-2643	VALVE, TEMPERATURE C
BYLB51045	4810-01-219-3417	VALVE TEMP. CONTROL
C-4808/ARC		SELECTOR ANTENNA
C4808ARC	5985-00-902-9935	SELECTOR,ANTENNA
C52C22	4810-00-670-1111	VALVE BUTTERFLY
C55D	6680-00-790-6839	COUNTER, FUEL FLOW
C-7041		AILERON TRIM TAB ACTUATOR
C7041-1	1860-00-088-6102	ACTUATOR,ELECTRO-MECHANICAL,LINE
C7041-2	1680-00-981-7652	ACTUATOR, ELECTRO-ME
C7088-1A	1680-00-789-9345	WING FLAP GEARBOX
C-823/AIC-10		INTERPHONE CONTROL
C-824A/AIC-10	5831-00-519-5883	INTERCOM CONTROL PANEL
C-826/AIC-10		INTERCOM CONTROL PANEL
CA59100-0011		ACTUATOR
CA75810-0001	3010-33-001-8008	ACTUATOR,HYDRAULIC
CA84500-0010	3010-33-001-9625	ACTUATOR, HYDRAULIC
CG12313	5930-00-965-7111	SWITCH PRESSURE
CSV4092-3	6110-01-344-0377	GENERATOR GONCORL UNIT
CYLB51055		CHECK VALVE
D25-05		REGULATOR
D52C22	4810-00-601-3146	WING ISOLATION VALVE
DL1326M11		ACTUATOR,ELECTRO-MECHANICAL,LINE
DRA45C8		SWITCH, AIR SPEED
DSL-50	6680-00-828-7610	INDICATOR LOX
DST29-2	6685-00-066-4581	INDICATOR TEMPEARTURE
DST-29-2		THERMO TEMP. IND.
DST29-3		TEMP TURBINE INDICATOR
DYLZ3990-3	1660-00-690-6150	VALVE ENVIRONMENTAL CONTROL
DYLZ3991-2	4810-05-224-595	VALVE ASSEMBLY
DYLZ3991-3	4810-00-682-5374	VALVE CONTROL
E0724104003	6610-00-585-1524	INDICATOR, TRUE AIR SPD
E07241-04003	6610-00-585-1524	AIRSPPEED INDICATOR
E07241-04-003	6610-00-585-1524	INDICATOR, TRUE AIR SPEED
E2206104016		ALTIMETER
E-384	5945-00-628-6484	RELAY,HYBRID
E6011M13-13	6105-00-698-5927	MOTOR DIRECT CURRENT



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
EA100ANH144	6680-00-580-9557	INDICATOR LIQUID
EA1045-037-2B	4320-00-949-6842	PUMP, HYD ELECT MOTOR
EA1045-837-2B		ELECTRIC MOTOR DRIVE
EA1065AW2315		TRANSMITTER, LIQUID QUANTITY
EA1065AW-2315		FUEL QUANTITY TANK UNIT
EHU11AA	6685-00-580-4732	EGT, INDICATOR
EHU15AA	6685-00-945-4979	INDICATOR TEMPERATURE THEROCOUPLER
EKCC-18043	6685-00-692-8341	INDICATOR
F60W0232M1	2915-00-574-3227	VALVE,FLOAT,AIRCRAFT FUEL TANK
F60W0233M1	2915-00-581-0477	VALVE INBOARD FUEL
FG450A52	6680-01-059-3386	COMPENSATOR FUEL
FS20	6105-01-108-2427	MOTOR DIRECT CURRENT
FS-9506B-4	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
G5400-1	6220-00-299-4621	LANDING LIGHT ASSY.
G5400-3		LANDING LIGHT ASSY
G-5400-3		LANDING LIGHT
G-6965-8	6220-00-421-9109	WARNING NAV LIGHT
G7406-10		VHF COMMUNICATION CONTROL PANEL
G7418-13		CONTROL PANEL VHL
GEU7A	6680-00-585-1503	TACHOMETER GENERATOR
GP20-15	6620-01-328-6940	GAUGE, PRESSURE DIAL
GPS MAP 295		GPS MAP 295
GTC85-71A		GAS TURBINE COMPRESSOR
JG40242-7	6680-00-580-1247	INDICATOR LIQUID WING
JG402A2	6680-00-580-1247	FUEL QTY IND
JG402A3	6680-00-580-1246	INDICATOR, LIQUID QU
JG402A32	6680-00-866-5116	INDICATOR,LIQUID QUANTITY
JG402A4	6680-00-580-1248	FUEL QTY IND
JG402A52	6680-01-056-1779	FUEL QTY IND
JG402A53	6680-01-060-5228	FUEL QTY IND
JG402A-53	6680-01-060-5228	FUEL QTY IND
JG402A54	6680-01-058-5859	FUEL QTY IND
JG402A-54	6680-01-058-5859	INDICATOR
JG402A55	6680-01-058-5860	FUEL QTY IND
JG412A3		FUEL QTY IND - ROUTINE
JG412A4	6680-00-585-8600	INDICATOR,LIQUID QUANTITY
JG412A-52	6680-01-063-0597	INDICATOR LIQUID QTY
JG412A53		FUEL QTY IND
JG412A-53	6680-01-058-5861	INDICATOR LIQUID QTY
JG412A-54	6680-01-058-5862	INDICATOR LIQUID QTY
JG412A-55	6680-01-342-7698	INDICATOR LIQUID QTY
JG412A56	6680-01-058-5864	FUEL QTY IND
JG412A-56	6680-01-058-5864	INDICATOR LIQUID QTY
L10-107		ACTUATOR
L16-107		ACTUATOR ELECTRO-MECH
L16-8-1	1680-00-720-5810	ACTUATOR ELECTRO-MECH LINEAR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
L16-8-3	1680-00-720-5810	ACTUATOR ELECTRO-MECH
L16-8-5	1680-01-378-1631	ACTUATOR ELECTRO-ME
L8602772-1	2935-01-440-9157	COOLER,LUBRICATING
LO3P1	5950-00-880-6005	TRANSFORMER POWER AUTO TRANSFORMER
M2901A-1B	4140-00-814-5758	FAN VANE AXIAL
M5921A1B	4140-00-717-5277	FAN,VANEAXIAL
M5921A-1B	4140-00-717-5277	FAN VANEAXIAL
MF30-3913-30ZE5	1650-00-204-1703	MOTOR,HYDRAULIC
MF30-3913-30ZE-5	1650-00-204-1703	MOTOR, HYD
MF93911-30ZE	4320-01-224-9869	MOTOR,HYDRAULIC WING FLAP
MF9-3911-30Z-S481	1650-00-815-9387	MOTOR HYDRAULIC
MIL-C-27336	1660-00-768-5256	CONVERTER LIQUID OXYGEN
MIL15356	6610-00-663-8723	INDICATOR AIRSPEED
MILT38394	6620-00-901-7848	TRANSMITTER, PRESSURE
MPEV3-032-2	4320-00-174-5811	HYD AUX ELEC PUMP
MPEV3-032-2A	4320-00-174-5811	HYD AUX ELEC PUMP
MS17983-2	6605-00-551-8187	COMPASS
MS24140-D1		RELAY
MS24182-D1		RELAY
MS24332M1		VOLTMETER
MS25038-4	6620-00-553-8892	TACH GENERATOR
MS28005		TRANSMITTER
MS28005-1		TRANSMITTER
MS28005-8	6685-00-526-7864	TRANSMITTER, PRESSURE
MS28005-8T		TRANSMITTER, PRESSURE
MS28010-5	6685-00-557-0215	INDICATOR PRESS
MS28075-1	6610-00-473-5046	INDICATOR, VERTICAL
MS28700-1	1650-00-640-8485	ACCUMULATOR, HYD
MS28700-2	1650-00-640-8491	ACCUMULATOR
MS28-700-2		HYDRAULIC ACCUMULATOR
MU-1	6620-00-557-3023	TACHOMETER
N1335C	5821-01-384-4435	DECODER,AUDIO FREQUENCY
NA135		DECODER AUDIO FREQUENCY
PV3-075	4320-00-404-1977	PUMP AXIAL VICKERS
PYLB51239-1	4810-01-237-5974	VALVE,SOLENOID
PYLB51239-2	4810-01-237-5974	VALVE,SOLENOID
R5170M34-3	1680-00-474-3300	ACTUATOR GTC DOOR
R5170M34-4	1680-00-426-5616	ACTUATOR GAS TURBINE COMP
R73-2008-42-1		TENSION REGULATOR
R84-1001-48-4A		REGULATOR CABLE TENSION
RC-60-MS		RATE OF CLIMB INDICATOR
RCS-60-1L	6610-00-473-5046	INDICATOR, VERTICAL
RD-301A		RADAR TEST SET COLOR BEN
RG14D3		TOTALIZER
RG14D7	6680-00-860-6390	TOTALIZER
RG-3-11		RATE OF TURN SENSOR



WINGS AEROSPACE, LLC

C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
RG-9680C	4310-00-568-1532	COMPRESSOR WITH ROTARY
RR11620-1	2915-00-983-1001	PUMP SUBMERGED C130
RR11620-3	2915-00-983-1001	FUEL BOOST PUMP
RR11640-1	2915-01-506-2354	Pump, Centrifugal Fuel Booster
RR11640A1	2915-01-196-4362	PUMP SUBMERGED AIRCRAFT
RR11640A3		PUMP, SUBMERGED AIRCRAFT
RR11640-D1	2915-01-196-4362	PUMP, SUB
RR52780A	2915-00-382-9088	PUMP,BOOST
RYLC51046	1680-01-222-3117	ACUTATOR
S-512-50-2	1650-00-721-6415	ACCUMULATOR
S65-5366-2L		MODE 'C' ANTENNA
S65-8280-10		VHF ANTENNA LOWER
SK40LC1	6610-01-109-5105	Max Allowable Airspeed Ind
SLZ3501		TRANSMITTER, ANGLE OF ATTACK
SPL5568-3	3040-00-566-0336	ACTUATOR,MECHANICAL,LINEAR
SR151A	6685-00-515-3996	PRESSURE INDICATOR
SR152A	6685-00-526-5625	PRESSURE INDICATOR
SRD4B	6685-00-678-2948	INDICATOR PRESSURE
SRD-4B	6685-00-678-2948	DUAL OIL PRESS IND
SSD12042A		Altitude Encoding Digitizer
SSD120-42A		ALTIMETER ENCODE
ST104A	6620-00-901-7848	TRANSMITTER PRESSURE
ST-104A		OIL PRESS TRANS
ST-7D		HYD PRESS TRANS
SYLZ50684	1660-01-121-7386	CONTROL TEMP
T1580S3A	5342-00-881-1719	CLAMP ASSY - ENG TAIL PIPE
TED9-464-40		INDICATOR , FUEL
TG255-007	6680-00-923-8466	TACH GENERATOR
TS5106UPX	6625-01-156-6940	TEST SET
UA524240-1	2915-00-789-1102	FUEL HEATER
UA534149-19	1650-01-065-3500	COOLER,HYDRAULIC
UA534149-21	1650-01-227-5464	COOLER, HYDRAULIC
UA538795-3	1650-01-228-8118	COOLER,HYDRAULIC OIL
UPX-27N	5895-01-206-7147	INTERROGATOR SET
V3900-11		VALVE SOLENOID
W1206-2		POWER SUPPLY
W33-7545-10	6645-00-089-7903	CLOCK AIRCRAFT
WJ2854-15A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
WJ2854-31A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR