



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
124.013		DUAL TEMP PRESSURE INDICATOR
124.04		AC/DC VOLTMETER
124.115		DUAL TEMP PRESSURE INDICATOR
124.933		TEMP IND
1000		OVEN HEATER
1111	5120-00-766-4798	CYLINDER ASSEMBLY, AILERON BOOSTER
1120	5120-00-089-0874	CYLINDER ASSEMBLY, RUDDER BOOSTER
4088	5945-00-601-3160	SWITCH,FUEL PRESSURE
4100		RELAY ASSEMBLY
5003		SWITCH
6204	4810-00-800-0079	VALVE, PRESS
6204	4810-00-800-0079	VALVE, HYDRAULIC SHUT-OFF
6301		VALVE
6301		VALVE, FUEL SHUT-OFF
7046	1650-00-071-6388	CYLINDER ASSEMBLY ACTUATING LINE
7046	1650-00-071-6388	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
7360	6645-00-218-5010	WINCH, CARGO
7556		CYLINDER ASSY
8118	1680-01-107-2666	ACTUATOR ASSY TRIM TAB
8347	1680-00-373-8044	GEAR BOX ASSEMBLY AL
8347	1680-00-373-8044	GEAR BOX ASSEMBLY MAIN LANDING GEAR
8348	4940-01-478-1420	GEARBOX, MANUAL, MLG
8353		BALL SCREW
8353		BALL SCREW ASSEMBLY, MAIN LANDING GEAR
8430		BALL SCREW
8430		BALL SCREW ASSEMBLY
8445		ACTUATOR, INBOARD WING FLAP
8446	1680-00-615-1335	ACTUATOR, MECHANICAL
8446	1680-00-615-1335	ACTUATOR, OUTBOARD WING FLAP
8521	1680-01-257-2445	GEAR BOX ASSEMBLY
8521		GEAR BOX ASSEMBLY MAIN LANDING GEAR
8526		ACTUATOR,ELECTRO-MECHANICAL,LINE
8526	1680-01-279-3544	ACTUATOR, APU INLET DOOR
8544		GEAR BOX
8544	5970-01-306-8256	GEAR BOX ASSEMBLY
8545	1680-01-217-5837	BALLSCREW ASSY
8545	1680-01-217-5837	JACKSCREW, INBOARD WING FLAP
8546	1680-01-222-2551	BALLSCREW ASSEMBLY
8546	1680-01-222-2551	JACKSCREW, OUTBOARD WING FLAP
8656		ACTUATOR
8656		ACTUATOR, OIL COOLER DOOR
10280		VALVE
10640		VALVE
10850		VALVE
10870		VALVE



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
11170		VALVE
11460		VALVE
11660		VALVE
11670		VALVE
12315	5975-01-498-6297	VALVE, HYDRAULIC SHUT-OFF
13210	4810-00-564-7793	VALVE, LINEAR
13930	4810-00-717-5076	VALVE, FLAP SELECTOR
14080		VALVE
15811	5930-00-139-9003	SWITCH, PRESSURE
16000	5996-00-501-2379	N1 AMPLIFIER
20057	4320-00-602-0597	PUMP, HAND
20348		SHUTTLE VALVE
20349		SHUTTLE VALVE
20350		SHUTTLE VALVE
20355		SHUTTLE VALVE
21020	4810-00-688-9939	VALVE,ANTI-ICE
21021	4810-00-738-6358	VALVE SOLENOID
21086	9540-00-528-8797	CONVERTER,LIQUID OXYGEN
22281		Dual Tachometer
22705	6610-00-006-5783	INDICATOR, MACH AND TRUE AIRSPEED
22887		SHUTTLE VALVE
22888		SHUTTLE VALVE
22889		SHUTTLE VALVE
27100		SUCTION PUMP
27100		PUMP, SUCTION BOOST
27531		SHUTTLE VALVE
27610	6530-01-608-3195	WINCH, PARATROOP RETRIEVAL
30170	4810-01-360-8278	VALVE, RAMP CONTROL
30678	1680-00-677-6317	ACTUATOR, ROTARY
32220	9540-01-378-5574	WINCH, PARATROOP RETRIEVAL
34538		ACTUATOR
34538	1680-00-516-7155	ACTUATOR, PARATROOP, SPOILER DOOR
39606	2935-01-244-1475	COOLER LUBRICATING
40088	5930-00-621-4524	SWITCH, PRESSURE
40122	5930-00-629-6660	SWITCH, PRESSURE
40122	8465-01-565-4004	SWITCH,FUEL PRESSURE
42066	2940-00-871-7053	SWITCH,OIL PRESSURE
42067	5930-00-557-1811	SWITCH,OIL PRESSURE
44910	6230-00-887-2308	LANTERN ELECTRIC
44910	6230-00-887-2308	EMERGENCY EXIT LIGHT
47560	4810-00-208-9693	VALVE LINEAR DIRECT
47610	4810-00-208-9709	VALVE, LINEAR
47680	4810-00-761-6225	VALVE SOLENOID
49740	4810-00-612-2696	VALVE RAMP CONTROL
49740	4810-00-612-2696	VALVE, RAMP CONTROL



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
50320		DAMPENER , FLUID PRESSURE
50659		SHUTTLE VALVE
50900	4810-00-522-4592	VALVE
51060	4320-00-738-6225	PUMP
52760		VALVE, SELECTOR EMERG
53230	1680-01-102-4577	SHUT-OFF VALVE
53230	1680-01-102-4577	VALVE,GATE
53404		VALVE
54055	4320-00-717-1138	PUMP UNIT,CENTRIFUGAL
55742	6615-00-459-9599	REPEATER, SERVO
57273	1650-00-794-7638	VALVE
66039	4320-00-616-3812	PUMP, AXIAL PISTONS
66039	4320-00-616-3812	PUMP, HYDRAULIC
70262	1650-00-803-2221	VALVE BYPASS
75427		SWITCH,OIL PRESSURE
83120	1660-00-304-5726	SEPARATOR, WATER
83308	2915-00-989-1082	HYDRAULIC MOTOR, FLAP
89000	6620-00-901-7848	TRANSMITTER, PRESSURE
95023	5930-00-961-8507	SWITCH, PRESSURE
95024	5930-00-961-8506	SWITCH, PRESSURE
96620		VALVE
96760		VALVE
96940		VALVE
100266	6610-00-557-3030	INDICATOR, ATTITUDE
102150		OUTFLOW VALVE
102150	1660-00-343-4692	CABIN OUTFLOW VALVE (A)
102402	5895-00-593-0509	EXCITER ASSEMBLY
102981	1650-00-873-6241	TURBINE DRIVES
103432		SHUT OFF VALVE
103721	2920-01-259-2137	VALVE, HYDRAULIC SHUT-OFF
104156		VALVE
104901	1650-00-872-7516	DRIVE UNIT,AIR TURBINE
104942	2520-00-773-8022	VALVE, MODULATING
106040		VALVE
106388	4810-00-513-4471	VALVE, BUTTERFLY
106616		VALVE
108136	4820-00-328-1459	VALVE,AIR PRESSURE REGULATOR
108420		STARTER CONTROL VALVE
108605	4810-00-541-6805	VALVE BUTTERFLY
109185		VALVE
109365		VALVE
110100		CYLINDER ASSEMBLY, AILERON BOOSTER
110535		VALVE
111065		VALVE
113538		ACTUATOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
115715	4320-00-6314859	PUMP, CENTRIFUGAL -1/12/2011 - 30/11/2012
119125		ANTI ICE VALVE
120793		HYDRAULIC MOTOR, FLAP
121000		VALVE
121010	4810-01-232-2676	VALVE SOLENOID
121355	4810-00-555-1418	VALVE BUTTERFLY
121535		VALVE
132555		VALVE,GATE
132845		VALVE
132845	4810-00-756-9892	VALVE, HYDRAULIC SHUT-OFF
135801	6625-00-649-2864	AMMETER
144625	4810-00-522-4592	VALVE
144865	1650-00-794-7636	VALVE
150201		ACTUATOR
151488	1650-00-540-0162	HYDRAULIC MOTOR, LANDING GEAR
152292		VALVE
152297	2995-00-775-9213	ACTUATOR, MOTOR ASSY
154485		CURRENT TRANSFORMER
166726	6625-00-555-4522	INDICATOR, LOADMETER
170998	1650-00-204-1703	HYDRAULIC MOTOR, LANDING GEAR
171232	1650-00-204-1703	HYDRAULIC MOTOR, LANDING GEAR
177913		ACTUATOR
179307	2915-00-616-5726	ACTUATOR ELECTRO ME
188911	5310-00-043-5309	HYDRAULIC MOTOR, FLAP
190772	2915-00-626-3123	VALVE ASSY PARALLEL
201090		COOLING TURBINE
202921	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
203430	1660-00-793-1564	TURBINE, AIRCRAFT CO
206040	5930-01-087-3694	HYDRAULIC MOTOR, FLAP
240863	4940-01-048-8944	HYDRAULIC MOTOR, FLAP
248507	5330-01-374-7015	HYDRAULIC MOTOR, FLAP
254030	6625-00-235-4782	VOLTMETER
301701	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
326544	4320-00-404-1977	PUMP
338992		ROD ASSY
341448		MLG TORQUE STRUT ASSY
341982		UPLOCK
343978		VALVE
344052		ROD ASSY, AILERON
344403	1660-00-307-1996	DUCT ASSY
345384		DOOR ACCESS AIRCRAFT
345745		RESERVOIR
348205		VALVE
350690		STARTER
354690		STARTER



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
396374	4320-01-100-9434	PUMP
398648		VALVE
400201	6645-00-950-8599	CLOCK AIRCRAFT
400202		CLOCK, AIRCRAFT MECHANICAL
400240	6645-00-076-3050	CLOCK
409202		ACCUMULATOR
411600		VALVE RELIEF TANK
428066		PUMP ASSEMBLY VARIABLE DISPLACEMENT
502600		VALVE
519661	1610-00-651-3887	INDICATOR ASSY OIL
520104	6625-00-649-2864	AMMETER
520430		VALVE DISCHARGE
537874	6105-00-628-7433	MOTOR 200VAC
538278		AUTOMATIC F. SWITCH
546488	1610-00-179-6130	Valve Housing Cover
548025		ACCUMULATOR
549460		ACCUMULATOR
549722	2915-00-971-9130	PUMP, FUEL BOOST
551025		ACCUMULATOR
551050		ACCUMULATOR
551580		ACCUMULATOR
552430		ACCUMULATOR
554654	1610-00-876-1812	SPINNER FRONT PROPELLOR
554665	1610-00-873-6251	SPINNER, PROP, A/I, REAR
560501	1610-00-873-6424	AFTERBODY HALF BODY
572865	1610-00-862-5524	BRUSH BLOCK, PROPELLER
572942	1610-00-332-3861	BRACKET ASSEMBLY
575427	6130-00-056-6718	STATIC INVERTER
582855	1610-00-009-6832	VALVE HOUSING
600748	6615-00-390-8510	GYROSCOPE, DISPLACEMENT
603281	6105-00-836-5259	MOTOR
603887	6105-00-565-9003	MOTOR-TACHOMETER GENERATOR
603888	6615-00-565-9004	INTEGRATOR ASSY, AMPLIFIER
604288	4320-00-856-9396	AUXILIARY PUMP UNIT,AXIAL PISTONS
604340	4320-00-856-9396	AUXILIARY PUMP UNIT,AXIAL PISTONS
604341	4320-00-786-7710	AUXILIARY PUMP UNIT,AXIAL PISTONS
604390	5996-00-348-3844	AMPLIFIER ASSY, AUTOPILOT
611692	4320-00-072-2291	MOTORPUMP
611692	4320-00-072-2291	AUXILIARY PUMP UNIT,AXIAL PISTONS
613146	5985-00-867-2600	CONTROL, PEDESTAL
615058	6625-00-794-8188	PRE-AMPLIFIER ASSEMBLY
617149	5930-00-463-7442	SWITCH, PRESSURE
618320	6615-00-676-2609	CONTROL, TURN, AUTOMATIC PILOT
618751	6615-00-676-3828	CONTROL, ALTITUDE ENCODING
667857	6615-00-663-8372	GYROSCOPE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
669780		RELAY BOX
692525	5930-00-732-2509	SWITCH PRESS OIL
692525	5930-00-732-2509	SWITCH,OIL PRESSURE
692993		VALVE SHUT-OFF
695004		CYLINDER ASSY
695022	4810-00-529-3584	VALVE, HYDRAULIC SHUT-OFF
695035		CYLINDER
695036		CYLINDER
695037	1650-00-092-4252	CYLINDER,RAMP UPLOCK
695038		CYLINDER
695040		NLG STEERING CYLINDER
695043		NLG UPLOCK CYLINDER
695119	1660-01-483-3094	VALVE, SAFETY
695187	6610-00-580-9363	INDICATOR, POSITION
695189	6610-00-580-9690	INDICATOR, POSITION
695190	6610-00-808-7037	ALTIMETER
695197	4810-00-529-3253	VALVE LINEAR DIRECTIONAL CONTROL
695197	4810-00-529-3253	VALVE, DIVERTER, RUDDER BOOSTER
695225	6610-00-514-5612	INDICATOR, AIRSPEED
695225	1650-00-071-6388	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
695230		ACTUATOR, PARATROOP, SPOILER DOOR
695260	6625-00-649-2864	AMMETER
695261	6685-00-692-8341	INDICATOR, TEMPERATURE
695271	4810-00-691-6713	VALVE
695271	4810-00-673-2727	VALVE, OIL SHUT-OFF
695292	6610-00-530-0961	TRANSMITTER, FLAP POSITION
695317	4810-00-529-3584	VALVE, AUXILIARY VENT
695324	4140-00-564-5980	FAN, COOLING
695324	4140-00-564-5980	ACTUATOR, ROTARY
695345	5930-00-296-6186	SWITCH, PRESSURE
695420	6620-00-526-7917	TRANSMITTER, PRESSURE
695427	1650-00-540-0162	HYDRAULIC MOTOR, LANDING GEAR
695434	1650-00-650-7610	CYLINDER ASSEMBLY, AILERON BOOSTER
695899	4810-00-800-0079	VALVE, HYDRAULIC SHUT-OFF
695908	4320-00-616-3812	PUMP
697752	4810-00-575-7781	VALVE
697752	4810-00-564-7793	VALVE, TEMPERATURE CONTROL
697753	4810-01-039-0459	VALVE
701674	5930-00-621-4524	SWITCH,FUEL PRESSURE
759057		PUMP
761442		CYLINDER
765000	1680-00-073-0841	SUPPRESSOR, SURGE
800530		EXTINGUISHER BOTTLE
1009350		ACTUATOR
1009350	2915-00-554-1888	ACTUATOR ASSEMBLY, ROTARY



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1105123	1680-01-208-0174	ACTUATOR,ELECTRO-MECHANICAL,LINEAR
1105123	1680-01-208-0174	ACTUATOR, OIL COOLER DOOR
1105149	6105-01-225-4098	MOTOR ASSEMBLY
1505380	5841-00-845-4243	GENERATOR,STABILIZATION DATA
1541326	4810-00-912-5945	VALVE,BUTTERFLY
1544979	4810-00-912-5946	VALVE,BUTTERFLY
1775277	6605-00-532-0310	TRANSMITTER, INDUCTION
1776956	6615-00-605-8497	ADAPTER, ELEVATOR TRIM
1887850	5841-01-051-6339	RADAR AND BEACON CI
1889519		SYNCHRONIZER
1889520		ANTENNA
1889523	5841-01-053-7872	Indicator, Az Range APN-59
4012375	6615-01-442-1421	GYROSCOPE, DISPLACEMENT
4079653	5930-01-481-3559	SWITCH ASSEMBLY
5002744	1630-01-014-0656	WHEEL,NOSE LANDING GEAR
5231975	2915-00-897-3164	NOZZLE FUEL SPRAYING
5232105	2915-00-655-1933	FUEL NOZZLE
6404486	2915-00-464-6946	SPEED SENSING CONTROL
6404524		CONTROL
6404525		CONTROL
6719826		VALVE
6730338		SWITCH
6739352		FILTER
6739595		FILTER
6780223		VALVE
6781563		VALVE
6781566		VALVE
6781640		SWITCH
6781978	4810-00-540-2106	VALVE SOLENOID
6782647		RELAYBOX
6788029		FILTER
6789595		FILTER
6792265	4320-00-674-0932	PUMP,ROTARY
6793049		PUMP
6794207		COORDINATOR
6794213		COORDINATOR
6794215	2915-00-777-9017	CONTROL ASSEMBLY, CO
6794320		NOZZLE,FUEL SPRAY
6805150	6620-00-690-8903	INDICATOR, TORQUEMETER
6805387		FILTER
6805769	5996-00-657-7888	AMPLIFIER, TEMPERATURE DATUM
6808341	2995-00-777-3690	VALVE ASSEMBLY,SPEED SENSITIVE
6809105		FILTER
6809387		PUMP
6809573		VALVE



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
6809618	2915-00-655-1933	NOZZLE ASSY FUEL
6809636		RELAY BOX
6809639	5945-00-854-4392	RELAY ASSY
6811702		VALVE
6812632		VALVE
6813972	6620-00-581-2278	INDICATOR, TORQUEMETER
6814707	6620-00-632-3631	INDICATOR, TORQUEMETER
6814740		CONTROL
6814762	2915-00-626-3123	VALVE, PARALLELING
6815100		SPEED CONTROL
6815120	6620-00-621-4269	INDICATOR, TORQUEMETER
6815131	6620-00-673-6867	INDICATOR, TORQUEMETER
6815622	2995-00-877-3666	VALVE ASSY ANTI-ICEING
6815922		FILTER
6815930		FILTER
6821460		FILTER
6821480		CONTROL
6821490		FILTER
6821491	2915-01-107-2763	FILTER, FLUID
6821493		SPEED VALVE
6821493	2995-00-876-9685	VALVE ASSEMBLY,SPEED SENSITIVE
6821701	6150-00-859-6815	WIRING HARNESS BRANCHED
6824286	4810-00-749-8896	VALVE SOLENOID
6826922		SWITCH
6827034	5996-00-578-6169	AMPLIFIER, TEMPERATURE DATUM
6827168	2995-00-675-3641	VALVE ASSEMBLY,SPEED SENSITIVE
6827239	2915-00-706-2719	VALVE ASSY TEMP
6827959		FILTER
6829274	6620-00-856-8263	FUEL FLOW INDICATOR
6829276	6620-00-053-2850	INDICATOR, TORQUEMETER
6829319		FILTER
6842553	5996-00-633-6912	AMPLIFIER, TEMPERATURE DATUM
6842961		FILTER
6842962		FILTER
6843151		COORINATOR
6843165		SWITCH
6844223		COORINATOR
6845515	5996-00-912-0840	AMPLIFIER, TEMPERATURE DATUM
6846396		PUMP
6846567	4320-00-012-7080	PUMP ASSY OIL SCAVENGE EXTERNAL
6846935		HOUSING,ANTIFRICTION
6847347		VANE SEGMENT,COMPRESSOR,AIRCRAFT
6850486		AMPLIFIER, TEMPERATURE DATUM
6850818		PUMP & FILTER ASSY
6852536	6620-00-914-2742	INDICATOR, TORQUEMETER



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
6852620		SEAL METALLIC AIRCRAFT
6858628		VALVE
6859424	2840-00-127-5730	HOUSING MECHANICAL P&A
6859769	5996-00-458-2768	AMPLIFIER, TEMPERATURE DATUM
6870095	2915-00-458-2767	AMPLIFIER TEMPERATURE
6870095	5996-00-458-2767	AMPLIFIER, TEMPERATURE DATUM
6870215		PUMP & FILTER ASSY
6871121		SPEED CONTROL
6871208		FILTER
6871248		SEAL METALLIC AIRCRAFT
6871749		FILTER
6873465	2915-00-464-6946	CONTROL ASSY SPEED SEN'R
6873466		CONTROL SPEED
6876338	5996-01-096-4648	AMPLIFIER, TEMPERATURE DATUM
6876399	2915-00-203-8084	AMPLIFIER, TEMPERATURE DATUM
6877256		FILTER
6877853		FILTER
6886127		SWITCH
6887091	5996-00-071-3996	AMPLIFIER, TEMPERATURE DATUM
6888911		SPEED CONTROL
6889811		CONTROL
6889842		SPEED CONTROL
6891597		FILTER
6894068	2840-01-049-1153	LINER COMBUSTION
6895037		COORINATOR
6895835		AMPLIFIER, TEMPERATURE DATUM
7810259	5930-00-557-1811	SWITCH,PRESSURE
7854687		SPEED CONTROL
7902600	1680-01-222-2551	ACTUATOR, OUTBOARD WING FLAP
7902601	1680-01-217-5837	ACTUATOR, INBOARD WING FLAP
8427707	2935-01-202-5339	COOLER ASSY OIL AIRCRAFT
8575504		SPEED SENSING CONTROL
8575600	2915-00-622-4036	CONTROL ASSEMBLY,SP
8576000		CONTROL
9305700	1660-00-595-7773	SENSOR,CABIN TEMPERATURE
9540918	1630-00-528-1858	BRAKE ASSEMBLY
9541667	1630-00-875-4866	BRAKE ASSEMBLY
9542662	1630-00-914-1329	WHEEL,NOSE LANDING GEAR
9549400	1660-00-583-7106	SENSOR, OVERHEAT
9550064		WHEEL, LANDING GEAR
9550071		BRAKE ASSEMBLY
9550402	1630-00-052-8403	BRAKE ASSEMBLY
9550616	1630-00-809-0394	MAIN WHEEL
9550616	1630-00-809-0394	WHEEL, LANDING GEAR
9560685		BRAKE ASSY



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
9560685	1630-00-825-4794	BRAKE ASSEMBLY
23002366		RELAYBOX
23004669		SEAL ASSY
23006660		PUMP
23008288		AMPLIFIER, TEMPERATURE DATUM
23009257	2915-01-274-7553	AMPLIFIER, TEMPERATURE DATUM
23009259	5895-01-340-5268	AMPLIFIER, TEMPERATURE DATUM
23031741		VANE SEGMENT 2ND STAGE
23031745	2840-01-255-7498	VANE
23031746	2840-01-247-0263	VANE
23031747	2840-01-247-0266	VANE
23031748	2840-01-247-0264	VANE
23037203		RETAINER ASSY
23052609	5996-01-274-7553	AMPLIFIER TEMPERATUR
23052609	5996-01-274-7553	AMPLIFIER, TEMPERATURE DATUM
23059687	5996-01-406-4035	AMPLIFIER. ELECTRONIC CONTROL
23059687	5996-01-406-4035	AMPLIFIER, TEMPERATURE DATUM
23063131	2840-01-497-4009	PUMP, FUEL METERING
23064874	2915-01-444-7667	FUEL CONTROL ASSY
23072685	2840-01-497-4108	PUMP, LUBE & SCAVENGE
23075074	2915-01-547-5283	PUMP, FUEL METERING
23076368	2840-01-506-8172	PUMP, FUEL METERING
23080759	2915-01-507-1919	PUMP, FUEL METERING
23080760	2915-01-507-1919	PUMP, FUEL METERING
23087916	2840-01-497-4108	PUMP, LUBE & SCAVENGE
26020066	5930-00-860-4159	THERMOSTAT ANTI ICING
26130010	4810-00-987-3948	VALVE, SOLENOID (SHUTOFF VALVE)
26930988	1660-00-166-2362	CONTROL BOX, ELECTRICAL
27231292	1660-00-583-7058	DUCT SENSOR
27231293	1660-00-583-7105	DUCT SENSOR
27231294	1660-00-583-7106	SENSOR, OVERHEAT
27231295	1660-00-588-3477	OVERHEAT SENSOR
27231296	1660-00-595-7773	SENSOR, CABIN TEMPERATURE
27231317	1660-00-570-1088	CONTROLLER, TEMP, FLIGHT STATION
27231318	1660-01-021-4981	CONTROL BOX, ELECTRICAL
27231318		CONTROLLER, TEMP, CARGO COMPARTMENT
27241301	4820-00-006-5087	CHECK VALVE
27431471	1660-01-015-5017	REGULATOR, EJECTOR
76123002		SYNCHROPHASER
88424010		ACCUMULATOR, BRAKE
185500000		BRAKE
186000000		BRAKE EMERGENCY, LH WING FLAP
1384740101	6615-00-061-3131	GYROSCOPE, RATE SWITCHING MC-1
1855000000		BRAKE
1860000000		BRAKE EMERGENCY, RH WING FLAP



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1.65E+29		ADAPTER
3.8E+74		VALVE
3.6E+85		STARTER
1.64E+88		ACTUATOR, INBOARD WING FLAP
1.855E+98		BRAKE
1.86E+98	1650-00-626-5728	BRAKE EMERGENCY, LH WING FLAP
1.855E+99	1650-00-626-5729	DISC,BRAKE
1.86E+99	1650-00-626-5729	BRAKE EMERGENCY, RH WING FLAP
1.65E+142		BRAKE
1.64E+193		ACTUATOR, OUTBOARD WING FLAP
1.65E+304		BRAKE ASSY
HEAT		
00000C522	5835-01-128-7757	CKPIT VOICE RECDR (A 100A) W/UNDERWATR LOC BEACON
0019000-01	6625-01-006-1584	TEST SET TACAN
015-870145-3-8	1680-01-437-0394	REEL HARNESS
022489-054-03	4320-00-654-3617	PUMP FUEL ROTARY
0253-0C04	1660-00-878-4034	CONVERTER,LIQUID OXYGEN
0411083-001	1650-01-198-2107	VALVE,9 PORT DIRECTIONAL CONTROL
066-01127-1601		Mode S Transponder
066-01143-0201	5821-01-482-8862	TRANSPONDER, MODE S
066-01143-0301		TRANSPONDER, MODE S
066-01143-0601		TRANSPONDER, MODE S
066-01146-1211	5841-01-552-1997	PROCESSOR,TCAS
066-01149-0048		RECEIVER
066-01171-0903		INDICATOR, TCAS VSI
066-01171-3706	6610-01-433-2219	INDICATOR VERTICAL
066-03084-0032		INDICATOR, RADAR TARGET
066-04031-1122		GPS RECEIVER
066-04031-2121		GPS RECEIVER
066-1071-00		TRANSPONDER
066-1077-00		DIG ADF REC
066-3031-01		RADIO ALT IND
066-3046-07		HSI IND
066-3084-32		IND RADAR
066-50000-2220	5841-01-514-7274	(TCAS) PROCESSOR,RADAR DATA
066-50000-2930		TCAS PROCESSOR
0666-5000-2220		T.C.A.S PROCESSOR
071-01480-0001		TCAS CONTROL PANEL
071-01480-001		TCAS CONTROLLER OF TCAS PROCESSOR TPA-81A
071-01515-1301		TCAS CONTROL PANEL
071-01519-0101		RT/ VERTICAL12" ANT
08-60169-001	1650-01-441-7404	ACCUMULATOR, BRAKE
08-60170-001		ACCUMULATOR
08-8422-001		ACCUMULATOR
08-8422-0011		ACCUMULATOR



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
08-8422-001-1		ACCUMULATOR
088422-010	1650-00-640-8491	ACCUMULATOR HYDRAULIC
08-8422-010		ACCUMULATOR
08-8423-001		ACCUMULATOR
08-8423-001-1		ACCUMULATOR
08-8423-010		ACCUMULATOR
08-8423-030		ACCUMULATOR
08-8423-030-1		ACCUMULATOR
08-8424-001		ACCUMULATOR
08-8424-0011		ACCUMULATOR
08-8424-001-1		ACCUMULATOR
08-8424-010		ACCUMULATOR
08-8424-100		CYLINDER
08-8425-010		ACCUMULATOR
08-8425-030		ACCUMULATOR
08-8425-100		CYLINDER
0911022-001	4810-00-013-7091	VALVE, SHUT-OFF, HYDRAULIC
092-000-001	6340-00-304-5556	DETECTOR ICE
10-0108-1	6220-01-537-0689	LIGHT, PANEL
10018-01		INDICATOR TORQUEMETER
10-0240-20	6220-01-533-4952	INDICATOR, LIGHT
10-0240-21	6220-01-533-4994	INDICATOR, LIGHT
10-0240-23	6220-01-533-5015	INDICATOR, LIGHT
10-0240-25	6220-01-533-5229	INDICATOR, LIGHT
10-0240-27	6220-01-533-5254	INDICATOR, LIGHT
10-0240-76	6220-01-533-5271	INDICATOR, LIGHT
10-0240-78	6220-01-533-5300	INDICATOR, LIGHT
10-0240-83	6220-01-533-5236	INDICATOR, LIGHT
10-0250-3	6220-01-537-0683	INDICATOR, LIGHT
10040-1000-0101	6680-01-220-4090	FUEL QTY DIGITAL INDICATOR
10040-3000-0101		FUEL QTY IND.
10040-5000-0101	6680-01-224-7271	INDICATOR, LIQUID
1005910-4		HYD. PRESSURE REDUCER VALVE
1005910-4		VALVE, PRESSURE REDUCER
1005910-5	4829-99-983-3598	VALVE REGULATING
1005910-5	4820-00-983-3598	VALVE, PRESSURE REDUCER
100-601702-051		MCDU CMA-2014
100-601900-402		FMU CMA-900
100-602517-000	6610-01-527-2395	INDICATOR, VERTICAL SPEED / TCAS
10073-0101	6680-01-350-8049	INDICATOR, LIQUID
10074-0101		FUEL QUANTITY INDICATOR
1008700-1		ACCUMULATOR
1008700-2		ACCUMULATOR
1008700-2	1650-00-516-6903	ACCUMULATOR, UTILITY SYSTEM
1008700-3		ACCUMULATOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1008700-4		ACCUMULATOR
1008700-5		ACCUMULATOR
1008700-6		ACCUMULATOR
1008700-7		ACCUMULATOR
1009350-1		ACTUATOR
1009350-1	2915-00-450-4492	ACTUATOR ASSEMBLY, ROTARY
1009350-2	2915-00-616-5726	ACTUATOR ELECTRO ME
1009350-2		ACTUATOR, ROTARY
1009350-2	2915-00-616-5726	ACTUATOR ASSEMBLY, ROTARY
10095-0101	6620-01-394-4018	INDICATOR
10-1026		VALVE
10-1026-1		VALVE
1010530-4	1650-00-395-2599	ACCUMULATOR, UTILITY SYSTEM
1010530-6		ACCUMULATOR
10-111160-3	2925-00-706-2720	EXCITER IGNITION
10-111160-6		VIBRATOR, IGNITION COIL
1012200-2	1650-00-730-3529	VALVE, RAMP CONTROL
1012200-3	4810-00-972-1897	VALVE, RAMP CONTROL
1012200-4	4810-00-014-1772	VALVE, LINEAR, DIRECT
1012200-4	4810-00-014-1772	VALVE, RAMP CONTROL
10-1296-1	6220-01-534-0550	PANEL, INDICATING, LIGHT
10-1301-1	6220-01-537-0674	PANEL, INDICATING, LIGHT
10-1326-1	6220-01-309-8385	LIGHT UNIT, EMERGENCY
101450-31243	6610-01-176-9314	ALTIMETER ENDCODER
1018-1-200		CONTROL DISPLAY UNIT
102076-1-5		OUTFLOW VALVE CONTROLLER
102076-1-6		OUTFLOW VALVE CONTROLLER
102076-3	1660-00-784-7463	AIR PRESS CONTROLLER
102076-3		OUTFLOW VALVE CONTROLLER
102076-3-11		OUTFLOW VALVE CONTROLLER
102076-3-12		OUTFLOW VALVE CONTROLLER
102076-350-1		OUTFLOW VALVE CONTROLLER
102076-5	1660-00-857-0742	CONTROLLER
102076-5		OUTFLOW VALVE CONTROLLER
102076-500-3		OUTFLOW VALVE CONTROLLER
102076-745-3	1660-00-784-7463	CABIN PRESS CONTROL
102076-745-3		OUTFLOW VALVE CONTROLLER
102116-2-1		CABIN AIR PRESS VALVE
102116-3-1		CABIN AIR PRESS VALVE
102150-0	1660-00-343-4692	REGULATOR,AIR PRESSURE,AIRCRAFT
102150-0		CABIN AIR PRESS VALVE
102150-0 SERIES 13	1660-00-343-4692	VALVE,OUTFLOW
102150-0-12		VALVE
102150-0-12		CABIN AIR PRESS VALVE
102150-0-13		CABIN AIR PRESS VALVE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
102150-0-13		CABIN AIR PRESS VALVE
102150-0-13		CABIN OUTFLOW VALVE
102150-0-14		CABIN AIR PRESS VALVE
102150-0-14		CABIN AIR PRESS VALVE
102150-0-15		CABIN AIR PRESS VALVE
102150-0-15		VALVE,OUTFLOW
102150-0-16		VALVE,OUTFLOW
102376-4-1		VALVE
102538-2-1	1660-00-062-0301	CONTROLLER,AIR PRESSURE,AIRCRAFT
102538-2-1		CABIN AIR PRESS CONTROL
102538-3-1		CONTROLLER
102538-5-1		CABIN AIR PRESS CONTROL
102650FA		DC MOTOR
102650FA	6105-00-806-8826	MOTOR, DC
102650JE	6105-00-806-8827	ACTUATOR, FUEL SHUT-OFF
102650K100	6105-01-006-2868	MOTOR, SHUT-OFF VALVE
102842ED	1680-00-675-8017	ACTUATOR, ELECTRO-MECH
102842ED		ACTUATOR
102842FM		ACTUATOR
102842FM	2915-00-870-4535	ACTUATOR, SHUT-OFF VALVE
102842FN	2915-00-775-6674	ACTUATOR,ELECTRO-MECHANICAL,ROTA
102842FN	2915-00-775-6674	ACTUATOR, SHUT-OFF VALVE
103006-1-6		VALVE
103006-1-9		VALVE
103006-2-6		VALVE
103006-714		VALVE
103006-810-1		VALVE
1030119-2		CCA
103036-3	1660-00-783-6159	REG AIR FLOW
103036-3		CABIN AIR PRESS VALVE
103036-3	1660-00-783-6159	VALVE, SAFETY (SERIES 4)
103036-3-6		SAFETY VALVE
103036-5	1660-01-483-3094	REGULATOR, AIR FLOW
103036-5	1660-01-483-3094	VALVE, SAFETY
103036-724	1660-00-735-3655	REGULATOR,AIR PRESSURE,AIRCRAFT
103036-724		SAFETY VALVE
103036-724	1660-00-735-3655	VALVE, SAFETY
103036-780-1		SAFETY VALVE
103036-780-1	1660-00-777-0721	AIR PRESSURE REG
103036-835		VALVE, SAFETY
103036-835-1		VALVE, SAFETY
103104-2-4		VALVE
103104-2-5		VALVE
103104-3		VALVE
103104-6-1		VALVE



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
103104-942		VALVE
103104-942-2		VALVE
103430-2		VALVE
103430-3		VALVE
103432-1		VALVE SHUT OFF
10401N01P00	6620-01-394-4019	INDICATOR, PRESSURE
10405N01P00	6620-01-394-4042	INDICATOR, PRESSURE
104156-1	4810-00-529-3584	BUTTERFLY VALVE
104156-1	4810-00-529-3584	VALVE, AUXILIARY VENT
104156-1-6		VALVE
104156-1-6	4810-00-529-3584	BUTTERFLY VALVE
104156-1-6	4810-00-529-3584	VALVE, AUXILIARY VENT
104156-1-7	4810-00-529-3584	VALVE BUTTERFLY
104156-1-7	4810-00-529-3584	BUTTERFLY VALVE
104156-1-7	4810-00-529-3584	VALVE, AUXILIARY VENT
10450-31105	6610-00-160-3226	PRESSURE ALTIMETER
10450-31105	6610-00-160-3226	ALTIMETER, PRESSURE
1051R104	1620-00-674-9069	GEARBOX, MANUAL, MLG
1051R115	1680-00-674-9069	GEARBOX, MANUAL, MLG
1051R160	1620-00-633-6543	GEARBOX, MANUAL, MLG
1051R195	1620-00-674-9069	GEARBOX, MANUAL, MLG
1051R228	1620-00-859-6786	GEARBOX, MANUAL, MLG
1051R268	1620-00-067-0135	GEARBOX, MANUAL, MLG
1051R274		GEAR BOX, LANDING GEAR
1051R274	1620-00-014-3131	GEARBOX
1051R274		GEARBOX, MANUAL, MLG
1051R300	1620-00-406-5828	GEAR BOX LANDING GEAR
1051R300	1620-00-406-5828	GEARBOX
1051R300	1620-00-406-5828	GEARBOX, MANUAL, MLG
106040-0-7		VALVE
106040-0-7	1660-00-532-1527	VALVE, FLOW CONTROL
106040-1		VALVE
106040-1-1		FLOW CONTROL AND SHUT OFF
106040-2		VALVE
106040-2	1660-00-610-0601	AIR PRESS REG
106040-2	1660-00-610-0601	VALVE, FLOW CONTROL
106040-2-2		VALVE
106040-2-2		VALVE, FLOW CONTROL
106040-3	1660-00-625-6195	REGULATOR AIR PRESSURE
106040-3		VALVE
106040-3	1660-00-625-6195	VALVE, FLOW CONTROL
106040-3-1		VALVE
106040-3-1		VALVE, FLOW CONTROL
106040-4		VALVE
106040-4		VALVE, FLOW CONTROL



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
106040-4-1	1660-00-084-6707	REGULATOR AIR PRESSURE
106040-4-1		VALVE
106040-4-1	1660-00-084-6707	VALVE, FLOW CONTROL
106040-6-1	1660-01-551-6823	VALVE, FLOW CONTROL
10-61068-1	4410-00-689-1609	HEATER WATER ELECT
106388-1-2	4810-00-513-4471	VALVE BUTTERFLY
106388-1-2		VALVE
106388-1-2	4810-00-513-4471	VALVE, RADOME ANTI-ICING, SHUT OFF
106388-3-1		VALVE
106475-1		VALVE
106475-1	4810-00-529-3929	VALVE
106475-1	4810-00-529-3929	VALVE, DIVERTER, RUDDER BOOSTER
106475-2		VALVE
106475-3		VALVE
106475-4		VALVE
106616-0-3		VALVE
106616-0-3	1660-00-610-9686	VALVE
106616-0-3	1660-00-610-9686	VALVE, FLOW CONTROL
106616-1		VALVE
106616-1-1	1660-00-084-6708	FLOW CONTROL AND SHUT OFF VALVE (FLT DECK)
106616-1-1		VALVE
106616-1-1	1660-00-084-6708	VALVE, FLOW CONTROL
106616-2	1660-00-084-6708	VALVE
106616-2	1660-00-084-6708	VALVE, FLOW CONTROL
106A154-1	6220-01-309-8385	LIGHT UNIT, EMERGENCY
107996-1-1		PNEUMATIC THERMOSTAT
107996-66	6685-00-934-8208	THERMOSTAT, FLOW CONTROL
108032-0-39		REGULATOR DIFERENCIAL PRESSURE
108032-0-39	2835-00-091-6349	REGULATOR, AIR P
108032-3		REGULATOR
108032-3		REGULATOR, AIR P
108032-8	4820-01-201-5308	REGULATOR AIR
108136-0-2	4820-00-328-1459	VALVE, AIR PRESSURE REGULATOR
108136-1	1660-01-293-4916	REGULATOR
108136-1-1		REGULATOR
108136-11-1		REGULATOR
108136-21-3		REGULATOR
108136-22-1		REGULATOR
108136-25-1	1660-01-213-0439	REGULATOR
108136-26-1	4820-01-548-3932	REGULATOR
108354-4		REGULATOR
10870-2		VALVE
109016-11	2835-00-682-5352	VALVE
109016-11-1	2835-00-682-5352	VALVE
109016-7	4810-00-797-3261	VALVE LOAD CONTROL



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
109206-2		VALVE
109206-3		VALVE
109206-3	2995-00-675-3641	VALVE ASSEMBLY,SPEED SENSITIVE
109206-7		VALVE
109206-7	2995-00-777-3690	VALVE ASSEMBLY,SPEED SENSITIVE
109350-6	4820-00-639-9685	REGULATOR
109382-13	4810-00-494-5727	VALVE BUTTERFLY
109486-6-1		VALVE, BLEEDER
109710-1-1		VALVE
109710-1-1	4810-00-299-7847	BUTTERFLY VALVE
109710-2	4810-01-014-2632	BUTTERFLY VALVE
109710-2-1		APU BUTTERFLY VALVE
109710-2-1		VALVE
109710-3-1		VALVE
109710-4-1		VALVE
109710-5-1		VALVE
109710-6	4810-01-229-3584	BUTTERFLY VALVE
109710-6-1		BLEED VALVE
109710-6-1		VALVE
109710-7-1		VALVE
109710-8-1		VALVE
109710-9	4810-01-229-3584	BUTTERFLY VALVE
109710-9-1	4810-01-393-3991	CONVERT LVC
109710-9-1	4810-01-393-3991	VALVE, BUTTERFLY
10C-0001-0026	1660-00-122-8101	CONVERTER LIQUID OXY
10C0001-26	1660-00-122-8101	CONVERTER,LIQUID OXYGEN
10C-0001-26	1660-00-122-8101	CONVERTER,LIQUID OXYGEN
10C-0001-26	1660-00-122-8101	CONVERTER,LIQUID OXYGEN
10C-0001-26		CONVERTER,LIQUID OXYGEN
10-C0001-26	1660-00-768-5256	CONVERTER,LIQUID OXYGEN
110100-2		CYLINDER ASSEMBLY, AILERON BOOSTER
1105123-1	1680-01-254-6893	ACTUATOR,ELECTRO-MECHANICAL,LINE
1105123-1		ACTUATOR
1105123-1	1680-01-254-6893	ACTUATOR, OIL COOLER DOOR
11060-2		VALVE
11060-3		POWER BRAKE VALVE
11060-7	1630-00-859-3997	VALVE, POWER BRAKE
110745-1		VALVE
1111-2	5999-00-927-1541	CYLINDER ASSEMBLY, AILERON BOOSTER
1111-3	1650-00-650-7610	CYLINDER ASSEMBLY, AILERON BOOSTER
1111-4		CYLINDER ASSEMBLY, AILERON BOOSTER
1111-5	1650-00-650-7610	CYLINDER ASSY, ACTUATING
1111-5	1650-00-650-7610	CYLINDER ASSEMBLY, AILERON BOOSTER
1111-548030		VALVE
1111-568748		VALVE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1111-568749		VALVE
111302-5	6605-01-245-7660	INDICATOR, HORIZONTAL SITUATION
1120-1		CYLINDER ASSEMBLY, RUDDER BOOSTER
1120-2		CYLINDER ASSEMBLY, RUDDER BOOSTER
1120-3	1650-00-629-3900	CYLINDER ASSEMBLY, RUDDER BOOSTER
1121F8-2.0		VALVE
1121F-8-2.0		VALVE
1121F8-9.0		VALVE
1121F-8-9.0		VALVE
114672-0		PUMP AND CONTROL ASSEMBLY,FUEL
114PS205-2	3010-00-420-5226	ACTUATOR, ELECTRO-MECHANICAL, ROTARY
115-230	6685-01-329-0849	INDICATOR TEMPERATURE
1164-1		VALVE
116595-01	6610-00-557-3030	INDICATOR, ATTITUDE
11670-1		VALVE
118115-01	6615-00-530-3061	GYROSCOPE, DISPLACEMENT
1184R100	1680-00-674-3545	WINCH, PARATROOP RETRIEVAL
1184R125	1680-00-733-3491	WINCH AIRCRAFT MOUNTED
1184R125	1680-00-733-3491	WINCH, AIRCRAFT
1184R125		WINCH, PARATROOP RETRIEVAL
118769-01	6610-00-590-8270	INDICATOR, REMOTE ATTITUDE
118930-01	6610-00-607-8292	INDICATOR, REMOTE ATTITUDE
118930-02-01	6610-00-965-9840	INDICATOR
1192-30-111101		NAVIGATION COMPUTER UNIT
1192-30-111101		NAVIGATION COMPUTER UNIT
119538-01	6615-00-613-5476	GYROSCOPE
119538-02	6615-00-555-3962	GYROSCOPE
120435-1		VALVE
12085-1		MOTOR ASSY PYLON
121000-1		VALVE
121000-1	4810-01-220-6060	VALVE
121000-1	4810-01-220-6060	VALVE,ANTI-ICE
12-10001-01	6680-01-419-1995	TRANSMITTER,LIQUID QUANTITY
121000-2		VALVE
121000-2	4810-01-220-6060	VALVE
121000-2	4810-01-220-6060	VALVE,ANTI-ICE
1214BX-8-05	6610-00-526-7947	INDICATOR AIR SPEED
1214DX8-05	6610-00-530-0026	INDICATOR AIR SPEED
121535-1	4810-00-706-0266	SHUTOFF VALVE ASSY
121535-1	4810-00-706-0266	VALVE AIR BLEED
121535-1	4810-00-706-0266	VALVE, SHUTOFF
121672-01	6615-00-550-6628	GYROSCOPE, DISPLACEMENT
121672-01-15	6615-00-973-2218	GYROSCOPE, DISPLACEMENT
121672-01-16	6615-00-074-4036	GYROSCOPE, DISPLACEMENT
121672-01-17	6615-00-900-5959	VERTICAL DISPLACEMENT GYRO



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1221LP	6220-00-808-3655	PANEL, INDICATING, LIGHT
123488-010-01	4320-00-631-4859	FUEL PUMP
123488-010-01	4320-00-631-4859	CENTRIFUGAL FUEL PUMP
123510-010-01		PUMP
123510-010-01	2915-01-579-2811	PUMP, FUEL BOOST
123510-011-01		PUMP
123510-011-01	2915-00-073-8891	PUMP, FUEL BOOST
123510-014-01	2915-01-185-1847	PUMP
123510-014-01	2915-01-185-1847	PUMP, FUEL BOOST
123796-1-1	4820-00-356-1040	VALVE, CHECK
124.115-3		DUAL TEMP PRESSURE INDICATOR
124-1006-1	6620-01-328-0926	INDICATOR ENG OIL TE
124-1007-1	6620-01-308-2520	INDICATOR PRESSURE
124-1207	6685-01-328-7139	INDICATOR TEMPERATURE
124623-01	6615-00-581-2265	GYROSCOPE, DISPLACEMENT
124623-01-09	6615-00-852-1611	GYROSCOPE, DISPLACEMENT
124623-01-10	6615-00-951-9140	GYROSCOPE, DISPLACEMENT
124623-01-12	6615-00-994-8940	GYROSCOPE, DISPLACEMENT
124623-01-13	6615-00-999-2630	GYROSCOPE, DISPLACEMENT
124623-01-14		MD1 Gyro
124-934		DUAL AC/DC VOLT
124-934A		DUAL AC/DC VOLT
126-179	6620-01-308-2604	INDICATOR, ITT
127123-01	6615-00-585-0990	INDICATOR
130211-3		HYD SERVO VALVE
130234-5		HYD SERV VALVE
130234-7		HYD SERVO VALVE
131400-01	6610-00-580-9562	INDICATOR
13210-1		VALVE
132555-1		VALVE OIL SHUT OFF
132555-1		VALVE,GATE
1333-613233		ENGINE BLEED SHUT OFF
1333-613233		VALVE, SHUTOFF
1333-613233M1	4810-00-065-9471	VALVE BUTTERFLY
1334-3		HYD SERVO VALVE
1334-5		HYD SERVO VALVE
1334-7		HYD SERVO VALVE
1334-7	1650-00-670-6581	SERVOVALVE, RUDDER BOOSTER
1356-512107		ACCUMULATOR
1356-512457		ACCUMULATOR
1356-512463		ACCUMULATOR
1356-512465		ACCUMULATOR
1356-512471		ACCUMULATOR
1356-512473		ACCUMULATOR
1356-512475		ACCUMULATOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1356-542107		ACCUMULATOR
1356-542838		ACCUMULATOR
1356-542839		ACCUMULATOR
1356-542897	1650-00-987-8389	Accumulator Assembly, Double Shell
1356-542899	1650-00-721-6416	ACCUMULATOR, HYDRAULIC
1356-542901		ACCUMULATOR
1356-542903		ACCUMULATOR
1356-542905		ACCUMULATOR
1356-552235		ACCUMULATOR
1356-552237		ACCUMULATOR
1356-583315		ACCUMULATOR
1356-583315-101	1650-01-159-0327	ACCUMULATOR, BRAKE
1356-583317		ACCUMULATOR
136600-01-03	6610-00-855-9349	INDICATOR
1371-598820	4810-00-737-3349	VALVE SOLENOID
1371-598850		VALVE
1372-3		SERVO VALVE HYDRAULIC
1372-4	1650-00-513-5415	SERVOVALVE, ELEVATOR BOOSTER
1372-5		SERVOVALVE, ELEVATOR BOOSTER
138094-01-02	6610-00-990-9825	INDICATOR
138474-01-01	6615-00-061-3131	GYROSCOPE
139100-01-01	6615-00-994-2152	DISPLACEMENT GYRO
13V600-6		VALVE
140180-01-01	6615-00-738-6204	RATE GYRO
140-207	5835-01-085-9586	TRANSDUCER, WHEEL SPEED
140260-01-03	6615-00-928-0072	GYROSCOPE
14080-1	4810-00-610-9390	VALVE LINEAR DIRECT
14080-1	4810-00-610-9390	VALVE LINEAR DIRECT
14125-1-A	6615-00-618-9804	GYROSCOPE
142765-1		VALVE
142853-01-02	6615-00-135-7967	DEMODULATOR
142853-41-02	6615-00-135-7967	DEMODULATOR
1437-10	4320-00-017-7865	PUMP, SUCTION BOOST
1437-8	4320-00-811-3746	PUMP, SUCTION BOOST
14602-1J-D1	6610-00-663-8798	INDICATOR, ATTITUDE
14602-1J-F1	6610-00-663-8800	INDICATOR, ATTITUDE
147601-2	2915-00-072-6226	HEATER AND STRAINER
147B31	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31A2	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31A3	6685-00-005-9025	INDICATOR TEMPERATURE
147B31A4	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31B	6685-00-692-8341	INDICATOR, TEMPERATURE
147B31F	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B31G	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
147B8	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
14950-17	1660-00-856-0550	REGULATOR OXYGEN
14950-34		OXYGEN REGULATOR
14950-34M	1660-01-010-4949	OXYGEN REGULATOR
14950-40	1660-00-169-1888	OXYGEN REGULATOR
14950-45	1660-00-169-1888	REGULATOR,OXYGEN,DILUTER DEMAND
149D6050-1	1680-01-021-8032	DROGUE STOWAGE ASSEMBLY
15-0009-3	6220-01-534-1102	LIGHT, DOME
15-0015-37	6220-01-509-4789	LIGHT, COCKPIT, AIRCRAFT
15-0015-39	6220-01-509-4790	LIGHT, COCKPIT, AIRCRAFT
15-0069-1	6220-01-534-0539	SPOTLIGHT
15019-1A1	6615-00-207-4771	TRANSMITTER, FLUXGATE
15-0601-23	6220-01-509-4792	LIGHT, COCKPIT, AIRCRAFT
15-0836-3	6220-01-509-4402	LIGHT, DOME
15101-1EA1	6610-00-514-5272	INDICATOR, THREE AXIS TRIM
15150-1	6615-00-570-4960	CONTROL, SLAVING
152050-4		OIL COOLER
15236-1A1	6615-00-325-6981	ADAPTER, AUTOPILOT
1541492-1	6115-00-351-5768	DISCONNECT ASSY,GENERATOR
1545675-1	6115-00-351-5760	DISCONNECT ASSY,GENERATOR
15482-1A1	5996-00-855-9045	AMPLIFIER, ELECT
1580997-2	6115-00-327-4068	ROTOR GENERATOR
15811-1	5930-00-139-9003	SWITCH, PRESSURE
15826-1-A	6615-00-618-9800	GYROSCOPE, DISPLACEMENT
158410-3		OIL COOLER
159245-3		ALTIMETER, INDICATOR
1593-503	6220-00-299-4621	LIGHT, LANDING
162B2	6685-00-553-4726	INDICATOR, TEMPERATURE
162B202A	6685-00-553-4726	INDICATOR LAMP
162B203	6685-00-514-5327	INDICATOR, TEMPERATURE
162B2A	6685-00-838-7429	INDICATOR, TEMPERATURE
162B2D	6685-00-097-6263	INDICATOR,TEMPERATURE,ELECTRICAL RESISTANCE
162B2G	6685-00-005-9024	INDICATOR TEMP
162B3	6685-01-484-9826	INDICATOR, TEMPERATURE RATIO
162B3F	6685-00-514-5327	INDICATOR, TEMPERATURE
162B4	6685-00-514-5328	INDICATOR, TEMPERATURE
164-1	6680-00-753-8932	LIQUID OXY QTY IND
16430-1		PUMP
1650E412	1620-00-677-6681	BALLSCREW MAIN GEAR
1650E420		BRAKE
1650E420	1620-00-723-1880	HYDRAULIC BRAKE ASSY
1650E490		BRAKE
1650E490	1620-00-996-4561	HYDRAULIC BRAKE ASSY
1650E497		BALL SCREW ASSEMBLY, MAIN LANDING GEAR
1650E615		BALL SCREW
1650R21	1680-00-510-8671	GEAR BOX ASSEMBLY MAIN LANDING GEAR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
1650R319	1680-00-627-9857	GEAR BOX ASSY, MAIN
1652-6AJ-B6-1	6610-00-639-3615	INDICATOR, RATE OF CLIMB
168396-01-01	6605-01-250-9782	CONTROL, INDICATOR
168396-02-01	6605-01-311-9074	CONTROL, INDICATOR
168396-03-01	6605-01-436-5128	CONTROL, INDICATOR
16VZ001-55	6615-00-137-6038	GYROSCOPE, RATE
1701BX-03	6610-00-844-1195	INDICATOR, AIRSPEED
1701BX8-04	6610-00-844-1195	INDICATOR, AIRSPEED
1701CX8-04	6610-00-531-4160	INDICATOR, AIRSPEED
1701DX10-04	6610-01-067-0228	INDICATOR AIRSPEED
1701DX4-04	6610-00-585-4931	INDICATOR AIRSPEED
1701DX8-04	6610-00-179-9033	INDICATOR AIR SPEED
1701DX-8-04	6610-00-179-9033	INDICATOR AIR SPEED
172-1704	6685-00-450-4489	TRANSMITTER, PRESSURE
173DA2		BRAKE ASSY, FLAP DRIVE
1790043-1	6615-00-887-6765	POWER SUPPLY, MONITOR
179250-0003	5865-01-451-2868	COUNTERMEASURES DISPENSER SWITCH
179598-1	2915-00-633-6912	AMPLIFIER, TEMPERATURE DATUM
17960-0102-002		GNS-XLS FMS
179649-1	2915-00-633-6912	AMPLIFIER, TEMPERATURE DATUM
179684-1	5996-00-605-8496	AMPLIFIER ASSY
179727-2	5996-00-764-6258	AMPLIFIER, TEMPERATURE DATUM
179822-1		TD amplifier
179827-1		AMPLIFIER, TEMPERATURE DATUM
17M700-274		FLIGHT RECORDER
18000-2	5826-01-459-5969	INDICATOR BEARING
18-0044-1	6695-01-381-1905	LIGHT, INSTRUMENT
18-0045-1	6695-01-381-2277	LIGHT, INSTRUMENT
18-0046-1	6695-01-381-2047	LIGHT, INSTRUMENT
18-0049-1	6695-01-381-2126	LIGHT, INSTRUMENT
18-0062-1	6695-01-381-1526	LIGHT, INSTRUMENT
18-0063-1	6695-01-425-5333	LIGHT, INSTRUMENT
180-147		CONTAINER
18-1105	6685-00-557-0215	FUEL PRESSURE IND.
18-1278		OIL PRESS IND
18-1704	6685-00-450-4489	TRANSMITTER, HYDRAULIC PRESSURE
18-54903-3	1660-01-049-3423	PRESSURE REG. VALVE SHUT OFF
1855D10	1650-00-570-8730	SWITCH, LH SENSING
1855D11	1650-00-570-8731	SWITCH, RH SENSING
1855D7		REDUCER, SPEED, LH
1855D8		REDUCER, SPEED, RH
1855D97	1650-00-626-5730	REDUCER, SPEED, LH
1855D98	1650-00-626-5731	REDUCER, SPEED, RH
188440-2-1		HEAT EXCH
18900-160	4820-00-880-4744	VALVE REGULATING TE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
190585-1	4810-00-540-2106	VALVE
190772-1		VALVE
190772-2	2915-00-626-3123	VALVE ASSY PARALLEL
190772-2	2915-00-626-3123	VALVE, PARALLELING
191006-1-1	1660-00-588-3478	WATER SEPERATOR
191006-1-2	1660-01-044-0091	WATER SEPARATOR, AIR CON
191390-2-2	1660-01-150-9084	HEAT EXCHANGER
19-20-5	6610-00-580-9363	INDICATOR, POSITION
19A513	4140-00-564-5980	ACTUATOR, ROTARY
1-A	6610-00-526-4798	INDICATOR, AIRSPEED
1A20454H01	4440-01-324-1783	COMPRESSOR DEHYDRATOR
1A23446H01	5895-01-316-1232	INTERROGATOR SET
1D17431G01	6130-01-182-3032	POWER SUPPLY
1D17431G02	6130-01-318-3166	POWER SUPPLY
1D17627G01	5840-01-182-6432	EXCITER RADIO
1D17627G01	5840-01-182-6432	EXCITER RADIO
1D18517G01		CIRCUIT CARD ASSEMBLY
1D18517G01		CIRCUIT CARD ASSEMBLY
1D18517G02	5998-01-316-0046	CIRCUIT CARD ASSEMBLY
1D20464G01	6130-01-221-6862	INVERT POWER MODULE
1D20801G01	6130-01-215-8501	POWER SUPPLY
1D22877G01		ANTENNA PEDESTAL
1D23052G01	6130-01-262-8351	POWER SUPPLY
1D23551G01	5840-01-350-9085	DISPLAY UNIT RADAR
1D27054G01		CIRCUIT CARD ASSY
1D27545G02	5998-01-300-2228	CIRCUIT BOARD
1D27545G02	5998-01-300-2228	CIRCUIT BOARD
1D27749G02	5998-01-299-9945	CIRCUIT BOARD
1D27749G02	5998-01-299-9945	CIRCUIT BOARD
1D5745G2	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
1D5745G3	5865-01-066-1671	BIT/HIV INPUT ASSEMBLY A6
1EN61-6B	5930-00-709-1054	SWITCH, PUSH
1G107	5930-00-615-7340	SWITCH, PRESSURE
20000532091-001	6615-01-415-0067	CONTROL, MODE SELECT
200027176-10		NLG STEERING CYLINDER
200-037-002	6680-01-073-7582	INDICATOR, LIQUID QUANTITY
200-037-005	6680-01-120-7609	INDICATOR, LIQUID QUANTITY
200-1000-01	6130-01-360-4061	POWER SUPPLY
200-1001-01	6220-01-360-5434	CONTROL ELEC. LIGHT
20-0106-1	6220-01-533-5349	LIGHT, INDICATOR
20-063	6670-01-061-6419	ACTUATOR, PARATROOP, SPOILER DOOR
20-063A		ACTUATOR, PARATROOP, SPOILER DOOR
2006629-105		ARM
201-004-001	6620-01-038-5801	TORQUE INDICATOR
201090-1		COOLING TURBINE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
201090-10		COOLING TURBINE
201090-11		COOLING TURBINE
20140-0351	6610-00-006-5783	AIRSPEED INDICATOR
20201-3	1650-00-611-0431	CONSTANT SPEED DRIVE
20-224-01	6680-01-290-5920	INDICATOR, LIQUID QUANTITY
202919-306	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
202921-303	5895-01-307-7347	RECEIVER SIGNAL SELECTOR
203-003-002	6680-00-333-6757	QUANTITY INDICATOR
203430-1		COOLING TURBINE
203430-2		COOLING TURBINE
203430-4		COOLING TURBINE
203430-4-1		COOLING TURBINE
203720-1	1660-00-897-4306	TURBINE, AIRCRAFT
203720-2		TURBINE
203720-3		TURBINE COOLER
203720-3-1		TURBINE
2038091-0502		RX-AFC MOD
2039669-0503	6220-01-343-1578	PANEL, INDICATING, LIGHT
2041232-1104	6210-00-140-8738	RADAR PILOTO INDICATOR
2041232-1104	6210-00-140-8738	INDICATOR,RADAR
2041232-3110		RADAR INDICATOR
204A1A5A	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
2052002-521	5826-00-543-0759	RECEIVER
206-075-190-1		TEMP. INDICATOR
2067157-0162		RADAR TRANSCEIVER
2068599-0705	5985-01-495-3531	WAVE GUIDE SWITCH
2070409-0101		RADAR ANTENNA
2070410-0101	5821-01-408-7392	TRANSCEIVER
2070552-0103		RADAR CONTROL UNIT
2070963-0103		WEATHER RADAR RT
2070963-0104		RECEIVER TRANSMITTER RADAR
2070963-0105	5841-01-314-9947	TRANSCEIVER RADAR
2070964-0107	5841-01-314-9991	SCOPE RADAR
2070965-0105		CONTROL SET RADAR
207410-0101		RNTX UNIT RADAR IF
209-070-262-101	5895-01-252-5691	TEMP INDICATOR
209-070-262-3		INDICATOR TEMP
209-070-262-9		INDICATOR,TEMP PRESS
209-070-263-1	6625-00-248-6971	DUAL AC/DC VOLT
209-070-263-3		DUAL INDICATOR
209-070-264-1	6625-00-248-6976	AMP METER
209-070-264-3		DUAL AMP METER
209-070-275-1	6620-15-160-0834	INDICATOR FUEL 0-50 PSI
20B95-4	6110-01-109-5099	REGULATOR VOLTAGE
20B95-4A	6110-01-109-5099	REGULATOR,VOLTAGE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
21020-1	4810-00-688-9939	VALVE,ANTI-ICE
210-2360	4730-00-626-9199	SWIVEL JOINT
21086-1	1660-00-730-0150	CONVERTER,LIQUID OXYGEN
21086-1	1660-00-730-0150	CONVERTER,LIQUID OXYGEN
211-009-002	6680-01-121-7070	INDICATOR, LIQUID QUANTITY
211-009-003	6680-01-123-2647	INDICATOR, LIQUID QUANTITY
211-009-004	6680-01-121-7071	INDICATOR, LIQUID QUANTITY
211-009-005	6680-01-342-7698	INDICATOR, LIQUID QUANTITY
2118-363		ACCELEROMETER
2118-364	6610-01-391-9062	ACCELEROMETER, MECHANICAL
2119-001	6610-00-585-5929	ACCELEROMETER
2119-001-2	6610-00-585-1355	ACCELEROMETER
2119-001-3	6610-00-684-1666	ACCELEROMETER, MECHANICAL
2119-500	6610-00-007-1030	ACCELEROMETER, MECHANICAL
2120-1		VALVE
212-070-108-7	6680-01-492-3356	TRIPLE TACH IND.
212-070-116-9	6620-01-492-3358	PRESSURE INDICATOR
212-070-160-005		DUAL TORQUE IND.
212-070-160-101		DUAL TORQUE IND.
212-070-160-15		DUAL TORQUE IND.
212-070-160-17		DUAL TORQUE IND.
212-070-160-5	6680-01-478-4288	DUAL TORQUE IND.
212-070-160-7	6680-01-492-3357	DUAL TORQUE IND
212-070-238-3		ALTIMETER
212-070-238-7		ALTIMETER
212-070-239-001	6610-00-617-6056	VERTICAL SPEED INDICATOR
212-075-036-101	6625-01-252-7616	INDICATOR,TEMPERATURE
212-075-037-101		GAS PRODUCER TACH
212-075-067-105		ITT INDICATOR
212-075-420-3		ITT INDICATOR
212-075-562-1		ITT INDICATOR
212-075-562-3	6685-01-492-2612	INDICATOR I.T.T.
2187C		GEAR BOX
2196D		GEAR BOX
2196E		GEAR BOXFLAP
219A967	1630-00-914-1329	WHEEL LANDING GEAR
219A967-1		NOSE WHEEL
21B17-10-B	6110-01-044-4331	REGULATOR VOLTAGE
21SN27-1	5930-00-732-2509	SWITCH,OIL PRESSURE
21SN27-3	5930-01-502-4004	SWITCH, PRESSURE
21SN27-3	5930-01-502-4004	SWITCH,OIL PRESSURE
2200440-6-1		REFRIGERATOR UNIT
22A524	6680-00-585-1503	GENERATOR, TACHOMETER
22A554	6680-00-585-1503	GENERATOR, TACHOMETER
22A703		TACH GENERATOR



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
2301420-1	5996-01-406-9088	INTERMEDIATE FREQUENCY AMPLIFIER
23052609A	5996-01-274-7553	AMPLIFIER TEMPERATURE
23059687B	5996-01-406-4035	AMPLIFIER, TEMPERATURE DATUM
23079-1020		ARMATURE
2311M-28-1	6105-00-630-5828	WINDSHIELD WIPER MOTOR ASSEMBLY
2311M-28-2	6105-01-471-1593	WINDSHIELD WIPER MOTOR ASSEMBLY
2312M-30-17	1680-00-712-0716	CONVERTER, WINDSHIELD WIPER
23410-3	1630-00-998-7897	VALVE, BRAKE CONTROL
235550-4	5821-01-245-9095	RECEIVER, TRANSMITTER
239-004		FREQUENCY METER
2488136G001	5865-01-178-0408	DOWN CONVERTER MIXER
250A200	1630-01-188-6735	WHEEL, LANDING GEAR
250A200-1LC	1630-01-188-6735	WHEEL, LANDING GEAR
25100-004		ALERTER
25122A37B-1-A1		HYD PRESSURE IND.
25122-A37B-1-A1	6685-00-557-0215	INDICATOR, SYNCHRO
2527T100-1	1680-00-070-9980	WINCH
25430135-02		TEMP CONTROL BOX
25430135-03		TEMP CONTROL BOX
25430135-04	1660-00-735-3655	CONTROL BOX, ELECTRICAL
25430135-06		CONTROL BOX TEM
25430135-07	1660-00-387-4319	BOX CONTROL TEMP
25430135-08		TEMP CONTROL BOX
25430135-09		TEMP CONTROL BOX
25523158-03	5930-00-658-6512	SWITCH, THERMOSTATIC
25530562-01		THERMOSTAT
25730032-02		SOLENOID SHUT-OFF VALVE
25730032-03		SOLENOID SHUT-OFF VALVE
25730032-04		AIR CONTROL VALVE
25730043-02		SOLENOID SHUT-OFF VALVE
25730043-03		VALVE,SOLENOID
25730043-04		VALVE
2586257-1	6605-00-447-9654	COMPENSATOR, REMOTE
2586261-1	6605-00-447-9665	DIGITAL CONTROLLER
2586333-1		DIRECTIONAL GYRO
2586333-2	6615-00-180-0895	DIRECTIONAL GYRO
2586333-3	6615-01-065-7226	GYROSCOPE DISPLACEMENT
2587193-43	6615-01-020-7531	GYRO DIRECTIONAL
2588302-3		GYROSCOPE DISPLACEMENT
2589226-1		AMP POWER SUPPLY
2591200-901	6605-01-034-8737	MAGNETIC COMPENSATOR
2591201-902	6605-01-034-5256	COUPLER, COMPASS
2591202-912	6605-01-036-5089	CONTROLLER, COMPASS
26130010-01	4810-00-987-3948	VALVE SOLENOID
2690346-1	6615-01-260-8214	RATE INTEGRATING GYRO, LC22



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
270-2196-020	6615-01-068-8713	AIRSPED SENSOR
27231317-01	1660-01-014-4509	CONTROLLER TEMPERATURE
27231317-01	1660-01-014-4509	CONTROLLER, TEMP, FLIGHT STATION
27231318-01	1660-01-021-4981	CONTROL, TEMPERATURE
27231318-01		CONTROLLER, TEMP, CARGO COMPARTMENT
272B308042	6220-00-299-4621	LIGHT, LANDING
27431466-01	1660-01-003-6297	CONTROLLER, TEMP, LOW LIMIT
275540-003	5826P275540-003	RMI
27610-B		WINCH, PARATROOP RETRIEVAL
27620-1	1650-01-217-7899	BRAKE HYDRO-MECANICAL
27620-2		BRAKE
27A10614-101-11		ACCUMULATOR
28300-8		VALVE
28300-81		VALVE
28B135-145A		AC GENERATOR
28B58-93	6115-01-224-5848	GEN ALTERNATING
28B58-9B	6115-01-224-5848	GENERATOR ALTERNATOR BEN
28B58-9-B	6115-01-224-5848	GENERATOR, BENDIX
28VS200C1	6130-00-081-7844	POWER SUPPLY
28VS200C-1	6130-00-081-7844	POWER SUPPLY
2905-001	6105-01-216-4182	MOTOR,DIRECT CURRENT
29270-10A-A1	1660-00-243-0393	OXYGEN REGULATOR
29270-10A-B1	1660-00-243-0393	OXYGEN REGULATOR
2CM11BAA5	6620-00-785-2251	ALTERNATOR
2CM353C1	6115-00-946-8441	Generator Alt
2CM353C1P	6115-00-946-8441	GENERATOR
2CM5ADR	6680-00-487-4289	Tach Generator
2CM63E1A	2925-00-178-0940	GENERATOR
2CM9ADE8	6680-00-008-4544	TACHOMETER GENERATOR
300-0746-002	6685-01-366-3065	TRANSMITTER, PRESSURE
3006T88G05	2915-00-143-6107	VALVE, FUEL PRESS
30-1131-1	6220-01-055-3992	LIGHT, NAVIGATIONAL
30170A	4810-01-360-8278	VALVE, RAMP CONTROL
30-2217-1	6220-01-426-4360	LIGHT, NAVIGATIONAL
30-231	6340-01-087-2792	SMOKE DETECTOR TYPE II
30678-17	1680-00-797-4478	ACTUATOR ELECTRO MECH
30678-18	1660-00-719-5261	ACTUATOR, ROTARY
30A8-690		VALVE
31008-1066		ROTOR,GENERATOR
31-032599-04	5985-01-154-9125	AMPLIFIER DETECTOR
31220-003		GENERATOR
31220-004	6115-00-678-6319	GENERATOR AC
31416000-1	6130-01-387-7271	POWER SUPPLY
318357-000	5998-01-236-3735	BACKPLANE ASSEMBLY
318427-001	5998-01-407-6121	CIRCUIT CARD ASSEMBLY



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
318476-901	5998-01-269-6978	VIDEO PROCESSOR NO. 1 CIRCUIT CARD ASSEMBLY
318557-000	5998-01-236-3735	BACKPLANE ASSEMBLY
32005-002	6680-00-585-1503	GENERATOR,TACHOMETER
32005-005	6680-00-585-1503	GENERATOR,TACHOMETER
32005-007	6680-00-585-1503	TACHOMETER GENERATOR
320362-3-1		VALVE , SOLENOIDE
32-054528-02	5865-01-165-9375	RF ASSEMBLY (A5)
32-054542-01	5865-01-059-4560	IF FILTER
32-054576-01	6130-01-059-1470	POWER SUPPLY
3213722-1-1		VALVE
3213722-1-1		VALVE, PRESSURE REGULATING
3213722-2-1	4810-01-004-5634	VALVE REGULATING
3213722-2-1	4810-01-004-5634	VALVE, PRESSURE REGULATING
3213722-3-1	4820-01-093-9141	BLEED VALVE ASSY
3213722-3-1	4820-01-093-9141	VALVE, PRESSURE REGULATING
3213722-4-1	VALVE,PRESS REG.	VALVE, PRESSURE REGULATING
3213722-5-1	4810-01-157-2583	VALVE REGULATING FLUID
3213722-5-1		VALVE, PRESSURE REGULATING
3213722-6-1		VALVE
3213722-6-1	4810-01-375-2478	VALVE, PRESSURE REGULATING
3213722-8-1	4810-01-561-7540	VALVE, PRESSURE REGULATING
321502-3-1		VALVE
321502-4-1	4810-00-796-1672	VALVE BUTERFLY
321502-4-1	4810-00-796-1672	VALVE,BUTTERFLY
32220-1	1680-01-387-6739	WINCH, AIRCRAFT
3252010-1101	6610-01-039-5020	ALTIMETER, ENCODING
325996-003	5998-01-459-5226	CIRCUIT CARD ASSEMBLY
3260011-0101	1660-01-005-6318	REG OXYG DILUTER
3290290-1-1	4810-01-482-4911	VALVE, BUTTERFLY
3290290-2-1		VALVE
3290290-2-3	4810-01-417-7022	VALVE, BUTTERFLY
3291272-2-1	4810-01-483-3116	VALVE, AUXILIARY VENT
3291272-2-2	4810-01-509-7171	VALVE, AUXILIARY VENT
3302196-13		MLG SHOCK STRUT ASSY
3302196-13		STRUT ASSEMBLY, MAIN LANDING GEAR SKI, LC-130H
3302196-15		CYLINDER
3302196-15		CYLINDER ASSEMBLY, MAIN LANDING GEAR SHOCK
3302196-17	1620-01-449-2064	PISTON
3302196-17	1620-01-449-2064	PISTON ASSEMBLY, MAIN LANDING GEAR SHOCK
3302196-19		MLG SHOCK STRUT ASSY
3302196-19	1620-01-438-6191	STRUT ASSEMBLY, MAIN LANDING GEAR SHOCK, LC-130H
3302196-21	1620-01-450-4647	CYLINDER
3302196-21	1620-01-450-4647	CYLINDER ASSEMBLY, MAIN LANDING GEAR SHOCK
330332-4	2915-00-706-2719	TD VALVE
330332-5	2915-01-318-8927	VALVE, TEMPERATURE D



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
330332-5	2915-01-318-8927	VALVE,TEMPERATURE DATUM
3303583-5	1620-00-572-2605	COLLAR, ACTUATOR ATT
3303589-1	1620-01-103-5244	CYLINDER
3303589-3		CYLINDER
3303589-5		CYLINDER
3303590-1	1620-00-574-3346	CYLINDER ASSEMBLY, NLG STRUT
3303590-11	1620-01-315-0424	CYLINDER ASSEMBLY
3303590-5	1620-00-574-3346	CYLINDER ASSEMBLY
3303590-7		CYLINDERASSEMBLY
3303590-9	1620-01-314-7772	CYLINDER ASSEMBLY
3303591-1	1620-00-085-2624	NLG STRUT ASSY
3303591-1	1620-00-085-2624	LANDING GEAR, NOSE
3303591-3	1620-00-505-1184	LANDING GEAR,RETRACTABLE (NLG STRUT ASSY)
3303591-5	1620-00-505-1184	LANDING GEAR, NOSE
3303591-7	1620-00-505-1184	LANDING GEAR, NOSE
3303595-1	1630-01-391-7191	NOSE LANDING GEAR
3303595-1	1630-01-391-7191	LANDING GEAR, NOSE
3303595-11	1620-01-440-6996	LANDING GEAR, NOSE
3303595-5		LANDING GEAR, NOSE
3303595-9	5365-01-437-7761	LANDING GEAR, NOSE
330625-101	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
330625-211	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
3308-950	6605-00-020-3886	SERVO MECHASISM
3314203-3	1620-01-045-8540	STRUT, NOSE LANDING GEAR
3314205-3		LANDING GEAR, NOSE
3314765-1	1600-01-057-2189	VALVE, PRESSURE REGULATING
3314765-15	1660-01-510-1166	VALVE, PRESSURE REGULATING
3316498-1		MLG SHOCK STRUT ASSY
3316498-17		PISTON ASSEMBLY, MAIN LANDING GEAR
3316498-3	1620-01-521-5645	CYLINDER AND PISTON
3316498-5		CYLINDER AND PISTON
3316498-7		MLG SHOCK STRUT ASSY
3316498-7	1620-00-896-1203	STRUT ASSEMBLY, MAIN LANDING GEAR SHOCK, C-130E, C
3316498-9		CYLINDER AND PISTON
3316500-1		LANDING GEAR, NOSE
3316500-11		LANDING GEAR, NOSE
3316500-13	1620-01-304-4562	RET LANDING GEAR
3316500-13	1620-01-304-4562	LANDING GEAR, NOSE
3316500-15		MLG SHOCK STRUT ASSY
3316500-15	1620-01-304-7618	STRUT ASSEMBLY, MAIN LANDING GEAR SKI, LC-130H
3316500-3		LANDING GEAR, NOSE
3318488-1	1660-01-130-4645	CONTROL BOX WINDSHIELD
332D-11A	6615-00-348-3874	VERTICAL REFERENCE
332D-6	6615-00-556-8024	VERTICAL GYRO
3343503-1	4820-01-447-3226	VALVE ASSEMBLY



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
3-34D15	6130-01-170-7850	MC-1, POWER SUPPLY
3360-2	4810-01-243-7901	ACTUATOR, FUEL SHUT-OFF
338329-26		LEADING EDGE, OUTER
339814-601		ELEV CTL BOOSTER MECH ASY
339814-604		ELEV CTL BOOSTER MECH ASY
340070-1		CYLINDER
3400770-1		CYLINDER
3400770-3		CYLINDER
3400770-5		CYLINDER
3400770-7	1620-00-410-0874	NLG CYLINDER
3400770-7		CYLINDER ASSEMBLY, DRAG STRUT
3400770-9		CYLINDER
3401835-3		PARTS KIT PROPELLER
3402292-1	6110-01-109-5100	PANEL CONTROL
3403172-1	4920-01-236-7670	TEST SET, INDICATOR
3408-12	4810-00-566-7114	VALVE, RAMP CONTROL
340877-601		PISTONASSEMBLY
340877-603		PISTONASSEMBLY
3408-8	1650-00-807-0869	VALVE, RAMP CONTROL
34102C1C4-1C1	6620-00-959-6614	INDICATOR, TACHOMETER
34102-C1C-4-1C1	6620-00-959-6614	INDICATOR, TACHOMETER
341260-1		CYLINDER, MAIN LANDING GEAR SHOCK STRUT
341417-3		MANIFOLD ELEVATOR
343D902G01		INDICATOR HEIGHT
34538-2		ACTUATOR
34538-4	1680-00-845-0699	ACTUATOR SPOILER DOOR
34538-4	1680-00-845-0699	ACTUATOR, PARATROOP, SPOILER DOOR
345726-7		NLG DRAG BRACE ASSY
345726-8		NLG DRAG BRACE ASSY
345A-7	6615-00-134-5980	RATE OF TURN SENSOR
345A-7A	6615-00-134-5980	RATE OF TURN SENSOR
345C-2A	6615-01-043-2763	ACCELERATION SENSOR
3501-01A	6220-01-446-3883	EMERGENCY EXIT LIGHT
3505228-1-1	2995-00-337-5145	STARTER,ENGINE,AIR TURBINE
3505230-1		STARTER
3505230-1-1	2995-00-337-5116	STARTER ENGINE
35-055	4810-00-528-3666	VALVE, SOLENOID
3505672-1	2995-01-227-6650	STARTER
3505672-1-1		STARTER
3505674-1	2995-01-227-6649	STARTER
3505674-1-1		STARTER
3505786-1	2995-01-493-4166	STARTER,ENGINE,AIR TURBINE
3505786-1-1		STARTER
351484-3	1650-00-652-5021	HYDRAULIC BOOSTER
351484-600	1650-00-652-5021	HYDRAULIC BOOSTER



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
351485-3		AILERON BOOSTER ASSEMBLY
351485-3		BOOSTER, AILERON
351485-4		AILERON BOOSTER QUAD ASSY
351486-9		BOOSTER
35160-0124	6610-01-346-2795	INDICATOR, RATE OF CLIMB
352-1	7025-01-211-6011	PRINTER AUTOMATIC
352773-5		RESERVOIR
352773-6		RESERVOIR
352863-9		SCOOP ASSEMBLY ENGINE
352866-13	4820-01-395-5254	VALVE
352866-3	4820-01-395-5254	VALVE
353D226G01	5840-01-066-9001	INTERFERENCE BLANKER SET
353D582G01	5985-01-027-0225	COUPLER ROTARY RADIO
354148-3		AILERON BOOSTER ASSY
354148-3		BOOSTER, AILERON
354148-4		AILERON BOOSTER QUAD ASSY
354148-600		AILERON BOOSTER ASSEMBLY
354148-600	1650-00-600-0487	BOOSTER, AILERON
354153-1		RUDDER CTL BOOSTER ASSY
354153-601		RUDDER CTL BOOSTER ASSY
354731-1		FAN
355390-2	1560-00-576-3920	GEARBOX
355390-3	1560-00-576-3920	GEARBOX
355390-501	1560-00-576-3920	GEARBOX
355400-1		PISTON ASSEMBLY
355883-3		FRAME
35-589	4810-00-870-8922	VALVE
3567609-3703	6685-01-146-8649	AUTOSYN PRESSURE TRANSMITTER
356883-1		EXHAUST
3571281-8102	6620-01-159-4330	TACHOMTER
357370-600		CYLINDERASSEMBLY
357370-601		CYLINDER
357370-603	1620-00-410-0870	CYLINDERASSEMBLY
357370-605		CYLINDER
358800-1		UPLOCK ASSY
358800-5		UPLOCK ASSY
358800-7		UPLOCK ASSY
358800-9		UPLOCK ASSY
359614-1		PISTONASSEMBLY
359614-3	6680-00-966-0157	PISTONASSEMBLY
359900-27		CONTROL COLUMN
360-058-001	6680-01-099-0790	TOTALIZER, FUEL QUANTITY
3603100-1		FUEL CONTROL
3603100-1-1	2910-01-013-2741	FUEL CONTROL
360414-1L	1560-00-613-6501	DOOR ACCESS AIRCRAFT



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
3604174-1	5930-01-019-5594	SWITCH SLIDE
3604174-1-1	5930-01-019-5594	SWITCH SLIDE
3605812-12		APU STARTER
3605812-14		APU STARTER
3605812-17		APU STARTER
3605812-18		APU STARTER
3605812-18-1		APU STARTER
360614-1	1560-00-624-9338	DOOR,AIRCRAFT
3609150-3-1		FUEL CONTROL UNIT
3609150-8	2910-01-329-3239	FUEL CONTROL
36104-1H8A1	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
36104-1L11A2	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
36105-1N1C1	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
3614657-0102	5841-01-314-9993	MODE SELECTOR
362511-1		OIL TANK ASSY
362511-95	1560-00-886-9037	Tank Oil
363001-1		DOOR PASSENGER AIRCRAFT
363498-1	1650-00-652-9673	ELEVATOR HYD BOOSTER
363576-11		UPLOCK ASSY
363576-12		UPLOCK ASSY
363576-13		UPLOCK ASSY
363576-14		UPLOCK ASSY
363576-15		UPLOCK ASSY
363576-17		UPLOCK ASSY
363576-2		UPLOCK ASSY
363576-5		UPLOCK ASSY
363576-6		UPLOCK ASSY
363576-7		UPLOCK ASSY
363576-9		UPLOCK
363579-1		STRUTASSEMBLY,SHOCK
363579-3		STRUTASSEMBLY,SHOCK
363579-5		STRUTASSEMBLY,SHOCK
363579-7		STRUTASSEMBLY,SHOCK
363590-1		STRUT ASSY NLG
363590-1		STRUTASSEMBLY,NOSELANDINGGEAR
363590-3		STRUT ASSY NLG
363590-5		STRUT ASSY NLG
363590-5		STRUTASSEMBLY,NOSELANDINGGEAR
363590-7		STRUT ASSY NLG
363590-7	1620-00-784-5563	STRUTASSEMBLY,NOSELANDINGGEAR
364697-1		RUDDER CTL BOOSTER ASSY
364D540G01		FREQUENCY MULTIPLIER
365D019G01	5840-01-158-0146	PULSE FREQUENCY MODULE
36726-1		MOTOR
36745-1		DIRECT CURRENT MOTOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
368067-7		LANDING GEAR, NOSE
36A225543G01	6115-00-412-0340	STATOR,GENERATOR
36A84		STARTER
36E165-2C		AIR STARTER
36E165-2QC	2995-01-329-6341	STARTER,ENGINE,AIR TURBINE
36E79-10QA	2995-01-604-7728	STARTER
36E79-12QA	2995-01-124-1891	STARTER
36E79-12QB	2995-01-604-7727	STARTER
36E79-18QA		STARTER
36E79-18QB	2995-01-452-1844	STARTER
36E80-10QA		STARTER
36E80-12QA		STARTER
36E80-12QB	2995-01-164-9483	STARTER
36E80-8QA		STARTER
36E84-10QF		STARTER,AIR TURBINE
36E84-16QA		STARTER
36E84-16QB	2995-00-574-3573	STARTER
36E84-16QC	2995-01-050-2462	STARTER
36E84-18		STARTER
36E84-18B		STARTER,AIR TURBINE
36E84-18C		STARTER ASSY
36E84-18F	2995-01-060-4443	STARTER, AIR TURBINE
36E84-18QA		STARTER
36E84-18QC	2995-01-060-4443	STARTER, ENGINE, AIR TUR
36E84-18QD	2995-01-130-9394	STARTER ENGINE AIR TURBINE
36E84-18QF	2995-01-194-8153	STARTER,ENGINE,AIR TURBINE
370012-1		LEADING EDGE, VERTICAL
370018-5	1560-00-928-3106	ELEVATOR AIRCRAFT
370018-6	1560-00-928-3105	ELEVATOR AIRCRAFT
370019-602	1560-00-659-0362	VALVE
370438-1		MLG SHOCK STRUT ASSY
370438-13	1620-00-784-5509	STRUT
370438-2		PISTON ASSEMBLY, MAIN LANDING GEAR SHOCK
370438-21	1620-00-109-7340	LANDING GEAR, MAIN
370438-3		CYLINDER ASSEMBLY, MAIN LANDING GEAR SHOCK
370438-7	1620-00-784-5507	STRUT
370439-3		CYLINDER, MAIN LANDING GEAR SHOCK STRUT
370440-1	1620-00-652-3891	PISTON ASSEMBLY
370442-1		MLG TORQUE STRUT ASSY
370510-29	1560-00-716-2869	LEADING EDGE AIRCRAFT
370639-3L		DRIVE
370639-3R		DRIVE
370749-1	1650-00-620-7514	CYLINDER ASSEMBLY
370750-1	1650-00-788-8799	CYL ASS RAMP
370768-1		RESERVOIR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
370772-1		RESERVOIR ASSY
370772-3		RESERVOIR ASSY
370772-5		RESERVOIR ASSY
370772-5	1650-00-675-2635	RESERVOIR ASSEMBLY
370888-1		RESERVOIR ASSY
370888-3		RESERVOIR ASSY
370888-7		RESERVOIR ASSY
371640-1		STRUT ASSEMBLY,SHOCK
371671-1		STRUT ASSY NLG
371675-1	1620-00-613-3512	CYLINDER ASSEMBLY
371675-2		CYLINDER ASSEMBLYOF
371677-1	1620-00-613-3515	PISTON ASSEMBLY
371688-101	2910-00-907-7481	FUEL PUMP & CONTROL ASSY
371688-39	2915-01-171-3486	PUMP & CONTROL UNIT FUEL
371689-11		NLG DRAG BRACE ASSY
371689-12		NLG DRAG BRACE ASSY
371689-7		NLG DRAG BRACE ASSY
371689-8		NLG DRAG BRACE ASSY
372021-1		BOOSTER, RUDDER
372021-11	1650-01-132-3641	SERVO MECHANISM, HYDRAULIC/PNEUMATIC, AIRCR
372021-11X119	1650-01-132-3641	BOOSTER ASSY RUDDER
372021-3		RUDDER CTL BOOSTER ASSY
372021-5	1650-00-651-4180	RUDDER CONTROL BOOSTER
372021-7		SERVOMECHANISM,HYDRAULIC/PNEUMAT
372522-80	1560-00-084-3747	DOOR LANDING GEAR
372682-1		CYLINDER ASSY
372697-18	2920-01-013-9867	STARTER,ENGINE,ELECTRICAL
372697-18-1	2920-01-359-9819	STARTER
372697-21-1		APU STARTER
372697-24-1	2925-01-217-5889	STARTER, ENGINE, ELECTRICAL
373531-1		VALVE
373531-3		VALVE
373531-5	1620-00-953-5572	NLG STEERING VALVE
373531-5A		VALVE
373531-7	1620-00-953-5572	VALVE, STEERING
373587-1		PISTON ASSEMBLY, MAIN LANDING GEAR STRUT
374453-3		HYDRAULIC ASSY
374454-1		HYDRAULIC ASSY
374455-1		AILERON BOOSTER QUAD ASSY
374455-2	1650-00-784-9692	AILERON BOOSTER ASSY
374455-3	1650-00-784-9692	SERVOMECHANISM HYDRAULIC
374455-5		AILERON BOOSTER QUAD ASSY
374455-7	1650-01-134-4415	SERVOMECHANISM HYDRAULIC
374461-11	1650-01-472-5564	BOOSTER, ELEVATOR
374461-5	1650-00-784-9693	ELEVATOR CONTROL BOOSTER ASSY



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
374461-601		ELEV CTL BOOSTER MECH ASSY
374461-605		ELEV CTL BOOSTER MECH ASSY
374461-7		BOOSTER
374461-7		BOOSTER, ELEVATOR
374461-9		BOOSTER, ELEVATOR
374761-1		RESERVOIR ASSY
374761-17		RESERVOIR
375322-10		STARTER, ENGINE, ELE
375322-7	2920-00-573-0329	STARTER
375322-8	2990-00-483-1432	STARTER
375322-9	2920-00-060-0057	STARTER ASSY
375456-7	1560-00-912-1806	FLAP INBOARD LH
37604-1E5A1	5826-00-882-1203	INDICATOR, BEARING DISTANCE
376269-1		VALVE
376269-7		VALVE
376730-0-024	2835-00-007-7955	GTC
376730-0-24	2835-00-007-7955	GAS TURBINE COMPRESSOR
37D401750P104		SPRAYBAR ASSY, MAIN
380204-5	1620-01-091-4761	STRUT, NOSE LANDING GEAR
380205-17	1620-01-308-7603	PISTON ASSEMBLY, NOSE LANDING GEAR
380205-21	1620-01-308-7603	PISTON ASSEMBLY, NOSE LANDING GEAR
380409-15		RESERVOIR ASSY
380410-13		RESERVOIR ASSY
380410-29		RESERVOIR ASSY
380606-1		RESERVOIR ASSY
38106-001	6130-01-217-5880	POWER SUPPLY, REMOTE
381116-1	2835-01-056-6467	AUXILIARY TURBINE (APU)
381116-1-7		APU
381116-1-7		ENGINE,AUXILIARY POWER UNIT
381116-1-8	2835-01-437-1578	ENGINE,GAS TURBINE,NONAIRCRAFT
381116-1-8	2835-01-437-1578	ENGINE,AUXILIARY POWER UNIT
381116-1-9	2835-01-566-2836	ENGINE,AUXILIARY POWER UNIT
381252-1-1	2835P381252-1-1	APU ASSY GTC P85-185L
38140-7	1680-00-677-6238	ROTARY ACTUATOR
38140-9-1		ROTARY ACTUATOR
381410-19		RESERVOIR ASSY
382052-1	1560-00-716-2869	LEADING EDGE ASSY
383056-1		STARTER
383056-1-3		STARTER
383056-1-4		STARTER
383074-1-1		STARTER
383074-1-2		STARTER
383074-1-5		STARTER
383076-1-1		STARTER
383076-1-2		STARTER



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
383076-1-5		STARTER
383198-1-1	2995-00-985-1355	STARTER ENGINE AIR TURBINE
383198-1-2		STARTER
383198-1-3		STARTER
383198-1-4		STARTER
383198-1-4-1		STARTER
383298-1-4		STARTER
383350-11-1		STARTER
383350-12-1		STARTER
383350-13-1		STARTER
383350-14-1		STARTER
383350-2-1		STARTER
383350-3-1		STARTER
383350-4-1		STARTER
383350-5-1		STARTER
383350-6		STARTER
383350-6-1		STARTER
383350-7		STARTER
383350-7-1		STARTER
383350-8-1		STARTER
383350-9-1		STARTER
383534-1-2		STARTER
383534-2-1	2995-00-007-7957	STARTER ASSY
383534-2-2		STARTER
383534-7-1		STARTER
383650-1-1		STARTER
383650-1-2		STARTER
383652-1-1		STARTER
383968-1-1		STARTER
383968-1-2		STARTER
388028-1		PISTON ASSEMBLY
388028-13	1620-01-564-8051	PISTON ASSEMBLY
388028-17	1620-01-109-0140	PISTON ASSEMBLY, NOSE LANDING GEAR
388028-19	1620-01-423-3708	PISTON, LANDING GEAR
388028-19	1620-01-423-3708	PISTON ASSEMBLY
388028-7		PISTON ASSEMBLY
388028-9	1680-00-589-2077	PISTON ASSEMBLY
388046-1	1620-00-862-8285	CYLINDER ASSEMBLY, MLG STRUT
388046-3	1620-00-862-8285	CYLINDER & PISTON
388046-9	1620-01-270-3196	CYLINDER & PISTON
388058-1		MLG SHOCK STRUT ASSY
388058-11		CYLINDER ASSEMBLY, MAIN LANDING GEAR
388058-13		PISTON ASSEMBLY, MAIN LANDING GEAR
388058-15		CYLINDER ASSEMBLY, MAIN LANDING GEAR
388058-17		CYLINDER ASSEMBLY, MAIN LANDING GEAR SHOCK



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
388058-19		MLG SHOCK STRUT ASSY
388058-3		PISTON ASSY
388058-5		CYLINDER ASSY
388058-7	1620-00-784-5504	LANDING GEAR, MAIN
388058-9		MLG SHOCK STRUT ASSY
388059-1	1620-00-862-4057	PISTON ASSEMBLY, MAIN LANDING GEAR STRUT
388059-11	1620-00-862-4057	PISTON AY SHOCK STRUT
388059-13	1620-01-449-1551	PISTON ASSEMBLY, MAIN LANDING GEAR SHOCK
388059-9		PISTON ASSEMBLY, MLG STRUT
388064-1		MLG TORQUE STRUT ASSY
388064-3	1620-00-805-8495	DRAG BRACE, LANDING GEAR, MLG
388064-3	1620-00-805-8495	STRUT, TORQUE
388067-11		LANDING GEAR, NOSE
388067-3		LANDING GEAR, NOSE
388067-7		LANDING GEAR, NOSE
388067-9		LANDING GEAR, NOSE
388071-1	1620-00-896-1209	STRUT, NOSE LANDING GEAR
388071-3	1620-00-085-2624	LANDING GEAR, RETRAC
388071-5	1620-00-784-5556	STRUT, NOSE LANDING GEAR
388071-9	1620-00-784-5553	STRUT, NOSE LANDING GEAR
388074-1	1620-00-862-4061	STRUT ASSEMBLY, SHOCK
388074-11	1620-00-954-8000	PISTON ASSEMBLY
388074-3	1620-00-862-4062	PISTON ASSEMBLY
388074-5	1620-00-954-8000	PISTON ASSEMBLY
388074-7		STRUT, NOSE LANDING GEAR
388074-9		PISTON ASSEMBLY, NOSE LANDING GEAR
389154-1	1560-00-888-2231	RADOME ASSY
38E73-4A	2925-01-038-5770	VALVE CONTROL
38E73-4A	2925-01-038-5770	AIR CONTROL VALVE
38E73-5A		VALVE
38E73-6A		VALVE
38E73-7A	4810-01-060-5087	VALVE ASSY, STARTER CONTR
39-075	1630-00-908-9999	VALVE, DUAL CONTROL
39-075A	1630-00-998-7896	VALVE, SKID CONTROL
392122-1		VALVE
392122-1-1	4810-00-897-7308	VALVE, STARTER CONTROL
393004-23681	6680-00-618-5806	INDICATOR, LIQUID QTY
393004-34750	6680-00-809-4354	INDICATOR, LIQUID QTY
393004-65333	6685-00-872-3976	INDICATOR, LIQUID QTY
393084-11358	6680-00-981-7828	INDICATOR, LIQUID QTY
393084-11881	6680-00-877-7009	INDICATOR, LIQUID QTY
396175-11	1560-01-007-1640	LANDING GEAR, NOSE
396175-17	1560-01-007-1640	LANDING GEAR, NOSE
396308-1-1	4810-01-040-2372	VALVE CONTROL FLOW
396308-1-1	4810-01-040-2372	VALVE, FLOW CONTROL



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
396308-1-2		VALVE, FLOW CONTROL
396308-2-1	4810-01-040-2372	VALVE CONTROL FLOW
396308-2-1	4810-01-040-2372	VALVE, FLOW CONTROL
396308-2-2	4810-01-040-2372	VALVE CONTROL FLOW
396308-2-2	4810-01-040-2372	VALVE, FLOW CONTROL
396308-3-1		VALVE
396308-3-1	4810-01-380-0393	VALVE, FLOW CONTROL
396308-4-1	4810-01-470-7884	VALVE, FLOW CONTROL
398648-1-1		VALVE, BUTTERFLY
398648-1-1	4810-00-575-7781	VALVE, TEMPERATURE CONTROL
398648-1-2	4810-00-575-7781	VALVE BUTTERFLY
398648-1-2	4810-00-575-7781	VALVE, TEMPERATURE CONTROL
398648-1-4		VALVE
398648-2-1	4810-01-523-0579	VALVE, TEMPERATURE CONTROL
398650-1-1	4810-00-575-7789	VALVE,BUTTERFLY
398650-1-1	4810-00-575-7789	VALVE, AUXILIARY VENT
398652-1-1	4810-00-612-9419	VALVE
398654-1-1	4810-00-601-3194	TEMP CONTROL VALVE
398654-1-1	4810-00-601-3194	VALVE, TEMPERATURE CONTROL
398654-1-2	4810-01-039-0459	SHUTOFF VALVE
398654-1-2	4810-01-039-0459	VALVE, TEMPERATURE CONTROL
398654-1-3		AIR VALVE
398654-1-3	4810-01-039-0459	VALVE, TEMPERATURE CONTROL
398654-1-4		AIR VALVE
398654-1-4	4810-01-039-0459	VALVE, TEMPERATURE CONTROL
398854-1		MOTOR VALVE
3A004	4820-00-991-0785	VALVE, PRESSURE REDUCER
3A016	4820-00-983-3598	VALVE, PRESSURE REDUCER
3A95550-107	4810-00-796-1672	VALVE
3A95550-107	4810-00-796-1672	VALVE,BUTTERFLY
3D58770G01	5985-01-387-4414	COUPLER ROTARY RADIO
3S2060DC102D1	6110-00-944-3046	CONTROL GENERATOR
3S2060DR113C2	6110-01-206-9877	REGULATOR VOLTAGE
4000504-0301		Antenna, Radar
4000504-0303		RADAR ANT
4000831-0105		RADAR RT
4001670-2511		INDICATOR RADAR TARGET
4005A	6610-00-557-3030	INDICATOR, ATTITUDE
4020936-903	6615-01-280-4702	SYNCHRONIZER, ELECTR
402306-3		NLG STEERING CYLINDER
402306-5		NLG STEERING CYLINDER
402306-7		NLG STEERING CYLINDER
4024400-7		FLIGHT RECORDER
403-6BX		RELAY VOLTAGE AC
40-621	6695-00-719-7103	TRANSDUCER



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
40-621-1	6695-00-055-6481	TRANSDUCER, MOTIONAL
4078952-39		TUBE ASSY
4079653-1	5930-01-481-3559	SWITCH ASSEMBLY
4088T42P01	6620-01-328-6973	INDICATOR ELEC TACH
41 10004		SUCTION PUMP
411000-1	4320-00-653-5494	PUMP
411000-2	4320-00-050-8205	PUMP HYDRAULIC
411000-4	4320-00-152-1488	Pump, Suction Boost Hydraulic
41-2036-002		VALVE
41-2036-004		VALVE, SOLENOID
41-2036-005		VALVE
41750-3	1680-00-516-8402	WINCH, CARGO
41750-3-41BG		CARGO WINCH
41910A1-22	6220-00-453-6968	LIGHT, NAVIGATIONAL
41C220-53	1660-00-822-3344	VALVE AIR
42066-2	5930-01-502-4004	SWITCH, PRESSURE
42-109	1630-00-085-2625	BOX CONTROL ANT-SKI
42-109-1A	1630-00-133-8183	CONTROL UNIT ANTISKID
42-109A	1630-01-104-1015	ANTI-SKID BOX
42G52	5930-00-557-1811	SWITCH,OIL PRESSURE
42G68	5930-00-732-2509	SWITCH,OIL PRESSURE
42G68-2	5930-01-502-4004	SWITCH, PRESSURE
430391A		REGULATOR,VOLTAGE
4344D1-1		BALLSCREW
4344D1-2		BALL SCREW
4344D1-3	1680-01-181-9873	ACTUATOR INBOARD WING FLAP JACKSCREW
4344D1-4	1680-01-181-9874	ACTUATOR INBOARD WING FLAP JACKSCREW
4344D2-1		SCREW AND YOKE, OUTBOARD
4344D2-2	1680-00-006-3144	SCREW AND YOKE ASSY
4344D2-3		SCREW AND YOKE, OUTBOARD
4344D2-4	1680-00-006-3144	SCREW AND YOKE ASSY
4344EA03	1680-00-615-1335	ACTUATOR, OUTBOARD WING FLAP
4344EA1	1680-00-615-1335	ACTUATOR, OUTBOARD WING FLAP
4344EA-1		ACTUATOR
4344EA2		ACTUATOR
4344EA-2	1680-01-004-2086	SCREW ASSEMBLY INBOARD
4344EA3	3040-01-414-2019	ACTUATOR,MECHANICAL,LINEAR
4344EA-3	3040-01-414-2019	ACTUATOR JACK SCREW
4344EA4		ACTUATOR
4344EA-4		SCREW ASSEMBLY, INBOARD
435193-1	2915-00-912-0840	AMPLIFIER, TEMPERATURE DATUM
43932-052	6610-01-074-2819	ALTIMETER
440970-1		FUEL CONTROL UNIT
440970-2	2915-01-113-8557	CONTROL, MAIN
440978-1	2915-01-008-7398	FUEL CONTROL UNIT



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
44302-10		WINCH, CARGO
443147-2	6620-00-856-8263	INDICATOR, TORQUEMETER
44344EA-4		ACTUATOR ASSY
44910-5	6220-00-370-5447	EMERGENCY EXIT LIGHT
45-0024-1	6220-00-051-3811	LIGHT LANDING
45-0292-1	6220-01-340-4711	LIGHT, LANDING, AIRCRAFT
45-0325-1	6220-01-437-7640	LIGHT, LANDING
45-0325-3	6220-01-437-7640	LIGHT, LANDING
451200-02-03		MODE SELECTOR UNIT LTN-92
452080-05-04	6605-01-107-5585	INERTIAL NAV UNIT LTN-72
452080-05-85-15		INU/GPS
452090-02	6605-01-053-5554	CONTROL DISPLAY UNIT
452100-02		LTN-72 MODE SELECTOR
452100-02-03	6605-01-290-5720	MODE SELECT UNIT LTN-51
452574-01	6605-01-048-2000	COMPUTER NAVIGATION LTN-51
454620-01-28-04		INERTIAL NAV UNIT LTN-72
457EA0		ACTUATOR
457EA-0		ACTUATOR
457EA1		ACTUATOR MECHANICAL
457EA-1		ACTUATOR
457EA2	1680-00-777-0135	ACTUATOR O/B FLAP JAKSSC
457EA-2		ACTUATOR
457EA3		BALLSCREW ASSEMBLY
457EA-3	1680-00-777-0136	ACTUATOR
457EA4	1680-00-773-2904	GEARBOX WING FLAP
457EA-4		GEAR BOX
457EA5	1680-01-163-4291	ACTUATOR, OUTBOARD WING FLAP
457EA-5		ACTUATING ASSY
457EA6	1680-00-006-3143	ACTUATOR, INBOARD WING FLAP
457EA-6		ACTUATING ASSY
457EA-7		SCREW JACK
458900-06-01	7025-01-290-5721	CONTROL DISPLAY UNIT
458900-08-01		CONTROL CDU UNIT LTN-92
463001-04-05	6605-01-294-6975	INERTIAL NAV UNIT LTN-92
463001-6000-0413		INERTIAL NAVIGATION UNIT
463001-7000-0506	6605-01-425-2022	CONTROL UNIT, NAVIGATION SET (LTN-92)
468100-0-1		RELAY DE-ICING TIMER
469100-0-1	4320-00-289-6142	PUMP, HAND
482-0061-030	6655-01-283-0303	RADIO MAGNETIC INDICATOR
48285-3-1		MOTOR
48285-3-2		MOTOR
48285-4-1		MOTOR
48285-7-1		MOTOR
48285-7-2		MOTOR
48285-8-1		MOTOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
48285-8-2		MOTOR
4954A		VALVE
4A037-1	4810-00-908-2931	VALVE LINEAR
4K90075-103A	6605-01-078-1701	COUPLER, HEADING
4U4059		AFT CARGO DOORLOCK CYL
4-U-4059		AFT CARGO DOORLOCK CYL
500012-01	6130-01-412-3096	INS (BATTERY)
500702-3021	4140-00-051-2620	FAN, VANEAXIAL
5008-3001		SERVO TEMP INDICATOR TOT
501-1533-51	6610-01-309-1413	INDICATOR, ATTITUDE
50150-20	4810-00-728-3396	VALVE, LINEAR, DIRECTIONAL CONTROL
5021-3001		TURBINE OUTLET TEMPERATURE INDICATOR
50260-1		VALVE
502BL10	6685-00-061-6255	INDICATOR TEMP
502BL10A	6685-00-937-4039	INDICATOR TEMPERATURE
5050051-9	6615-01-397-7980	CONTROLLER, FLIGHT, AUTOPILOT
50680-1	1650-01-087-0956	VALVE
5-09010-8	5930-00-658-6512	SWITCH, THERMOSTATIC
510414-3-2	6610-00-759-7170	COMPUTER, TRUE AIR
51107-003	6110-00-649-8835	REGULATOR VOLTAGE
51509-002R	6110-00-165-3755	VOLT REG & PROT PANEL
51509-009D		GENERATOR CONTROL UNIT
517626-1-1	6105-00-490-4835	MOTOR, DIRECT CURRENT
518-28007-204	6610-01-259-0251	ALTIMETER, ENCODING
518-28007-208	6630-01-071-1654	ENCODING ALT
52.0261.650.00	5865-01-059-4560	IF FILTER
522-0578-005	6610-00-557-0867	INDICATOR, COURSE
522-0579-005	6610-00-557-0868	APPROACH HORIZON INDICATOR
522-1230-00		RECEIVER TRANSMITTER
522-1501-00		HF TRANSCEIVER
522-1658-000		MOUNTING BASE ELECTRIC
522-1747-00	6610-00-830-5832	INDICATOR, HORIZONTAL SITUATION
522-2213-000	5821-00-838-7051	Control Radio Set
522-2412-00	6610-00-830-5832	INDICATOR, HORIZONTAL SITUATION
522-2412-000	6610-00-830-5832	INDICATOR, HORIZONTAL SITUATION
522-2424-004	5821-00-846-6037	OSCILATOR RADIO FR
522-2447-252		CONTROL NAVIGATION
522-2447-556		CONTROL RADIO SET
522-2494-100	5826-00-346-7298	INSTRUMENTATION
522-2702-014		D.M.E.
522-2702-061		D.M.E.
522-2900-057	6615-01-038-7294	CONTROL, SERVO, AUTOMATIC PILOT
522-2996-011	5826-00-114-4063	RECEIVER RADIO NAVIG
522-3195-00	5895-01-106-3765	RECEIVER RADIO
522-3197-00	5826-00-141-3785	INSTRUMENTATION



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
522-3552-005	5955-00-768-7694	OSCILLATOR
522-3698-003	5826-00-758-4546	ALTIMETER RADIO SET
522-3985-001		VERTICAL GYRO
522-4114-003	5841-00-758-4547	INDICATOR RADIO ALTIM'TR
522-4114-010	5841-00-134-5975	INDICATOR RADIO ALTIMETER
5232105N		FUEL NOZZLE
523EA		GEAR BOX, FLAP DRIVE
523EA-1		GEAR BOX, FLAP DRIVE
523EA-2		GEAR BOX, FLAP DRIVE
523EA-5		GEAR BOX, FLAP DRIVE
523EA6		GEAR BOX
523EA-6		GEAR BOX, FLAP DRIVE
523EA-7		GEAR BOX, FLAP DRIVE
523EA-8		FLAP DRIVING MOTOR
523EA-9		GEAR BOX, FLAP DRIVE
528-0113-005	5821-00-868-7528	TRANSLATOR, SIGNAL DATA
528-0598-004		POWER SUPPLY
52C22	4810-00-672-1085	VALVE,BUTTERFLY
53150-1	4810-01-066-0321	VALVE LINEAR DIRECTION CONTROL
53150-2		VALVE
53230-1	2995-01-228-8008	VALVE
532-38105-202	6610-01-263-1400	INDICATOR AIRSPEED & DIRECT
532-38105-304		INDICATOR AIRSPEED
53C3794	1660-00-787-3961	PORTABLE OXYGEN BOTTLE
540200-1		ACTUATOR,ELECTRO-MECHANICAL,LINEAR
540200-2	1680-00-080-2959	ACTUATOR ELECTRO-MECHAN
540200-3	1680-00-060-2959	ACTUATOR
540538-1		ACTUATOR, PARATROOP, SPOILER DOOR
540538-2-1		ACTUATOR
540906-2-2	1660-00-999-5275	ACTUATOR, ELECTRO-MECHANICAL
540906-2-4		ACTUATOR, ELECTRO-MECHANICAL
540906-2-5		ACTUATOR, ELECTRO-MECHANICAL
540906-2-6	4810-00-999-5275	ACTUATOR ELECTRO MECH
540906-3-1	1660-01-083-3603	ACTUATOR, ELECTRO-MECHANICAL
540906-3-3		ACTUATOR, ELECTRO-MECHANICAL
540906-3-4	4810-01-506-4286	ACTUATOR, ELECTRO-MECHANICAL
540906-3-5	4810-01-083-3603	ACTUATOR ELECTRO MECHANICAL
540907-16		ACTUATOR, ELECTRO-MECHANICAL
540907-17		ACTUATOR, ELECTRO-MECHANICAL
540907-18		ACTUATOR, ELECTRO-MECHANICAL
540907-19		ACTUATOR, ELECTRO-MECHANICAL
540907-20		ACTUATOR, ELECTRO-MECHANICAL
540907-6		ACTUATOR, ELECTRO-MECHANICAL
541044-1-2	1680-00-070-9980	WINCH, PARATROOP RETRIEVAL
541214-1-2	1660-00-777-0154	ACTUATOR ELECTRO-MECHAN



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
543681-1	5996-00-458-2767	AMPLIFIER, TEMPERATURE DATUM
544388-6-1		ACTUATOR
544-9291-00	6130-00-019-8398	Power Supply
544-9293-00	5896-00-845-8367	RECEIVER TRANSMITTER SUBASSY
546-7273-004	5821-00-818-3738	AMPLIFIER SUBASSEMBLY
548025-5		ACCUMULATOR
549-1680-004	5821-00-019-6291	BOARD ASSY
549460-1		ACCUMULATOR
549460-2		ACCUMULATOR
549460-3		ACCUMULATOR
549460-4		ACCUMULATOR
549460-5		ACCUMULATOR
549460-6		ACCUMULATOR
549460-7		ACCUMULATOR
549460-8		ACCUMULATOR
54C82-1	4810-00-670-1111	VALVE,BUTTERFLY
54H60-117	1610-01-096-7677	Hub & Blade
54H60-91	1610-00-846-8332	PROPELLER,AIRCRAFT
54H60-91/-117		PROPELLERS
5502636-1	2915-00-458-2768	AMPLIFIER, TEMPERATURE DATUM
5502636-2	5996-01-096-4648	AMPLIFIER,ELECTRONIC CONTROL
5502636-4	2915-01-221-6837	AMPLIFIER,TEMPERATU
5505088-1	2915-00-225-2418	AMPLIFIER, TEMPERATURE DATUM
5505088-2		AMPLIFIER, TEMPERATURE DATUM
551025-1		ACCUMULATOR
551050-1		ACCUMULATOR
551050-10		ACCUMULATOR
551050-12		ACCUMULATOR
551050-3		ACCUMULATOR
551200-1		ACCUMULATOR
551200-10		ACCUMULATOR
551200-11		ACCUMULATOR
551200-13		ACCUMULATOR
551200-17		ACCUMULATOR
551200-18		ACCUMULATOR
551200-22		ACCUMULATOR
551200-25		ACCUMULATOR
551200-26		ACCUMULATOR
551200-28		ACCUMULATOR
551200-3		ACCUMULATOR
551200-5		ACCUMULATOR
551R291G01	6130-01-310-4939	POWER SUPPLY
551R291G02	6130-01-310-4939	POWER SUPPLY
55204-8		VALVE
55204-81		VALVE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
552430-1		ACCUMULATOR
552430-3		ACCUMULATOR
560-005	6625-00-235-4782	VOLTMETER
560-707	6625-00-235-4782	VOLTMETER
562A5M5	6615-01-040-0126	COMPUTER,FLIGHT CONTROL
562C-8A	6625-01-038-7297	YAW COMPUTER
56B17A	6685-01-534-1475	SENSOR, AMBIENT TEMPERATURE
56B3A	6685-00-373-9004	TRANSMITTER, TEMPERATURE
57023932-012		ALTIMETER
570-23932-012	6610-01-074-2819	ALTIMETER BAROMETRIC
571925-1-1		COOLING TURBINE
571925-2-1		COOLING TURBINE
571925-3-1	1660-01-036-5903	TURBINE ACFT COOLING
57-761-04	4820-00-876-9872	VALVE,REGULATING,FLUID PRESSURE
581R481H01	5996-01-036-5639	SOLID STATE AMPLIFIER
581R481H04	5996-01-224-7914	AMPLIFIER ASSEMBLY
583R181H03	5865-01-082-0338	SIGNAL PROCESSOR
583R181H08	5865-01-224-2714	PROCESSOR, COUNTERMEASURES SIGNAL
585R195H03	5996-01-224-8905	RADIO FREQUENCY AMPLIFIER
585R944H01	6130-01-192-6999	POWER SUPPLY
585R944H02	6130-01-361-0655	POWER SUPPLY
590A3J	6615-01-038-7296	CONTROL, AIR DATA
590A3J1	6615-01-477-9209	CONTROL AIR DATA
590A-3J1	6615-01-091-0363	AIR DATA CONTROL
590A-3KI	6615-01-188-4494	CONTROL,AIR DATA
595568-5		CYLINDER
5A527-000	2935-00-966-3321	COOLER AND VALVE
5A835	2935-00-999-5673	COOLER & VALVE ASSY
5A844	4820-00-072-5573	VALVE, REGULATING, TEMPERATURE
5A844-000		VALVE, REGULATING
5C16-42-35K05-1D		INDICATOR AIRSPEED
5C16-42-35K05-1DA		INDICATOR AIRSPEED
5C5786		SWIVEL,JOINT HIDRAULIC
5C5787-3	1650-00-009-6833	VALVE ASSEMBLY HYDR
5C5787-7	1650-00-208-3344	SERVO VALVE HYDRAULIC
5C5788-3	1650-00-007-1027	VALVE ASSY
5C5788-4	1650-00-007-4155	SERVOVALVE, ELEVATOR BOOSTER
5C5791	1650-00-257-7934	CYLINDER ASSY ACTUATING LINE
5C5792		BOOSTER ACT
5C5792-1	1650-01-069-2337	CYLINDER ASSY,ACTUATING
5C5803	1650-01-060-5133	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
5C5819		BUTTON, FEATHER
6014-1		THERMOSTAT OIL TEMP CONTROL
601-4203-003		CIRCUIT CARD ASSY.
601-4204-003		CIRCUIT CARD ASSY.



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
601-4205-001		CIRCUIT CARD A-5
601-4209-001		CIRCUIT CARD
601-4209-003		CIRCUIT CARD
601-4301-001		CIRCUIT CARD ASSY.
601-5764-001	5998-01-270-1079	CIRCUIT CARD ASSY
601-5779-004		CIRCUIT CARD ASSEMBLY
601-5780-002	5998-01-121-7033	CIRCUIT CARD ASSEMBLY
601-5801-004	5998-01-134-1079	CIRCUIT CARD ASSEMBLY
601696-100	6615-00-515-5392	GYROSCOPE, DISPLACEMENT
601696-106	6615-00-348-3842	GYROSCOPE, DISPLACEMENT
60-331A	2915-00-084-3949	PUMP
60-369A	2915-00-971-9130	PUMP FUEL TANK
60-371	2915-01-506-2355	PUMP, FUEL BOOST
60-371A	2915-01-506-2355	PUMP ASSY, FUEL BOOSTER
60-371B	2915-00-971-9131	PUMP SUBMERGED ACFT
60-371C		PUMP
60-371D	2915-01-160-8283	PUMP SUBMERGED AIRCRAFT
60-551	4320-00-631-4859	PUMP UNIT ROTARY
608-6615-001	5999-01-115-1898	CIRCUIT CARD ASSY
609-8479-001		CIRCUIT CARD ASSY
609-8479-013	5998-01-074-3255	CIRCUIT CARD ASSEMBLY
611J781G10	5840-01-182-1110	MATRIX COMBINER
611J870G01	5840-01-182-1107	MATRIX ASSY
616418-166	6615-00-605-8498	ACTUATOR
617-8408-001	6130-01-086-8130	POWER SUPPLY
617-9113-004	5998-01-086-2023	CIRCUIT CARD ASSEMBLY
618-3896-004	5999-01-115-1899	CIRCUIT CARD ASSEMBLY
618-4349-001		SENSOR SUB ASSY
618751A	6615-00-676-3828	CONTROL, ALTITUDE ENCODING
61B3-1A	6115-00-351-5766	DISCONNECT ASSY, GEN. PROP.
61B3-1-A	6115-01-459-1272	DISCONNECT ASSEMBLY
61B3-21A	6115-01-459-1272	DISCONNECT ASSY,GENERATOR
6204-4		VALVE, HYDRAULIC SHUT-OFF
62-052748-01	5985-01-062-8035	RF SWITCH
620577-1	6615-00-550-6628	GYROSCOPE, DISPLACEMENT
620578-1	6615-00-555-3962	GYROSCOPE, RATE
621-0453-003	6625-01-092-5457	SYNTHESIZER ELECTRIC
62201239-001		RECEIVER, VOR/LOC/GS/MB
622-0458-001		COUPLER ANTENNA
622-0507-001	5826-01-012-1938	RECEIVER-TRANSMITTER, RADIO
622-0944-003		MODE SEL
622-0945-007	6615-01-038-7295	MODE SELECTOR
622-1001-001		CONTROL AIR DATA
622-1001-002	6615-01-038-7296	CONTROL AIR DATA
622-1001-022	6615-01-038-7296	CONTROL AIR DATA



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
622-1239-001		VOR RECEIVER VIR-31
622-1396-002		VHF COM TRANSCEIVER
622-1396-102	5821-01-316-3554	RADIO SET
622-1678-001	5826-01-012-4864	ADAPTER MX 9577A
622-2224-002		ATC TRANSPONDER
622-2224-003		ATC TRANSPONDER
622-2360-001	5826-01-012-7084	CONTROL C-10057A-ARN 118
622-2362-001	5826-01-125-1023	RECEIVER,RADIO
622-2921-002	5826-01-126-6339	DME TRANSCEIVER
622-3016-001	6615-01-168-4952	SERVO PRIMARY
622-3257-001		RECEIVER VOR/ILS
622-3371-001	5820-01-312-2024	TRANSCEIVER (628T-2A)
622-3372-001		RECEIVER - TRANSMITTER
622-3374-002	6610-01-101-1927	INDICATOR ATTITUDE
622-3380-001	5895-01-122-3456	AMPLIFIER RADIO SET
622-3700-001	5821-01-081-0367	RECEIVER TRANSMITTER
622-3702-001		BEARING DIST IND
622-3742-001		RECEIVER TRANSMITTER
622-3890-003	5841-01-220-1390	ALTIMETER SET, ELECT
622-3915-001		INDICATOR,RANGE
622-4298-001		HORIZONTAL SITUATION IND
622-4393-002	6615-01-092-0363	CONTROL BOX
622-4394-013		COMPUTER AIR DATA
622-4565-001	6615-01-328-1062	VERTICAL REFERENCE GYRO
622-4956-004	5821-01-286-6543	RECEIVER
622-4956-103	5821-01-258-7579	RECEIVER-TRANSMITTER, RADIO
622-5132-401	5841-01-432-3798	RECEIVER TRANS
622-5146-001		TACAN RT
622-5149-001	6610-01-171-0319	ADAPTER, BEARING
622-5377-001	5895-01-254-2749	RECEIVER TRANSMITTER
622-5486-001	5826-01-188-4493	SELECTOR, MODE
622-5486-001N		MODE SELECTOR
622-5796-399		AP COMP
622-5846-011		MODE SELECTOR
622-5985-001		RECEIVER-TRANSMITTER, RT-1341
622-6129-001	5985-01-151-5848	COUPLER,ANTENNA
622-6136-002		GYRO
622-6190-204	5895-01-289-5799	COMPUTER
622-6324-002	5821-01-215-3451	V/UHF CONTROL PANEL
622-6376-004		RECEIVER, RADIO
622-6521-009		CONTROLLER, DISPLAY (CTL-32)
622-6521-015	5895-01-493-3013	NAV CONTROLLER
622-6521-016	5821-01-249-6476	CONTROL INDICATOR
622-6728-213	6610-01-450-2713	INDICATOR AIR SPEED
622-8051-003	6605-01-450-7993	COMPUTER, AIR DATA



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
622881-09		SERVO AMPLIFIER,MOD 1&2
622-9210-004		TRANSPONDER
622-9722-233	6610-01-450-2710	ALTIT, PRE, AUP, LRU1
622G607	5840-01-088-9011	BALL TRACKER
6-256-251	2915-00-822-3059	VALVE, FLOAT VENT
626125-5	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
6301-1	2.91501E+12	VALVE, FUEL SHUT-OFF
630-34960-235	6610-01-312-1580	COMPUTER AIR SPEED
630-37070-235	6610-01-101-1905	COMPUTER AIR SPEED
634065-3	5930-00-961-8507	SWITCH, PRESSURE
6350-A33-CC-C	1660-00-250-0681	CYLINDER VALVE ASSY
6404486J		CONTROL
64141-351-1		ALTIMETER
642-4203-001		CIRCUIT CARD RMI DRIVER
642-4204-001	5998-01-370-9424	CIRCUIT CARD
642-4208-001	5961P*-4208-001	CIRCUIT CARD
642-4214-001		INTERCONNECT BOARD
644131-11	5930-00-996-0388	SWITCH ASSEMBLY
644131-132	5930-00-996-0388	SWITCH ASSEMBLY
644133-11	5930-00-996-0389	SWITCH ASSEMBLY
644133-134	5930-00-996-0389	SWITCH ASSEMBLY
6-458-101-1	2915-00-566-0334	FUELING VALVE
645A570A01	5895-01-182-1104	RECEIVER SUB ASSY
645A589A07		AMPLIFIER RADIO FREQUENCY
648R028G02	5995-01-057-0538	CABLE ASSEMBLY
648R195G01	5995-01-056-8526	CABLE ASSEMBLY, W7
656751-2	6986-00-137-0488	DRIVE ANTENNA
657501-1	5895-00-411-3480	NOISE SOURCE, AVALANCHE, SOLID STATE (RCVR - XMITTER)
657565-1	5998-00-411-1682	CORRECTION CIRCUIT CARD ASSEMBLY
657670-2		RECEIVER RADAR
657793-1	5841-00-411-3461	MODULATOR RECEIVER
657828-1	5895-00-411-3464	AMPLIFIER, INTERMEDIATE
658020-1	5841-00-411-3473	OSCILLATOR SOLID STATE
6599-1	5930-00-621-4524	SWITCH,FUEL PRESSURE
6599-4	5930-00-629-6660	SWITCH,FUEL PRESSURE
65A27D1	5841-00-900-8081	WARNING SET
66039-01	4320-01-171-0452	HYDRAULIC PUMP
66039-02	4320-00-616-3812	PUMP
66039-03	4320-01-529-2024	PUMP, HYDRAULIC
662841-14	5985-00-252-3494	SEQUENCER, MOD 1
662845-06		CIRCUIT CARD ASSY.
662845-07	5999-00-153-4123	CIRCUIT CARD ASSEMBLY
662849-01		SYNCHRO REPEATER
662849-06		SYNCHRO REPEATER LTN 51
662849-12		SYNCHRO REPEATER



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
662853-03	5998-00-153-4126	CIRCUIT CARD ASSEMBLY
662853-6	5998-00-153-4126	CIRCUIT CARD ASSY. LTN-51
662857-12	5975-01-240-3259	MOUNTING BASE ELEC LTN-51
662857-13	5975-01-240-3258	MOUNTING BASE ELEC LTN51
662869-05		INPUT CONVERTER
662873-06		CCA D/A CONVERTER
662881-01	5998-01-319-3886	CIRCUIT CARD ASSEMBLY
662881-01-04		SERVO AMPLIFIER, MOD3
662881-04		SERVO AMPLIFIER UNMODIFY
662881-05		SERVO AMPLIFIER UNMODIFY
662881-06		SERVO AMPLIFIER
662881-17		SERVO AMPLIFIER, MOD 3
662881-18	5975-01-240-3258	SERVO AMPLIFIER MOD3
662889-04		CIRCUIT CARD AMB LTN-51
662889-05		CIRCUIT CARD ASSY
662897-02		CIRCUIT CARD ASSY LTN-51
662897-05		QUANTIZER INERTIAL
662897-06		QUANTIZER
662897-10		CCA QUANTIZER
662897-12	5998-01-240-3681	CIRCUIT CARD ASSY LTN-51
663450-08		51 INU
663454-01	6515-01-313-9905	GIMBAL ASSY LTN-51
663454-03		GIMBAL
663550-04-01	6605-00-124-9447	CDU LTN-51
663570-03	6605-00-165-5888	MODE SELECTOR UNIT
663604-03	6605-00-152-7238	TRANSFORMER RECTIFIER
663604-04	6605-00-152-7238	TRANSFORMER RECTIFIER
667500-01	6625-01-096-8663	GYROSCOPE
667500-02		GYROSCOPE
667826-17	6615-00-521-4893	CONTROL, ALTITUDE, AUTOMATIC PILOT
66WBD300	4320-00-650-0792	PUMP HYDRAULIC
66WBD300-1	4320-00-955-3126	PUMP AXL
66WBD300-4	4320-00-213-5986	PUMP HYDRAULIC
66WBD300-4A		PUMP, HYDRAULIC
66WBG300-4		PUMP
66WU300-4	4320-00-955-3125	Pump
67-2734-001		VALVE
67-2735-001		VALVE
67-2790-001		VALVE, BUTTERFLY
67-2790-002	4810-00-003-4369	Valve Butterfly
67-2790-003		VALVE, MODULATING
673443-01		CIRCUIT CARD, DATA
673718-01		POWER SUPPLY LTN-51
673718-03		POWER SUPPLY INU
6782647-J		RELAY IGNITION



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
6794320(K)		NOZZLE,FUEL SPRAY
6798233L	4920-00-891-3616	TEST SET ELECTRONIC SYSTEMS
6809618-L		FUEL NOZZLE
6809639MX		RELAY BOX
6821493R		SPEED VALVE
683R592G01	6130-01-090-0628	POWER SUPPLY
686R068G01	5865-01-107-0151	POWER SUPPLY SUBASSEMBLY
686R750G01	5998-01-192-2738	BAND 4/5 A10 BOARD ASSEMBLY
6904-2720-1	6625-00-424-4197	TEST SET SUBASSEMBLY
692525-2	5930-01-502-4004	SWITCH, PRESSURE
692751-1	5985-00-252-3494	ANTENNA - LINE 20
692756-1	5841-00-252-3497	RECEIVER TRANSMITTER
692757-1	5841-00-252-3498	CONTROL RADAR
692760-1	5841-00-252-3500	INDICATOR,AZIMUTH-RANGE
692762-1		INDICATOR,RADAR TARGET
692762-3	5841-01-089-1753	INDICATOR RADAR TARGET
692762-4	5841-01-088-8142	INDICATOR, RADAR TARGET
695001-4		CYLINDER ASSEMBLY, MAIN LANDING GEAR SHOCK
695001-9A		MLG SHOCK STRUT ASSY
695043-1	1650-00-994-8631	CYLINDER ASSEMBLY,ACTUATING,LINEAR
695043-3		NLG UPLOCK CYLINDER
695069-1		VALVE
695069-3		VALVE
695069-3A		VALVE
695119-1		VALVE, SAFETY
695119-3	1660-01-472-9795	VALVE, SAFETY
695119-7	1660-01-483-3094	VALVE, SAFETY
695187-1	6610-00-580-9363	INDICATOR, FLAP POSITION
695260-1	6625-00-649-2864	AMMETER
695269-1	4820-00-639-9685	REGULATOR
695315-8	5930-00-658-6512	SWITCH, THERMOSTATIC
695335-3		LIGHT, LANDING
695335-5	6220-00-893-8777	LIGHT, LANDING
695335-7	6220-01-316-4577	LIGHT, LANDING
695335-9		LIGHT, LANDING
695383-1	6685-00-810-6047	GAGE, HYDRAULIC PRESSURE
695422-10	1650-00-626-5728	BRAKE FLAP LH
695422-11	1650-00-626-5729	DISC,BRAKE
695422-12		REDUCER, SPEED, LH
695422-13		REDUCER, SPEED, RH
695422-3		BRAKE EMERGENCY, LH WING FLAP
695422-4		BRAKE EMERGENCY, RH WING FLAP
695422-7		SWITCH, LH SENSING
695422-9		SWITCH, RH SENSING
695463-3		VALVE, OUTFLOW



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
695464-13	1660-00-062-0301	AIR PRESSURE CONT.
695485-3	1650-00-512-1690	SERVOVALVE, AILERON BOOSTER
695485-5		SERVOVALVE, RUDDER BOOSTER
695485-7	1650-00-670-6581	SERVOVALVE, RUDDER BOOSTER
695495-3	4810-00-866-8212	VALVE, LINEAR DIRECT
695497-3		CYLINDER ASSEMBLY, RUDDER BOOSTER
695497-5		CYLINDER ASSEMBLY, RUDDER BOOSTER
695497-7		CYLINDER ASSEMBLY, RUDDER BOOSTER
695508-3		VALVE, RADOME ANTI-ICING, SHUT OFF
695521-3		LIGHT
695521-5	6220-00-421-9109	LIGHT, ROTATING BEACON
695526-3	4810-00-208-9693	VALVE
695539-3	6620-00-573-7870	THERMOSTAT FLOW CONTROL
695539-4		UNDER FLOOR HEAT THERMOSTAT
695545-3		PUMP, SUCTION BOOST
695545-5	4320-00-050-8205	PUMP
695547-1	4810-00-208-9709	VALVE
695548-3		NLG STEERING CYLINDER
695561-1		CYLINDER
695568-1	1650-00-570-8688	CYLINDER ASSEMBLY,ACTUATING,LINE
695568-3		CYLINDER ASSY. NOSE LANDING GEAR
695568-5	1650-01-155-6849	CYLINDER NLG HYD
695572-1	6610-00-808-7038	INDICATOR, FLAP POSITION
695579-11		GEAR BOX ASSEMBLY MAIN LANDING GEAR
695579-41	1620-00-626-8652	HYDRAULIC BRAKE ASSY
695579-45	1680-00-373-8044	GEARBOX
695579-53		GEARBOX, MANUAL, MLG
695579-55		HYDRAULIC BRAKE ASSY
695579-69	1620-00-617-9123	GEARBOX
695579-71	1620-00-677-6681	BALL SCREW ASSEMBLY, MAIN LANDING GEAR
695592-1	4320-00-631-4859	ROTARY PUMP
695592-3	4320-00-631-4859	PUMP
695594-3	1650-00-513-5414	SERVOVALVE, ELEVATOR BOOSTER
695594-4	1650-00-513-5415	SERVOVALVE,HYDRAULIC
695594-5		SERVOVALVE, ELEVATOR BOOSTER
695606-7	1680-00-677-3666	REGULATOR, ENGINE CABLE TENSION
695612-1		CYLINDER
695619-5	2915-00-084-3949	PUMP
695625-1		CYLINDER
695674-1	6685-00-753-7668	INDICATOR, PRESSURE
695674-3	6620-01-394-4042	INDICATOR, PRESSURE
695676-1	1680-00-610-8932	ACTUATOR, OUTBOARD WING FLAP
695676-11	1680-01-004-2086	ACTUATOR ASSEMBLY
695676-13	1680-01-472-9783	ACTUATOR, OUTBOARD WING FLAP
695676-15	1680-01-217-5837	ACTUATOR, INBOARD WING FLAP



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
695676-3	1680-00-610-8931	ACTUATOR, INBOARD WING FLAP
695676-5		ACTUATOR, OUTBOARD WING FLAP
695676-7	1680-00-006-3143	ACTUATOR, INBOARD WING FLAP
695676-9	1680-00-615-1335	ACTUATOR
695683-1		SWITCH SIGNAL
695683-3	5930-00-629-6660	SWITCH, PRESSURE
695691-1		PUMP, FUEL BOOST
695698-3	2915-00-574-3227	VALVE OUTBOARD VENT
695700-3		ELEVATOR TRIM TAB ACTUATOR
695718-9	1650-00-872-7516	AIR TURBINE DRIVE
695719-1	4140-00-051-2620	FAN
695723-1	1650-00-670-5822	CYLINDER
695743-1	4320-00-786-7710	AUXILIARY PUMP UNIT, AXIAL PISTONS
695745-1	4810-00-653-7572	VALVE
695746-1	2915-00-632-7932	VALVE FUEL SYSTEM
695747-1		VALVE, BUTTERFLY
695747-3		VALVE, BUTTERFLY
695747-5	4810-00-672-1085	VALVE, BUTTERFLY
695747-7	4810-00-670-1111	VALVE, BUTTERFLY
695748-13		VALVE
695748-15		SOLENOID SHUT-OFF VALVE
695750-1		VALVE, SHUTOFF
695755-1	1680-00-733-3491	WINCH
695755-3	1680-01-223-8908	WINCH
695755-5	1680-01-387-6739	WINCH
695759-1		GEAR BOX, FLAP DRIVE
695759-3		GEAR BOX, FLAP DRIVE
695759-5		GEAR BOX, FLAP DRIVE
695759-7		GEAR BOX, FLAP DRIVE
695762-1	4810-00-730-3529	VALVE, RAMP CONTROL
695762-3	4810-00-566-7114	VALVE LINEAR
695762-5	4810-01-360-8278	VALVE, RAMP CONTROL
695763-1		VALVE, FLOW CONTROL
695763-3	4810-00-612-2696	VALVE, FLOW CONTROL
695768-1	2915-00-971-9130	PUMP
695769-1	2915-00-971-9131	PUMP, FUEL BOOST
695769-3	2915-00-083-9373	PUMP SUBMERGED AIRCRAFT
695775-1		ACTUATOR
695775-2	1680-00-981-7652	ACTUATOR, ELECTRO-MECHANICAL, LINE
695780-1	6625-00-555-4522	INDICATOR, LOADMETER
695789-11	1680-01-114-3119	PANEL, LANDING GEAR CONTROL
695789-19	5930-01-391-8430	SWITCH ASSEMBLY
695797-1	6680-00-580-1247	INDICATOR LIQUID QUANTITY
695798-3	6680-01-099-0790	TOTALIZER, FUEL QUANTITY
695805-1	4810-00-987-3948	VALVE, ANTI-ICING



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
695807-1	1680-01-208-0174	ACTUATOR ELECTRO-MECHANICAL
695807-3	1680-01-254-6893	ACT ELEC MACH LINE
695807-5	1680-01-378-1631	ACTUATOR, OIL COOLER DOOR
695807-7		ACTUATOR
695810-3	2915-00-789-1102	HEATER ASSEMBLY,FUEL
695812-2	4810-00-673-2727	VALVE
695812-2C		SHUT-OFF VALVE
695838-3	1680-00-426-5616	ACTUATOR
695845-1		VALVE, PRESSURE REDUCER
695845-3	4820-00-991-0785	VALVE, PRESSURE REDUCER
695845-5	4820-00-991-0785	VALVE, PRESSURE REDUCER
695859-1		VALVE, MODULATING
695859-3		VALVE, MODULATING
695859-5		VALVE, MODULATING
695890-1	6105-00-630-5828	WINDSHIELD WIPER MOTOR ASSEMBLY
695890-51		CONVERTER, WINDSHIELD WIPER
695899-1	1650-00-013-7091	VALVE, HYDRAULIC SHUT-OFF
695906-1	5930-00-615-7340	SWITCH, PRESSURE
695908-1	4320-00-650-0792	PUMP, HYDRAULIC
695916-1	4810-00-627-5271	VALVE
695943-1		FAN, RECIRCULATING
695943-3	4140-00-814-5758	FAN, RECIRCULATING
695953-13		NUT
695960-1		SCREWJACK
695960-5		SCREWJACK
695974-1	2915-00-775-9195	VALVE
695974-3		VALVE, FUEL SHUT-OFF
697133-1	1650-01-087-0956	VALVE
697134-1	4810-00-522-4592	VALVE
697149-1	5930-00-727-3638	SWITCH, PRESSURE
697183-1		ACTUATOR,ELECTRO-MECHANICAL,LINEAR
697183-3	1680-01-222-3117	ACTUATOR,ELECTRO-MECHANICAL,LINEAR
697199-1		REGULATOR, ENGINE CABLE TENSION
697201-1	6115-00-946-8441	GENERATOR
697232-1	1650-00-204-1703	MOTOR HYDRAULIC
697234-3	4820-00-983-3598	VALVE, PRESSURE REDUCER
697235-1	1680-01-221-8261	ACTUATOR, PARATROOP, SPOILER DOOR
697235-3	3040-01-423-0504	ACTUATOR, PARATROOP, SPOILER DOOR
697237-7	6615-00-459-9599	REPEATER, SERVO
697244-1	6620-00-856-8263	INDICATOR, TORQUEMETER
697260-1	4820-00-978-8886	VALVE
697283-1	4820-00-063-2438	VALVE
697339-1		VALVE,9 PORT DIRECTIONAL CONTROL
697395-1	1630-00-998-7897	VALVE, BRAKE CONTROL
697396-1	6695-00-719-7103	TRANSMITTER



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
697397-3	1630-00-908-9999	VALVE
697424-1		DISCONNECT ASSY,GENERATOR
697424-3		DISCONNECT ASSY,GENERATOR
697424-5		DISCONNECT ASSY,GENERATOR
697489-1	1630-00-914-1329	WHEEL,NOSE LANDING GEAR
697638-3	4810-01-004-5634	VALVE
697638-9	4810-01-157-2583	VALVE
697639-11		CONTROLLER, TEMP, FLIGHT STATION
697639-13	1660-00-595-7773	SENSOR,CABIN TEMPERATURE
697639-15	6680-00-583-7105	DUCT SENSOR
697639-17	1660-00-583-7106	SENSOR, OVERHEAT
697639-21		CONTROLLER, TEMP, CARGO COMPARTMENT
697639-25	1660-00-583-7058	DUCT SENSOR
697639-27	5905-00-588-3477	OVERHEAT SENSOR
697639-35		CONTROLLER, TEMP, LOW LIMIT
697639-37	1.66001E+12	CONTROLLER, TEMP, FLIGHT STATION
697639-39		CONTROLLER, TEMP, CARGO COMPARTMENT
697749-1	6680-01-220-4090	FUEL QTY DIGITAL INDICATOR
697749-15	6680-01-350-8049	INDICATOR, LIQUID
697749-9		INDICATOR LIQUID QTY
697752-1		VALVE, TEMPERATURE CONTROL
697753-1	4810-01-219-3417	VALVE, TEMPERATURE CONTROL
697757-1	4820-01-522-1983	VALVE, CHECK
697967-1	6220-01-446-3883	EMERGENCY EXIT LIGHT
698042-1	6620-01-444-5516	INDICATOR, MULTIPLE
698043-1	6620-01-443-1214	INDICATOR, MULTIPLE
698050-1	1680-01-475-6529	WINCH, CARGO
698056-1	6610-01-444-0168	ALTIMETER, SERVO CONTROL
698057-1	6610-01-444-0169	INDICATOR, AIRSPEED
698611-1		TORQUEMETER IND
7000A	6615-00-530-3061	GYROSCOPE, DISPLACEMENT
7000B	6615-00-973-2218	GYROSCOPE, DISPLACEMENT
7000E	6615-00-951-9140	GYROSCOPE
700647-1	5998-00-422-3252	CIRCUIT CARD
7006M51G02	2915-00-480-8112	T5 AMPLIFIER
701-2003	5930-01-436-0623	SWITCH ASSEMBLY
701-2605	5930-01-413-8954	SWITCH ASSEMBLY
70262-1		VALVE
703873-2	5985-00-252-3493	PITCH ACTUATOR ASSEMBLY
703874-2	5985-00-252-3492	ANTENNA DRIVE
7041-1	4820-01-215-9990	ACTUATOR, AILERON TRIM
7041-2		ACTUATOR, RUDDER TRIM
704175-1	1610-00-895-8588	SPINNER,PROPELLER,AIRCRAFT
704175-2	1610-01-372-0536	SPINNER PROPELLER
705079-1	1610-00-941-4353	BRACKET ASSY



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
707-5412	5930-01-311-5657	SWITCH ASSEMBLY
7088-1A	1680-00-789-9345	GEAR BOX, FLAP DRIVE
7-115945		VALVE ASSY
714325-3	1610-01-038-5779	VALVE HOUSING PROPELLER
714325-5	1610-01-016-2196	VALVE HOUSING
714325-7	1610-01-318-4870	HOUSING ASSEMBLY, VA
714819-1	5895-00-252-3492	ROLL ACTUATOR SUBASSEMBLY
714820-1	5985-00-252-3493	PITCH ACTUATOR ASSEMBLY
716BK-8-036	6610-00-663-4153	INDICATOR
716BU-8-036	6610-00-663-4156	RATE OF CLIMB INDICATOR
722-2032-001		AUDIO ASSY
722-5140-002		SENSOR RATE OF TURN
724BK03M	6610-00-526-4803	INDICATOR, AIRSPEED
724CU-4-012	6610-00-514-5612	INDICATOR, AIRSPEED
724CU-5-011	6610-00-531-4299	INDICATOR, AIRSPEED
724CU5-03M	6610-00-526-4798	INDICATOR, AIRSPEED
724CU8-011	6610-00-531-4296	INDICATOR, AIRSPEED
724DX4-012	6610-00-526-7944	INDICATOR, AIRSPEED
731300-3	2915-00-357-2496	VALVE, FLOAT, AIRCRAFT
733872-2	1610-00-005-8685	HOUSING ASSY PUMP
733872-5	1610-01-350-7769	PUMP HOUSING
733872-6	1610-01-220-6052	PUMP HOUSING
7360-1	1680-00-904-3465	WINCH, CARGO
736639-1	5996-00-421-8429	AMPLIFIER ASSEMBLY
736639-2	5895-01-103-5399	AMPLIFIER ASSEMBLY
738338-1		BRACKET ASSEMBLY
75-0291-1	6220-01-466-8702	PANEL, INDICATING, LIGHT
751872-3	1660-01-019-8577	AIR CONDITION
75-55132-001	6605-01-122-7891	REPEATER, SERVO
75-55136-001	6605-01-078-6948	REPEATER, SERVO
756LPE50	6220-00-808-3655	PANEL, INDICATING, LIGHT
757R501	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY
757R501G02	6130-01-310-0809	LOW VOLTAGE POWER SUPPLY
759R379G01	6130-01-211-8075	POWER SUPPLY CONTROL
759R379G02	6130-01-211-8075	POWER SUPPLY CONTROL
75J808000-103	6610-01-309-1413	INDICATOR, ATTITUDE
76067-1	1730-01-118-6120	SWITCH, CENTRIFUGAL
76067-13	2835-00-909-6868	SWITCH, CENTRIFUGAL
76067-14		SWITCH, CENTRIFUGAL
76067-15	5930-00-022-7504	SWITCH, CENTRIFUGAL
76067-2	2835-00-909-6868	SWITCH, CENTRIFUGAL
76067-4	5930-00-620-9591	SWITCH, CENTRIFUGAL
76067-5		SWITCH, CENTRIFUGAL
7609-17B5-1	6620-00-526-7917	SSUFDR
7609-37-C5-1	6685-00-526-7864	TRANSMITTER



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
7609-37H5-1	6685-00-990-5746	TRANSMITTER, PRESSURE
7609-37M5-2	6685-00-954-7417	TRANSMITTER, PRESSURE
761230-2		SYNCHROPHASER
766840-1	1610-01-097-8728	SYCHROPHASER
766840-2	1610-01-155-9337	SYNCHRO PHASER
766926-1		CYLINDER
766985-1		CYLINDER
766R023G01	5998-01-246-1704	ANTENNA BOARD ASSEMBLY
7-702755		VALVE
771180-1		CYLINDER
7-716835	2915-00-739-3047	VALVE, FLOAT AIRCRAFT
772-5140-001		RATE SENSOR
772-5140-002	6615-01-134-3127	GYROSCOPE FLIGHT
772-5370-003	5826-01-065-9189	HORIZONTAL SIT.IND.
774474-1	1610-01-112-3771	STOP ASSEMBLY PROPELLER
774800-1	1610-01-128-7400	Synchrophaser
776840-2	1610-01-155-9337	SYNCHRO PHASER
777-1034-001	6615-00-134-5980	RATE OF TURN SENSOR
777-1225-001		CONTROL,RADIO SET
777-1493-006		ADF CONTROL
77D0069-1	6130-01-058-5927	POWER SUPPLY
784755-1	5977-01-209-4979	HOLDER ELECTRICAL
7854687C		SPEED CONTROL
792-6140-001	5985-01-089-3064	MOD. COUPLER
792-6216-004		ADF RECEIVER
792-6221-003		REMOTE SELECTOR
792-6255-005		MODE CPLR
792-6275-002	5826-01-065-1759	CONTROL GAIN ADF
792-6348-005	6615-01-038-7299	CONTROLLER AUTOPILOT
792-6348-005N		AUTO PILOT CONTROLLER
792-6357-002		ATTITUDE DIR IND
7926486-10	1620-01-143-1155	STRUT, NOSE LANDING GEAR
7926486-30	1620-01-143-1155	STRUT, NOSE LANDING GEAR
7926486-50	1620-01-080-6190	STRUT, NOSE LANDING GEAR
7926487-10	1620-01-080-6189	STRUT, NOSE LANDING GEAR
7926487-30	1620-01-143-1155	STRUT, NOSE LANDING GEAR
7926623-10	1620-01-146-5708	STRUT, NOSE LANDING GEAR
7926623-30	1620-01-143-8557	STRUTASSEMBLY,NOSELANDINGGEAR
792-6657-001		VHF COMM TRANS
792-6694-001	6615-00-348-3874	VERTICAL REFERENCE
792-6703-003	6615-01-040-0126	COMPUTER,FLIGHT CONTROL
792-6781-003	6615-01-037-7780	SERVO UNIT
792-6785-002	6615-01-065-9448	MOUNT, SERVO
794260-1	6610-01-385-8527	INDICATOR, POSITION
797-2445-013	5998-01-074-0568	CIRCUIT CARD ASSY



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
797-3639-013	5998-01-074-5119	ELECTRONIC COMPONENTS ASSEMBLY
797-7711-001	6615-01-037-7780	SERVO UNIT
798C528G01	6115-01-014-5457	ROTOR
798C635G01		Stator Generator
7MJ1	6685-00-954-7417	TRANSMITTER, PRESSURE
800500-19	4120-01-010-5171	CONTAINER ASSY FIRE
800530-1	4210-01-300-5266	EXTINGUISHER
8037-255		AC MOTOR
8037M1		ACTUATOR
8037M2	1680-01-013-9501	ELE TRIM ACTUATOR
80-5181	6610-01-527-2395	INDICATOR, VERTICAL SPEED / TCAS
806500-1		VALVE
8067-1A	1680-01-009-8293	ELEVATOR SCREW JACK
8067-2A	1680-01-009-8294	SCREW-JACK, ELEVATOR
8067-3A	1680-01-131-0901	SCREW-JACK
8067-4A	1680-01-131-0902	SCREW-JACK
8118A	1680-01-107-2667	ACTUATOR ASSY, DUAL OUTP
81940-1		SEPARATOR, WATER
81940-2	1660-00-719-5521	SEPARATOR, WATER
81940-3	1660-00-793-6559	SEPARATOR, WATER
81D0240-1	6130-01-192-6999	POWER SUPPLY
82-052759-01	5996-01-060-6746	LOG VIDEO AMPLIFIER
82-052760-01	5865-01-059-4571	IF DISCRIMINATOR
82-052795-01	6130-01-058-5927	POWER SUPPLY
822-0761-001	5826-35-787-5499	RECEIVER TRANSMITTER
822-1046-001	5820-01-474-0840	RECEIVER , 618M-5A
822-1114-001	5821-01-467-8793	VHF COMM TRANS
822-1413-001		UNIT, CONTROL DISPLAY
822-1944-001	6610-01-519-0844	INDICATOR AIRSPEED & DIRECTION
83120-0-5	1660-00-337-4491	SEPARATOR, WATER
83120-1		SEPARATOR, WATER
83120-2-1	1660-00-659-0140	SEPARATOR, WATER
8318-0610	5930-01-216-3233	SELECTOR SWITCH
8318-0610-1	5930-01-216-3233	SELECTOR SWITCH
8340922-10	1630-01-038-5126	WHEEL, LANDING GEAR
8340922-30		WHEEL, LANDING GEAR
8340922-50		WHEEL, LANDING GEAR
8340922-70		WHEEL, LANDING GEAR
8347-12	1680-01-257-2445	GEARBOX
8348M1	1620-00-617-9123	LANDING GEARBOX
8353M1		BALL SCREW
8353M2		BALL SCREW
83832-1	1660-00-870-9373	HEAT EXCHANGER
83832-1-2	1660-00-870-9373	HEAT EXCHANGER AIR
839966-1		AMPLIFIER TEMPERATURE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
83D0439-1	6130-01-192-6999	POWER SUPPLY
8422-001	1650-00-640-8491	ACCUMULATOR, HYDRAULIC
8430M1	1620-01-065-4867	BALL SCREW ASSEMBLY
8430M2		BALLSCREW
8430M3		BALL SCREW
8430M4	1620-01-263-6733	BALLSCREW ASSEMBLY
8440-2		VALVE
8445M1	1680-01-324-8157	INBD FLAP ACTUATOR
8446M1	1680-01-324-8158	FLAP ACTUATOR
8448M2		BALL SCREW ASSEMBLY
8448M3		BALL SCREW ASSEMBLY
8448M4		BALL SCREW ASSEMBLY
85027-1	1660-01-468-3917	HEAT EXCHANGER AIR
8526M1	3010-01-461-4547	ACTUATOR, APU INLET DOOR
8545M1		BALLSCREW ASSEMBLY
8546M1	1680-01-222-2551	BALLSCREW ASSEMBLY
8555-120-1		MOTOR ASSY
8555-120-2	6105-01-335-9937	MOTOR ASSY
8555-125-1		MOTOR & BLOCK ASSY
8555-125-2	6105-01-335-7814	MOTOR & BLOCK ASSY
8555M1		LANDING LIGHT
8555M2		LANDING LIGHT
8555M3		LANDING LIGHT
8555M4		LANDING LIGHT
8555M5		LANDING LIGHT
8555M6		LIGHT LANDING
8555M7		LIGHT LANDING
8555M8	6220-01-471-6339	LIGHT, LANDING
8555M9		LIGHT LANDING
8575600G		CONTROL SPEED SENSITIVE
86250-2		OIL COOLER ASSY W/ REGULATOR
8656M2	1680-01-497-7142	ACTUATOR, ELECTRO-MECHANICAL, LINE
880057-1	5895-01-206-7147	INTERROGATOR SET
880T100		ACTUATOR
880T100-1		ACTUATOR
880T100-3	1680-01-329-7411	ACTUATOR, ELECTRO-ME
89000-1	6620-00-901-7848	PRESSURE TRANSMITTER
89000-1 / TRU81/A		TRANSMITTER PRESSURE
892541-100	6350-00-015-8049	FIRE CONTROL UNIT
898028-1-1	4820-00-007-7956	STARTER VALVE
89D0834-1	6130-01-361-0655	POWER SUPPLY
8DJ100WAA1	6685-00-897-8400	INDICATOR, TEMPERATURE
8DJ100WAA2	6685-00-897-8400	INDICATOR TEMPERATURE
8DJ100WAD2	6685-00-780-7787	INDICATOR, TEMPERATURE
8DJ100WAD3	6685-00-780-7787	INDICATOR, TEMPERATURE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
8DJ100WAD5	6685-00-780-7787	INDICATOR, TEMPERATURE
8DJ135LWB1	6680-01-061-3996	RATE OF FLOW IND
8DJ179WAD1	6685-01-096-6867	TEMP INDICATOR
8DJ179WAD4		TEMP IND
8DJ179WBK1	6685-00-138-1564	INDICATOR TEMPERATURE
8DJ43AAM	6620-00-515-4541	INDICATOR ELECTRICAL TACHOMETER
8DJ43AAM13	6680-00-663-4207	TACHOMETER INDICATOR
8DJ43AAM14	6680-00-663-4271	TACHOMETER INDICATOR
8DJ43BAD		Electric Thermometer
8DJ48FAL2	6610-00-515-4600	FLAP POSITION INDICATOR
8DJ48FAR	6610-00-580-9363	INDICATOR, POSITION
8DJ48FAR2	6610-00-580-9363	INDICATOR, POSITION
8DJ48FCM2	6610-01-392-7980	INDICATOR, POSITION
8DJ49GAW	6610-00-531-5417	INDICATOR, POSITION
8DJ49GAW2	6610-00-808-7037	INDICATOR, POSITION
8DJ49GAY	6610-00-580-9690	INDICATOR, POSITION
8DJ49GAY1	6610-00-580-9690	INDICATOR, POSITION
8DJ49GAY2	6610-00-580-9690	INDICATOR, POSITION
8DJ49GBV2	6610-00-808-7038	INDICATOR, POSITION
8DJ49GEP2	6610-01-393-2386	INDICATOR, POSITION
8DJ49GER2	6610-01-393-4116	INDICATOR, POSITION
8DJ49GET2	6610-01-393-2384	INDICATOR, TRIM, CONTROL
8DJ49LAM2	6610-00-817-8771	DC SELSYN POSITION INDICATOR
8DJ49LAN2	6610-00-817-8772	DC SELSYN POSITION INDICATOR
8DJ64GBC1	6620-01-098-2960	INDICATOR FUEL
8DJ64GBH1	6620-01-038-5769	FUEL FLOW IND
8DJ64GBW1	6620-01-391-2998	INDICATOR, RATE OF FUEL FLOW
8DJ67FCA		Tachometer Indicator
8DJ71GAB	6620-00-551-2631	INDICATOR RATE OF FLOW
8DJ71GAB1	6620-00-551-2631	INDICATOR RATE OF FUEL FLOW
8DJ71GAK2	6620-00-621-2903	INDICATOR, RATE OF FUEL FLOW
8DJ72GAB	6620-00-551-1270	INDICATOR, RATE OF FUEL FLOW
8DJ72GAB1	6620-00-551-1270	INDICATOR, RATE OF FUEL FLOW
8DJ72GAD2	6620-00-621-2904	INDICATOR, RATE OF FUEL FLOW
8DJ81CAA1	6620-00-621-0143	TACHOMETER INDICATOR
8DJ81CAA2	6620-00-969-3972	TACHOMETER INDICATOR
8DJ81CAA4	6620-01-063-9636	TACH IND
8DJ81CBD1	6620-00-877-3266	INDICATOR, TACHOMETER
8DJ81CBD2	6620-00-877-3266	INDICATOR, TACHOMETER
8DJ81CBD4	6620-01-157-9266	INDICATOR TACHOMETER
8DJ82CAS1	6620-00-895-0976	INDICATOR, TACHOMETER
8DJ98AAC1	6685-00-621-2906	INDICATOR, TEMPERATURE
8DJ98AAD1	6685-00-621-2906	INDICATOR, TEMPERATURE
8T51GAA5	6130-00-772-8567	POWER SUPPLY ACH
8TJ50(4A5-5)		FUEL FLOW METER



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
8TJ50GA		FUEL FLOW METER
8TJ50GAA5	6620-00-720-3223	F/F TRANSMITTER
8TJ50GAB	6620-00-515-5208	FLOWMETER, FUEL FLOW
8TJ50GAS4		FLOWMETER, FUEL FLOW
8TJ50GAS5	6620-00-720-3223	F/F TRANSMITTER
8TJ51-GAA		POWER SUPPLY FLOW METER
8TJ51GAA4		FUEL MASS FLOWMETER
8TJ51GAA5		POWER SUPPLY
8TJ64GBW2		TRANSMITER FLOW METER
8TJ64GBW-2		TRANSMITTER FUEL FLOW
8TJ95GAA1		POWER SUPPLY, FUEL FLOW METER
8TJ95GAA4		POWER SUPPLY
907-74	6625-00-199-1879	METER, ELECTRICAL
908-164	6625-00-199-1879	METER ELECTRICAL
9120-1		VALVE
9120-2		VALVE
914858-851		RECEIVER TRANSMITTER
915-38106-001	6130-01-217-5880	POWER SUPPLY REMOTE
9180-1		VALVE
9180-2		VALVE
918476-000	5998-01-269-6978	CIRCUIT CARD ASSEMBLY
918819-801	5998-00-570-4262	CIRCUIT CARD ASSEMBLY
9205-4584		RELAY
92160-01	6610-00-526-4718	INDICATOR, ATTITUDE
92160B	6610-00-526-4718	INDICATOR, ATTITUDE
9235340-10	1620-01-511-0040	PISTON ASSEMBLY
9235507-10	1630-01-385-4508	PISTON ASSEMBLY
9235508-10		STRUT ASSY NLG
93-100-90	5835-01-128-7757	RECORDER
93A100-90	5835-01-128-7757	VOICE RECORDER
93-A100-90	5835-01-128-7757	CVR (COCK-PIT RECORDER)
93-A152-16		CONTROL UNIT VOICE RECORDER
9440-11	1680-01-385-3219	WINCH, CARGO
9-464-40 / -62		INDICATOR, FUEL FLOW
9-464-40MOD-B	6680-01-484-0254	INDICATOR, FUEL FLOW
948894-4-1		CONTROL OVERTEMP.
9550402-1	1630-01-307-9124	BRAKE ASSEMBLY
9550616-1	1630-01-094-1104	WHEEL, LANDING GEAR
9550616-1LC	1630-01-038-5126	WHEEL LANDING GEAR
9560685-1		BRAKE ASSY
9616-03	6685-00-650-0570	AMPLIFIER, ENGINE
9616-38	6625-00-869-5478	AMPLIFIER, SYNCHRO
9616-48	6625-00-839-8678	AMPLIFIER
965-0412-002	6610-01-101-1913	COMPUTER, AIR DATA
965-0476-088	6340-01-101-1888	COMPUTER WARNING GPWS



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
976J215-1	6110-00-689-8602	CONTROL GENERATOR
976J215-2	6110-00-689-9842	PANEL PROTECTION
976J480-1	6115-00-136-6617	GENERATOR
976J480-2	6115-00-997-6517	GENERATOR AC
979470-2-1		SHUTOFF VALVE
980-4120-RXUS		SSUFDR
9817-01	6685-00-642-0533	INDICATOR, TEMPERATURE
9819-08	6610-00-058-9527	ATTITUDE IND
98G41-1	5930-00-463-7442	SWITCH,PRESSURE
98G41-2B		BODY
98G-45		CAP
9900-39		REGULATOR
9A022-1	4810-00-013-7091	VALVE PRESSURE
9A100	6620-01-206-5748	INDICATOR
9A1100	6620-01-206-5748	TORQUEMETER IND
9A2090	6620-01-437-3144	TORQUEMETER INDICATOR
9A2100	6620-01-264-8685	TORQUEMETER IND
9A360	6680-00-900-8356	INDICATOR, LIQUID QUANTITY
9A360HEA	6680-00-937-0429	INDICATOR LIQUID QUANTITY
9A375	5585-00-148-8247	TEMPERATURE INDICATOR
9A-375	6685-00-148-8247	TEMPERATURE INDICATOR
A100		VOICE RECORDER UNIT
A13A	6645-00-403-4947	CLOCK 8 DAY
A13A-2	6645-01-235-9465	CLOCK,PANEL
A1600	6610-00-739-3046	INDICATOR, TURN & SLIP
A1605	6610-00-625-6035	INDICATOR, TURN & SLIP
A25363-10-002	6610-00-531-4582	INDICATOR, VERTICAL VELOCITY
A25363-10-003	6610-00-531-4582	INDICATOR, VERTICAL VELOCITY
A25753-10-001	6610-00-531-4587	INDICATOR, VERTICAL VELOCITY
A40A1750	6110-00-500-0391	VOLT.REG.
A40A1750-2	6110-00-483-9247	REGULATOR VOLTAGE
A451M9A	1680-01-077-3439	LANDING GEAR CONTROL
A487-1		SCREW JACK
A487-2		SCREW JACK
A487-3	1680-00-705-9996	ACTUATOR MECHANICAL
A487-4	1680-00-777-0135	ACTUATOR MECHANICAL
A489-2		GEAR BOX
A489-3		ACTUATOR ELECTROMICHANICAL ROTARY
A489-3/A489-4	1680-00-672-8931	ACTUATOR ELECTRO-MECH
A489-4		ACTUATOR ELECTRO-MECH
A489-5	1680-01-013-3229	ACTUATOR ELECTRIC
A551-1		ACTUATOR
A555-1	1680-00-580-0172	ACTUATOR, AILERON TRIM
A555-1A	1680-00-822-0170	ACTUATOR,ELECTRO-MECHANICAL,LINEAR
A555-2		ACTUATOR



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
A555-2A	1680-00-822-0171	ACTUATOR ELECTRO-MECHAN
A555-3		ACTUATOR
A555-4		ACTUATOR
A700AQ4		RELAY CURRENT CUT-OUT
A7111D-2	1610-00-482-7947	Blades
A-751NL	5945-00-029-8412	CONTACTOR, POWER
A800530	1680-00-677-6319	EXTINGUISHER SUB ASSY
A800530-1	1680-01-300-5266	EXTINGUISHER FIRE AIRCRAFT
A80-AAU-8/A	6610-00-774-5656	ALTIMETER PRESSURE
A80AAU8A	6610-00-774-5656	ALTIMETER
A-80MA-1	6610-00-691-0874	ALTIMETER, PRESSURE
A846-6	5945-00-628-6484	RELAY HYBRID
A9550616	1630-00-809-0394	WHEEL, LANDING GEAR
AAU-21A	6610-00-168-0797	ENCODER/ALTIMETER
AAU-27/A	6610-00-160-3226	ALTIMETER, PRESSURE
AAU27A	6610-00-468-1958	ALTIMETER, PRESSURE
AAU-31/A	6610-00-110-3368	PRESSURE ALTIMETER
AAU-31/A-1	6610-01-039-5020	ALTIMETER, PRESSURE
AAU-32A	6610-00-134-5625	ALTIMETER
AAU-8/A	6610-00-722-0967	ALTIMETER, PRESSURE
AAU8A	6610-00-722-0967	ALTIMETER PRESSURE
ABU-8A/A	6610-01-391-9062	ACCELEROMETER, MECHANICAL
AC2031-12		FILTER
AC2291-104	1650-00-067-7094	FILTER,FLUID
AC310064		GYROSCOPE VERTICAL
AC410037	6610-01-311-5872	INDICATOR
AC60742		AXLE MAXARET
AE149-016-99	1660-01-130-4645	CONTROL BOX, ELECTRICAL
AEK3B13200	6625-00-229-0582	AMMETER
AEU-13/A	6620-01-172-6946	TORQUEMETER IND.
AF200	6685-00-514-5061	INDICATOR, CABIN ALTITUDE
AF200A	6685-00-514-5061	INDICATOR, CABIN ALTITUDE
AG34		GENERATOR,TACHOMETER
AI-803CR	6610-01-461-5251	INDICATOR, ATTITUDE
AL 232AS-PC		AIR SPEED INDICATOR
AM-6639/ALR	5985-01-154-9125	AMPLIFIER DETECTOR
AN3203V30	6625-00-235-4782	VOLTMETER
AN5527-3	6620-00-224-3451	TRANSMITTER, RATIO
AN6012-1A	4820-00-528-3264	VALVE
AN6248-2		HAND PUMP
AN6281-8-10		FUSE HYD.
ANUPM33A	6625-00-539-8587	TEST SET RADAR
AP4V-16-01		E.D.P.
AP4V-18		PUMP
AP4V-18-01		PUMP



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
AP4V-18-02		PUMP
AP4V-18-03	4320-01-529-2024	PUMP, HYDRAULIC
ARU-14/A	6610-00-854-9166	INDICATOR, ATTITUDE
ARU-4/A	6610-00-585-9160	INDICATOR, ATTITUDE
AT740A	5985-00-673-5831	MODE 'S' ANTENNA
AV 16B1470C		VALVE MOTOR OPERATED FUEL SHUT OFF
AV16B1139D		VALVE
AV16B1360C		VALVE
AV16B1361C		VALVE
AV16B1362D		VALVE
AV16B1446C		VALVE
AV16B1450D	2915-00-632-7932	VALVE,FUEL SYSTEM
AV16B1451C		VALVE
AV16B1464C	4810-00-627-5271	GATE VALVE
AV16B1467D	2915-00-632-7932	VALVE 1 INCH MOTOR OPERATED FUEL SHUTOFF
AV16B1470C	4810-00-653-7572	GATE VALVE
AV16B1867D	2915-00-632-7932	VALVE FUEL SYSTEM
AV16F1103		HOUSING
AV17B1038D		BUTTERFLY VALVE
AV17B1215D	2915-01-060-1265	VALVE, FUEL SHUT-OFF
AV19E1003-1	4810-01-123-7254	VALVE PRESSURE VENT
AVR743D8	5945-00-729-1244	RELAY UNDER VOLTAGE DC
AVR-743D-8	5945-00-729-1244	RELAY UNDER VOLTAGE DC
AVR869E		PHASE SEQUENCE RELAY
AW1821AC02	6685-00-810-6047	GAGE, HYDRAULIC PRESSURE
AW2017AC01	6685-00-684-1667	GAGE, HYDRAULIC PRESSURE
AW2017AC02	6685-00-972-5920	INDICATOR, BRAKE PRESSURE
AW-2-17-A	6685-00-684-1667	GAGE, PRESSURE
AW-2-17-G	6685-00-684-1667	GAGE, PRESSURE
AW2812AH04	6610-00-798-2241	INDICATOR, AIRSPEED
AYLF50678	6680-01-192-5312	DUCT SENSOR
AYLF50679	1660-00-583-7106	SENSOR, OVERHEAT
AYLF50681	1660-00-583-7058	DUCT SENSOR
AYLF50682	5905-00-588-3477	OVERHEAT SENSOR
AYLF52267	5905-01-396-8551	SENSOR,CABIN TEMPERATURE
B0020-14107	6610-00-911-8295	ALTIMETER, PRESSURE
B118-249	6680-00-918-0273	INDICATOR, LIQUID QTY
B-123B	5945-00-675-7413	CONTACTOR, POWER
B123J	5945-00-675-7413	CONTACTOR, ELECTRIC
B-123J	5945-00-675-7413	CONTACTOR, POWER
B123JA	5945-01-250-9675	RELAY,ELECTROMAGNETIC
B-124K	5945-00-675-7412	CONTACTOR, POWER
B15-945-42-05-11N		CLOCK, AIRCRAFT
B1-A	6610-00-526-4718	INDICATOR, ATTITUDE
B44202-10-002	6610-01-091-3701	PRESSURE ALTIMETER



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
B4515210003	6610-01-038-2081	ALTIMETER, PILOT
B45152-10-003	6610-01-038-2081	ALTIMETER, ENCODING
B45152-10-013	6610-01-477-4148	ALTIMETER
B45152-10-02	6610-01-134-5625	ENCODING ALTIMETER
B4515210103	6610-01-038-2122	ALTIMETER
B45152-10-103	6610-01-038-2122	ALTIMETER, PRESSURE
B-459	5945-01-250-9675	RELAY,ELETROMAGNETIC
B52C22	4810-00-672-1085	VALVE ASSY, WING DUCT P&A
BH187M-4	6685-00-883-4096	INDICATOR
BH187R111	6685-00-573-7407	INDICATOR,TEMPERATURE,SYNCHRO
BTI600-202M	6685-01-356-7401	INDICATOR TEMP
BYLB51044	4810-01-218-2643	VALVE, TEMPERATURE C
BYLB51045	4810-01-219-3417	VALVE TEMP. CONTROL
BYLB51249	4810-01-381-8016	VALVE, AUXILIARY VENT
BYLB7606	4810-00-784-7462	VALVE, MODULATING
BYLB7606-1		VALVE, MODULATING
BYLB9769		VALVE, MODULATING
C12405-00-005	6610-00-073-6828	TRANSMITTER, AIRSPEED
C19A513		ACTUATOR, ROTARY
C-4808/ARC		SELECTOR ANTENNA
C4808ARC	5985-00-902-9935	SELECTOR,ANTENNA
C52C22	4810-00-670-1111	VALVE BUTTERFLY
C55D	6680-00-790-6839	COUNTER, FUEL FLOW
C-7041		AILERON TRIM TAB ACTUATOR
C7041-1	1860-00-088-6102	ACTUATOR,ELECTRO-MECHANICAL,LINE
C7041-2	1680-00-981-7652	ACTUATOR, ELECTRO-ME
C7088-1A	1680-00-789-9345	WING FLAP GEARBOX
C7088-93		BRAKE ASSY, FLAP DRIVE
C-823/AIC-10		INTERPHONE CONTROL
C-824A/AIC-10	5831-00-519-5883	INTERCOM CONTROL PANEL
C-826/AIC-10		INTERCOM CONTROL PANEL
CA59100-0011		ACTUATOR
CA75810-0001	3010-33-001-8008	ACTUATOR,HYDRAULIC
CA84500-0010	3010-33-001-9625	ACTUATOR, HYDRAULIC
CB-2100-T4	6605-00-663-5637	COMPASS, MAGNETIC
CG12112	5930-00-642-9386	SWITCH, PRESSURE
CG12313	5930-00-965-7111	SWITCH PRESSURE
CSV4092-3	6110-01-344-0377	GENERATOR GONCORL UNIT
CYLB51055		CHECK VALVE
CYLB51063	4820-00-356-1040	VALVE, CHECK
CYLZ4271-2	1660-00-697-0846	CONTROL BOX, ELECTRICAL
D1093-02-1	6615-00-967-0480	SYNCHRONIZER, ELECTRICAL
D22061-04-004	6610-00-649-8380	ALTIMETER, PRESSURE
D22061-04-010	6610-00-649-8380	ALTIMETER, PRESSURE
D25-05		REGULATOR



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
D52C22	4810-00-601-3146	WING ISOLATION VALVE
D5725	3010-00-635-4730	ACTUATOR, LANDING LIGHT
D5725-1	6105-01-177-5691	MOTOR, LANDING LIGHT
D5725-2	6105-00-350-6922	MOTOR, LANDING LIGHT
DF-206	6220-01-466-8702	PANEL, INDICATING, LIGHT
DL1326M11		ACTUATOR,ELECTRO-MECHANICAL,LINE
DL1431M2	1680-00-497-0426	ACTUATOR, APU INLET DOOR
DM24M-H1	5930-00-621-4524	SWITCH,FUEL PRESSURE
DM24MH2	5930-00-629-6660	SWITCH,FUEL PRESSURE
DRA45C8		SWITCH, AIR SPEED
DSL-50	6680-00-828-7610	INDICATOR LOX
DST29-1	6685-00-066-4581	INDICATOR, TEMPERATURE
DST29-2	6685-00-066-4581	INDICATOR TEMPEARTURE
DST-29-2		THERMO TEMP. IND.
DST29-3		TEMP TURBINE INDICATOR
DT-310/AJN	6605-00-632-0667	TRANSMITTER, INDUCTION
DYL26263		VALVE
DYLM43403-2		VALVE
DYLM43700-4		VALVE, TEMPERATURE CONTROL
DYLZ3990		VALVE
DYLZ3990-1		VALVE
DYLZ3990-2		VALVE
DYLZ3990-3	1660-00-690-6150	VALVE ENVIRONMENTAL CONTROL
DYLZ-3990-3		VALVE
DYLZ3990A		VALVE
DYLZ3991		VALVE
DYLZ3991-1		VALVE
DYLZ3991-2	4810-05-224-595	VALVE ASSEMBLY
DYLZ3991-3	4810-00-682-5374	VALVE CONTROL
DYLZ-3991-3		VALVE
DYLZ3991A		VALVE
E0724104003	6610-00-585-1524	INDICATOR, TRUE AIR SPD
E07241-04003	6610-00-585-1524	AIRSPEED INDICATOR
E07241-04-003	6610-00-585-1524	INDICATOR, TRUE AIR SPEED
E07241-10-003	6610-00-834-0713	INDICATOR, AIRSPEED
E07241-10-004	6610-01-393-1139	INDICATOR, AIRSPEED
E07243-10-002	6610-00-834-0713	INDICATOR, AIRSPEED
E2206104016		ALTIMETER
E22061-04-016		PRESSURE ALTIMETER
E-384	5945-00-628-6484	RELAY,HYBRID
E52C22	4810-00-601-1070	VALVE,BUTTERFLY
E6011M13-13	6105-00-698-5927	MOTOR DIRECT CURRENT
E6015M564-1	6105-00-794-0008	MOTOR AND BRAKE ASSEMBLY
E6015M64-1	6105-00-794-0008	MOTORANDBRAKEASSEMBLY,DC
E97241-04-003	6680-00-740-7044	INDICATOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
EA100ANH144	6680-00-580-9557	INDICATOR LIQUID
EA100ANH-172	6680-01-394-2556	INDICATOR, LIQUID QTY
EA-1045-037-1		AUXILIARY PUMP UNIT,AXIAL PISTONS
EA-1045-037-1A		AUXILIARY PUMP UNIT,AXIAL PISTONS
EA1045-037-2	4320-00-072-2291	PUMP,AXIAL PISTONS
EA-1045-037-2		AUXILIARY PUMP UNIT,AXIAL PISTONS
EA1045-037-2B	4320-00-949-6842	PUMP, HYD ELECT MOTOR
EA-1045-037-2B		AUXILIARY PUMP UNIT,AXIAL PISTONS
EA-1045-039-2A		AUXILIARY PUMP UNIT,AXIAL PISTONS
EA1045-837-2B		ELECTRIC MOTOR DRIVE
EA1065AW2315		TRANSMITTER, LIQUID QUANTITY
EA1065AW-2315		FUEL QUANTITY TANK UNIT
EA1204		CYLINDER ASSEMBLY, AILERON BOOSTER
EA1205		DUAL RUDDER BOOSTER ACT
EA1205-1		DUAL RUDDER BOOSTER ACT
EA1261-1		CYLINDER
EA1261-2		CYLINDER
EA1320-442	4320-00-152-1488	PUMP,AXIAL PISTONS
EA1320-442-1	4320-00-949-6840	AUXILIARY PUMP UNIT,AXIAL PISTONS
EA326-15	6610-00-808-7038	INDICATOR, POSITION
EA326-15A	6610-00-808-7038	INDICATOR, POSITION
EA326-2	6610-00-557-0894	INDICATOR, POSITION
EA326-8	6610-00-580-9690	INDICATOR, POSITION
EA327-3	6610-00-531-5417	INDICATOR, POSITION
EA573A1	6610-00-530-0961	TRANSMITTER, FLAP POSITION
EFU-4/A	6620-00-621-2903	INDICATOR, RATE OF FUEL FLOW
EFU-5/A	6620-00-621-2904	INDICATOR, RATE OF FUEL FLOW
EHU11AA	6685-00-580-4732	EGT, INDICATOR
EHU-15/A	6685-00-897-8400	INDICATOR, TEMPERATURE
EHU-15A/A	6685-00-945-4979	INDICATOR, TEMPERATURE
EHU15AA	6685-00-945-4979	INDICATOR TEMPERATURE THEROCOUPLER
EHU-9/A	6685-00-226-6612	INDICATOR
EKCC18043	6685-00-692-8341	INDICATOR, TEMPERATURE
EKCC-18043	6685-00-692-8341	INDICATOR
EN30-2217-1	6220-01-426-4360	LIGHT, NAVIGATIONAL
F60W0232		VALVE, FUEL
F60W0232M1	2915-00-574-3227	VALVE,FLOAT,AIRCRAFT FUEL TANK
F60W0233		VALVE
F60W0233M1	2915-00-581-0477	VALVE INBOARD FUEL
FG450A52	6680-01-059-3386	COMPENSATOR FUEL
FS20	6105-01-108-2427	MOTOR DIRECT CURRENT
FS-9506B-4	5955-01-435-5551	NONCRYSTAL CONTROLLED OSCILLATOR
G-10	6685-00-005-9024	INDICATOR, OUTSIDE AIR TEMPERATURE
G5400-1	6220-00-299-4621	LANDING LIGHT ASSY.
G-5400-1		LANDING LIGHT



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
G5400-2		LIGHT, LANDING
G5400-3		LANDING LIGHT ASSY
G-5400-3		LANDING LIGHT
G5400-4		LIGHT, LANDING
G5400-5	6620-00-893-8777	LIGHT, LANDING
G-5400-6		LANDING LIGHT
G6965		LIGHT
G6965-22	6220-00-346-6820	LIGHT, ROTATING BEACON
G-6965-22		LIGHT, ANTI-COLLISION
G6965-34	6220-00-548-0008	LIGHT, ANTI-COLLISION
G-6965-34		LIGHT,NAVIGATIONAL,AIRCRAFT
G6965-6		LIGHT
G6965-8		LIGHT
G-6965-8	6220-00-421-9109	WARNING NAV LIGHT
G7406-10		VHF COMMUNICATION CONTROL PANEL
G7418-13		CONTROL PANEL VHL
GEU7A	6680-00-585-1503	TACHOMETER GENERATOR
GG2479AB01	6615-00-137-6038	GYROSCOPE, RATE
GG2-79	6615-00-137-6038	GYROSCOPE, RATE
GMU-11/A	6680-00-828-6559	INDICATOR
GMU-28	6680-00-105-9527	INDICATOR, LIQUID QUANTITY
GMU-28/A	6680-00-993-3435	INDICATOR, LIQUID QUANTITY
GMU-28A/A	6680-00-937-0429	INDICATOR, LIQUID QUANTITY
GP20-15	6620-01-328-6940	GAUGE, PRESSURE DIAL
GPS MAP 295		GPS MAP 295
GTC85-71A		GAS TURBINE COMPRESSOR
GYLC4369		ACTUATOR
GYLC4369-1		ACTUATOR
GYLC9102		ACTUATOR
GYLC9103		ACTUATOR
H60G0398		VALVE
HIR01987-020	1620-00-574-3346	CYLINDER ASSEMBLY
HIR01987-028		CYLINDER
HIR01987-033-1		NLG STRUT ASSY
HIR01988-007-1		PISTON ASSEMBLY
HP367100		VALVE
HP558100-1		VALVE
ID-250A/ARN	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
ID-525/ARN	6610-00-851-8727	INDICATOR, ILS, RUNWAY
ID-663/U	5826-00-882-1203	INDICATOR, BEARING DISTANCE
IVA-81D		INDICATOR,VERTICAL SPEED / TCAS
J23059687		AMPLIFIER, TEMPERATURE DATUM
JG3B9	6680-00-526-8284	INDICATOR, LIQUID QUANTITY
JG40242-7	6680-00-580-1247	INDICATOR LIQUID WING
JG402A2	6680-00-580-1247	FUEL QTY IND



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
JG402A3	6680-00-580-1246	INDICATOR, LIQUID QU
JG402A32	6680-00-866-5116	INDICATOR, LIQUID QUANTITY
JG402A4	6680-00-580-1248	FUEL QTY IND
JG402A52	6680-01-056-1779	FUEL QTY IND
JG402A53	6680-01-060-5228	FUEL QTY IND
JG402A-53	6680-01-060-5228	FUEL QTY IND
JG402A54	6680-01-058-5859	FUEL QTY IND
JG402A-54	6680-01-058-5859	INDICATOR
JG402A55	6680-01-058-5860	FUEL QTY IND
JG412A1	6680-00-580-1249	INDICATOR, FUEL QUANTITY
JG412A10	6680-00-849-7809	INDICATOR, FUEL QUANTITY
JG412A11	6680-00-865-7930	INDICATOR, FUEL QUANTITY
JG412A2	6680-00-585-5859	INDICATOR, FUEL QUANTITY
JG412A3		FUEL QTY IND - ROUTINE
JG412A4	6680-00-585-8600	INDICATOR, LIQUID QUANTITY
JG412A-52	6680-01-063-0597	INDICATOR LIQUID QTY
JG412A53		FUEL QTY IND
JG412A-53	6680-01-058-5861	INDICATOR LIQUID QTY
JG412A-54	6680-01-058-5862	INDICATOR LIQUID QTY
JG412A-55	6680-01-342-7698	INDICATOR LIQUID QTY
JG412A56	6680-01-058-5864	FUEL QTY IND
JG412A-56	6680-01-058-5864	INDICATOR LIQUID QTY
JG7044A37	6615-00-556-8024	CAGEABLE VERTICAL GYRO
K-3	6610-01-067-0228	INDICATOR, AIRSPEED
K51004		CYLINDER ASSEMBLY, ELEVATOR BOOSTER
K51004-3		CYLINDER ASSEMBLY, ELEVATOR BOOSTER
K51004-4	1650-00-609-0551	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
K51004-6	1650-00-799-8564	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
KTD0701K	6680-00-452-6315	INDICATOR, TACHOMETER
L10-107		ACTUATOR
L16-107		ACTUATOR ELECTRO-MECH
L16-8		ACTUATOR
L16-8-1	1680-00-720-5810	ACTUATOR ELECTRO-MECH LINEAR
L16-8-2		ACTUATOR
L16-8-3	1680-00-720-5810	ACTUATOR ELECTRO-MECH
L16-8-5	1680-01-378-1631	ACTUATOR ELECTRO-ME
L8602772-1	2935-01-440-9157	COOLER, LUBRICATING
LE452-0032	5930-01-413-8954	SWITCH ASSEMBLY
LE452-0038-0001	5930-01-436-0623	SWITCH ASSEMBLY
LO3P1	5950-00-880-6005	TRANSFORMER POWER AUTO TRANSFORMER
M1-A	6610-00-585-1524	INDICATOR, AIRSPEED
M-1A	6610-00-557-3096	INDICATOR, AIRSPEED
M2901A-1B	4140-00-814-5758	FAN VANE AXIAL
M30423A	6105-00-775-6054	MOTOR, FAN
M3500-5	6610-00-912-3572	INDICATOR, TURN & SLIP



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
M5921A1B	4140-00-717-5277	FAN,VANEAXIAL
M5921A-1B	4140-00-717-5277	FAN VANEAXIAL
M9201A1B		FAN ASSY
M9201A-1B	4140-00-814-5758	FAN, RECIRCULATING
M9201A2A1		FAN ASSY
MA-1	6610-00-684-1666	ACCELEROMETER, MECHANICAL
MA11A1024B	4810-01-237-2269	ACTUATOR
MA-7	6620-01-038-5769	INDICATOR, RATE OF FUEL FLOW
MA-7/A	6620-01-391-2998	INDICATOR, RATE OF FUEL FLOW
MA-8	6620-00-551-1270	INDICATOR, RATE OF FUEL FLOW
MB-1		TRANSMITTER, RATE OF FUEL FLOW
MB-6	6620-00-553-8892	GENERATOR, TACHOMETER
MC-1	6615-00-618-9297	GYROSCOPE, RATE
MD-1	6615-00-973-2218	GYROSCOPE, DISPLACEMENT
MD-2	6615-01-065-7226	GYROSCOPE, DISPLACEMENT
MF-2	6665-01-080-6508	INDICATOR
MF30-3913-25ZE5		MOTOR ASSEMBLY, HYDRAULIC
MF30-3913-30ZE5	1650-00-204-1703	MOTOR,HYDRAULIC
MF30-3913-30ZE-5	1650-00-204-1703	MOTOR, HYD
MF9-3911-30Z	1650-00-508-7109	HYDRAULIC MOTOR, FLAP
MF93911-30ZE	4320-01-224-9869	MOTOR,HYDRAULIC WING FLAP
MF9-3911-30ZE		HYDRAULIC MOTOR, FLAP
MF9-3911-30ZS481	1650-00-815-9387	HYDRAULIC MOTOR, FLAP
MF9-3911-30Z-S481	1650-00-815-9387	MOTOR HYDRAULIC
MGE23-340	6125-01-101-3723	INVERTER
MGE23-400	6125-00-020-3217	INVERTER
MGE23-400A	6125-00-020-3217	INVERTER
MGH548-1	6125-00-020-3217	MOTOR, GENERATOR
MIL-A-5498	1650-00-517-8849	ACCUMULATOR, UTILITY SYSTEM
MIL-C-27336	1660-00-768-5256	CONVERTER LIQUID OXYGEN
MILI5356	6610-00-663-8723	INDICATOR AIRSPEED
MILT38394	6620-00-901-7848	TRANSMITTER, PRESSURE
MJ-1	6685-00-087-8229	TRANSMITTER, PRESSURE
MM-4	6610-00-557-3030	INDICATOR, ATTITUDE
MNI300	6610-00-543-1402	INDICATOR, ILS, RUNWAY
MPEV3-032-2	4320-00-174-5811	HYD AUX ELEC PUMP
MPEV3-032-2A	4320-00-174-5811	HYD AUX ELEC PUMP
MS17983-2	6605-00-551-8187	COMPASS
MS24140-D1		RELAY
MS24182-D1		RELAY
MS24332-1	6625-00-538-9683	VOLTMETER
MS24332M1		VOLTMETER
MS24478-2	6685-00-557-5317	INDICATOR, GAGE PRESSURE
MS24569-1	6685-00-183-0351	INDICATOR, TEMPERATURE
MS25025-1	6625-00-544-5899	INDICATOR, LOADMETER



**WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST**

PARTNO	NSN	ITEM_NAME
MS25038-4	6620-00-553-8892	TACH GENERATOR
MS28000-1	6620-00-515-4541	INDICATOR, TACHOMETER
MS28005		TRANSMITTER
MS28005-1		TRANSMITTER
MS28005-3		PRESSURE TRANSMITTER
MS28005-4	6620-00-557-0385	TRANSMITTER, PRESSURE
MS28005-5	6685-00-526-7881	TRANSMITTER, PRESSURE
MS28005-8	6685-00-526-7864	TRANSMITTER, PRESSURE
MS28005-8T		TRANSMITTER, PRESSURE
MS28009-1	6685-00-557-0370	INDICATOR, TEMPERATURE RATIO
MS28009-2	6685-00-514-5327	INDICATOR, TEMPERATURE
MS28009-4	6685-00-514-5327	INDICATOR, TEMPERATURE
MS28010-5	6685-00-557-0215	INDICATOR PRESS
MS28023-1	6610-00-515-4600	INDICATOR, POSITION
MS28027-1	5820-00-505-3094	INDICATOR, RADIO MAGNETIC
MS28036-1	6610-01-393-1139	INDICATOR, AIRSPEED
MS28041-1A	6610-00-912-3572	INDICATOR, TURN & SLIP
MS28046-T1	6610-00-899-7445	INDICATOR, AIRSPEED
MS28049-1	6610-00-530-0028	INDICATOR, VERTICAL SPEED
MS28054-2	6620-00-551-3825	GENERATOR, TACHOMETER
MS28075-1	6610-00-473-5046	INDICATOR, VERTICAL
MS28075-1B	6610-01-346-2795	INDICATOR, VERTICAL
MS28700-1	1650-00-640-8485	ACCUMULATOR, HYD
MS28700-2	1650-00-640-8491	ACCUMULATOR
MS28-700-2		HYDRAULIC ACCUMULATOR
MS28700-4		ACCUMULATOR
MS28700-5		ACCUMULATOR
MS28720-12		FILTER
MS28720-6		FILTER
MS28797-4		ACCUMULATOR, UTILITY SYSTEM
MU-1	6620-00-557-3023	TACHOMETER
N1335C	5821-01-384-4435	DECODER,AUDIO FREQUENCY
N400-4B3		MOTOR
N400-4B4		MOTOR
NA135		DECODER AUDIO FREQUENCY
NYLC51168		VALVE, TEMPERATURE CONTROL
NYLC51188		VALVE, TEMPERATURE CONTROL
PS75427	5930-00-557-1811	SWITCH,OIL PRESSURE
PV3-075	4320-00-404-1977	PUMP AXIAL VICKERS
PV3-075-16		PUMP ASSEMBLY, HYDRAULIC
PV3-075-4	4320-00-404-1977	PUMP
PYLB51239-1	4810-01-237-5974	VALVE,SOLENOID
PYLB51239-2	4810-01-237-5974	VALVE,SOLENOID
R5170M34-2		ACTUATOR
R5170M34-3	1680-00-474-3300	ACTUATOR GTC DOOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
R5170M34-4	1680-00-426-5616	ACTUATOR GAS TURBINE COMP
R73-2004-42-2A	1680-00-677-3666	REGULATOR, ENGINE CABLE TENSION
R73-2004-42-3A	1680-00-005-3320	REGULATOR, ENGINE CABLE TENSION
R73-2008-42-00	1680-00-863-8721	REGULATOR, ENGINE CABLE TENSION
R73-2008-42-1		TENSION REGULATOR
R73-2008-42-1A		REGULATOR, ENGINE CABLE TENSION
R84-1001-48-4A		REGULATOR CABLE TENSION
RC-60	6610-00-530-0028	INDICATOR, VERTICAL SPEED
RC-60MS	6610-00-291-7040	INDICATOR, VERTICAL SPEED
RC-60-MS		RATE OF CLIMB INDICATOR
RC-60MS-10-3	6610-00-951-4451	INDICATOR, VERTICAL SPEED
RC-60-MS-AAU-9/A	6610-00-804-6312	INDICATOR, RATE OF CLIMB
RCS-60-1L	6610-00-473-5046	INDICATOR, VERTICAL
RD-301A		RADAR TEST SET COLOR BEN
RG14D3		TOTALIZER
RG14D7	6680-00-860-6390	TOTALIZER
RG15A1	6680-00-310-3305	TOTALIZER, FUEL QUANTITY
RG-3-11		RATE OF TURN SENSOR
RG-9680C	4310-00-568-1532	COMPRESSOR WITH ROTARY
RR11620-1	2915-00-983-1001	PUMP SUBMERGED C130
RR11620-2		PUMP, FUEL BOOST
RR11620-3	2915-00-983-1001	FUEL BOOST PUMP
RR11640		PUMP, FUEL BOOST
RR11640-1	2915-01-506-2354	Pump, Centrifugal Fuel Booster
RR11640A		PUMP, FUEL BOOST
RR11640A1	2915-01-196-4362	PUMP SUBMERGED AIRCRAFT
RR11640A3		PUMP, SUBMERGED AIRCRAFT
RR11640D		PUMP, FUEL BOOST
RR11640D1		PUMP, FUEL BOOST
RR11640-D1	2915-01-196-4362	PUMP, SUB
RR52780A	2915-00-382-9088	PUMP,BOOST
RYLC51046	1680-01-222-3117	ACUTATOR
RYLC51047		ACTUATOR
RYLC51047-1	1680-01-221-8261	ACTUATOR, PARATROOP, SPOILER DOOR
RYLC51047-10	3040-01-423-0504	ACTUATOR, PARATROOP, SPOILER DOOR
S369-100		ACCUMULATOR
S369-50		ACCUMULATOR
S4000	5825-01-619-8508	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
S4000-1	1650-00-592-7890	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
S4000-2	1650-00-675-2631	CYLINDER ASSEMBLY, ELEVATOR BOOSTER
S462-25		ACCUMULATOR
S462-50		ACCUMULATOR
S463-100		ACCUMULATOR
S463-50		ACCUMULATOR
S477-100		ACCUMULATOR



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
S477-200		ACCUMULATOR
S477-50		ACCUMULATOR
S512-25		ACCUMULATOR
S512-50-1	1650-00-516-2100	ACCUMULATOR, UTILITY SYSTEM
S512-50-2	1650-00-721-6415	ACCUMULATOR, UTILITY SYSTEM
S-512-50-2	1650-00-721-6415	ACCUMULATOR
S513-100		ACCUMULATOR
S-513-100-2	1650-00-640-8486	ACCUMULATOR, UTILITY SYSTEM
S513-100-2T		ACCUMULATOR
S513-200		ACCUMULATOR
S513-200-2T		ACCUMULATOR
S513-50		ACCUMULATOR
S513-50-2T		ACCUMULATOR
S618-A		ACCUMULATOR
S65-5366-2L		MODE 'C' ANTENNA
S65-8280-10		VHF ANTENNA LOWER
SBK-8A/24G-1A	6615-00-994-2152	GYROSCOPE, DISPLACEMENT
SK1093	6615-00-967-0480	SYNCHRONIZER, ELECTRICAL
SK-40LC	6610-01-096-4601	INDICATOR, AIRSPEED
SK40LC1	6610-01-109-5105	Max Allowable Airspeed Ind
SLZ3501		TRANSMITTER, ANGLE OF ATTACK
SPL5568-3	3040-00-566-0336	ACTUATOR,MECHANICAL,LINEAR
SR151A	6685-00-515-3996	PRESSURE INDICATOR
SR152A	6685-00-526-5625	PRESSURE INDICATOR
SR-3A	6620-00-557-0362	INDICATOR
SR-3C	6620-00-060-0549	INDICATOR
SR-4A	6620-00-557-0350	INDICATOR
SR-4B	6620-00-557-0363	INDICATOR
SR-5A	6620-00-526-6120	INDICATOR, PRESSURE
SR-6A	6620-00-514-5334	INDICATOR, PRESSURE
SR-7A	6620-00-557-0214	INDICATOR, PRESSURE
SR-8B	6620-00-557-0816	INDICATOR, PRESSURE
SR-9A	6620-00-526-8272	INDICATOR, PRESSURE
SRA-14A	6620-00-526-8273	INDICATOR, TORQUEMETER
SRA-14E	6620-00-581-2278	INDICATOR, TORQUEMETER
SRD-4A	6685-00-678-2948	INDICATOR, DUAL OIL PRESSURE
SRD4B	6685-00-678-2948	INDICATOR PRESSURE
SRD-4B	6685-00-678-2948	DUAL OIL PRESS IND
SRD-4G	6620-00-811-7614	INDICATOR, DUAL OIL PRESSURE
SRD-7C	6685-00-531-2741	INDICATOR, DUAL HYDRAULIC PRESSURE
SSD12042A		Altitude Encoding Digitizer
SSD120-42A		ALTIMETER ENCODE
ST104A	6620-00-901-7848	TRANSMITTER PRESSURE
ST-104A		OIL PRESS TRANS
ST-104A1	6685-00-821-7351	TRANSMITTER, PRESSURE



WINGS AEROSPACE, LLC
C-130 REPAIR/OVERHAUL CAPABILITIES LIST

PARTNO	NSN	ITEM_NAME
ST-207A	6685-00-087-8229	TRANSMITTER, PRESSURE
ST-6B	6620-00-553-8988	INDICATOR, PRESSURE
ST-6C	6685-00-756-5671	TRANSMITTER, PRESSURE
ST-7C	6685-00-526-7864	TRANSMITTER, PRESSURE
ST-7D		HYD PRESS TRANS
STU-1/A		STARTER
SYLZ50191-000	1660-00-147-1009	CONTROL BOX, ELECTRICAL
SYLZ50212	1660-00-130-0048	CONTROL BOX, ELECTRICAL
SYLZ50683-1	1660-01-126-1784	CONTROL BOX, ELECTRICAL
SYLZ50684	1660-01-121-7386	CONTROL TEMP
SYLZ50685	1660-01-021-4981	CONTROL BOX, ELECTRICAL
T1580S3A	5342-00-881-1719	CLAMP ASSY - ENG TAIL PIPE
TED9-464-40		INDICATOR , FUEL
TG255-007	6680-00-923-8466	TACH GENERATOR
TP25-2A		AIR TURBINE DRIVE
TP25-2B		AIR TURBINE DRIVE
TP25-2C		AIR TURBINE DRIVE
TR-349/A	6685-01-373-2860	TRANSMITTER, PRESSURE
TRK-56/A27J-1	6685-00-526-7864	TRANSMITTER, PRESSURE
TRK56A27J1	6685-00-990-5746	TRANSMITTER, PRESSURE
TS5106UPX	6625-01-156-6940	TEST SET
TS-585/U	6625-00-151-4230	WATTMETER
UA524240-1	2915-00-789-1102	FUEL HEATER
UA534149-19	1650-01-065-3500	COOLER, HYDRAULIC
UA534149-21	1650-01-227-5464	COOLER, HYDRAULIC
UA538795-3	1650-01-228-8118	COOLER, HYDRAULIC OIL
UPX-27N	5895-01-206-7147	INTERROGATOR SET
V3900-11		VALVE SOLENOID
W1206-2		POWER SUPPLY
W33-7545-10	6645-00-089-7903	CLOCK AIRCRAFT
WJ2854-15A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
WJ2854-31A	5955-01-393-2390	NONCRYSTAL CONTROLLED OSCILLATOR
X702-102		FAN
XW20058M1	6105-00-630-5828	WIPER MOTOR
XW20058-M1	6105-00-630-5828	WIPER MOTOR
XW20173M1	6105-00-789-5575	WINDSHIELD WIPER MOTOR ASSEMBLY
XW20173-M1		WINDSHIELD WIPER MOTOR ASSEMBLY
XW-20173-M1		WINDSHIELD WIPER MOTOR ASSEMBLY
XW20345-318-46	1680-00-712-0716	CONVERTER, WINDSHIELD WIPER
XW20345-318-58		CONVERTER, WINDSHIELD WIPER