

## GENEFORCE INSTRUCTIONS

1. Maintain the GENEFORCE plugged into a 120v wall socket at all times. It will sense a power failure through the plug.
2. Always maintain the **CHARGE** button ON. It will shut OFF independently.
3. To view the Battery State, press **CHARGE** button.
4. Connect equipment directly into the 4 electrical output sockets or use a surge protector.
5. During a power failure, press the **INVERT** button, and the GENEFORCE will provide electricity within 1 second. Also, pressing the **INVERT** button switches the GENEFORCE into automatic stand-by mode. During power failures, the GENEFORCE automatically turns ON without pressing the **INVERT** button.
6. When the power is restored, the Geneforce will begin charging automatically. If not on, be sure to press **CHARGE** button after the power has been restored to the facility. It will ensure a long lasting GENEFORCE.