

Valves and Valve Accessories

Metal valves, Truck nickel-plated, for European style Alcoa alloy rims



156176



156177



156141



156167



562 6830

Ref. No.	Description	Rim hole	Installation torque	ETRTO No.	Bending angle
156176	Metal valve, 40 MS	9.7mm	8 - 5nm		
156177	Metal valve, 54 MS	9.7mm	9 - 5nm		
156141	Metal valve, 70 MS	9.7 mm	3 - 5 Nm	n/a	7 °
156167	Metal valve, 60 MS	9.7 mm	12 - 15 Nm	n/a	27 °
562 6830	Metal valve, 70 MS	9.7 mm	12 - 15 Nm	V3-20-5	27 °

Metal valves, Truck for European steel wheels



156146



156145



156272



156270, 156271



562 6829, 156266



156273
156268



156150



156276

Ref. No.	Description	Rim hole	Installation torque	ETRTO No.	Bending angle
156146	Metal valve, V-8135 LU	9.7 mm	13 - 15 Nm	V3-22-1	45 °
156145	Metal valve, V-8135 L-NI	9.7 mm	13 - 15 Nm	V3-22-1	45 °
156272	Metal valve, V-8102, 41 MS	9.7 mm	13 - 15 Nm	V3-20-1	
156161	Metal valve, 70 MS	9.7 mm	13 - 15 Nm	V3-20-5	27 °
156270	Metal valve, V-8108, 80 MS	9.7 mm	13 - 15 Nm	n/a	
562 6829	Metal valve, V-8138, 80 MS	9.7 mm	13 - 15 Nm	V3-20-10	27 °
156271	Metal valve, V-8110, 90 MS	9.7 mm	13 - 15 Nm	V3-20-3	
156266	Metal valve, V-8140, 90 MS	9.7 mm	13 - 15 Nm	V3-20-4	27 °
156273	Metal valve, V-8141, 97 MS	9.7 mm	13 - 15 Nm	V3-20-2	27 °
156275	Metal valve, V-8113, 102 MS	9.7 mm	13 - 15 Nm	V3-20-11	
156150	Metal valve, V-8183, 102 MS	9.7 mm	13 - 15 Nm	V3-20-11	27 ° double bend
156276	Metal valve, V-8143A, 102 MS	9.7 mm	13 - 15 Nm	V3-20-12	27 °
156268	Metal valve, V-8145, 115 MS	9.7 mm	13 - 15 Nm	V3-20-6	27 °
156274	Metal valve, V-8111, 97 MS	9.7 mm	13 - 15 Nm	V3-20-2	

Valves and Valve Accessories

Metal valves, Truck standard, for American style steel wheels



563 5016, 156250



170120



156153



563 5023 563 5030, 156262,
563 5054, 563 5057

Ref. No.	Description	TR No.	Rim hole	Installation torque	ETRTO No.
563 5016	Metal valve, 54 MS	TR 500	16 mm	4 - 6 Nm	V3-21-3
156250	Metal valve, 42 MS	TR 501	16 mm	4 - 6 Nm	V3-21-2
170120	Metal valve V-8717 NI	TR 510	16mm	4 - 6 Nm	
156153	Metal valve V-8738 NI	TR 515	16mm	4 - 6 Nm	
563 5023	Metal valve, 84 MS	TR 570	16 mm	4 - 6 Nm	V3-21-4
563 5030	Metal valve, 89 MS	TR 571	16 mm	4 - 6 Nm	V3-21-5
156262	Metal valve, 90 MS	TR 572	16 mm	4 - 6 Nm	V3-21-6
563 5054	Metal valve, 114 MS	TR 573	16 mm	4 - 6 Nm	V3-21-7
563 5057	Metal valve, 132 MS	TR 574	16 mm	4 - 6 Nm	V3-21-8
563 5022	Metal valve, 90° bend	TR 570	16 mm	4 - 6 Nm	V3-21-9

Metal valves, Truck for European style wheels



156143



156278



570 9992



257160



570 9997



562 6939

Ref. No.	Description	Rim hole	Installation torque	ETRTO No.	Bending angle
156143	Metal valve, V-0-09-3 Scania	16 mm	9 - 14 Nm	V-0-09-3	174 °
156278	Metal valve, V-8802	16 mm	9 - 14 Nm		
570 9992	Metal valve, V-8834	16 mm	9 - 14 Nm	V-3-13-1	153 °
257160	Metal valve, 1161/TACA8 TT8844B	16 mm	9 - 14 Nm	V-3-14-3	147 ° double bend
570 9997	Metal valve, TT8844B	16 mm	9 - 14 Nm	V-3-14-3	147 ° double bend
562 6939	Metal valve, V-8984	20.5 mm	9 - 14 Nm	V-3-17-2	172 °

Metal valves, Truck for European style wheels - continued



170120



570 9995

Ref. No.	Description	Rim hole	Installation torque	ETRTO No.	Bending angle
170120	Metal valve, V-8717	16 mm	9 - 14 Nm		
570 9995	Metal valve, V-8845A	16 mm	9 - 14 Nm	V-3-14-2	147 °



156040

Snap-in valves for air/water filling



Ref. No.	Description	Rim hole	Length
156040	Snap-in valve	16 mm	56 mm

Metal valves for air/water filling



562 3080



562 3082



562 3114, 562 3097



562 3107



562 3066



562 3042

Ref. No.	Description	TR No.	Rim hole	Length	ETRTO No.	Bending angle
562 3080	Metal valve	TR 618 A	16 mm	50 mm	V5-01-1	
562 3082	Metal valve, Haltec	TR 618 A	16 mm	50 mm	V5-01-1	
562 3114	Metal valve	TR 623 A	16 mm	57 mm	V5-02-3	65°
562 3097	Metal valve	TR 621 A	16 mm	75 mm	V5-02-1	65°
562 3107	Metal valve	TR 622 A	16 mm	115 mm	V5-02-2	90°

Accessories:

562 3066 Core housing, V594

562 3042 Core housing, V595



562 3138

103919



103917

Water filling and draining fittings



Ref. No.	Description
562 3138	Water filler V599
103917	Water filler (front) N1091
103919	Water filler (rear) 2346
156032	Rim nut, V-175, 19mm
156249	Rim hole plug, V-720

Earthmover Valving (LB / SLB)

Earthmover valves, straight



Ref. No.	Description	Type
562 9709	Valve EM	TR J670
562 9711	Valve EM	H-42



562 9709

Earthmover valves, turret type



Ref. No.	Description	Type
156420	Valve EM	J690 V-944-119 Turret
156424	Valve EM	EXJ-69BB Turret
156425	Valve EM	EXJ-690B/1 Turret
156426	Valve EM	EXJ-691 Turret
156427	Valve EM	EXJ-691/2 Short Turret
562 9641	Valve EM	WH-330-J-691B Turret



156420, 156426

Earthmover valves, swivel stem



Ref. No.	Description	Type	Bending angle
562 9637	Valve EM	V-960 J650	80°
562 9644	Valve EM	V-962 J651	90°
562 9747	Valve EM	V-930-64	90°
156335	Valve EM	EXJ-4003	90°
156345	Valve EM	EXJ-4004	90°
156350	Valve EM	EXJ-4004 1/2	90°
156355	Valve EM	V-930-127	90°
156370	Valve EM	V-930-153	90°
156390	Valve EM	V-930-200	90°
156384	Valve EM	EXJ-4008 3/4	90°
156388	Valve EM	EXJ-4010	90°
156395	Valve EM	V-930-356	90°
156397	Valve EM	EXJ-4018	90°
156308	Valve EM	V-930-500	90°
156399	Valve EM	EXJ-4022	90°
156401	Valve EM	EXJ-4024	90°
156402	Valve EM	EXJ-4025 1/2	90°
156405	Valve EM	V-930-710	90°
156400	Valve EM	WH-45-34	90°



562 9637



156355

Earthmover valves, swivel stem - continued



Ref. No.	Description	ETRTO No.	Bending angle
156341	Valve EM	EXJ-52-2	25°
562 9638	Valve EM	EXJ-650	80°
562 9640	Valve EM	WH-300-J650	80°
562 9749	Valve EM	WH-300-J653	80°
562 9660	Valve EM	WH-49-J654	60°
156352	Valve EM	WH-45-4 1/2	90°
156357	Valve EM	WH-45-5	90°
156372	Valve EM	WH-45-6	90°
562 9761	Valve EM	V-930-191	90°
156392	Valve EM	WH-45-8	90°
103050	Valve EM	EXJ-654	60°
103042	Valve EM	EXJ-4028	90°
103046	Valve EM	WH-58-2 1/2	60°
103047	Valve EM	EXJ-54-20	90°
103053	Valve EM	EXJ-4036	90°
156343	Valve EM	WH-55-2 1/2	90°

Earthmover valves, swivel stem, multi-bend



Ref. No.	Description	Type
103043	Valve EM	WHG-0570VC
103044	Valve EM	WHG-8018VC
103045	Valve EM	WHG-8019VC

Valves and Valve Accessories

Earthmover valve accessories



103062



562 9698



562 9699



103256

Ref. No.	Description	Type	Spud
103062	Valve EM	EXC-10	Screw-in Spud
562 9698	Valve EM	V-909, Tasmania	Spud
562 9699	Valve EM	H-41	Spud
103256	Valve EM	T-670	Loader Valve

C

Super large bore valve assemblies



103080



103295



103275

Ref. No.	Description	Type
103080	Valve SLB	M-5000 Valve Assembly
103295	Valve SLB	MR-800-8 Swivel Stem
103296	Valve SLB	EXMR-8009.25 Swivel Stem
103085	Valve SLB	EX-7890 (CAT 789)
103275	Valve SLB	EXT-999 Loader Valve

NOTE:
More valve products in earthmover categories are available upon request.

Valve caps, metal



562 0155



160219



565 0100



156210



562 0124



156220



562 0368



156026



156227

Ref. No.	Description	TR No.	Colour	Content			
562 0155	Valve cap, metal	VC 3		100	•		•
160219	Valve cap, aluminium • Used to indicate the use of nitrogen		green	100	•		•
562 0100	Valve cap, screwdriver top	VC 2					•
156210	Valve cap V2B Inflate - Thru, double seal • Does not need to be removed to check pressure						•
562 0124	Valve cap, screwdriver top	VC-6					•
156220	Adaptor, V-655 • Internal adaptor						•
562 0368	Adaptor, V-656 • Internal adaptor	AD 2					•
156026	Valve cap EM V-67 hex	VC-7					•
156227	Valve cap, A-149 hex	VC-7					•

Valve Tools

Valve core screwdriver



156230



156232



562 8119



170503



156231



170260

Ref. No.	Description
156230	Valve core screwdriver V-673 standard, VG5 • Plastic grip, nickel-plated metal parts
156232	Valve core screwdriver V-673B standard/EM, VG5/VG8 • Plastic grip, nickel-plated metal parts
562 8119	Valve core screwdriver standard/EM, VG5/VG8 • Plastic grip, burnished metal parts, with sockets for valve cores/caps
170503	Valve core screwdriver 3-104B standard, VG5 • Plastic grip, hardened tip • Extended shaft 75 mm long
156231	Valve core screwdriver EX-1017 EM, VG8 • Plastic grip, long shaft with locking tip
170260	Valve core screwdriver EX-1019 EM, VG8 • Plastic grip, nickel-plated metal parts, long shaft

Valve repair tools



- To remove valve cores
- Easy out to remove damaged valve cores
- Thread cutter for the repair of damaged threads



562 8061

156236

Ref. No.	Description
----------	-------------

562 8061	Valve repair tool, 4-piece <ul style="list-style-type: none"> • EM valve core mounting/removal tool VG5 • External thread VG12 • Internal thread VG5 • External thread VG8
-----------------	---

156236	Valve repair tool, 4 way V-676A <ul style="list-style-type: none"> • Core removal tool VG5 • Easy out to remove damaged cores VG5 • Internal thread VG5 • External thread VG8
---------------	--



170509

102111

170509	Valve repair tool, 4 way W-205 <ul style="list-style-type: none"> • Core removal tool VG5 • Easy out to remove damaged cores VG5 • Internal thread VG5 • External thread VG8
---------------	---

102111	Valve repair tool, 4 way EX-1525 <ul style="list-style-type: none"> • Repairs tractor and EM valves • Core removal tool VG8 • Internal thread cutter VG8 (EM core) • Internal thread cutter VG10 (tractor core housing) • External thread cutter VG12
---------------	---



103264

103264	SLB T-620 assembly tool Haltec
---------------	---------------------------------------

Valve fishing tools



- Designed to assist valve hole location when fitting tubes



562 8315



562 8318

Ref. No.	Description
----------	-------------

562 8315	Valve fishing tool
-----------------	---------------------------

562 8318	Valve fishing tool Alligator
-----------------	-------------------------------------

562 8320	Valve fishing tool long
-----------------	--------------------------------



562 8212

Valve holder



- For cutting thread stubs on broken rubber based tube valves.

Ref. No.	Description
----------	-------------

562 8212	Valve holder, with cutting gauge
-----------------	---