

HEATER CHART FOR BALDOR MOTORS

		A-B Starter	Sylvania Starter
3HP Check Motor VAC Rating	208	W-50 - 03-104	2443 - 03-301
	230	W-49 - 03-103	2442 - 03-302
	460	W-43 - 03-100	2434 - 03-303
	600	W-41 - 03-099	2432 - 03-304
5HP	208	W-55 - 03-106	2446 - 03-0311
	230	W-53 -	2445 - 03-0389
	460	W-46 - 03-101	2436 - 03-0308
	600	W-46 - 03-101	2436 - 03-308
10HP	208	W-64 - 03-159	2455 - 03-0371
	230	W-63 - 03-158	2454 - 03-0309
	460	W-55 - 03-106	2447 - 03-0305
	600	W-51 - 03-105	2444 - 03-0312
15HP	208	W-68 - 03-161*	-----
	230	W-67 - 03-0514*	2460 - 03-0515
	460	W-60 - 03-156*	2452 - 03-0390
	600	W-57 - 03-155	2448 - 03-316
20HP	208	W-69 - 03-0162	-----
	230	W-68 - 03-0161	-----
	460	W-62 - 03-0494	-----
30HP	208	W-75 - 03-222	-----
	230	W-74 - 03-0516	-----
	460	W-65 - 03-160	-----

*Heaters listed are for Size 3 starter. If Size 2 is used consult Allen Bradley heater chart.

SINGLE PHASE

3/4HP	120	W-52-	2443 - 03-0301
	230	W-45-	2434 - 03-0303
3HP	208	W-58-	2447 - 03-0305
	230	W-57 - 03-0155	2447 - 03-0305
5HP	230	W-61 - 03-0157	2451 - 03-0315
10HP	208	W-68 - 03-0161	-----
	230	W-68 - 03-0161	-----