Microtemp Electronics - 4" Digital Thermometer

CASE SCREW →   **53**   ← CASE SCREW

↑

CASE SCREW

To Mount:

1. Remove packing. Do not remove face plate protective cover until installation is complete.

2. Remove case screws and separate the two halves. See arrows for screw locations.

3. Mount back half using the three holes and screws supplied. Be sure unit is level.

4. After back is mounted, drill large hole into cooler wall for power and sensor cables. Remove shavings.

5. Plug power supply into a 115 Volt outlet inside cooler. Insert the power cable into the hole in wall and back plate of unit.

6. From cooler side, insert the sensor cable through the wall hole, into back plate of unit.

7. Make sure sensor is securely through the hole and located inside the cooler. Confirm the sensor is plugged into the system, allowing the unit to display accurate temperature.

8. Re-assemble the two halves, pushing excess power and sensor cables into cooler. After confirming halves are correctly assembled, replace case screws. DO NOT OVER TIGHTEN SCREWS.

9. When finished with installation, seal penetration, remove face plate protection.

Contact information for any questions:
Phone: 360-256-6789
Email: microtemp-mfg@msn.com

WARRANTY:

Good for one year from date of purchase. Covers labor and material only. This unit cannot cause a refrigeration failure and is not liable for product loss. If unit becomes defective, contact manufacturer for replacement or repairs as soon as possible.