


2nd Season Lower Console Keypad



- Press cyclically the "#" key to display the time, date, year and voltmeter
- Press the "*" key for switch in 24 or 12 hour format
- Hold "ITEM" to enter in setting mode
- In setting mode use numbers for set time, date and year, press "ITEM" and "Price" for swap to left and right, press "ECM" for save the settings

The DTMF input work only with GND signals

