

finial adaptors

If the finial you want isn't shown in the diameter you need, ask us to add a finial adaptor, for a nominal fee. The finial adaptor acts as the new finial base.

Finials are located in certain diameter categories based on the following criteria:


- the finial base fits the pole without additional modification
- finial shape and size is in proportion to the pole diameter

Finial Adaptor Tips:

- It is typically easier and more visually pleasing to adapt a finial to a larger diameter pole, rather than a smaller diameter pole.
- Many finials are located in multiple size categories because they look appropriate for several pole sizes; you may not need an adaptor.

		base ac	laptor size	use for pole diameters
	•	small:	1 3∕8 "Dia	1/2", 3/4",]",] 1/4"
	\bigcirc	medium:	2"Dia] 1⁄2"-] 3⁄4"
		large:	3"Dia	2"-21/4"
	\bigcirc	FC1:	21⁄ 2 "Dia	1 1⁄2"-1 3⁄4" ,2"-21⁄4"

If the finial you want isn't in the diameter you need, you can add a finial adaptor.



Finial Adaptor Tips:

- It is typically easier and more visually pleasing to adapt a finial to a larger diameter pole, rather than a smaller diameter pole.
- Many finials are located in multiple size categories because they look appropriate for several pole sizes; you may not need an adaptor.