



LE-169095N 126 127 17 EXHAUST END PACKING DIAFRAM PACKING STEAM END PACKING ARRANGEMENT 2 TYPICAL LABYRINTH TYPICAL LABYRINTH TYPICAL LABYRINTH NOTE:
FOR PROPER TYPE AND NUMBER OF PACKING SEALS
(STEAM END, DIAFRAM, AND EXHAUST END) SEE
LEAKAGE DIAGRAM DRAWING IN UNIT'S INSTRUCTION BOOK. 2360 40 147 FOR EMERGENCY TRIP PARTS SEE SEPARATE ASSEMBLY -FOR BEARING CASE PARTS SEE SEPARATE ASSEMBLY 2359 140 2357 144 2356 2358 143 142 146 145 2351 2360 ARRANGEMENT" 2350 2475 2482 2480 2481 2479 203 2489 200 2478 2450 756 2476 2250 752 750 NOTE:
HAND VALVES IN UPPER HALF
ARE DETERMINED BY TURBINE NOTE: WHEN ORDERING REPAIR PARTS SECTION - TURBINE - LONGITUDINAL GIVE THE FOLLOWING INFORMATION:
1. THIS DRAWING NUMBER. FOR PARTS LIST SEE DRAWING NUMBER LC-169095 INLET STEAM REQUIREMENTS. 2. PART NO. 8 NAME OF PART. 3. SIZE , TYPE & SERIAL NO. OF UNIT. HTTUS-THE LEMENT OF THE CHARGE THE PERSON OF THE SEMBLE OF THE CHARGE THE PERSON OF THE CHARGE THE THE THE CHARGE THE THE THE THE THE CHARGE THE CHARGE TO THE THE THE THE THE

time

F(G, 2.0/