



SUN-HJWL1

Battery Heated Jacket with Hood for Women

It's perfect for both cold-weather job site conditions faced by ladies and more as well as outdoor activities such as Shopping, skiing and many more..

Offering a stylish look and performance that fit and provides maximum flexibility and comfort, this multi-layered soft shell Jacket with hood features three carbon fiber heating zones that are sewn into the fabric to distribute heat to core body areas.

The water- and wind-resistant Jacket has three heat settings for varying heat needs, which can be set to high, medium, or low with a simple touch of a button on the label.



Key Features and Specifications



Cold weather Technology: Multi-layered fabric actively warms the body and stimulates blood circulation.

Three heat zones: Jacket distributes heat to core body areas via three sewn-in carbon fiber heating zones.

Superior run-time: Up to 7 hours of heat on a single charge of one Jacket battery.

Easy-to-operate heat controller: Includes three heats settings—high, medium, and low—plus a warm-up feature.

Jacket battery holder: Sleek pocket design for minimal interference during job site work or outdoor activity.

Three pockets: Includes two hand pockets plus a chest pocket—ideal for storing cell phone, MP3 player, keys, and more.

3 level Heat Control: The Heat control button.

How to Operate the Jacket with Hood

Switch ON: To switch on the Jacket, Press and hold continues for 3 sec to switch ON the button located on the left side front up.

This sends the Jacket Heated Jacket into pre-heat mode, which provides accelerated heat output to quickly warm the product before it drops down to a medium heat output standby mode indicating Blue light.

The control LED button will blink with a red color in this pre-heat mode. You can then control the heat level in the following ways:



Push the button again to put the button in HIGH (LED button will light up solid red).

Push again to go to MEDIUM heat (LED button will light up white).



Push again to go to LOW heat (LED button will light up blue). Push again to go back to HIGH.



SWITCH OFF: To switch off Heating, press and hold the button for continues 3 seconds and the LED Light indicator will switch off and so will the heating process completely.

Description: Heated Jacket with Hood



3 temperature settings (high, medium and low) keep you warm and comfortable in the coldest weather

Wind Proof

Easy on/off LED button activates front- and back-core warming zones for quick warm-up

Specifications:

Size: S/M/L/XL

Number of Batteries Included: 1.0

Charger Included: Yes

Wind Proof : Yes

Battery Voltage: 7.4 (Lithium-Ion)

Heat Zones: 3.0

Number of Pockets: as per design

Exterior Material: Soft shell

Manufacturer Color/Finish: Black/Red


Battery Type: Lithium-ion

Model: SUN-HJWL1

Size Chart (cm / Inch)

	Shoulder	Chest	Length	Neckline	Waist
Small (S)	37 cm/14.567	43 cm/16.929	63 cm/24.803	19 cm/7.480	*****
Medium (M)	38.5 cm/15.157	45 cm/17.717	65 cm/25.591	20 cm/7.874	*****
Large (L)	40 cm/15.748	47 cm/18.504	67 cm/26.378	21 cm/9.268	*****
Extra Large (XL)	*****	*****	*****	*****	*****
2 Extra Large (XXL)	*****	*****	*****	*****	*****

Brand : Stay Warm Type : Single-Zone



Shoulder

Chest

Length

