

## 5 Motor, 10 Amp Power Distribution Panel



The Following is also included with your Power Panel:

1. Qty 1 110 V AC Power Cord
2. Qty 1 Strain-Relief for 110 V AC Power Cord
3. Qty 1 Grommet for Knock Out
4. Qty 1 Panel lock with Qty 2 Keys

**Note: See Reverse for Further Instructions**

email us at [customerservice@porterpreston.com](mailto:customerservice@porterpreston.com)

[www.porterpreston.com](http://www.porterpreston.com) • Tel: (866) 753-1113 • Fax: (203) 597-8828

## 5 Motor, 10 Amp Power Distribution Panel

Step 1: Power Cord to be attached as follows:

Black wire attach to L  
White wire attach to N  
Green wire attach to Ground



Step 2: Motors to be attached as follows:

24 V Motor Wire  
+24 Positive  
-24 Neutral  
Note: These wires are polarity sensitive

email us at [customerservice@porterpreston.com](mailto:customerservice@porterpreston.com)

www.porterpreston.com • Tel: (866) 753-1113 • Fax: (203) 597-8828