


# Philips – Easy Link Setup

## Setup Type 1

Switch on EasyLink on the TV, press the  button on the remote control and select Setup> Installation > Preferences > EasyLink, select On.

## Setup Type 2

### EasyLink (HDMI CEC)

This function allows you to operate the linked functions between our brand Devices with a EasyLink feature and this unit connecting through an HDMI cable. You must connect this unit to our brand EasyLink devices and be sure its EasyLink (HDMI CEC) setting is also set to On.

- 1 Use ▲▼ to select Preferences, then press OK.
- 2 Use ▲▼ to select EasyLink, then press OK.
- 3 Use ▲▼◀▶ to select the item you want to adjust, then press OK.

Location	Master EasyLink	On
EasyLink	Auto TV On	On
TV placement	RC key forwarding	Select
	HDMI-ARC	Off
	Device List	Select

Set the Master EasyLink to On or Off.