

Select Windows or MAC Program version

[Download Windows Version](#)   [Download MAC Version](#)

1. After download "Double Click" program to run
2. Insert 2Gig SD card or smaller into computer
3. Follow software instructions to generate restore card
4. Once card is generated take SD card to Camera
5. Remove power from Camera
6. Insert SD card into Camera
7. Power Camera back up
8. Display should show programming progress - DO NOT REMOVE POWER during the programming
9. Once "Done" is displayed on Camera, remove SD card and remove power from Camera
10. Power Up Camera normally