

Telium Series RETAIL

Quick Reference Guide

Credit Card Sale	Credit Card Return	Credit Card Void	Guide to Keys
Sale 1	Press 2	Press 3	Use to Set Language
Select 1 - CREDIT	Select 1 - CREDIT	Search Menu/Reversal	• ENTER Key
Enter the Sale amount and press	Enter Return amount and press	1=All 2=Reference # 3=Server # 4=Invoice #/PO #	(Green) Note: ENTER Key at Idle will also access a Main Menu of functions. CLEAR Key
Enter PIN # on PIN Pad Terminal will display CAPTURE response and print a SALE receipt. Additional optional prompts may appear depending on terminal configuration. * Note: The option to Tap the card for various functions will be dependent on the hardware being used and the terminal's configuration for Contactless processing.	Swipe/Insert/Tap/key Terminal will display CAPTURE response and print a RETURN receipt. Additional optional prompts may appear depending on terminal configuration. * Note: The option to Tap the card for various functions will be dependent on the hardware being used and the terminal's configuration for Contactless processing. Optional Prompts Optional Prompts may include: password, invoice/order number,	5=Account # 6=Customer # 7=RRN 8=Approval Code If ALL is selected, use the up/down arrows to scroll through the transactions and press the F4 key to select a transaction to be Voided. Confirm Void Amount? Select Yes or No Terminal will display CAPTURE response and print a VOID receipt. Authentication (Datawire Only) Press	CANCEL Key (Red) ADMIN Key FUNCTION Key Use F key to access the System Manager Menu and to create alpha characters. Press a number key then F repeatedly to create alpha characters when needed. Detail Report Press
	password, invoice/order number, card present, address, zip, CVC code, pass terminal, enter merchant number for multi-merchant, tax amount, customer code, imprint card, and enter last 4 digits. Not all optional prompts are shown.	Select 4 - Maintenance Select 4 - Authenticate If successful, Datawire will reply with an accepted response and user can proceed with transactions. If an error message is received, please call helpdesk for assistance.	Select 0 - Reports Menu Select 1 - Detail 1 - Print 2 - Display
Summary Report	Batch Total	Settlement	Reprint
Select 0 – Reports Menu Select 2 – Summary 1 – Print 2 – Display	Select 2 – Batch Menu 1 – Batch Totals 2 – View History 3 – Change Batch Number 4 – Delete Batch	Credit/Debit/EBT Close Batch and Deposit Funds? Select Yes or No Confirm Summary of Merchant Total? Select Accept or Cancel	Press Select 3 – REPRINT Reprint Menu 1= Last Receipt 2= Search If search menu ALL is selected, use the up/down arrows to scroll through the transactions and press the F4 key to select a transaction to be re-printed.

Credit Card Force	Pre Auth (Auth Only)	Pre Auth Completion	Credit Card Trans Adjust
Press 4	Press 8	Press 4	Press 8
Select 1 – CREDIT Enter the Sale amount and press	Select 2 – PRE AUTH	Select 2 -PRE AUTH COMPLETION	Select 1 – TRANS ADJUST
Swipe/Insert/Tap/key	Enter the Sale amount and press	Search Menu	Search Menu 1=All
Enter Approval Code	Swipe/Insert/Tap/key	2=Reference # 3=Server #	2=Reference # 3=Server # 4=Invoice #/PO #
Terminal will display CAPTURE response and print a FORCE	Enter PIN # on PIN Pad	4=Invoice #/PO # 5=Account # 6=Customer #	5=Account # 6=Customer # 7=RRN
SALE receipt. Additional optional prompts may	Terminal will display CAPTURE	7=RRN 8=Approval Code	8=Approval Code If ALL is selected, use the up/down
appear depending on terminal configuration. * Note: The option to Tap the card for	response and print a PRE AUTH receipt.	If ALL is selected, use the up/down arrows to scroll through the transactions and press the F4 key to	arrows to scroll through the transactions and press the F4 key to select a transaction to be adjusted.
various functions will be dependent of the hardware being used and the terminal's configuration for		select a transaction to be completed. Confirm Sale Amount?	Enter new Sale Amount?
Contactless processing	* Note: The option to Tap the card for various functions will be dependent on the hardware being used and the terminal's configuration for Contactless	Select Accept or Change Terminal will display CAPTURE response and print a PRE AUTH COMPLETION receipt.	Terminal will display CAPTURE response and print a receipt.