Hotel Just Got Digital HD Cable Boxes... What about the Gym Cardio Equipment?







Once a hotel has been transitioned from analog to new digital cable with a Cable Box, problems typically arise as to how to interface these cable boxes with the Fitness Center Gym Equipment. Typical gym and fitness center equipment have controls for Volume, Ch+/CH-, Mute and Power. Once a cable box is introduced, the channel changing functions must be directed to the cable box. The ability to select channels by maneuvering through the guide is not possible without a standard hand held remote control, as the built-in controls don't have the ability to interface with cable boxes. By adding a very simple, easy to install FitPad on any open space on the fitness center console, the user can find and select their television channel without a remote control.

Key features

- Plug it in and stick it on. FitPad is simple to use and can be installed in about 2 minutes
- FitPad adds the necessary control to navigate and select the cable box Channel Guide
- Users still control Volume, Mute and Power with the Gym Equipment's built in controls
- FitPad can work with any cable box that has an IR input jack. Some configuration might be necessary
- Almost permanent adhesive secures FitPad to any available space on the console, only 2" x 2.7"
- Only one thin 3.5mm stereo audio cable provides signal from, and power to the FitPad
- No hand held remotes to get lost, damaged or interfere with adjacent fitness equipment users
- Detachable 2M cable to fit most installations, can be extended to longer lengths if necessary