

Gas Fireplace

Lighting instructions for the pilot light:

1. Remove bottom grill, then slightly depress gas cock knob and turn to OFF, then wait 5 minutes;
2. Slightly depress knob and turn to PILOT;
3. Slightly depress knob and light pilot burner. Keep knob depressed for one minute or until pilot burner stays lit after knob is released;
4. Turn gas cock knob to ON;
5. Turn on electric switch located on the wall.

To shut off:

1. For temporary shut off; turn off electric switch if used or turn gas cock knob to PILOT.
2. For long term shut off; slightly depress knob and turn to OFF position.

Maintenance Instructions:

1. Have the appliance installation checked yearly including a visual check of the vent system, the burner and pilot flame.
2. The fireplace must be kept clear and free of combustible materials, gasoline and other flammable valves and liquids.
3. On sealed or direct vent fireplace units there may be a requirement for periodic cleaning of the glass. The frequency of cleaning will depend on the amount of usage.
4. To clean the glass, remove the trim piece at the perimeter of the glass to expose the screws, which hold it in place. Remove the screws and clean the glass with regular turtle wax. Reinstall the glass and trim and light the pilot flame.

Please refer to the manufacturer's manuals for proper care and maintenance of all your appliances.

Note: This is an extract from the Homeowner Manual (Care and Maintenance Section) which was supplied by Bosa to all of the original condo owners