



- 1. air filter
- 2. pressure gauge
- 3. breath
- 4. safety valve
- 5. oil mirror
- 6. pump
- 7. motor
- 7 a- motor fan
- 7 b- ampere breaker
- 7 c- motor pulley

- 8. starter switch
- 9. pressure switch
- 10. nrv (check valve)
- 11. belt
- 12. pulley pump
- 13. draine valve
- 14. wheel\ monting
- 15- belt safety gaurd
- 16- pressure regulator

## 1. Air filter



We have stock of Chinese and Italy air compressor **air filter**. Which are very necessary to replace in short intervals to keep air compressor stable and continue to running condition . The new and good quality air filter keep the air compressor dust free, contamination free.

## 2. Pressure gauge



Pressure gauge is vital parts of air compressor. It shows the air pressure of reservoir tank.

Receiver tank, line filter, Air dryer , instrument , equipment , machine , tools etc. we have collection of very kind air pressure gauge.

### 3. Breather

**Breather is a vital parts of air compressor. By which the pump release its internal pressure. To keep oil label stable and pump stable air compressor**

**should have a clean and perfect size breather, different pump have different kind breather ,**

**we have mostly air compressor pump breather collection.**



### 4. Safety valve

Safety valve is necessary to keep the reservoir stable, and keep safe from overfill.

Every

inspection team first inspects the safety valve of air compressor. Otherwise a blast would

happen if the tank is overfilled. Every operator should check the safety valve activity or

change after a intervals time. We have many kinds, many size safety valve,



## 5. Oil mirror

Oil mirror is a kind of measurement of oil of pump. It indicates the oil status of pump. If invisible the label of oil. it should change instantly.

We have collection of many sizes oil mirror.





## 6. Pump(head)

Air compressor value is depend on pump, high

Pressure, low pressure, high bar, and many more.

We have many kind pump collections. Chinese Italy or USA made.



### Single stage belt driven compress



B2800I



B3800B



B2800/B2800B

### Two stages belt driven compress



B4900



B5900B



B6000



B7000



B7900



BV8900



## 6A Pump gasket

Pump gasket kit is necessary to service the pump.

We are making the gasket on spot of service place

And we have many more gasket kit collection as Italy and china make pump.



### 6.B air compressor flywheel

Flywheel are required to replace the old one

As flywheel damage, broken or alteration .we are providing all kind flywheelof air compressor

pump.





## 7. Electric Motor

|                                                                                                                     |                                                                                                                     |                                                                                                                       |
|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------|
|  <p>1/2hp , 1/3 ps, 2b/4b(14")</p> |  <p>1 hp,1/3 ps,2b/4b,(19")</p>    |  <p>2hp,1/3ps,2b/4b,(19-24)"</p>   |
|  <p>3hp,1/3ps,2b/4b,(24")</p>      |  <p>4hp,1/3 ps,2b/4b,(24")</p>     |  <p>5.5 hp,1/3ps,2b/4b(24/28")</p> |
|  <p>7.5 hp,3ps,2b/4b,(28"-38")</p> |  <p>10hp,3ps,2b/4b(38")</p>        |  <p>15hp,3ps,2b/4b,(38)"</p>      |
|  <p>20hp,3ps,2b/4b,</p>          |  <p>25hp, 3ps,2b/4b,</p>         |  <p>30p,3ps,2b/4b,</p>           |
|  <p>40hp,3ps,2b/4b,</p>          |  <p>75hp,3ps,2b/4b (65mm)</p>    |  <p>100hp,3ps,2b/4b,(75mm)</p>   |
|  <p>4.5hp plange,1/3ps,2b/4b</p> |  <p>5.5hp plange,1/3ps,2b/4b</p> |  <p>double plange,(to be do)</p> |

Air compressor is run by electric motor, different air compressor have different kinds, different sizes, different power electric motor. We provide all kind Electric motor as requirements



### 7A. Electric motor pulley

Different kind motor need different kind pulley

We have variety of pulley as requirement



### 7B. Electric motor cooling fan

Electric motor cooling fan is vital for cool the electric motor. We have variety of cooling fan

for different motor



### 7c resettable motor protector

Resettable motor protectors are vital for air compressor. As many time air compressor become jam.

Take ampere over and burn. We have collection of many kind resettable motor protector



### 7d . capacitor for electric motor

Starting capacitor and running capacitor both play

A vital role. to run the electric motor. We have both kind capacitor collection.



### 7e. air compressor control panel

Mostly high pressure air compressor using air compressor control panel. Star delta controller,

double motor controller, we are providing every kind controller panel



### 8. Starter switch

There are many kind starter , dol, star delta, magnetic , isolator to on/off the air compressor.

We have many more collection or starter



### 9. Pressure switch

Pressure switch are common in every air compressor. They make the air compressor run on automatic.

We have many kind pressure switches



### 10. Nrv (non return valve)

Different air compressor has different nrv. We have many kind nrv collections



### 11. Belt

Belt should be change every service time. Because belt become torn and heated as continue running. It damage the flywheel and pulley.





## 12. Drain valve

Drain valve is necessary to release the contaminated water, otherwise it make rust on tank.

We have different size drain valve.



## 13. Air compressor wheel

We provide all kind wheels to moving the air compressor to one place to another place.




#### 14. Anti vibration mountings

Air compressor vibration makes the compressor in fault, trouble. So on installation time good mountings are necessary to safe the air compressor.



#### 15. Belt safety guards



Belt safety guards are necessary to safe the workers, and air compressor. We provide all kind belt safety guards.

#### 16. Pressure regulator



---

Pressure regulators are required to maintain the factory machine requirement. Different machine need different kind pressure. We provide different kind pressure regulators.