



www.XtremeHardDensifier.com
9924 Universal Blvd, Suite 224-115
Orlando, FL 32819
1-888-203-6791

Xtreme Hard Concrete Densifier Dusting Control Process

The following process is only for control of dusting on concrete flooring. This process is not for concrete polishing or anything other than hardening and the control of dusting.

TO CONTROL DUSTING:

1. Clean thoroughly with Xtreme Clean.
2. Densify using Xtreme Hard Densifier.
3. Run a burnisher over it using 400 grit Roll-X Pads.
4. Clean again using Xtreme Clean.

For more information, including distributor information and pricing, please go to www.XtremeHardDensifier.com or contact Angela Hensley, International Sales Director, via email at AngelaHensley@XtremeHardDensifier.com or toll-free at 1-888-203-6791.