

BREEZAIRE PRODUCTS COMPANY

8610 Production Avenue San Diego, California 92121

Phone (858) 566-7465 Fax (858) 566-1943

Web Site: www.breezaire.com Email: info@breezaire.com

INSTRUCTIONS FOR REPLACING SENTINEL II CONTROL BOARD

***COOLING UNIT MUST BE DISCONNECTED FROM POWER SOURCES**

1. Using a #2 Phillips screw driver, remove the two (2) screws holding the upper evaporator outlet grille.
2. Locate the installed control board in the cold air outlet. Label each wire with tape (white medical) number each wire from front to back. Position your replacement control board near the original one so that you may start to transfer the wires.
3. Use Needle Nose pliers to remove each connector, one by one from the original control board and move it to the replacement control board.
4. After all wires have been transferred to the replacement board; disconnect the telephone type wiring connection. This board is pressed onto the six- (6) plastic mounts. Use a flat blade screwdriver and pry up at each mount location. Install the replacement board on the mounts and press it into place.
5. Before applying power to the cooling unit ensure the fans are clear of any obstacles, (i.e. Wires, Tools, Hands, etc.).
6. Connect cooling unit to the power outlet. (NOTE - This control board is similar to a small home computer and can be effected by unstable power. Power surges and/or electrical storms can cause this control board to malfunction or lose its memory settings. Connecting it to a surge protection device can help protect your control board against various power stability problems.)