

- 1 Attach the Dethatcher Arm Assembly (Item 2) to the Dethatcher Plate (Item 1) using the bolts and nuts (Item 3 & 4) provided in the box.
- 2 Screw in the PoP Pin W/ Lockout Position (Item 5) to the Dethatcher Arm Assembly (Item 2).
- 3 Insert the Wing Bolt Spring (Item 6) on the Wing Bolt (Item 7).

J.C.B

4 - Screw in the Wing Bolt with the spring onto the Dethatcher Arm Assembly.

	REVISION HISTORY			
	REV	DATE		
	В	4/2/2019		

	Parts List				
ITEM	QTY	PART NUMBER	DESCRIPTION		
1	1	DTP134	34" Dethatcher Plate		
1.2	1	DTP140	40" Dethatcher Plate		
1.3	1	DTP146	46" Dethatcher Plate		
1.4	1	DTP152	52" Dethatcher Plate		
2	1	DTDA	Dethatcher Arm Assembly		
3	4	3816-1	3/8-16 X 1" Bolt		
4	4	69730014	3/8-16 Flange Nut		
5	1	69860003	PoP Pin W/ Lockout Position		
6	1	69860005	Wing Bolt Spring		
7	1	69860006	Wing Bolt		