Your Partner For Success

EasyControl Operator

The EasyControl Operator application allows for setup, programming, and monitoring of the ELKA barriers via a PC either by directly connecting to the barrier or via a network or by using a Windows tablet. The "Operator" provides full control for up to 16 ELKA barriers through a centralized security and control system.

Features:

- Real time monitoring
- Up to 16 ELKA barriers
- TCPIP
- Settings download
- Settings upload
- Dashboard can be setup to your needs
- Recording of camera images for predetermined events
- System status updates through E-Mail or text messages
- Open space counting system
- Timer to automatically control barriers for reoccurring events.

Application:

- Facility access
- Unpaid parking facilities
- Visitor control
- Security application
- Controlled recreational facilities (Campgrounds, Parks)
- Remote locations
- Hospitals

Q-SAQ, INC
2735 Center Place STE 104
Melbourne, FL 32940

Phone: +1 321-248-6749
 Fax: +1 888-870-3812
Email: info@q-saq.com

Your Partner For Success

Live image of the surveillance camera

Protocols of error analysis

User administration

Standard operating elements

Direct contact to service partner

User: ADMIN (Administrator)

| Logout | User | Message log | Error memory | Service |

Barrier 1

HOLD OPEN
OPEN
STOP
CLOSE
HOLD CLOSED
ERROR

Barrier 2

HOLD OPEN
OPEN
STOP
CLOSE
HOLD CLOSED
ERROR

Reset service counter | End position „closed" reached
Multi-relay 1 (Impulse) | End position „open" reached
Multi-relay 2 (Impulse)
Multi-relay 4 (Impulse)

Reset service counter | End position „closed" reached
Multi-relay 1 (Impulse) | End position „open" reached
Multi-relay 2 (Impulse) | Vehicle under the barrier boom
Multi-relay 3 (Impulse) | Barrier boom missing

Take a photo / photo archive   Self-defined functions   Self-defined status messages