



MERCUR 000 PA



MERCUR 100 PA



M 300 P

Width	26-29"	26-29"	23"
Depth	25-27"	24-26"	23"
Height	48"	40"	35"
Seat Width	20"	20"	19"
Seat Depth	19-21"	19-21"	19"
Back Width	19"	19"	18"
Back Height	29"	21"	18"

■ **4D Armrest – Maximum Ergonomics, Personalized Comfort**

Function keys are located under the armpad and on the latch mechanism beneath the armrest. Fully adjustable design offers superior ergonomics.

Polyurethane pad with textured top surface enhances the overall design.

Height adjustment: Use the button under the armpad for 10 cm (3.95 inç) upward movement.

Angle adjustment: Twist the armpad to the desired angle.

Width adjustment: Use the latch mechanism located beneath the armrest.

Depth adjustment: Push the armpad forward.

The armrests provide ergonomic support to reduce strain on the arms and shoulders.

■ **Adjustable Lumbar Support
Align with Your Spine**

Pull the lumbar support up or down with both hands simultaneously to set it to your preferred position.

Proper lumbar positioning supports your spine and enhances comfort during long sitting hours.



■ **Adjustable Headrest
Ergonomic Support, Perfectly Adjusted**

Hold the headrest with both hands and move it up or down to easily personalize your head and neck height. Enhances comfort by supporting the head and neck area.



“Channel your power
into work.”

MERCUR

SIT RIGHT, FEEL LIGHT.



goldsit
OFFICE FURNITURE

goldsit.us

goldsit
OFFICE FURNITURE



■ Smart safety – Brake Locking Caster

With its user-friendly design, caster brake system combines mobility and safety in one seamless solution.

When the user is seated: The wheels are released, allowing the chair to move freely.

When the user stands up: The brake system is automatically activated, keeping the chair securely in place and preventing unintended movement.

■ Smart Motion That Adapts to Your Body Weight

Experience effortless comfort with a self-adjusting mechanism that responds to your body weight - no need for manual tension adjustment. Smart support, personalized comfort.



■ Height Adjustment / Control Rod on the Right Side of the Mechanism

To lower the seat, place your full weight on the chair and twist the control rod upward. Once the desired height is reached, release the rod.

To raise the seat, shift your weight onto your feet and twist the control rod upward again. The chair will rise automatically.



■ Synchro Mechanism Lock in Three Positions Control Rod on the Left Side of the Mechanism

Twist the rod upward to engage the tilt lock

Twist the rod downward to release the tilt lock

■ Sliding Seat / Function Lever Located Under the Right Side of the Seat

To activate the sliding seat function, pull the lever located under the right side of the seat.

To move the seat forward: Pull the lever and shift your body weight forward.

To move the seat backward: Shift your weight to your feet and pull the lever again.

The seat slides up to 7 cm (2,75 inç) forward and backward, adapting to different body types and providing maximum seating comfort.



MERCUR.

Fluid design, relaxed atmosphere



Designed with flowing forms in every surface that touches the body, Mercur brings warmth and motion to any space.

Its smooth, non-angular structure is where comfort meets friendliness.



“Perfect balance
within simplicity.”