			DII	
MFG	SIZE	MODEL	PART NUMBER	NOTES
BRADLEY	36"	Stand On Compact	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Bradley	48"	Stand On Compact	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bradley	52"	Stand On Compact	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
BOBCAT	36"	Quick Cat (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Bobcat	48"	Quick Cat (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Bobcat	52"	Quick Cat (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Bobcat	61"	Quick Cat (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Bobcat	61"	Predator Pro	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	72"	Predator Pro	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	Pro Cat 6000MX	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	Pro Cat 6000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	Pro Cat 6000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	48"	Pro Cat 5000	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	Pro Cat 5000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	Pro Cat 5000	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	36"	Fast Cat Pro SE	N/A (Not confirmed)	
Bobcat	42"	Fast Cat Pro SE	N/A (Not confirmed)	
Bobcat	48"	XRZ Pro RS	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	XRZ Pro & XRZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	XRZ Pro & XRZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	42"	CRZ	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	48"	CRZ	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Bobcat	52"	CRZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Bobcat	61"	CRZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
BAD BOY	61"	Renegade & Diesel Renegade	EQUIPPED	
Bad Boy	72"	Renegade & Diesel Renegade	EQUIPPED	
Bad Boy	54"-72"	Rogue	EQUIPPED	
Bad Boy	54"-72"	Rebel	EQUIPPED	
Bad Boy	48"-54"	Revolt (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
<b>BIG DOG</b>	52"	Diablo	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Big Dog	60"	Diablo	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Big Dog	72"	Diablo	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS

## D'TTACH HITCH FIT LIST

Bit Dog     36"     Trooper (Stand On)     DTHSM-UNI     TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS       Big Dog     52"     Trooper (Stand On)     DTHG-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS       Big Dog     52"     Trooper (Stand On)     DTHG-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS       BILLY GOAT     X/A     Z3000 Stand On Blower     DTHA     EXACT FIT       CUB CADET     44"     Pro 2 548 (S00 Series)     DTHMED-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS       Cub Cadet     64"     Pro 2 560 (S00 Series)     DTHG-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS       Cub Cadet     64"     Pro 2 750 (700 Series)     DTHG-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS       Cub Cadet     60"     Pro 2 772 (700 Series)     DTHG-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS       Cub Cadet     72"     Pro 2 772 (700 Series)     DTHG-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS       Cub Cadet     74"     Pro 2 540 (S00 Series)     DTHG-UNI     TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS					
Big Dog.52"Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBig Dog.60"Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBILLY GOATN/AZ3000 Stand On BlowerDTH2BEXACT FITCUB CADET44"Pro 2 548 (500 Series)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 550 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 550 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro 2 750 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro 2 752 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 654 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 336DTHSM-UNI<	Big Dog		Trooper (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Big Dog60°Trooper (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSBILLY GOATN/A23000 Stand On BlowerDTHXBEXACT HTBILLY GOATN/A23000 Stand On BlowerDTHXBEXACT HTCUB CADT48°Pro 2 584 (S00 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 32-636 INCHES BETWEEN CASTOR WHEELSCub Cadet64°Pro 2 554 (S00 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60°Pro 2 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60°Pro 2 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60°Pro 2 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72°Pro 2 927 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64°Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64°Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64°Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54°Pro HW 336DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54°Pro HW 348DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEE	Big Dog	48"	Trooper (Stand On)	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
BILLY GOATN/AX3000 Stand On BlowerDTHXBEXACT FITBIILY GOAT48"Yroz 548 (SOO Series)DTHXB-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCUB Cadet64"Pro 2 560 (SOO Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 2 560 (SOO Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro 2 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro 2 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro 2 792 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 663 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 664 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 345DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 345DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 345DTHLG-UNITELESCOPIC CROSS BA	Big Dog	52"	Trooper (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Billy GoatN/A23000 Stand On BilowerDTH2BEXACT FITCUB CADET44"Pro Z 548 (500 Series)DTHMED-UNITELESCOPIC CROSS BAR SPAN 23-63 INCHES BETWEEN CASTOR WHEELSCub Caded64"Pro Z 556 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Caded60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Caded60"Pro Z 750 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet74"Pro X 548 (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHMS-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 354DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 354DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 354DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR	Big Dog	60"	Trooper (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
CUB CADET48"Pro Z 548 (500 Series)DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro Z 554 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 500 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet84"Pro X 664 (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 664 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 664 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 664 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro K 464 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet84"Pro HW 336DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-66 INCHES BETWEEN CASTOR WHEELSCub Cade	<b>BILLY GOAT</b>	N/A	X3000 Stand On Blower	DTHXB	EXACT FIT
Cub Cadet54"Pro Z 554 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 560 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 770 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 792 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 664 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHLG-UNITELESCOPIC CROSS BAR SPAN 30-26 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHLG-UNITELESCOPIC CROSS BAR SPAN 30-26 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHLG-UNITELESCOPIC CROSS BAR SPAN 30-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHL	Billy Goat	N/A	Z3000 Stand On Blower	DTHZB	EXACT FIT
Cub Cadet60"Pro Z 560 (500 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 654 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHMG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 336DTHMG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 348DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DT	CUB CADET	48"	Pro Z 548 (500 Series)	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Cub Cadet60"Pro Z 760 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 9772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet74"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 336DTHLMD-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHLG-UN	Cub Cadet	54"	Pro Z 554 (500 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet72"Pro Z 772 (700 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet72"Pro Z 648 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 648 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet64"Pro HW 336DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet44"Pro HW 348DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet44"Pro HW 348DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore32"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHLG-UNI <td>Cub Cadet</td> <td>60"</td> <td>Pro Z 560 (500 Series)</td> <td>DTHLG-UNI</td> <td>TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS</td>	Cub Cadet	60"	Pro Z 560 (500 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet60"Pro Z 960 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 648 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro HW 336DTHMED-UNITELESCOPIC CROSS BAR SPAN 21-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 21-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore54"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHLG-UNITELESCOPI	Cub Cadet	60"	Pro Z 760 (700 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet72"Pro Z 972 (900 Series)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro X 648 (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (stand On)DTHMS-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore54"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore54"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore54"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CRO	Cub Cadet	72"	Pro Z 772 (700 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet48"Pro X 648 (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro X 656 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-	Cub Cadet	60"	Pro Z 960 (900 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet54"Pro X 654 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmarkALLNavigatorDTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWE	Cub Cadet	72"	Pro Z 972 (900 Series)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet60"Pro X 660 (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSCub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkAltNavigatorDTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEXmarkAltNavigatorDTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkAltNavageDTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkS4"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS <td>Cub Cadet</td> <td>48"</td> <td>Pro X 648 (Stand On)</td> <td>DTHMED-UNI</td> <td>TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS</td>	Cub Cadet	48"	Pro X 648 (Stand On)	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Cub Cadet36"Pro HW 336DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSCub Cadet48"Pro HW 348DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkALLNavigatorDTHWALLEXACT FITExmark36"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark54"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITE	Cub Cadet	54"	Pro X 654 (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet48"Pro HW 348DTH MED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSCub Cadet54"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark36"VantageDTHMALLEXACT FITExmark36"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC	Cub Cadet	60"	Pro X 660 (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Cub Cadet54"Pro HW 354DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkAllNavigatorDTHWALLEXACT FITExmark36"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark54"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark54"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark54"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark54"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark54"VantageDTHLG-UNITELESCOPIC CROSS	Cub Cadet	36"	Pro HW 336	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
ENCORE32"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHUG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkALNavigatorDTHWALLEXACT FITExmark36"VantageDTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark61"IS3200 (Except Midnight)DTHER-1EXACT FIT<	Cub Cadet	48"	Pro HW 348	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Encore36"Rage (Stand On)DTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSEncore48"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEXMARKALLNavigatorDTHWALLEXACT FITExmark36"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark61"IS3200 (Except Midnight)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Cub Cadet	54"	Pro HW 354	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Encore48"Rage (Stand On)DTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSEncore52"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEXMARKALLNavigatorDTHWALLEXACT FITExmark36"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSFerriss61"IS3200 (Except Midnight)DTHFER-1EXACT FITFe	ENCORE	32"	Rage (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Encore52"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEncore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEXMARKALLNavigatorDTHWALLEXACT FITExmark36"VantageDTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark61"IS3200 (Except Midnight)DTHFE-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Encore	36"	Rage (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Encore60"Rage (Stand On)DTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSEXMARKALLNavigatorDTHWALLEXACT FITExmark36"VantageDTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark61"Is3200 (Except Midnight)DTHER-1EXACT FITFerris61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Encore	48"	Rage (Stand On)	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
EXMARKALLNavigatorDTHWALLEXACT FITExmark36"VantageDTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark61"LazerCALLNEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENTFERRIS61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Encore	52"	Rage (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Exmark36"VantageDTHSM-UNITELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELSExmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkALLLazerCALLNEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENTFERRIS61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Encore	60"	Rage (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Exmark48"VantageDTHMED-UNITELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELSExmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkALLLazerCALLNEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENTFERRIS61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	EXMARK	ALL	Navigator	DTHWALL	EXACT FIT
Exmark52"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkALLLazerCALLNEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENTFERRIS61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Exmark	36"	Vantage	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Exmark60"VantageDTHLG-UNITELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELSExmarkALLLazerCALLNEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENTFERRIS61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Exmark	48"	Vantage	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
ExmarkALLLazerCALLNEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENTFERRIS61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Exmark	52"	Vantage	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
FERRIS61"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris72"IS3200 (Except Midnight)DTHFER-1EXACT FITFerris61"IS2600DTHFER-5EXACT FIT	Exmark	60"	Vantage	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Ferris     72"     IS3200 (Except Midnight)     DTHFER-1     EXACT FIT       Ferris     61"     IS2600     DTHFER-5     EXACT FIT	Exmark	ALL	Lazer	CALL	NEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENT
Ferris 61" IS2600 DTHFER-5 EXACT FIT	FERRIS	61"	IS3200 (Except Midnight)	DTHFER-1	EXACT FIT
	Ferris	72"	IS3200 (Except Midnight)	DTHFER-1	EXACT FIT
Ferris 52" IS2100 DTHFER-5 EXACT FIT	Ferris	61"	IS2600	DTHFER-5	EXACT FIT
	Ferris	52"	IS2100	DTHFER-5	EXACT FIT

Ferris	61"	IS2100	DTHFER-5	EXACT FIT
Ferris	52"	ISX800	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	ISX800	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	52"	IS700	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	IS700	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	44"	IS600	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	48"	IS600	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61""	IS600	DTHFER-3	EXACT FIT - REQUIRES ADDITIONALHOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	F320	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	72"	F320	DTHFER-1	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	61"	F210	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	48"	F160	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	52"	F160	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	36"	F60	DTHFER-3	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
Ferris	36"	SRS Z1	N/A	
Ferris	48"	SRS Z1	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	48"	SRS Z2	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	52"	SRS Z2	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	61"	SRS Z2	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	52"	SRS Z3	DTHFER-4	EXACT FIT
Ferris	61"	SRS Z3	DTHFER-4	EXACT FIT
Ferris	72"	SRS Z3	DTHFER-4	EXACT FIT
Ferris	61"	F800X	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	72"	F800X	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	61"	Pro Cut S	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	48"	FW35	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	52"	FW35	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	61"	FW35	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Ferris	36"	FW25	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	48"	FW25	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Ferris	N/A	FB2000 (Stand On Blower)	DTHXB	EXACT FIT
Ferris	N/A	FB3000 (Stand On Blower)	DTHZB	EXACT FIT
Ferris	ALL	ISX3300, 2200	DTHFER-6 (Coming Soon)	EXACT FIT - REQUIRES ADDITIONAL HOLE/HOLES DRILLED FOR PROPER USE WITH ATTCHMT
GRAVELY	32"	Pro Stance	N/A	

Gravely	36"	Pro Stance	N/A	
Gravely	48"	Pro Stance	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Stance	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Stance	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Turn 400	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn 400	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	72"	Pro Turn 400	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Turn 200	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn 200	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	72"	Pro Turn 200	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn Mach 1	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	48"	Pro Turn Z & ZX	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	Pro Turn Z & ZX	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	Pro Turn Z & ZX	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	44"	ZT HD	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	48"	ZT HD	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Gravely	52"	ZT HD	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Gravely	60"	ZT HD	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
HURRICANE	N/A	X3 Stand On Blower	DTHXB	EXACT FIT
Hurricane	N/A	Z3 Stand On Blower	DTHZB	EXACT FIT
HUSQVARN	<b>A</b> 48"	Z548	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Husqvarna	54"	Z554	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Husqvarna	60"	Z560	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Husqvarna	72"	Z572	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Husqvarna	54"	V554 (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Husqvarna	48"	V548 (Stand On)	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
HUSTLER	54"	Super Z & Super Z Hyper Drive	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	60"	Super Z & Super Z Hyper Drive	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	66"	Super Z & Super Z Hyper Drive	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	72"	Super Z & Super Z Hyper Drive	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	36"	Trimstar	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Hustler	48"	Trimstar	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Hustler	54"	Trimstar	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	60"	Trimstar	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS

Hustler	60"	Z Diesel	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	72"	Z Diesel	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Hustler	36"	Super S (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Hustler	48"	Super S (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Hustler	52"	Super S (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Hustler	60"	Super S (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
JOHN DEER	E 36"	Quick Trak 636M (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
John Deere	48"	Quick Trak 648M (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
John Deere	52"	Quick Trak 652M (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
John Deere	52"	652E (Stand On Fix Deck)	DTHLG-FD	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
КИВОТА	48"	Z400 Series	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	54"	Z400 Series	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	60"	Z400 Series	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	48"	Z700 Series	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Kubota	54"	Z700 Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Kubota	60"	Z700 Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
REDMAX	54"	CZT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Redmax	60"	CZT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Redmax	72"	CZT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
SCAG	52"	Turf Tiger II	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	61"	Turf Tiger II	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	72"	Turf Tiger II	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	48"	Cheetah	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	52"	Cheetah	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	61"	Cheetah	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	72"	Cheetah	DTHLG-UNI+2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	48"	Tiger Cat II	DTHMED-UNI+1	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	52"	Tiger Cat II	DTHLG-UNI+1	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	61"	Tiger Cat II	DTHLG-UNI+1	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	36"	V-Ride I	DTHSM-VR1	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Scag	48"	V-Ride I	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	52"	V-Ride I	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	61"	V-Ride I	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Scag	ALL	V-Ride II	DTHV2	EXACT FIT - REQUIRES 2 HOLES DRILLED FOR PROPER USE WITH ATTCHMT

Scag	36"	SWZT	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Scag	48"	SWZT	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	52"	SWZT	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Scag	61"	SWZT	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
SPARTAN	48"	RZ Series	DTHMED-U2X2	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Spartan	54"	RZ Series	DTHLG-U2X2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Spartan	61"	RZ Series	DTHLG-U2X2	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Spartan	54"	RT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Spartan	61"	RT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Spartan	54"	SRT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Spartan	61"	SRT Series	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
TORO	36"	Grandstand (Stand On)	DTHSM-UNI	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Toro	40"	Grandstand (Stand On)	DTHSM-U2X2	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Toro	48"	Grandstand (Stand On)	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Toro	52"	Grandstand (Stand On)	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Toro	ALL	Z Master	CALL	NEED MEASUREMENTS AND PICTURES TO PROCEED W/ PROPER FITMENT
Toro	ALL	8000 Series	DTHWALL	EXACT FIT
Toro		Multi Force	DTHMF	EXACT FIT
WALKER	ALL	Model S	DTHWALL	EXACT FIT
Walker	ALL	Model C	DTHWALL	EXACT FIT
Walker	ALL	Model T	DTHWALL	EXACT FIT
Walker	ALL	Model D	DTHWALL	EXACT FIT
WRIGHT	ALL	Rapid Height (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Stander I "Intensity" (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Stander X (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Stander ZX (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	36"	Stander Fixed Deck (Stand On)	DTHSM-3642	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Wright	42"	Stander Fixed Deck (Stand On)	DTHSM-3642	TELESCOPIC CROSS BAR SPAN 20-26 INCHES BETWEEN CASTOR WHEELS
Wright	48"	Stander Fixed Deck (Stand On)	DTHLG-FD	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	52"	Stander Fixed Deck (Stand On)	DTHLG-FD	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	61"	Stander Fixed Deck (Stand On)	DTHLG-FD	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	48"	Stander B (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	52"	Stander B (Stand On)	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	36"	Sport I	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS

Wright	48"	Sport X	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Wright	52"	Sport X	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	61"	Sport X	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	ALL	Sport RH	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Sentar	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	ALL	Sentar Sport	DTHALL	MOWER MUST BE EQUIPPED WITH ACCESSIBLE CROSS BAR BETWEEN CASTOR ARMS
Wright	48"	ZTO	DTHMED-UNI	TELESCOPIC CROSS BAR SPAN 26-36 INCHES BETWEEN CASTOR WHEELS
Wright	52"	ZTO	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	61"	ZTO	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	52"	MMZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS
Wright	61"	MMZ	DTHLG-UNI	TELESCOPIC CROSS BAR SPAN 31-44 INCHES BETWEEN CASTOR WHEELS