JABIRU ENGINE PARTS BOOK



Jabiru 4 Cylinder 2200cc Engine.

Jabiru Aircraft Pty Ltd ACN 010 910 077 PO Box 5792 Bundaberg Australia 4670

Australia: Phone 07 4155 1778 Fax 07 4155 2669
International: Phone + 61 7 4155 1778 Fax + 61 7 4155 2669
Email: info@jabiru.net.au Web: www.jabiru.net.au

Applicable for Jabiru 2200 Aircraft Engines. S/No. 2068 onwards.



Please fill in your engine and aircraft details for future reference.

Engine Serial #:	
Aircraft Type:	
Model:	
Serial #:	
Registration #:	

Note:

- 1. Not all parts are illustrated
- 2. All efforts are made to ensure accuracy at the time of publication, if you find any discrepancies, or have any questions about the contents of this publication please contact Jabiru Aircraft Pty Ltd.
- 3. All quantities are per engine unless stated otherwise.
- 4. When ordering parts always quote engine serial number and any upgrades carried out on the engine, as well as item number, part number, description, page number and issue number. This complete information will ensure Jabiru Aircraft Pty Ltd supply the correct part.

Jabiru Aircraft



Parts Catalogue Index

Figure 1 – Crankcase and Crank Assy 3/8 Barrel Studs	
Figure 2 – Crankcase and Crank Assy 7/16 Barrel Studs	5
Figure 3 – Cylinder Head Assy up to S/N 2552	6
Figure 4 – Cylinder Head Assy from S/N 2553 to S/N 3357	7
Figure 5 – Cylinder Head Assy from S/N 3358	8
Figure 6 – Head Assy Including Valve Guides & Seats up to S/N 2552	9
Figure 7 – Head Assy Including Valve Guides & Seats from S/N 2553 to S/N 3357	10
Figure 8 – Head Assy Valve Guides & Seats (Pushrod Oil Feed) from S/N 3358	11
Figure 9 – Head Mounting & Pushrod Assy up to S/N 2552	12
Figure 10 – Head Mounting & Pushrod Assy from S/N 2553	13
Figure 11 – Head Mounting & Pushrod Assy (Pushrod Oil Feed) from S/N 3358	14
Figure 12 – Barrel, Piston & Conrod Assy	15
Figure 13 – Timing & Distributor Assy	16
Figure 14 –Rear Plate & Flywheel Assy up to S/N 2731	17
Figure 15 –Rear Plate & Flywheel Assy from S/N 2732	18
Figure 16 – Flywheel Assy up to S/N 2731	19
Figure 17 – Flywheel Assy from S/N 2732 on	20
Figure 18 - Crankshaft to Flywheel Assy up to S/N 2731	21
Figure 19 – Crankshaft to Flywheel Assy from S/N 2732	22
Figure 20 – Induction System Assy	23
Figure 21 – Carburetor Assy	24
Figure 22 - Oil Pump Assy	25
Figure 23 - Dipstick Assy up to S/N 2552	26
Figure 24 - Dipstick Assy from S/N 2553	27
Figure 25 - Starter Assy	28
Figure 26 - Starter Assy Cast Housing	29
Figure 27 - Rocker Oil Lube Supply up to S/N 3357	30
Figure 28 - Oil Relief Valve, Filter & Adapter	31
Figure 29 - Exhaust Assy	32
Figure 30 – Sump Assy up to S/N 2552	33
Figure 31 – Sump Assy from S/N 2553 on	34
Figure 32 - Propeller Flange Assy	
Figure 33 - Fuel Pump Assy	36
Figure 34 - Fuel Pump Assy Zhejiang Tongshun	

Note: Refer to Installation Manual for details of parts used in engine installation. Refer to Installation Manual for data & installation details on engine cooling ducts.






Figure 1 - Crankcase and Crank Assy 3/8 Barrel Studs






Figure 2 - Crankcase and Crank Assy 7/16 Barrel Studs






Figure 3 - Cylinder Head Assy up to S/N 2552






Figure 4 - Cylinder Head Assy from S/N 2553 to S/N 3357





Figure 5 - Cylinder Head Assy from S/N 3358






Figure 6 - Head Assy Including Valve Guides & Seats up to S/N 2552






Figure 7 – Head Assy Including Valve Guides & Seats from S/N 2553 to S/N 3357






Figure 8 – Head Assy Valve Guides & Seats (Pushrod Oil Feed) from S/N 3358






Figure 9 - Head Mounting & Pushrod Assy up to S/N 2552







Figure 10 - Head Mounting & Pushrod Assy from S/N 2553





Z	DADT No	NOITGIGUESE	Ć
-	4	ROCKER COVER NARROW FINS	, –
7	452329N-7	WASHER - HEAD	က
9	PH0535N	1/4" x 0.75" UNC CAP SCREW	4
4	AN960-416	1/4" FLAT WASHER	4
ū	PH9852N-1	PLUG 1/8 NPT	-
9	PG4A028N	ROCKER COVER O-RING BS238V	-
7	PI 10582N	SPARK PLUG	8
8	PI4A000N-1	SPARK PLUG TERMINAL NUT	7
G	PG10042N-1	BS114V O RING	7
10	PH082N	5/16"UNF x 1 3/4" CAP SCREW	4
11	4A080A0D-6	ADAPTOR PUSHROD TUBE	2
12	4A101A0D-4	COVER TUBE PUSHROD HYD LIFTER	7
13	PG4A025N	O-RING (BS119V)	7
14	4A073A0D-4	CYLINDER HEAD STRONGBACK - SLIMLINE	-
15	4A285A0D-1	HEAD WASHER OFFSET WITH FLAT	-
16	PH0798N	5/16 UNF x 3" CAP SCREW	ļ
17	PH0840N-2	5/16-UNF x 4" CAP SCREW	ŀ
18	4A421D0D-3	HOLLOW PUSHROD ASSY (215 mm)	7
19	4A240A0D-3	HEAD WASHER OFFSET	-
20	4A501A0D-3	HEAD ASSY W/- VALVES & SPRINGS # 1 & 4	-
		(PUSHROD OIL FEED)	
21	4A502A0N-3	HEAD ASSY W/-VALVES & SPRINGS # 2 & 3	ļ
		(PUSHROD OIL FEED)	






Figure 12 - Barrel, Piston & Conrod Assy






Figure 13 - Timing & Distributor Assy






Figure 14 -Rear Plate & Flywheel Assy up to S/N 2731






Figure 15 - Rear Plate & Flywheel Assy from S/N 2732






Figure 16 - Flywheel Assy up to S/N 2731






Figure 17 - Flywheel Assy from S/N 2732 on






Figure 18 - Crankshaft to Flywheel Assy up to S/N 2731






Figure 19 - Crankshaft to Flywheel Assy from S/N 2732






Figure 20 - Induction System Assy






Figure 21 - Carburetor Assy






Figure 22 - Oil Pump Assy






Figure 23 - Dipstick Assy up to S/N 2552






Figure 24 - Dipstick Assy from S/N 2553






Figure 25 - Starter Assy






Figure 26 - Starter Assy Cast Housing






Figure 27 - Rocker Oil Lube Supply up to S/N 3357






Figure 28 - Oil Relief Valve, Filter & Adapter






Figure 29 - Exhaust Assy






Figure 30 - Sump Assy up to S/N 2552






Figure 31 - Sump Assy from S/N 2553 on






Figure 32 - Propeller Flange Assy






Figure 33 - Fuel Pump Assy






Figure 34 - Fuel Pump Assy Zhejiang Tongshun