

WALL CONTROL COMPATIBILITY CHART

The VB20W push-button timer is compatible with all units, whereas the 59W crank-timer is compatible with all units, except for the ERVS100S unit.

Model no.	Name	VT9W	VT8W version 4.04 and up (NOTE 1)	VT7W version 2.04 and up (NOTE 1)	VT4W	VT6W	VB60W
ERV140TE	ERV140TE		PJ1214xxxxxxxx (NOTE 2)	PJ1214xxxxxxxx (NOTE 2)			
HRV160TE	HRV160TE						
HRV160T	HRV160T						
ERV200TE, HRV200TE, ERV250TE & HRV250TE	ERV200TE, HRV200TE, ERV250TE & HRV250TE						
ERV70T, ERV70S	ERV70T, ERV70S						
HRV80T, HRV80S	HRV80T, HRV80S						
HRV90T, HRV90S	HRV90T, HRV90S						
HRV150S	HRV150S			NOTE 4			
HRV190S	HRV190S			NOTE 4			
ERV180S	ERV180S			NOTE4			
ERV110T	ERV110T						BL101702 xxxxx (NOTE 3)
ERV110S	ERV110S						BK101702 xxxxx (NOTE 3)
ERV120T	ERV120T						LD711702 xxxxx (NOTE 3)
ERV120S	ERV120S						LC711702xxxxx (NOTE 3)
HRV120T	HRV120T						LF711702 xxxxx (NOTE 3)
HRV120S	HRV120S						LE711702 xxxxx (NOTE 3)
ERV100SP	ERV100SP						
ERV100S	ERV100S			NOTE 4			
ERVS100S	ERVS100						
HRVH100S & ERVH100S	HRVH100S & ERVH100S						
HRV150FLS & HRV190FLS	HRV150FL & HRV190FL						
HRV130FL & ERV130FL	HRV130FLS & ERV130FLS			NOTE 4			

NOTE 1: Wall control including configurable low speed recirculation in intermittent mode.

NOTE 2: Low speed recirculation in intermittent mode starts with this unit serial number.

However, this control remains compatible with units with serial number under this one.

NOTE 3: The compatibility starts from this unit serial number.

NOTE 4: Recirculation mode is not available for this unit.

	Compatible
	Not compatible
Letters and numbers	This code is the serial number of the ventilation unit; consider only the letters and numbers mentioned, not the "xxx". E. g.: ERV140TE with serial number PJ12150004007 is fully compatible with VT8W version 4.04 and VT7W version 2.04 (PJ1215 is higher than PJ1214).

Subject to change without prior notice. 22737 rev. 06