



PARTS LIST
31" SWEEPER HAAGA 677
SALES & SERVICE 1-877-977-3339

January 7, 2014

Diagram Number	Part Description	Part Number	
1.05	Edge guiding roller	000005	
1.07	Screw	000007	
1.10	Pivot housing	400112	
1.11	Hight adjustment dial	600111	
1.12	Housing	470112	
1.13	Cover	600113	
1.15	Waste bin handle latch	600115	
1.16	Slider height adjustment left	470119	
1.17	Slider height adjustment Right	470120	
1.18	Frame	600118	
1.20	Filter	600120	
1.21	Knob	600121	
1.22	Guide	600122	
1.23	Deflector left	470219	
1.24	Deflector right	470220	
2.10 L/R	Circular brush set (2 brushes)	670200	
2.10L	Circular brush left	670201	
2.10R	Circular brush right	670202	
3.02	Sleeve gear	200302	
3.10L	Clutch Left	400305	
3.10R	Clutch Right	400306	
3.11	Clutch Ring	200311	
4.00 L/R	Oblique wheel set (1 left & 1 right wheel)	200411	
4.00L	Oblique wheel with cover left	200451	
4.00R	Oblique wheel with cover right	200452	
4.02	6mm washer	000404	
5.01	Sweeping lip	000501	
5.14	Sweeping plate with rake	600514	
6.00	Waist bin complete	400500	
6.01	Axle for waist bin wheel	000611	
6.05	Waist bin handle	000605	
6.07	Tread wheel	000607	
6.08	Bushing	000608	
6.13	Micro Sweep Blade	600613	
7.11	Handle	600700	
7.12	Spring Clip	600712	
7.13	Handle holder	600713	
8.11	Brush gear	400811	
8.12	Ball bearing (6903zz)	400812	
8.15	Brush holder	400815	
8.16	Brush roller 470mm	400816	
9.11	Wheel gear (87 teeth)	600911	



PARTS LIST
31" SWEEPER HAAGA 677
SALES & SERVICE 1-877-977-3339

9.12	Wheel	600920	
9.14	Wheel clamp	600914	
9.15	Ball bearing (6805zz)	400915	
9.16	Pin	400916	
9.18	Seal	600918	
10.01	Switch with fuse	501026	
10.02	Charger Socket	501002	
10.03	Red wire	501003	
10.04	Screw M6 x 10	501004	
10.06A	Battery top bracket	501050	
10.06B	Battery left bracket	501051	
10.06C	Battery right bracket	501052	
10.08	12 volt battery	501008	
10.12	Cap	601012	
10.11	Switch & socket plate	621014	
10.13	Motor cable 1	601013	
10.14	Motor cable 2	601014	
10.15	Motor cable 3	601015	
10.16	Switch wire	551016	
10.19	Charger socket wire	501019	
10.20	Light	601016	
11.01	Motor gear cover	501101	
11.11	Motor for brush roller	501401	
11.12	Motor for disc brush	501402	
11.05	Motor cover	501105	
11.06	Spring pin 2 x 10 mm	501106	
12.01	Screw 4 x 60	501201	
12.02	Washer	501202	
12.03	Wheel Pin	501209	
12.04	Spring	501204	
12.05	Washer for pin	501205	
12.07	Geared wheel	551207	
12.08	Clutch element	501208	
12.06	Washer	501210	
	Charger	500001	
	Lubrakint Spray	923000	

haaga

PARTS LIST 31" SWEEPER HAAGA 677 SALES & SERVICE 1-877-977-3339

