


Unlock the power of Pico remote controls



Make your job easier, and give customers control where they need it.

What is a Pico?



Pico remote wall-mounting kit (sold separately)

Multi-location control
in a few minutes

A Pico is a battery-powered, RF remote that communicates with other Lutron wireless devices, including dimmers, switches, and shades, as well as with fans and audio integrated into a Lutron system.




Adding a Pico to a dimmer, switch, shade, fan, or Sonos Home Sound System provides an additional point of control. And it only takes a few minutes to do.

What can a Pico do for you?

- You can add a Pico to any wall surface without cutting holes, running wire, spackling, and repainting.
- You can easily add 3-way dimming or switching control where your customer needs it, in a fraction of the time and labor it takes to install a wired 3-way.
- You'll avoid callbacks. The Pico is battery-powered, with an industry-leading 10-year battery life.

Your time is valuable



15 minutes
or less


Adding a new control location with a Pico

You can add a Pico in 3 easy steps:

1. Replace an existing switch with a Lutron wireless dimmer or switch
2. Associate the Pico to the dimmer or switch*
3. Attach the Pico to a wall, place it on a pedestal, or use it with a car visor clip

Tools needed: screwdriver and pliers

* You can also easily associate a Pico directly to Lutron shades.



2-4 hours

Adding a new control location with a 3-way switch

Installing a traditional switch requires more time:

1. Run wire through a crawl space, attic, or fish through a wall
2. Cut a hole in drywall and install the wallbox
3. Wire the new control into the existing circuit
4. Repair the wall and paint it

Tools needed: screwdriver, wire stripper, drywall saw, fish tape, pliers

What can a Pico do for your customers?



With a Pico and just one touch, a customer can:

- Turn off all the lights in the house
- Control multiple lights or shades at one time
- Control audio (instead of opening an app on a phone)
- Control a ceiling fan

Control where your customer wants it

Mount a Pico on a tabletop pedestal. Tabletop pedestals are available in single, double, and triple configurations.

You can also mount a Pico on a wall.

Pico is also great problem solver — for entry lights...



Use a Pico with a car visor clip to turn on entry or foyer lights when coming home at night, to create a path of light into the house.



The Clear Connect wireless signal works around corners/through walls and is ultra-reliable, which equals no callbacks for you.

... and nurseries,

... as well as hallways.



Keep one close at hand to dim lights without getting up, when singing baby to sleep.



3-button Nightlight Pico with raise/ lower buttons
*Moon LED shown brighter than it actually appears.



Add additional control to high traffic areas that lack a convenient control location, such as a long hallway.



2-button Lights Pico mounted in a wallplate


Pico remote control

Control lights, shades, audio, and ceiling fans. Users can create a frequently used setting, save it, and then recall it with the "Favorite" button.

4-button Pico remote control


Control zones, scenes, or groups of lights and/or shades.

Lighting control



Pico remote for lights
PJ2-3BRL-GWH-L01

Shade control



Pico remote for shades
PJ2-3BRL-GWH-S01

Zone control

Control multiple lights or shades; operates the same as a 3-button remote with raise/lower, but without a "Favorite" button



Lights model
PJ2-4B-GWH-L01


Scene control

Control lights or shades to preset levels; differs from a Pico scene keypad in that all devices associated to the top button will also be associated to the other three buttons.




Lights model
PJ2-4B-GWH-L31

Audio control



Pico remote for audio
PJ2-3BRL-GWH-A02

Fan control



Pico remote for fans
PJ2-3BRL-GWH-F01

2-group control

Control two groups of lights, two groups of shades, or one group of lights/one group of shades.



Lights model
PJ2-4B-GWH-L21

4-group toggle

Toggles four loads on and off; designed for HomeWorks QS systems




Lights model
PJ2-4B-GWH-L41

Pico scene keypads

Control lights, shades, and audio. These keypads are available pre-engraved with common scenes for typical activities in a home. They autoconfigure in the Lutron App for Caséta and RA2 Select, saving you time, and can be easily configured in the app to personalize for the homeowner.


2-button Scene control



Use the “Goodnight” button to turn lights off and lower shades in other rooms of the house and the “Alert” button to turn hallway lights on and raise living room shades, all without getting out of bed.

Pico Bedside scene keypad
PJ2-2B-GWH-P02

4-button Scene control



Control all the kitchen lights with a single button press.

Pico Kitchen scene keypad
PJ2-4B-GWH-P02

| |  Ceiling lights |  Table lamp |  Shades |
|-------------|--|--|--|
| Home | 100% | 50% | Open |
| Away | Off | Off | Closed |


| |  Ceiling lights |  Island lights |  Pendant |  Shades |
|----------------|--|---|---|--|
| Bright | 100% | 100% | 100% | Open |
| Cooking | 100% | 100% | 50% | 75% Open |
| Dining | 20% | 65% | 50% | Half Open |
| Off | Off | Off | Off | Closed |

Pico remote controls for lighting


Ordering Information

Pico remote controls for lighting *with nightlight*

Ordering Information



Build a Pico Model Number



Button Configuration Codes:

| Button Configurations | Code |
|---------------------------|------|
| 2-button | 2B |
| 2-button with raise/lower | 2BRL |
| 3-button | 3B |
| 3-button with raise/lower | 3BRL |
| 4-button | 4B |

Button Marking Codes:

L01, L31, L21, LS21, L41


Color Codes:

| Gloss Colors | Code |
|--------------|------|
| White | GWH |
| Black | GBL |
| Ivory | GIV |
| Light Almond | GLA |
| White/Gray | GWG* |

Satin Colors

| Satin Colors | Code |
|--------------|------|
| Snow | TSW |
| Biscuit | TBI |
| Midnight | TMN |

Build a Pico Model Number



Button Configuration Codes:

| Button Configurations | Code |
|---------------------------|------|
| 2-button | 2B |
| 3-button with raise/lower | 3BRL |

Button Marking Code:

L01

Color Codes:

| Gloss Colors | Code |
|--------------|------|
| White | GWH |
| Black | GBL |
| Ivory | GIV |
| Light Almond | GLA |

Pico remote controls for shades


Ordering Information

Pico remote control for video screens

Ordering Information



Build a Pico Model Number



Button Configuration Codes:

| Button Configurations | Code |
|---------------------------|------|
| 2-button with raise/lower | 2BRL |
| 3-button with raise/lower | 3BRL |
| 4-button | 4B |

Button Marking Codes:


S01, S02, S03, S04, S05, S06, S07, S09, S10, S21, S31

Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | GWH | □ |
| Black | GBL | ■ |
| Ivory | GIV | ■ |
| Light Almond | GLA | ■ |
| White/Gray | GWG* | ■ |

| Satin Colors | Code | |
|--------------|------|---|
| Snow | TSW | □ |
| Biscuit | TBI | ■ |
| Midnight | TMN | ■ |

Build a Pico Model Number



Button Configuration Codes:

| Button Configurations | Code |
|-----------------------|------|
| 2-button | 2B |

Button Marking Code:

S08

Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | GWH | □ |
| Black | GBL | ■ |
| Ivory | GIV | ■ |
| Light Almond | GLA | ■ |

| Satin Colors | Code | |
|--------------|------|---|
| Snow | TSW | □ |
| Biscuit | TBI | ■ |
| Midnight | TMN | ■ |

Pico remote control for audio



Ordering Information

Pico remote control for fans

Ordering Information



PJ2-3BRL-GWH-A02
(actual size)



PJ2-3BRL-GWH-F01
(actual size)

Build a Pico Model Number

PJ2-3BRL-XXX-A02

Color Code

Button Configuration Codes:

| | |
|------------------------------|-------------|
| <u>Button Configurations</u> | <u>Code</u> |
| 3-button with raise/lower | 3BRL |

Color Codes:

| | | |
|---------------------|-------------|-------------------------------------|
| <u>Gloss Colors</u> | <u>Code</u> | |
| White | GWH | <input type="checkbox"/> |
| Black | GBL | <input checked="" type="checkbox"/> |

Button Marking Code:

A02

| | | |
|---------------------|-------------|-------------------------------------|
| <u>Satin Colors</u> | <u>Code</u> | |
| Snow | TSW | <input type="checkbox"/> |
| Biscuit | TBI | <input type="checkbox"/> |
| Midnight | TMN | <input checked="" type="checkbox"/> |

Build a Pico Model Number

PJ2-3BRL-XXX-F01

Color Code

Button Configuration Codes:

| | |
|------------------------------|-------------|
| <u>Button Configurations</u> | <u>Code</u> |
| 3-button with raise/lower | 3BRL |

Color Codes:

| | | |
|---------------------|-------------|-------------------------------------|
| <u>Gloss Colors</u> | <u>Code</u> | |
| White | GWH | <input type="checkbox"/> |
| Black | GBL | <input checked="" type="checkbox"/> |
| Ivory | GIV | <input type="checkbox"/> |
| Light Almond | GLA | <input type="checkbox"/> |

Button Marking Code:

F01

| | | |
|---------------------|-------------|-------------------------------------|
| <u>Satin Colors</u> | <u>Code</u> | |
| Snow | TSW | <input type="checkbox"/> |
| Biscuit | TBI | <input type="checkbox"/> |
| Midnight | TMN | <input checked="" type="checkbox"/> |

Pico scene keypads

Ordering Information

Custom 4-button Pico remote controls

Ordering Information: lutron.com/custompico



PJ2-2B-GWH-P01
(actual size)

PJ2-2B-GWH-P02
(actual size)

PJ2-4B-GWH-P01
(actual size)

PJ2-4B-GWH-P02
(actual size)

PJ2-4B-GWH-P03
(actual size)

PJ2-4B-GWH-EL1
(lights example)


PJ2-4B-GWH-ES1
(shades example)

PJ2-4B-GWH-EL2
(lights example)

PJ2-4B-GWH-ES2
(shades example)

Build a Pico Model Number

PJ2- -XXX-XXX



Button Configuration Codes:

| Button Configurations | Code |
|-----------------------|------|
| 2-button | 2B |
| 4-button | 4B |

Button Marking Codes:

P01, P02, P03


Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | GWH | □ |
| Black | GBL | ■ |
| Ivory | GIV | ■ |
| Light Almond | GLA | ■ |

| Satin Colors | Code | |
|--------------|------|---|
| Snow | TSW | □ |
| Biscuit | TBI | ■ |
| Midnight | TMN | ■ |

Build a Pico Model Number

PJ2-4B-XXX-XXX



Button Configuration Codes:

| Button Configurations | Code |
|-----------------------|------|
| 4-button | 4B |

Button Marking Codes:

EL1, EL2, ES1, ES2

Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | GWH | □ |
| Black | GBL | ■ |
| Ivory | GIV | ■ |
| Light Almond | GLA | ■ |

| Satin Colors | Code | |
|--------------|------|---|
| Snow | TSW | □ |
| Biscuit | TBI | ■ |
| Midnight | TMN | ■ |

Pico remote controls — mounting accessories

Ordering Information



L-PED1-WH



L-PED2-WH



L-PED3-WH



Claro wallplate
(CW-1-WH)

- Provides a clean, screwless look
- Available in 1-6 openings



Wallplate bracket
(PICO-WBX-ADAPT)

- Use to surface-mount a Pico to a wall
- Required when mounting a Pico over a 120V wallbox



Car visor clip
(PICO-CAR-CLIP)

- Insert the Pico into the clip for convenient control from your car

Pedestal Model Number

L-PEDX-XX

Capacity Code
Color Code

Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | WH | □ |
| Black | BL | ■ |

Single, double, and triple pedestals available

Gloss Wallplate Model Number

CW- -XX

Openings
Color Code

Satin Wallplate Model Number

SC- -XX

Openings
Color Code

Wallplate Color Codes:

| Gloss Colors | Code | |
|--------------|------|---|
| White | WH | □ |
| Black | BL | ■ |
| Ivory | IV | ■ |
| Light Almond | LA | ■ |

| Satin Colors | Code | |
|--------------|------|---|
| Snow | SW | □ |
| Biscuit | BI | ■ |
| Midnight | MN | ■ |

Pico remote controls — flexibility

You can use a Pico with Lutron standalone dimmers and shades, as well as with the following Lutron systems

Caséta



Pico remote, Caséta dimmer, and Serena shades

RadioRA 3



Pico remote, Sunnata keypad, and Sivoia QS Triathlon shades

RA2 Select



Pico scene keypad, Maestro dimmer, and Sivoia QS Triathlon shades

HomeWorks QS



Pico remote, Palladiom keypad, and Palladiom shades

The Lutron logo, Lutron, Caséta, Claro, Clear Connect, HomeWorks, Maestro, Palladiom, Pico, RadioRA 2, RA2 Select, Satin Colors, seeTouch, Serena, Sivoia QS, and Triathlon are trademarks or registered trademarks of Lutron Electronics Co., Inc., in the U.S. and/or other countries.

Sonos and Works with Sonos are trademarks or registered trademarks of Sonos, Inc.

lutron.com/pico

Lutron Electronics Co., Inc., 7200 Suter Road, Coopersburg, PA 18036-1299

Customer Assistance

Online: lutron.com/help | Email: support@lutron.com | Phone: 1.844.LUTRON1 (588.7661) — includes 24/7 technical support

© 03/2023 Lutron Electronics Co., Inc. | P/N 367-2821 REV C

