

## How To change Fahrenheit To Celsius on OMRON Controls



THERE ARE ONLY 2 SETTINGS YOU SHOULD EVER CHANGE ON THE OMRONS:

1. EITHER RUNNING ROASTER IN FAHRENHEIT OR CELSIUS
2. CHANGE THE MAXIMUM TEMP. SETTING

1. PRESS THE CIRCLE KEY (LEVEL KEY) ON FAR LEFT SIDE OF OMRON AND HOLD IT UNTIL MENU SETTINGS APPEAR (3 SECONDS)

2. THE FIRST MENU SETTING WILL APPEAR. NEXT PRESS THE 2ND KEY FROM LEFT ONCE WHICH IS THE MODE KEY. (FIRST PARAMETER SETTING IS: IN-T SETTING= IMPORT TYPE) FOR A BC ROASTER THIS SHOULD BE SET TO 6 FOR TYPE K THERMOCOUPLE WE USE



3. ONCE MENU MODE IS IN THE ONE ABOVE (D-U) YOU WILL SEE AT BOTTOM RIGHT EITHER AN F OR C. (F=FAHRENHEIT, C=CELSIUS)

USING THE UP OR DOWN ARROW ON RIGHT SIDE TO CHANGE TO/FROM C TO F OR F TO C

4. AFTER CHOOSING EITHER FAHRENHEIT OR CELSIUS PRESS THE CIRCLE KEY ON FAR LEFT TO RETURN TO NORMAL SETUP.

5. THEN YOU WILL NEED TO SET THE MAXIMUM TEMPERATURE SETTING FOR THE TEMPERATURE ROASTER CAN GO TO: IN FAHRENHEIT WE RECOMMEND THE BT PROBE BE SET TO 480F OR 248C. AND ON THE ET CONTROL 480-500F OR 260C

