



BC-ELECTRIC ROASTERS- RELAY TESTING

The light(in the red circle) on the SSR75AA relay will light up when you press the heating button. If the light of the SSR75AA is not on when you press the heating button, you can test the voltage between these two point(in the red box), it should be 220V.





BC-ELECTRIC ROASTERS- RELAY TESTING

Testing voltage on the relays:



BC-ELECTRIC ROASTERS- RELAY TESTING

Using a voltage meter you can connect probes to the following points and they should read 220V (200-250V range)



RECORD READINGS AND EMAIL: TECH@BUCKEYECOFFEE.COM (send with your account #)