

Quick Setup Guide

Connection in 3 easy steps –

Step 1 : Ensure your Cable or Satellite box is connected to your TV's HDMI 1 input.


Step 2 : Connect your Blu-Ray, DVD, Game box, or other device that has an HDMI output. Unplug its HDMI cable. Insert the HDMI cable into the HD Boomerang™ and then the other end of the HD Boomerang™ into your device. Plug the other end of the cable into your TV's HDMI 2 input.



Step 3 : Use your TV's Remote Control to access the TV's MENU and then SETTINGS. Find CEC, turn it to ON.

Some TV brands use other names in place of "CEC". Examples are AnyNet+, SimpLink, VieraLink, IN Link, AquosLink, Control for HDMI, Bravia Link, Bravia Sync, EZ Link, Kuro Link, CE-Link, Regza Link, HDAVI Control, EZ-Sync, NetCommand for HDMI & more.

(See www.HDBoomerang.com/support for more)



For help connecting your HD Boomerang™
www.HDBoomerang.com/support