

Restrictor latch

The window restrictor latch allows the window to be opened marginally. To allow the full opening of the window, the latch needs to be unhooked with a finger. The latch is then re-engaged when the window is closed. The restrictor latch is used primarily for safety reasons to prevent children being able to fully open a window.

