


Product panel operating instructions, can through LCD screen display to show the program, switching menu options through mechanical switches



Press **HOME** button, Recall the first program menu,

DOWN, UP to choose the function.

Press **HOME** to confirm.

Setting the DMX address and dimming the lighting can press **DOWN, UP** to adjust.

If don't have any operating within 5s,the LCD screen will be locked, if need to unlock, please press **HOME** button to unlock.