

Mr Big



PROFESSIONAL CURLING IRON
with adjustable temperature settings and Auto Shut Off after 60 minutes



Operating Instructions/Safety Guide

IMPORTANT SAFEGUARDS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER – As with most electrical appliances, electric parts are electrically live even when the switch is off.

To reduce electrical shock risk:

- Always “unplug it” immediately after using.
- Do not use while bathing.
- Do not place or store appliance where it can fall or be pulled into tub or sink.
- Do not place in or drop into the water or other liquid.
- If an appliance falls into water, “unplug it” immediately. Do not reach into the water.

WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons:


- Do not leave appliance unattended while it is operating or is plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged in any manner or dropped into the water. Take appliance to the nearest service facility for examination and repair or mechanical adjustment.
- Keep the cord away from hot or heated surfaces. Do not wrap the cord around the appliance.
- Never use while drowsy or while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used. Do not operate where oxygen is being administered.
- This curling iron and clamp are hot when in use. To avoid burn hazard, do not let eyes and bare skin touch heated surfaces.
- Do not place the heated unit directly on any surface while it is hot or still plugged in; use the safety stand provided.
- Do not use an extension cord with this appliance.

SAVE THESE INSTRUCTIONS

POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug fits in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug and try again. If it still does not fit fully, contact a qualified electrician. Do not attempt to defeat this safety feature.

1. Rotating Safety Cool Tip
2. Triple Plated Ceramic Coated Barrel
3. Foldaway Rubberized Support Stand
4. Rotary Temperature Dial
5. 360° Swivel Cord
6. 60 minute auto shut-off



LINE CORD SAFETY TIPS

- Never pull or yank on the cord or the appliance.
- To insert plug, grasp it firmly and guide it into outlet.
- To disconnect appliance, grasp plug and remove it from outlet.
- Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced and the line cord replaced. Please see warranty section for instructions on replacement and service.
- Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.

DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE, OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

HOW TO USE

This appliance is for household use and can be plugged into any 120 volt AC electrical outlet.

IMPORTANT: During the first few minutes of initial use, you may notice smoke and a slight odor, as well as a humming noise. This is normal and is not cause for concern. Start with lowest temperature and only increase temperature as your hair type and style requires.

TEMPERTURE SETTINGS

HairType	Temperature Setting
Fine or chemically processed hair – Fragile	80 °C – 110 °C (180°F – 280 °F)
Easy-to-curl, normal hair – Fine	140 °C – 170 °C (280 °F – 330 °F)
Thick, wavy hair – Medium	170 °C – 200°C (330 °F – 380 °F)
Dense, hard-to-curl hair – Coarse	200 °C – 230°C (380 °F – 430 °F)

STYLING

For optimum styling, hair should be clean and dry.

1. Start by sectioning the hair into strands of not more than 1/2-inch thick and 2 inches wide.
2. Open the clamp, take one section of hair at a time and place the end over the barrel. Then close the clamp, making sure that the ends extend just a bit beyond the clamp.
3. Keep the section of hair taut as you wind it around the hot barrel by turning the handle with one hand. Wind the curl toward the scalp as far as you wish to go without touching scalp with the hot barrel. Note: When using this curling iron, keep your hand away from the end of the handle to avoid blocking the swivel action of the cord.
4. Hold the curl in place for up to 20 seconds for tight curls or if hair is hard to curl. Hold for less time if hair is easy to curl, or if you want loose curls or just waves.

CARE AND CLEANING

This appliance requires little maintenance and contains no user serviceable parts. Do not try to repair it yourself.

TO CLEAN: Unplug curling iron and allow to cool. Iron must be cleaned only when cool. Use a soft, slightly damp cloth to wipe the handle. Do not allow water or any other liquid to go into handle of the iron.

TO STORE: Unplug the appliance and let it cool, store in its box or in a clean, dry place. Store the cord loosely coiled. Never wrap the cord around unit; this could cause the cord to wear prematurely and break. Do not put any stress on cord where it enters the handle, as it could cause cord to fray and possibly break. Never hang unit up by the power cord.

LIMITED WARRANTY

Mr. Big Beauty Products, L.L.C. (“we”, “us” or “our”) warrants product against defects in materials and workmanship for one (1) year from original purchase date (“Warranty Period”). If you cannot prove original purchase date, Warranty Period runs one (1) year from date of product manufacture. If we receive a valid claim, we will repair or replace with product of equal or greater value at our option.

This Warranty Does Not Cover normal wear and tear such as shorts in the power supply cord or plug or excessive product build up on barrel or clamp or scratched or damaged barrel or clamp or damage due to accident, misuse or abuse such as: dropping (broken or cracked handle, broken or loose connection between barrel and handle or barrel and clamp, rattling noise, etc.), wrong voltage supply, neglect in safety precautions, or tampering such as repair or attempted repair by unauthorized person or use of unauthorized attachments.

WHAT TO DO IF YOU HAVE A CLAIM

If the product fails to operate properly under normal use because of a covered defect (within 1 year of purchase), return for repair or replacement. Please include a copy of your receipt and \$8.00 for postage and handling. (We are not responsible for products lost or damaged in transit; you must properly package product against possible damage.)

Mail product to the following address:

Mr Big Beauty Products, L.L.C.
P.O. Box 1242
Apex, NC 27502

TO THE MAXIMUM EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES AND CONDITIONS SET FORTH ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. WE SPECIFICALLY DISCLAIM ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF WE CANNOT LAWFULLY DISCLAIM OR EXCLUDE IMPLIED WARRANTIES UNDER APPLICABLE LAW, THEN TO THE EXTENT WE CANNOT DISCLAIM WARRANTIES, ALL SUCH WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL EXPIRE ON EXPIRATION OF THE WARRANTY PERIOD. WE EXPRESSLY EXCLUDE, AND WE WILL NOT PAY, CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR THE BREACH OF ANY WARRANTY, AND WE ASSUME NO RESPONSIBILITIES FOR YOUR LOSS OF USE OF THE PRODUCT, OR FOR ANY OTHER INCONVENIENCE OR CONSEQUENTIAL EXPENSE. **IN NO EVENT SHALL WE BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.** Your Legal Rights: Some countries, states, provinces and/or jurisdictions do not allow limitations on implied warranties and/or do not allow the exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

Mr Big Beauty Products, L.L.C.
P.O. Box 1242
Apex, NC 27502
phone: 919-249-8204
email: support@mrbigcurlingirons.com
website: <http://www.mrbigcurlingirons.com>