

Symbol	Description	Part #	Symbol	Description	Part #
S1	PROTECTION SWITCHCH	FGC10030	T1	TRANSFORMER	FGC10020
S2	POWER SWITCH	FGC10011	IC1	THREMOSTAT (FAST)	FGC10014
S3/S4	DOOR SWITCH	FGC10019	0	TERMPERATURE SENSOR (FAST)	FGC10059
S5	COOK/COOL SWITCH	FGC10011	HL1	INDICATOR LAMP (YELLOW)	FGC10047
S6	HI/LO SWITCH	FGC10011	0T2	FLAME SENSOR	FGC10064
S7	LAMP SWITH	FGC10011	0T1	HOT SURFACE IGNITOR (NLA)	FGC10016
HL	INTERIOR LIGHT	FGC10067	0T1	HOT SURFACE IGNITOR	FGC10062
M1	CONVECTION MOTOR ASSY. (F.I.R.)	FGC10061	0T1	HOT SURFACE IGNITOR BRACKET	FGC10063
PT	TIMER (N.C.)	FGC10012	J1	CONNECTOR (9 PIN)	FGC10018
HA	BUZZER	FGC10024	J2	CONNECTOR (4 PIN)	FGC10018-1

