

AZ ONE CUP MANUAL HANDLE REALIGNMENT

In the event your handle comes out of alignment with Spring Controlled plate inside unit on the manual AZ ONE CUP:

1. Loosen the Metric Hex keys on sides slightly
2. Remove the 2 front and two back screws with a Phillips driver
3. Pull back cover to access parts inside
4. Push down on the spring held bracket and turn handle to proper position



Adjust Handle to proper position while you push down on spring bracket

