

How to Find the Serial Number (R932114)

Shell - Located on the Right Side of the Back



Figure 1: Close Up of Label Plate on Shell



Figure 2: Label Plate Location on Shell

Subframe - Located on Right Side of the Top (Above Right Lift Arm)



Figure 3: Close Up of Serial # Stamped into Subframe




Figure 4: Stamped Serial # Location

Cylinders - Located in the Middle or Towards the Base End



Figure 5: Close up of Stamped Serial # and Sticker (Stickers after 3/19/14)



Figure 6: Stamped Serial # Location – Full Cylinder Image.