



Operating Instructions for Commercial Convection Oven

- Moffet Dimensions 28"W x 36"D x 38"H
- Imperial Dimensions 38"W x 40"D x 42"H

1. Connect regulator to propane tank (counter clockwise)
 2. Connect power cord to 110 volt outlet
 3. Turn mode switch to cook, wait 5 minutes
 4. Turn propane valve on & check for leaks
 5. Set temperature knob to desired setting
 6. You should hear a "ticking" sound for about 10 seconds, pilot should then light
 7. It may not light on the 1st attempt!
 8. If the red light does not come on within 60 seconds, turn oven off and repeat steps 5-7
 9. When the red indicating light comes on, the oven is heating up
 10. When the red indicating light goes off, the oven is at temperature
-
- Ovens operate on propane gas & 110 volts only
 - All equipment is tested before delivery but should be rechecked at least 6 hours prior to use in case of malfunction
 - Equipment must be kept dry and away from moisture
 - When using multiple pieces of electrical equipment, do not overload the circuit, this may cause the equipment to fail